



P/N	DESCRIPTION	AIRCRAFT PARTS
00-102835	STATOR	BAe146
002-6101-11	DRIVE SHAFT	
00-400430	CASING STATOR ASSEMBLY	
020-960-001	GAGE-FUEL CONTENTS	CN-235
020-960-011	PROBE-FUEL QUANTITY	CN-235
020-960-012	FUEL QUANTITY TANK UNIT	CN-235
021-922-001	AFORADOR	CN-235
021-922-011	GAGE-FUEL CONTENTS	CN-235
02-6100-04	DRIVE SHAFT	
02-6100-08	DRIVE SHAFT	
026101-11	DRIVE SHAFT	
02-6101-11	DRIVE SHAFT	
02-6101-13	DRIVE SHAFT	
0304HRA/1	RADIOALTIMETRO	
03-1802-2001	ANTI COLLISION LIGHT	ATR,EMB
03-1802-2001-1	STROBE LIGHT	ATR-42, ATR-72,CRJ700
03-6101-13	DRIVE SHAFT	
04-1505-1429	STROBE LIGHT PS	ATR-72,EMB
0503102-1	REGULATOR, CABLE TEN	
0555-11	DC GEAR MOTOR	
0618910G	ADAPTER BELL OUTPUT BAL ASSY	
0623006D	ADAPTER BELL OUTPUT BAL ASSY	
064-01054-30	VHF COMMUNICATIONS TRANSCEIVERS	
064-1023-00	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-01	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-02	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-03	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-04	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-05	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-06	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-07	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-08	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-09	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-10	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-11	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-12	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-13	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-14	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1023-15	KTR 908 VHF COMMUNICATIONS TRANSRECEIVER	AS 365-N-3, BELL 412
064-1047-61	RECEIVER, TRANSMITTER	
064-1054-30	TRANCIVER KY196A	
06-5010-6500	ENGINE OIL SERVICE UNIT	CN-235
066-01066 SERIES	KDM 706 A DISTANCES MEASURING EQUIPMENT	
066-01067-0000	RADAR RECEIVER	
066-03063	KI227 ADF INDICATOR	
066-03063-SERIES	KI227 ADF INDICATOR	
066-1093 SERIES	KDM 706 A DISTANCES MEASURING EQUIPMENT	
066-1093-30	DME INTERROGATOR	
066-1105-00	ADF RECEIVER	
066-3016-00	INDICADOR DE DISTANCIA	
066-3031-00	RADAR ALTIMETER INDICATOR	
066-3031-01	INDICATOR RADAR	C-212
066-3031-02	RADAR ALTIMETER INDICATOR	
066-3031-03	RADAR ALTIMETER INDICATOR	
066-3059-00	INDICATOR ADF	



P/N	DESCRIPTION	AIRCRAFT PARTS
069-01025-0025	RECEIVER TRANSMITTER	
069-1024	VHF NAV/COMM TRANSCEIVER	
069-1024-SERIES (KX155)	VHF NAV/COMM TRANSCEIVER	
069-1025	VHF NAV/COMM TRANSCEIVER	
069-1025-SERIES (KX165)	VHF NAV/COMM TRANSCEIVER	
0704-1-000/1	HIGH SPEED OVEN	
071-1348-00	ADF ANTENNA	
071-1377-01	NAV 1	
0711480-001	VALVE, SHUTOFF HYDRAULIC	A320, A340
0711480-003	VALVE, SHUTOFF HYDRAULIC	A320, A340
0711480-004	VALVE, SHUTOFF HYDRAULIC	A320, A340
0726150	REFUELLING UNIT	
0804-1-000/1	HIGH SPEED OVEN	
0856NC2	TUBE, PITOT	
0871DL5	PROBE-ICE DETECTOR	
08-8422-010	ACCUMULATOR, HYDRAULI	
1.241.078	INDICATOR HYDRAULIC PRESSURE	
10-0055	EMERGENCY EXIT LIGHT	EMB135
10-0055 SERIES	EMERGENCY EXIT LIGHT	
10-0055-11	LIGHT, EMERGENCY	C-212, CN-235, C-295,Q400
10-0055-3	LIGHT, EMERGENCY	C-212,EMB
1-001-0102-1000	STATIC INVERTER	B737-300,400,500,600,700,700C,800 AND 900 AND 747-400 SERIES 757,767AND 777.
1-002-0102-0265	INVERTER ASSY-STATIC	
1-002-0102-0542	SERIES LIGHT DIMMER	
1-002-0102-0714	STATIC INVERTER	B737,B757,B777
1-002-0102-0742	SERIES LIGHT DIMMER	
1-002-0102-0780	STATIC INVERTERS	
1-002-0102-0781	SERIES LIGHT DIMMER	
1-002-0102-0784	SERIES LIGHT DIMMER	
1-002-0102-0811	SERIES LIGHT DIMMER	
1-002-0102-0812	SERIES LIGHT DIMMER	
1-002-0102-0813	SERIES LIGHT DIMMER	
1-002-0102-0814	SERIES LIGHT DIMMER	
1-002-0102-0815	SERIES LIGHT DIMMER	
1-002-0102-0816	SERIES LIGHT DIMMER	
1-002-0102-0817	SERIES LIGHT DIMMER	
1-002-0102-0818	SERIES LIGHT DIMMER	
1-002-0102-0824	SERIES LIGHT DIMMER	
1-002-0102-1000	STATIC INVERTER	B737,B777,B707, B727, B747, B757, B767
1-002-0102-1002	SERIES LIGHT DIMMER	CN-235
1-002-0102-1011	STATIC INVERTERS	
1-002-0102-1012	STATIC INVERTERS	
1-002-0102-1013	STATIC INVERTERS	
1-002-0102-1014	STATIC INVERTERS	
1-002-0102-1015	STATIC INVERTERS	
1-002-0102-1016	STATIC INVERTERS	CN-235, C-295, P3 ORION, P3 CONVERSION
1-002-0102-1017	STATIC INVERTERS	
1-002-0102-1018	STATIC INVERTERS	
1-002-0102-1019	STATIC INVERTERS	



P/N	DESCRIPTION	AIRCRAFT PARTS
1-002-0102-1020	STATIC INVERTERS	C-212, CN-235
1-002-0102-1021	STATIC INVERTERS	
1-002-0102-1022	STATIC INVERTERS	
1-002-0102-1023	STATIC INVERTERS	
1-002-0102-1024	STATIC INVERTERS	
1-002-0102-1025	STATIC INVERTERS	C-212, CN-235, C-295
1-002-0102-1027	STATIC INVERTERS	
1-002-0102-1028	STATIC INVERTERS	
1-002-0102-1029	STATIC INVERTERS	
1-002-0102-1030	STATIC INVERTERS	
1-002-0102-1031	STATIC INVERTERS	
1-002-0102-1032	STATIC INVERTERS	
1-002-0102-1033	STATIC INVERTERS	
1-002-0102-1034	STATIC INVERTERS	C-295
1-002-0102-1035	STATIC INVERTERS	C-295, P3 CONVERSION
1-002-0102-1036	STATIC INVERTERS	
1-002-0102-1037	STATIC INVERTERS	
1-002-0102-1038	STATIC INVERTERS	
1-002-0102-1039	STATIC INVERTERS	
1-002-0102-1040	STATIC INVERTERS	
1-002-0102-1041	STATIC INVERTERS	
1-002-0102-1179	SERIES LIGHT DIMMERS	
1-002-0102-1180	SERIES LIGHT DIMMERS	
1-002-0102-1229	SERIES LIGHT DIMMERS	
1-002-0102-1231	SERIES LIGHT DIMMERS	
1-002-0102-1233	SERIES LIGHT DIMMERS	
1-002-0102-1245	SERIES LIGHT DIMMERS	C-212, CN-235, C-295, P3 ORION, P3 CONVERSION
1-002-0102-1254	SERIES LIGHT DIMMERS	
1-002-0102-1342	SERIES LIGHT DIMMERS	
1-002-0102-1346	STATIC INVERTERS	
1-002-0102-1449	STATIC INVERTERS	
1-002-0102-1551	STATIC INVERTERS	
1-002-0102-1635	STATIC INVERTERS	
1-002-0102-1652	SERIES LIGHT DIMMER	
1-002-0102-2090	STATIC INVERTER	B737-300,400,500,600,700,700C,800 AND 900, B747-400 SERIES,B757,B767,B777,B707, B727, B737, B747
10026-0000-02	FUEL QTY IND	ATR-72,ATR
10027-0000-01	FUEL QTY RP	ATR-72,DASH8
10037-0750	INDICATOR FUEL QUANTITY	B737
10037-0770	FUEL QTY INDICATOR	B737
10037-1000-0156	INDICATOR FUEL QTY	B737, B747,B757, B767
1005080-12-1	VALVE PRESSURE REDUCE RELIEF	DC-9, MD-80, MD-90,B737, B757
100524	INDICATOR HORIZON	
10074-0101	INDICATOR, LIQUID QUA	
10079-01	LOAD SELECT CONTROL UNIT	B767-200, B300, B400, B737-300, B400, B500, B747-300
1008700 SERIES	CYLINDRAL HYD PRESS ACCUM	
1008700-4	ACCUMULATOR, HYDRAULIC	C-130
1009350	ROTARY ACTUATOR ASSEMBLY	
1009350-1	ROTARY ACTUATOR ASSEMBLY	
1009350-2	ACTUADOR	C-130
101-000-137	RECEIVER, RADIO	



P/N	DESCRIPTION	AIRCRAFT PARTS
101003-04-01	MECHANISM ASSY	
10-1014-1	INTERIOR ILLUMINATED EMERGENCY EXIT SING	
10-1014-3	INTERIOR ILLUMINATED EMERGENCY EXIT SING	
10-1014-5	INTERIOR ILLUMINATED EMERGENCY EXIT SING	
10-1014-7	INTERIOR ILLUMINATED EMERGENCY EXIT SING	
1010530 SERIES	CYLINDRAL HYD PRESS ACCUM	
10-1175	EMERGENCY EXIT LIGHT	
10-1175-1	EMERGENCY EXIT LIGHT	
10-1175-11	EMERGENCY EXIT LIGHT	
10-1175-13	EMERGENCY EXIT LIGHT	
10-1175-15	EMERGENCY EXIT LIGHT	
10-1175-17	EMERGENCY EXIT LIGHT	
10-1175-19	EMERGENCY EXIT LIGHT	
10-1175-21	EMERGENCY EXIT LIGHT	
10-1175-23	EMERGENCY EXIT LIGHT	
10-1175-25	EMERGENCY EXIT LIGHT	
10-1175-27	EMERGENCY EXIT LIGHT	
10-1175-29	EMERGENCY EXIT LIGHT	
10-1175-3	EMERGENCY EXIT LIGHT	
10-1175-31	EMERGENCY EXIT LIGHT	
10-1175-33	EMERGENCY EXIT LIGHT	
10-1175-35	EMERGENCY EXIT LIGHT	
10-1175-37	EMERGENCY EXIT LIGHT	
10-1175-39	EMERGENCY EXIT LIGHT	
10-1175-41	EMERGENCY EXIT LIGHT	
10-1175-43	EMERGENCY EXIT LIGHT	
10-1175-45	EMERGENCY EXIT LIGHT	
10-1175-47	EMERGENCY EXIT LIGHT	
10-1175-49	EMERGENCY EXIT LIGHT	
10-1175-5	EMERGENCY EXIT LIGHT	
10-1175-51	EMERGENCY EXIT LIGHT	
10-1175-53	EMERGENCY EXIT LIGHT	
10-1175-55	EMERGENCY EXIT LIGHT	
10-1175-57	EMERGENCY EXIT LIGHT	
10-1175-7	EMERGENCY EXIT LIGHT	
10-1175-9	EMERGENCY EXIT LIGHT	
10-1327-1	FLUORESCENT WINDOW LIGHT	B757, B737,DC8, DC9, MD80
10-1327-10	FLUORESCENT WINDOW LIGHT	B757, B737
10-1327-2	LIGHT ASSY	B757, B737,DC10, MD11
10-1327-3	LIGHT ASSY	B757, B737,B717, DC9, MD90
10-1327-4	FLUORESCENT WINDOW LIGHT	B757, B737
10-1327-7	FLUORESCENT WINDOW LIGHT	B757, B737
10-1327-8	FLUORESCENT WINDOW LIGHT	B757, B737
10-1327-9	FLUORESCENT WINDOW LIGHT	B757, B737
10-1733-1	FLUORESCENT WINDOW LIGHT	B-757-200,B-737-100, B-737-500, B-737-900, B-737-300, B-737-600, B-737-400, B-737-800, B-757-700,B-737-200, B-757-300,B757, B767
10-1733-2	FLUORESCENT WINDOW LIGHT	B-757-200,B-737-100, B-737-500, B-737-900, B-737-300, B-737-600, B-737-400, B-737-800, B-757-700,B-737-200, B-757-300,B757, B767



P/N	DESCRIPTION	AIRCRAFT PARTS
10-1733-3	FLUORESCENT WINDOW LIGHT	B-757-200,B-737-100, B-737-500, B-737-900, B-737-300, B-737-600, B-737-400, B-737-800, B-757-700,B-737-200, B-757-300,CRJ100
10-1733-4	FLUORESCENT WINDOW LIGHT	B-757-200,B-737-100, B-737-500, B-737-900, B-737-300, B-737-600, B-737-400, B-737-800, B-757-700,B-737-200, B-757-300
102210-9	CONTROLLER, AIR PRESS	
102210-9A	CONTROLLER, AIR PRESS	P3 ORION, P3 CONVERSION
1024-4	DIMMER CONTROL UNIT	B737,B747,B777
1024-4A	DIMMER CONTROL UNIT	B737,B747,B777
1024-4B	DIMMER CONTROL UNIT	B737,B747,B777
1024-4C	DIMMER CONTROL UNIT	B737,B747,B777
10-3223-44	HYDRAULIC BRAKE PRESS IND	
1034540	ACTUATOR ELECTRO-ME	
1034540-1	ROTARY ACTUATOR ASSEMBLY	C-130
103696-1	CABIN AIR PRESS OUTFLOW / SAFETY VALVE	
1037-0770	PRESELECTOR INDICATOR	
1055-82-0ZZ-A	V/UHF ANTENNA	
10-60556-10	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-12	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-15	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-16	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-17	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-18	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-19	PUMP MOTOR PACKAGE	
10-60556-20	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-30	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-6	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-62204-17	ANTISKID VOLUMETRIC FUSE ASSEMBLY	B777-200
107-120	ARMATURE	
1103070-120	DECODER	
1103480-121	SEAT ELECTRONICS BOX	
1103860-120-02	SEAT ELECTRONIC BOX	
11059-15	TIMER	
11059-35	TIMER	
1-111-0102-0714	STATIC INVERTER	B737,B757,B777,B767
1112358	ROTOR	
1112359	ARMATURE ASSEMBLY	
1120-3	CYLINDER ASSEMBLY, AC	C-130
113A3943-1	TRACK ASSY-NO. 4	B-737
1140-0110	ROCKWELL-COLLINS	
1140-0110-SERIES	ROCKWELL-COLLINS	
114122002	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122003	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122004	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122006	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122007	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122008	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122009	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122010	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122011	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122012	MLG DOOR ACTUATOR	A318, A319, A320, A321
114122014	MLG DOOR ACTUATOR	A318, A319, A320, A321



P/N	DESCRIPTION	AIRCRAFT PARTS
114A7522-7	TRACK ASSY-MAIN, INBD SS 282.91	B-737
115.192	INDICATOR, DC VOLTMETER	
115.194	IND. DE GEN AMMETER	
115.195	INDICATOR EMERGENCY& NORMAL BRAKE PRESSURE	
115.218	IND. BATT. DC AMMETER	
115.220	INDICATOR, AC VOLTMETER	
115.230	INDICATOR CABIN TEMPERATURE	
115192	INDICATOR DC VOLTMETER	
115-192	VOLTMETER-DC	CN-235, P3 CONVERSION
115194	IND DE GEN AMMETER	
1152106-2	DC STARTER GENERATOR	Dash8
1152106-2 SERIES	DC STARTER GENERATOR	Dash8
1152106-3	STARTER GENERATOR	Dash8
1152106-3 SERIES	DC STARTER GENERATOR	CN-235, C-295, Dash8
1152106-X	DC STARTER GENERATOR	Dash8
115218	IND BATT DC AMMETER	
115-218	AMMETER	CN-235, C-295, Dash8
115220	INDICATOR AC VOLTMETER	
1152218-5	AC GENERATOR	
1152218-6	AC GENERATOR	
1152218-SERIES	AC GENERATOR	Dash8
1152218-X	AC GENERATOR	Dash8
115230	INDICATOR CABIN TEMPERATURE	
1152400-2	APU STARTER GENERATOR ASSEMBLY	Dash8
1152400-2 SERIES 1	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-3	APU STARTER GENERATOR ASSEMBLY	Dash8
1152400-3 SERIES 1	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-4	APU STARTER GENERATOR ASSEMBLY	Dash8
1152400-4 SERIES 1	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-4 SERIES 2	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-5	APU STARTER GENERATOR ASSEMBLY	Dash8
1152400-5 SERIES 1	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-5 SERIES 2	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-X	APU STARTER GENERATOR ASSEMBLY	Dash8
1153-1	ELECTRIC MOTOR	
115A297	AMMETER	CN-235
115A5260-1	FUSE PIN - TRUNNION SUPP - FWD	
115Q324	INDICATOR FUEL QTY	CN-235, C-295
11-6537-1	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-300, B-737-600, B-737, B-737-400, B-737-800, B-737-700, B-757-300,EMB
11-6537-3	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-300, B-737-600, B-737, B-737-400, B-737-800, B-737-700, B-757-300,B727
11-6537-5	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-300, B-737-600, B-737, B-737-400, B-737-800, B-737-700, B-757-300,B727
11-6537-7	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-
11-6537-9	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-
1167A	EXTINTOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
1183777	AUDIO PANEL CONTROL	
121-1001	STATOR	
1211179-003	ACTUATOR	
1211180-004	ACTUATOR	
121210-3	SCREW	B727, A300
122-4508	FIELD ASSEMBLY	
122-6607	ARMATURE	
122723-200-02	PUMP SUBMERGED, AIRCRAFT	
122723-SERIES	FUEL BOOST PUMP	
123488-010-01	ROTARY UNIT PUMP	C-130
123510-010-01	FUEL BOOSTER CENTRIFUGAL PUMP	
123510-011-01	FUEL BOOSTER CENTRIFUGAL PUMP	
124.1006-1	IND-ENGINE OIL TEM/PRES	
124.1007-1	IND PROP OIL TEM/PRESS	
124.1078	INDICATOR HYDRAULIC PRESSURE	
124.833	DC VOLTMETER	
1241006-1	IND ENGINE OIL TEMP/PRESS	
124-1006-1	IND-ENGINE OIL TEMP/PRESS	CN-235
1241007-1	IND PROPELLER OIL TEMP/PRESS	
124-1007-1	IND-PROP. OIL TEM/PRESS	C-212, CN-235
124-1007-1 MOD 2	INDICATOR	
124-1078	INDICATOR HYD. PRESSION	CN-235
124536	FUEL CONTROL UNIT	
124536 SERIES	FUEL CONTROL UNIT	
124833	DC VOLTMETER	
124-833	DC VOLTMETER	B737
124-834	AMMETER-DC	B737
12507G-13	HEADSET ELECTRICAL	
1251-1	MOTOR	
1251-2	MOTOR	
1259	MOTOR	
1259A	MOTOR	
126.177	INDICATOR, GAS GENERATOR SPEED	
126.178	INDICATOR, PROPELLER RPM	
126.179-1	INDICATOR, INTER-TURBINE TEMPERATURE	
126.179-2	INDICATOR, INTER-TURBINE TEMPERATURE	
126177	INDICATOR GAS GENERATOR SPEED	
126178	INDICATOR PROPELLER RPM	
126-178	INDICATOR NP	CN-235, C-295
1272	INDICATOR, HEIGHT	
1272-2700	INDICATOR, HEIGHT	
128182	PRESSURE SENSOR	
1303-1	STARTER	A330, A340, B767
1303-2	STARTER	A330, A340, B767
1303-3	STARTER	A330, A340, B767
130544-1	CONTROL, FREQUENCY SET	CN-235
1316200-3	BRAKE METERING VALVE	B737,B757
1321M39P02	STATOR ALTERNATOR	
1326	REGULATEUR TENSION	
133-255	DISC, BRAKE	
1386112-4	STATOR	
140180-01-01	GYROSWITCH, RATE	
14300-010	MOTOR PUMP FILTER ASSEMBLY	
14300-061	HOUSING AND STATOR ASSY WITH CONNECTOR LEADS	
14300-084	MOTOR PUMP FILTER ASSEMBLY	



P/N	DESCRIPTION	AIRCRAFT PARTS
14300-092	MOTOR PUMP FILTER ASSEMBLY	
14300-136	MOTOR PUMP FILTER ASSEMBLY	
14300-137	MOTOR PUMP FILTER ASSEMBLY	
14-40605-09	PISTON LANDING GEAR STRUT	
14-41607-3	CYLINDER PISTON ASSY LANDING GEAR	
1462	BALLAST UNIT	
1473M38G18	MANIFOLD	
147831A2	OIL TEMP	
15-0007-1	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-101	COCKPIT UTILITY LIGHT	B717, DC-9, MD-90
15-0007-103	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-105	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-107	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-109	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-111	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-111	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-113	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-115	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-117	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-119	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-121	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-123	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-125	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-127	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-129	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-13	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-131	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-133	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-135	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-137	LIGHT ASSY, COCKPIT	A300, B717, DC-9, MD-90, B757
15-0007-15	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-17	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-19	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-21	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-23	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-25	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-27	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-29	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-3	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-31	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-33	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-35	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-37	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-39	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-41	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-43	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-45	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-47	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-49	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-5	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-51	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-53	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-55	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-57	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-59	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90



P/N	DESCRIPTION	AIRCRAFT PARTS
15-0007-61	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-63	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-65	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-67	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-69	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-7	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-71	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-73	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-75	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-77	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-79	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-81	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-83	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-85	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-87	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-89	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-9	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-91	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-93	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-95	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-97	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-99	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
150015-15	LIGHT COCKPIT UTILITY	
15-0015-15	LIGHT COCKPIT	CN-235
15-0069	SPOTLIGHT	
15-0069-1	SPOTLIGHT	B727, B737
15-0069-13	SPOTLIGHT	B737
15-0069-17	SPOTLIGHT	B747, B737
15-0069-19	SPOTLIGHT	B737
15-0069-21	SPOTLIGHT	B737
15-0069-23	SPOTLIGHT	B737
15-0069-25	SPOTLIGHT	B737
15-0069-3	SPOTLIGHT	B727, B737
15-0069-5	SPOTLIGHT	B727, B737
150SG	STARTER GENERATOR	
150SG SERIES	STARTER GENERATOR	
150SG1064	ARMATURE	
150SG1073	PLATE DAMPENER	
150SG1103-7	DRIVE SHAFT	
150SG1156	STATOR SUB-ASSY	
150SG117Q	STARTER GENERATOR	
150SG122Q	STARTER GENERATOR	
15120-4	VALVE, BRAKE ACTUATI	P3 ORION, P3 CONVERSION
1518-14-A	INVERTER	
1518-14-E	INVERTER	
1518-16-A	INVERTER	
1518-1-F	INVERTER	
1518-1-G	INVERTER	
1518-1-H	INVERTER	
1518-8-C	INVERTER	
1518-8-D	INVERTER	
1518-8-E	INVERTER	
1523200-3	ACTUATOR NOSE GEAR	
1531428-2	EXCITER ROTOR	
1531442-2	ROTOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
1531442-3	ROTOR ASSEMBLY	
1532269	STATOR	
1532362-3	EXCITER STATOR	
1546-1-1	DIMMER LIGHT CONTROL	B757, B767
1546-1-2	DIMMER LIGHT CONTROL	B767
1546-1-3	DIMMER LIGHT CONTROL	B767, B757
1546-1-4	DIMMER LIGHT CONTROL	B757
1546-1-5	DIMMER LIGHT CONTROL	B757
1546-1-5 MOD A	DIMMER LIGHT CONTROL	
1546-1-5A	DIMMER LIGHT CONTROL	
1546-1-6	DIMMER CONTROL	B757
1546-1-6 MOD A	DIMMER LIGHT CONTROL	B757
1546-1-6A	DIMMER LIGHT CONTROL	
1546-1-SERIES	DIMMER LIGHT CONTROL	B737, B757, B767
1547143-1	EXC. STATOR	
1547154-1	STATOR C.W.	
1547162-1	EXC. ROTOR	
1547750-1	STATOR R.W.	
1549583-1	END BELL ASSY	
1571589-1	ROTOR	C130
1580147-1	MAIN ROTOR	
15809889-1	STATOR	
1580997-2	ROTOR ASSEMBLY, AC GENERATOR	
1580997-2 EXC.	EXCITER ROTOR	
1581594-1	STATOR	
1582363-1	STATOR	
1583816-2	ROTOR	
1583827-1	HOUSING	
1583829-1	STATOR HOUSING	
15840-1	AIR/OIL COOLER	C-212
15840-3	AIR/OIL COOLER	C-212
158410-1	AIR / OIL COOLER	
158410-3	AIR / OIL COOLER	
1589889-1	STATOR ASSEMBLY GENERATOR	C-130
16	KI227 ADF INDICATOR	
160SG1103-3	DRIVE SHAFT	
160SG139Q-2	STARTER-GENERATOR	
161N0001-115	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-116	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-136	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-147	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-148	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-54	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-55	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161T6005-4	SPINDLE	B767
16204	MOTOR PUMP FILTER UNIT ASSY	
16204-001	MOTOR PUMP FILTER UNIT ASSY	B757
1627608-1	TOGGLE	
162A1404-3	COLLAR	B737
162A1404-4	COLLAR	
162B203F	INDICATOR TEMPERATURE	
162B243	INDICATOR OIL TEMPERATURE	C-212
162B2G	TEMPERATURE	
162B3F	INDICATOR OIL	
162B48	INDICATOR TEMPERATURE	C-212



P/N	DESCRIPTION	AIRCRAFT PARTS
162BL SERIES	ELECTRICAL RESISTANCE THERMOMETER INDICA	
162BL602	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL701	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727, B707
162BL701A	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B727, B707, B737
162BL702	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B727, B707, B737
162BL703	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B727, B707, B737
162BL704	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704A	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704C	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704D	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704F	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704H	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704K	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704L	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737
162BL704N	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL802	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727, B747
162BL802A	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727, MD80
162BL803	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL803A	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
16430-1	PUMP UNIT, CENTRIFUGA	C-130
1646-1-6	DIMMABLE FLUORESCENT LAMP CONTROLLER	B737
1646-1-6 MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-6 MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-6A	FLUORESCENT LAMP CPNTROLLER	
1646-1-6B	FLUORESCENT LAMP CPNTROLLER	
1646-1-6MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-7	FLUORESCENT LAMP CONTROL	B737
1646-1-7 MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-7 MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-7A	FLUORESCENT LAMP CPNTROLLER	
1646-1-7B	FLUORESCENT LAMP CPNTROLLER	
1646-1-7MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	
16M002-5	DRIVE UNIT HYDRAULIC	
16M002-815	DRIVE UNIT HYDRAULIC	
16M002-821	DRIVE UNIT HYDRAULIC	
1700089	ROTOR BALANCE ASSEMBLY	B777, B767-400
1700089 SERIES	ROTOR BALANCE ASSEMBLY	B777, B767-400
1700089A	ROTOR BALANCE ASSEMBLY	B777, B767-400
1700089B	ROTOR BALANCE ASSEMBLY	B777, B767-400
1700586	VSCF GEN	B777
1701317	INTEGRATED DRIVE GENERATOR	CRJ700, CRJ900, CRJ1000, EMB170/EMB190
1701317A	INTEGRATED DRIVE GENERATOR	CRJ700, CRJ900, CRJ1000, EMB170/EMB190
1701320	GENERATOR ASSEMBLY	CRJ700/900, ERJ 170/190
1701320B	GENERATOR ASSEMBLY	CRJ700/900, ERJ 170/190
1701320C	GENERATOR ASSEMBLY	CRJ700/900, ERJ 170/190
1701410	ROTOR BALANCE ASSEMBLY	
1701410 SERIES	ROTOR BALANCE ASSEMBLY	
1701422	ROTOR BALANCE ASSEMBLY	B737
1701422 SERIES	ROTOR	
1701422A	ROTOR	B737
1701469	PMG AND SUPPORT ASSEMBLY	
1701483	STATOR ASSEMBLY	B757, A310
1701487	STATOR ASSEMBLY-PMG	



P/N	DESCRIPTION	AIRCRAFT PARTS
1701766	VSCF GEN	B777
1701768	VSCF GEN	B777
1702377	ROTOR ASSEMBLY, EXCITER	
1702690	STATOR ASSEMBLY - AC GENERATOR	
1702711	STATOR ASSEMBLY, ALTERNATING CURRENT	A320
1702713	STATOR ASSEMBLY, EXCITER	B757,A310
1702714	STATOR ASSEMBLY - MAIN GENERATOR	
1702715	STATOR ASSEMBLY, GENERATOR	
1702719	STATOR ASSEMBLY, GENERATOR	
1702726	STATOR ASSEMBLY - EXCITER	
1702733	EXCITER ROTOR ASSEMBLY	
1704-1-000/1	HIGH SPEED OVEN	
1704600-1	VALVE PRESSURE REDUCING 8	B737,B747
1706903	INTEGRATED DRIVE GENERATOR	A318, A319, A320, A321, A340
1706907	ROTOR BALANCE ASSEMBLY	B737
1708897	INTEGRATED DRIVE GENERATOR	A318, A319, A320, A321, A340
1708899	ROTOR BALANCE ASSEMBLY	B737
1708899A	ROTOR BALANCE ASSEMBLY	B737
171001-30	PLACA, CIRCUITOS C	
171851-01	PCU	
173227-502	VIDEO DISTRIBUTION BOX	
173595-02	DISPLAY	
1753M21P03	CABLE-THERMOCOUPLE U	
176202-77	CYLINDER ASSY	
1784389-653	COMPASS, GYROSYN	
1784460-656	RMI COMPASS INDICATOR	B727, DC-8, DC-9, MD-80
179120-3	STARTER MOTOR	B707, B717, B723, B737
179307	ELECTROMECHANICAL ACTUATOR	
17TE165	P.D.D.UNIT	CN-235
1804-1-000/1	HIGH SPEED OVEN	
18-1278	OIL PRESSURE	B737
18-1299-6	FLAP POSITION INDICATOR	B727, B737
181RA71R206C	CARGO- POWERED DRIVE UNITS	B767
1820M55P01	STATOR ASSEMBLY	
18-2141-3	TRANSMITTER	B747, B757, B767, B737,A320, DC9
18282G-02	HEADSET ELECTRICAL	CN-235, C-295
183990-0001	CONTROL UNIT, COCKPI	
185689	MOTOR HYDRAULIC	
1904-1-1	BALLAST	
1914-1-1	BALLAST	
1942T100-1	SENSOR CABINA	
19689	TRANSDUCER	
1A081-0155-1	TOILET FLUSH	B737,B757
1A081-0155-11	FLUSH TIMER SWITCH	B737,B757
1A3000-1A-HR	INVERTER POWER	
1B0712	PERMANENT MAGNET ALTERNATOR	
1B7997	PERMANENT MAGNET ALTERNATOR	
1C12-34	BOOTER PUMP	CN-235, C-295
1FA01134-1	VALVE SELECTOR RETRACTION/EXTENSION CONTROL,	
1FA01134-2	SELECTOR VALVE	B737
1G390	SWITCH	
1X2005097-00	LOGO LIGHT	A320
200-01062	INDICATOR TEMP	
200027176-10	NLG STEERING CYLINDER ASSY	



P/N	DESCRIPTION	AIRCRAFT PARTS
2000866-2	DC MOTOR	B767
2000866-3	DC MOTOR	MD-80, A310, A321, A320, DC-9
20031	AC GENERATOR	
20032-2	AC GENERATOR	ATR-72,B737
20033	ALTERNATEUR	
200566001	SHOCK ABSORBER	
200566002	SHOCKDAMPEN DIRECT	
200SG1064	ARMATURE	
200SG1103-9	DRIVE SHAFT	
200SGL	STARTER GENERATOR	
200SGL SERIES	STARTER GENERATOR	
200SGL1028-1	BELL END DRIVE	
200SGL1064	ARMATURE	
200SGL1064-5	ARMATURE	AGUSTA A119
200SGL1103-9	SHAFT DRIVE	
200SGL111Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL111Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL111Q-3	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL112Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180,
200SGL114Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180,
200SGL1156	FIELD	
200SGL1156-6	STATOR ASSY	
200SGL115Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL115Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL117Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE



P/N	DESCRIPTION	AIRCRAFT PARTS
200SGL118Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL119Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL119Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL120Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL121Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL124Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(1)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(3)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(4)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(5)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(8)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q1	STARTER GENERATOR	
200SGL130Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE



P/N	DESCRIPTION	AIRCRAFT PARTS
200SGL131Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL131Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL131Q-5	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q-3	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q-4	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q-5	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL142Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL144Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL145Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL147Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL147Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE



P/N	DESCRIPTION	AIRCRAFT PARTS
200SGL147Q-3	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL151Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL153Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180,
200SGL-SERIES	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180,
20101420-004	AUTO BRAKE VALVE MODULE	B757, B767
20101420-007	MODULE ASSY, VALVE	B757, B767
20102060-103	MODULE	B747, B747-400, B737
2011600-1	ARMATURE	
2011600-2	ARMATURE	
2012-1	CHARGER	B757, B767, B737, A318, A321
201F903	DRIVE ASSY ELECTROHYDRAULIC	
20202-01	FUEL COMPENSATOR	B737
20202-02	COMPENSATOR	
20219-0101	HYDRAULIC OIL QUANTITY TRANSMITTER	B737
20220-01	COMPENSATOR	
20220-0101	QTY TRANSMITTER	B737
2022538-6	UNIT AY - PDU CARGO AFT COMPT	B767, ATR42
2030781	MODULE ANTI-SKID SHUTTLE DISCONNECT	
203857-2	FUEL PUMP	
203936	ARMATURE	
2041207-2	STATOR	
2045M53P01	ALTERNATOR	
2045M53P02	ALTERNATOR	
2047410-1	ARMATURE	B757
2047410-2	ARMATURE	A300, A310, B757, B767
204790-1-1	TURBINE DRIVEN CENTRIFUGAL COMPRESSOR	
204790-2-1	COMPRESSOR CENTRIFUGA	
2056-01-01	SERVOED ALTITUDE INDICATOR	B737
2056-01-1	INDICATOR	
2057-01-1	ALTIMETER	B737
2057-02-1	SERVOED ALTITUDE INDICATOR	B737
20580-000-00	BRAKE FOR 6 INCH WHEEL	
20580-000-00-R1	BRAKE FOR 6 INCH WHEEL	
20580-000-01	BRAKE FOR 6 INCH WHEEL	
20580-000-03	BRAKE FOR 6 INCH WHEEL	
2061-11-1	FLAP POSITION INDICATOR	B727, B737
2061-12-1	FLAP POSITION INDICATOR	B727, B737
2061-13-1	FLAP POSITION INDICATOR	B727, B737
2061-14-1	FLAP POSITION INDICATOR	B737
2061-15-1	IND	B737
206400-3-1B	COMPRESSOR ROTARY	P3 ORION, P3 CONVERSION
2067593-2657	VHF NAV RECEIVER	
2070410-0106	RADAR TRANS-RECEIVER	B737
2070724-3206	ILS RECEIVER	
2070943-0101	ANTENNA COP	
20762	STATOR SUBASSEMBLY	B737
2083-08-1	MACH INDICATOR	B727, B737
2083-09-1	MACH INDICATOR	B727, B737
2083-10-1	MACH INDICATOR	B727, B737



P/N	DESCRIPTION	AIRCRAFT PARTS
2083-11-1	MACH AIRSPEED INDICATOR	B727, B737
20900110	CONTROL UNIT-INTE	
2092D	A.P.U. BOOSTER PUMP	
209568	STATOR	
209A10	CONTROL UNIT-INTE	
21007-1031	ARMATURE ASSY	
2101-01-1	INDICATOR, FUEL QTY	B737
2101-01-2	FUEL QTY INDICATOR	B737,B767
21113	WOUND STATOR ASSEMBLY	
2113	CASING / STATOR ASSY	
211C223-175	HYDRAULIC PRESSURE SWITCH	B747, B767, B757
211C223-176	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-177	HYDRAULIC PRESSURE SWITCH	B757, B747, B767,B737
211C223-178	HYDRAULIC PRESSURE SWITCH	B757
211C223-200	HYDRAULIC PRESSURE SWITCH	B757
211C223-203	HYDRAULIC PRESSURE SWITCH	B757, B737
211C223-208	HYDRAULIC PRESSURE SWITCH	B757,B777
211C223-209	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-211	HYDRAULIC PRESSURE SWITCH	B757
211C223-214	HYDRAULIC PRESSURE SWITCH	B757
211C223-216	HYDRAULIC PRESSURE SWITCH	B757,B777
211C223-252	HYDRAULIC PRESSURE SWITCH	B737, B757
211C223-253	HYDRAULIC PRESSURE SWITCH	B737, B757
211C223-278	HYDRAULIC SWITCH PRESSURE	B737, B757, B767
211C223-296	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-297	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-301	HYDRAULIC PRESSURE SWITCH	B757,B777
211C223-312	HYDRAULIC PRESSURE SWITCH	B737, B757
211C223-319	HYDRAULIC PRESSURE SWITCH	B757, B747, B767,B737,B777
211C223-320	HYDRAULIC PRESSURE SWITCH	B737, B757
211C223-321	HYDRAULIC PRESSURE SWITCH	B757, B767, B777
211C223-322	HYDRAULIC PRESSURE SWITCH	B757
211C223-323	HYDRAULIC PRESSURE SWITCH	B757, B777
211C223-326	HYDRAULIC PRESSURE SWITCH	B757, B767,B737, B777
211C223-327	HYD PRESSURE SWITCH	B757, B767,B737, B777
211C223-341	HYDRAULIC SWITCH PRESSURE	B737,B757,B777
211C223-461A	SWITCH-PRESSURE	CRJ200,ATR
211C223-516	HYD PRESSURE SWITCH	B767, B747, B757, B777,B737
211C223-518	HYDRAULIC PRESSURE SWITCH	B757, B767, B777,B737
211C223-519	HYDRAULIC PRESSURE SWITCH	B757, B767, B777,B737,B747
211C223-520	HYDRAULIC PRESSURE SWITCH	B757, B767, B777,B737
211C223-521	HYDRAULIC PRESSURE SWITCH	B757, B767, B777,B737
211C223-522	HYDRAULIC PRESSURE SWITCH	B757, B767, B777,B737
211C223-523	HYDRAULIC PRESSURE SWITCH	B757, B767, B777,B737
211C223-524	HYDRAULIC PRESSURE SWITCH	B757, B767, B777,B737
211C223-525	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-527	HYDRAULIC PRESSURE SWITCH	B757, B767, B777,B737
211C223-528	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-534	HYDRAULIC PRESSURE SWITCH	B767, B757, B777,B737
211C223-XXX	HYDRAULIC PRESSURE SWITCH	
2123M63P02	STATOR ASSEMBLY	CFM56-5A/B/C; CFM56-7B
2123M63P03	STATOR ASSEMBLY	CFM56-5A/B/C; CFM56-7B



P/N	DESCRIPTION	AIRCRAFT PARTS
212EAP	GYRO UNIT	
214001-10	PANEL CONTROL, ELECTRIC	
214C40-1-115	ALTITUDE SWITCH	B737-200, B757-200, B767-200, B767-300
214C40-1-71	SWITCH	B737-200, B757-200, B767-200, B767-300
214C40-1-75	PRUSSURE SPARE PARTS	B737-200, B757-200, B767-200, B767-300
214C40-1-77	ALTITUDE SWITCH	B737-200, B757-200, B767-200, B767-300
215344	ARMATURE	
217-04111	IND PRESSURE COMBU	C-212
217-05112	INDICATOR	C-212
218066-1	APU FUEL PUMP	B737-200, B737-300, B737-400, B737-500,
218066-2	APU FUEL PUMP	B737-200, B737-300, B737-400, B737-500,
218066-3	APU FUEL PUMP	B737-200, B737-300, B737-400, B737-500,
218387	APU FUEL PUMP	B737, B747, B757, B767, MD-11
218513	STATOR, ASSEMBLY	
21C1-1-16B	PRESSURE SWITCH	A-300
21C1-3-21	FUEL PRESS SWITCH	B757
21C1-3-22	FUEL PRESS SWITCH	B757
21SN04-104A	PRESSURE SWITCH	B737, B757, B767, B747, B777
21SN04-104B	PRESSURE SWITCH	B737, B767, B757, B747, B777
21SN04-104E	PRESSURE SWITCH	B737, B767, B757, B747, B777
21SN04-104F	PRESSURE SWITCH	B737, B767, B757, B747, B777
21SN04-209A	SWITCH-OIL	B737
21SN04-211	PRESSURE SWITCH	B767, B737
21SN04-211A	PRESSURE SWITCH	B767, B737
21SN04-223	FUEL PRESSURE SWITCH	B767, B747
21SN04-224	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B767, B747, B737
21SN04-225	SWITCH-OIL PRESSURE	A300, A310, B767, B747
21SN04-226	PRESSURE SWITCH	B767, B737
21SN04-226A	PRESSURE SWITCH	B767, B737
21SN04--226A	PRESSURE SWITCH	
21SN04-23F	PRESSURE SWITCH	B737, B757, B767, B747, B777
21SN04-23G	PRESSURE SWITCH	B737, B757, B767, B747, B777
21SN04-23H	PRESSURE SWITCH	B737, B757, B767
21SN04-23J	LOW OIL PRESS WRNG SWITCH	B737, B757, B767, B747, B777
21SN04-23K	PRESSURE SWITCH	B737, B757, B767, B747, B777
21SN04-300B	HYDRAULIC PRESSURE SWITCH	B767
21SN04-323A	FUEL PRESSURE SWITCH	B737, B757, B767
21SN04-324	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B737, B757, B767, B747
21SN04-325	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B737, B757, B767
21SN04-333	FUEL PRESSURE SWITCH	B737, B757, B767, B747
21SN04-334	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B767, B747
21SN04-422A	LOW OIL DIFFERENTIAL PRESSURE SWITCH	ATR
21SN04-422B	LOW OIL DIFFERENTIAL PRESSURE SWITCH	MD88, MD90
21SN04-466	FUEL PRESSURE SWITCH	B737, B757, B767
21SN04-467	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B737, B757, B767
21SN04-468	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B737, B757, B767



P/N	DESCRIPTION	AIRCRAFT PARTS
21SN04-XXX	SCAVENGE OIL FILTER DIFFERENTIAL PRESSURE SWITCH	
21SN41-42	PRESSURE SWITCH	B747, B767, B737
21SN41-52	SWITCH-THERMAL ANTI ICE	B747, B767, B737
21SN41-84	PRESSURE SWITCH	B747, B767, B737
2205170-1	AIR CYCLE MACHINE	B-737-400
2205170-2	AIR CYCLE MACHINE	B-737-400
22052	STATOR	
2214-11	STATOR	
22216	STATOR	
2243500-21	FLIGHT DATA ADQUISIT-DGTL	CN-235, C-295
2249956	STARTER GENERATOR	
229065	FUEL FEED PUMP	
229432	SUMERGED FUEL BOOSTER PUMP	
229893	STATOR	
229945	SUMERGED FUEL BOOSTER PUMP	
229959	STATOR	
23032	DC STARTER GENERATOR	
23032-	GENERATOR	
23032-018	GENERATOR	
23032-048	STARTER GENERATOR	
23032-1823	FIELD	
23032-1825	FIELD	
23032-1827	FIELD	
23032-1900	HUB DAMPENER	
23032-1901	HUB DAMPENER	
230321910	PLATE DAMPENER	
23032-1910	PLATE DAMPENER	
23032-1920	ARMATURE	
23032-2111	ARMATURE	
23032-2710	BACKPLATE DAMPENER	
23032-2711	BLACKPLATE DAMPENER	
23032-2844	DRIVE SHAFT	
23032-3210	PLATE & SENSOR DAMPENER	
23032-SERIES	DC STARTER GENERATOR	
23046 SERIES	DC STARTER GENERATOR	Corporate
23046-020	STARTER GENERATOR	Corporate
23046-1030	ARMATURE	
23046-1031	ARMATURE	
23046-1635	END BELL DRIVE END	
23046-310	STATOR AND HOUSING ASSY	
23046-311	STATOR AND HOUSING ASSY	
23046-313	FIELD	
23046-SERIES	DC STARTER GENERATOR	Corporate
23048	DC STARTER GENERATOR	Corporate
23048-1030	ARMATURE	
23048-1031	ARMATURE	
23048-1032	ARMATURE	
23048-SERIES	DC STARTER GENERATOR	Corporate
23065	DC STARTER GENERATOR	Heli/Corporate
23065 SERIES	DC STARTER GENERATOR	Heli/Corporate
23065-1020	ARMATURE	
23065-1520	DRIVE SHAFT	
23065-324	FIELD	
23069 SERIES	DC STARTER GENERATOR	
23069-1031	ARMATURE	



P/N	DESCRIPTION	AIRCRAFT PARTS
23069-322	STATOR AND HOUSING ASSEMBLY	
23069-332	FIELD	
23072-301	FIELD	
23072-314	ARMATURE	
23076-001	DC STARTER GENERATOR	
23076-001-1	DC STARTER GENERATOR	
23076-004	DC STARTER GENERATOR	
23076-004-1	DC STARTER GENERATOR	
23076-005	DC STARTER GENERATOR	
23076-310	STATOR AND HOUSING ASSY	
23076-312	STATOR AND HOUSING ASSY	
23078-003	DC STARTER GENERATOR	
23078-003-1	DC STARTER GENERATOR	
23078-005	DC STARTER GENERATOR	
23078-005-1	DC STARTER GENERATOR	
23078-006	DC STARTER GENERATOR	
23078-007	DC STARTER GENERATOR	
23078-008	DC STARTER GENERATOR	
23078-009	DC STARTER GENERATOR	
23078-010	DC STARTER GENERATOR	
23078-011	DC STARTER GENERATOR	
23078-012	DC STARTER GENERATOR	
23078-020	STARTER GENRATOR	
23078-1220	STATOR AND HOUSING ASSY	
23078-1222	STATOR AND HOUSING ASSY	
23078-1471	ARMATURE	
23078-311	FIELD	
23078-330	ARMATURE	
23079	DC STARTER GENERATOR	Heli/Corporate
23079 SERIES	DC STARTER GENERATOR	Heli/Corporate
23079-000-1	STARTER GENERATOR	Heli/Corporate
23079-005	GENERATOR	C-212, CN-235
23079-1020	ARMATURE	
23079-310	FIELD	
23079-330	ARMATURE	
23079-SERIES	DC STARTER GENERATOR	Heli/Corporate
23080 SERIES	DC STARTER GENERATOR	Corporate
23080-011	DC STARTER GENERATOR	Corporate
23080-012	DC STARTER GENERATOR	Corporate
23080-013	DC STARTER-GENERATOR	Corporate
23080-013A	DC STARTER-GENERATOR	Corporate
23080-013B	DC STARTER-GENERATOR	Corporate
23080-014	DC STARTER-GENERATOR	Corporate
23080-014A	DC STARTER-GENERATOR	Corporate
23080-018	STARTER GENERATOR	Corporate, C-212
23080-023	STARTER GENERATOR	Corporate, CESSNA
23080-1170	STATOR SUBASSY	
23080-301	STATOR AND HOUSING ASSY	
23080-306	STATOR AND HOUSING ASSY	
23080-323	STATOR AND HOUSING ASSEMBLY	
23080-370	ARMATURE	
23080-SERIES	DC STARTER GENERATOR	Corporate
23081	DC STARTER GENERATOR	
23081-043	STARTER GENERATOR	
23081-057	STARTER GENERATOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
23081-072	STARTER GENERATOR	
23081-073	DC STARTER GENERATOR	
23081-1010	ARMATURE	
23081-1011	ARMATURE	
23081-1155	DRIVE SHAFT	
23081-330	FIELD	
23081-390	STATOR AND HOUSING ASSEMBLY	
23081-SERIES	DC STARTER GENERATOR	
23085-001	DC STARTER GENERATOR	
23085-002	DC STARTER GENERATOR	
23085-003	DC STARTER GENERATOR	
23085-004	DC STARTER GENERATOR	
23085-004-1	DC STARTER GENERATOR	
23085-006	DC STARTER GENERATOR	
23085-009	DC STARTER GENERATOR	
23085-012	DC STARTER GENERATOR	
23085-013	DC STARTER GENERATOR	
23085-014	DC STARTER GENERATOR	
23085-015	DC STARTER GENERATOR	
23085-1080	FIELD	
23085-1352	DRIVE SHAFT	
23085-1500	ARMATURE	
23085-1501	ARMATURE	
23085-1503	ARMATURE	
23085-1530	FIELD	
23085-1532	STATOR AND HOUSING ASSEMBLY	
23085-A	BANDAS	
23088-001	DC STARTER GENERATOR	Dash 8
23088-001A	DC STARTER GENERATOR	Dash 8
23088-001B	DC STARTER GENERATOR	Dash 8
23088-002	DC STARTER GENERATOR	Dash 8
23088-002A	DC STARTER GENERATOR	Dash 8
23088-002B	DC STARTER GENERATOR	Dash 8
23088-003	DC STARTER GENERATOR	Dash 8
23088-003A	DC STARTER GENERATOR	Dash 8
23088-003B	DC STARTER GENERATOR	Dash 8
23088-004	DC STARTER GENERATOR	Dash 8
23088-004A	DC STARTER GENERATOR	Dash 8
23088-004B	DC STARTER GENERATOR	Dash 8
23088-006	DC STARTER GENERATOR	Dash 8
23088-006A	DC STARTER GENERATOR	Dash 8
23088-006B	DC STARTER GENERATOR	Dash 8
23088-008	STARTER GENERATOR	Dash 8
23088-300	STATOR HOUSING ASSEMBLY	Dash 8
23088-SERIES	DC STARTER GENERATOR	Dash 8
233A3201	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-13	WINDOW/PITOT HEAT MODULE ASSY	
233A3201-14	WINDOW/PITOT HEAT MODULE ASSY	
233A3201-2	WINDOW PITOT HEAT MODULE	B737
233A3201-302	WINDOW PITOT HEAT MODULE	
233A3201-305	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-306	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-313	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-314	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-5	WINDOW PITOT HEAT MODULE	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
233A3201-6	WINDOW/PITOT HEAT MODULE ASSY	B737
233A3201-8	WINDOW/PITOT HEAT MODULE ASSY	B737
233N3205-27	HYDRAULIC CONTROL PANEL	B757
233N3209-20	CONTROL PANEL	B757, B767
233N3211-1036	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1037	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1038	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1039	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1040	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1041	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1042	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1046	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1300	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1301	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1302	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1303	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1304	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1305	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1306	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1307	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1308	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1309	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1311	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-300	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-301	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-302	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-303	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-304	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-305	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-306	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-307	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-308	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-309	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-311	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-312	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-313	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-315	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-316	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-317	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-319	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-321	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-36	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-37	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-38	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-39	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-40	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-41	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-42	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-46	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3215-20	BLEED AIR PANEL	B757
233N6203-1007	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1009	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1012	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1013	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1021	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767



P/N	DESCRIPTION	AIRCRAFT PARTS
233N6203-1023	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1024	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-103	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1032	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1035	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1036	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-104	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1045	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1046	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1047	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1048	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-105	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1053	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1056	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1067	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1070	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1073	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1075	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1077	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1079	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1082	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1085	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1086	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-109	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-110	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1103	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1104	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1105	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1109	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-111	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1110	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1111	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1161	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1162	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1163	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1164	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1165	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1169	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1170	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1171	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1172	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1187	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1188	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1189	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1190	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1191	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1192	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1193	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1194	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1195	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1196	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1197	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1198	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-12	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1200	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767



P/N	DESCRIPTION	AIRCRAFT PARTS
233N6203-1202	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1203	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1206	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1219	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1220	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1221	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1226	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-13	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1301	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1302	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1303	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1304	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1305	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1347	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1348	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1349	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1350	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1351	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1352	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1353	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1354	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1356	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1358	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1359	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1381	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1382	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	
233N6203-1383	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1384	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1385	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1386	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1389	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1398	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1400	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1401	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1402	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1403	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1404	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1405	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1406	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1407	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1409	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1411	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1412	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1413	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1414	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1415	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1416	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1417	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1418	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1419	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1420	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1421	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1422	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-161	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-162	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767



P/N	DESCRIPTION	AIRCRAFT PARTS
233N6203-163	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-164	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-165	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-169	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-170	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-171	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-172	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-187	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-188	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-189	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-190	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-191	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-192	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-193	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-194	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-195	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-196	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-197	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-198	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-200	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-202	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-203	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-206	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-21	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-219	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-220	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-221	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-226	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-23	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-24	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-301	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-302	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-303	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-304	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-305	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-32	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-35	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-355	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-356	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-36	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-360	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-45	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-46	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-47	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-48	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-53	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-56	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-67	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-7	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-70	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-73	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-75	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-77	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-79	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-82	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767



P/N	DESCRIPTION	AIRCRAFT PARTS
233N6203-85	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-86	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-9	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-SERIES	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233T3210-306	LIGHT PANEL ASSY	B767, B757
233T3235-10	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1005	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1007	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1010	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1011	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1012	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1013	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1015	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-11	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-12	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-13	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1300	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1301	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1302	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1303	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1304	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1305	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1306	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1307	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-15	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-17	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-20	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-21	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-23	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-300	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-301	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-5	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-7	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T4246-1	SQUIB TEST PANEL ASSEMBLY M32	B757, B767
233T4246-11	SQUIB TEST PANEL ASSEMBLY M36	B757, B767
233T4246-18	SQUIB TEST PANEL ASSEMBLY M37	B757, B767
233T4246-4	SQUIB TEST PANEL ASSEMBLY M33	B757, B767
233T4246-7	SQUIB TEST PANEL ASSEMBLY M34	B757, B767
233T4246-8	SQUIB TEST PANEL ASSEMBLY M35	B757, B767
244-642-3	CARRIER LINNING	
2473-1B	CONTROL BOX ELECTRIC	
24A789-71	STATOR	
25038	ELECTRIC MOTORPUMP	CRJ700 & ERJ
250SG1 SERIES	STARTER GENERATOR	
250SG1064	ARMATURE	



P/N	DESCRIPTION	AIRCRAFT PARTS
251A1240-3	ACTUATOR FLICHT SPOILER	B737
251A1240-5	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY(SUB ASSY PN 251A1270-4, -5, -6)	
251A1240-6	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY(SUB	
251A1270-4	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	B-
251A1270-5	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	B-
251A1270-6	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	B-
251A1510-3	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
251A4510-3	STAB ACTUATOR	
2524038	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524057-2	FLOW DIVIDERS	E-26 TAMIZ
2524088-2	FLOW DIVIDERS	E-26 TAMIZ
2524115-2	FLOW DIVIDERS	E-26 TAMIZ
2524120-2	FLOW DIVIDERS	E-26 TAMIZ
2524148-3	FLOW DIVIDERS	E-26 TAMIZ
2524158-2	FLOW DIVIDERS	E-26 TAMIZ
2524164-2	FLOW DIVIDERS	E-26 TAMIZ
2524166-2	FLOW DIVIDERS	E-26 TAMIZ
2524172-2	FLOW DIVIDERS	E-26 TAMIZ
2524177-2	FLOW DIVIDERS	E-26 TAMIZ
2524188-1	FLOW DIVIDERS	E-26 TAMIZ
2524218-2	FLOW DIVIDERS	E-26 TAMIZ
2524219-2	FLOW DIVIDERS	E-26 TAMIZ
2524220-2	FLOW DIVIDERS	E-26 TAMIZ
2524221-2	FLOW DIVIDERS	E-26 TAMIZ
2524222-2	FLOW DIVIDERS	E-26 TAMIZ
2524223-2	FLOW DIVIDERS	E-26 TAMIZ
2524224-2	FLOW DIVIDERS	E-26 TAMIZ
2524225-2	FLOW DIVIDERS	E-26 TAMIZ
2524226-2	FLOW DIVIDERS	E-26 TAMIZ
2524227-2	FLOW DIVIDERS	E-26 TAMIZ
2524232-2	FLOW DIVIDERS	E-26 TAMIZ
2524240-2	FLOW DIVIDERS	E-26 TAMIZ
2524248-2	FLOW DIVIDERS	E-26 TAMIZ
2524265-2	FLOW DIVIDERS	E-26 TAMIZ
2524273	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524298	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524302-2	FLOW DIVIDERS	E-26 TAMIZ
2524327-2	FLOW DIVIDERS	E-26 TAMIZ
2524342-2	FLOW DIVIDERS	E-26 TAMIZ
2524366	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524397-2	FLOW DIVIDERS	E-26 TAMIZ
2524416-2	FLOW DIVIDERS	E-26 TAMIZ
2524420	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524421-2	FLOW DIVIDERS	E-26 TAMIZ
2524422	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524477	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524491	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES



P/N	DESCRIPTION	AIRCRAFT PARTS
2524492	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524500	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524534	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524556	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524571-2	FLOW DIVIDERS	E-26 TAMIZ
2524586-2	FLOW DIVIDERS	E-26 TAMIZ
2524601	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524610-2	FLOW DIVIDERS	E-26 TAMIZ
2524693	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524709	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524733	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524811	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524846	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524859	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524880	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
252T2110-3	ROD	B767
25615C27A26A1	INDICATOR PRESSURE	
25615-C27A-26-A1	DUAL AUTOSYN SYNCHRO INDICATOR	P3 ORION, P3 CONVERSION
25615-C29A-26-A1	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C29A-26-A3	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C32A-24-A1	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C32A-24-A2	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C32C-26-A2	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C32D-26-A3	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C33A-70-A3	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C33B-70-A3	DUAL AUTOSYN SYNCHRO INDICATOR	
256A3510-2	POWER DRIVE UNIT	B737
256A3515-1	FLAP ACTUATION GEABOX ASSEMBLY	B737
256A3515-2	FLAP ACTUATION GEABOX ASSEMBLY	B737
256A3515-3	FLAP ACTUATION GEABOX ASSEMBLY	B737
256A3515-4	FLAP ACTUATION GEABOX ASSEMBLY	B737
2588420-906	FLIGHT DIRECTOR CTRL	B737
2593604-222	CONTROL-FLIGHT DIRECTOR	C-212
2594618-901	INDICATOR TRUE	
2598E	XFMR	A340
260-398	PISTON HOUSING	
26-1000-250G	TRANSMITTER,PRESSUR	
2610-07-1	CLOCK ASSY	B737
2610-13-1	DAY / DATE CLOCK	A319, A320, A321, A330, A340, A320-100
26130010	VALVE, SOLENOID	C-130
26130010-01	VALVE, SOLENOID	C-130
26130010-01A	SHUT-OFF VALVE	C-130
26130011	SHUT-OFF VALVE	
26130011-01	SHUT-OFF VALVE	C-130
2-670001-1	VALVE	B747,B757
2670288-4	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	
2670288-5	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757
2670288-6	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757
2670288-7	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757,MD11
2670288-8	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757
2670288-9	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757,B737
267-989-001	INDICATOR-FUEL QNTY	C-212, CN-235
267-989-002	FUEL QUANTITY INDICATOR	
26B263-13B	AC GENERATOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
26S1000-250G	TRANSMITTER PRESSURE	CN-235
2704-1-000/1	HIGH SPEED OVEN	
2704202-1	ALTERNATING CURRENT GEARED MOTOR	B747
2704202-2	ALTERNATING CURRENT GEARED MOTOR	B747
2704202-3	ALTERNATING CURRENT GEARED MOTOR	B747
2704202-4	ALTERNATING CURRENT GEARED MOTOR	B747
2704202-5	ALTERNATING CURRENT GEARED MOTOR	B747
2704442-3	DIRECT CURRENT MOTOR	B777
2704442-4	DIRECT CURRENT MOTOR	B777
2704442-5	DIRECT CURRENT MOTOR	B777
2704458-1	APU STARTER	B737, B767
2704506-1	STARTER GENERATOR	A319, A321, A320
2704506-2	STARTER MOTOR	A319, A321, A320-100, A320
2704506-3	STARTER MOTOR	
2707905-3	HOUSING ASSY STATOR	
2709813-1	ARMATURE	
2709951-1	ARMATURE ASSY	B777
2709960-1	FIELD ASSY	B777
2709969-1	FRONT END BELL ASSEMBLY	
27-1000-4000SG	TRANSMITER	CN-235, C-295
2710503-1	FIELD ASSY	
2710503-2	FIELD	
2710772-1	FIELD	B757
271N6113-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
271N6113-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273A2501-1	ACTUATOR	B737, B727
273A3610-2	DAMPER	B737
273N2000-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2000-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2000-7	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2000-8	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-2	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-5	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273T1102-8	ACTUATOR	B767
273T4112-4	ACTUATOR NLG RETRACT	B767
273T4561-9	ACTUATOR ASSY	B767
273T6101-9	POSITIONER	B767
273T6201-3	ACTUATOR BEAR	B727, B767
2-7457-11	MLG DOOR ACTUATOR	B757, B737, B767, B777
2-7457-9	MLG DOOR ACTUATOR	B757
2-7460-5	ANTI SKID	B747, B747-400, B757, B767, B737
2-7460-SERIES	MODULE, ANTI-SKID SHUTTLE DISCONNECT	
2-7464-5	NLG DOOR ACTUATOR	B757
2-7464-7	NLG DOOR ACTUATOR	B757, B737
27531	VALVE, SHUTTLE	C130
2758	AIRCRAFT BATTERY	
275A1101-8	NLG STEERING ACTUATOR	B737
275N1211-2	NLG STEERING ACTUATOR	B757
275T6221-1	NOSE GEAR STEERING ACTUATOR ASSEMBLY	B767
275T6221-2	NOSE GEAR STEERING ACTUATOR ASSEMBLY	B767



P/N	DESCRIPTION	AIRCRAFT PARTS
275T6221-3	STEERING ACTUATOR	B767
2-7680-1	FLOW RATE FUSE ASSEMBLY	B737-200, B737-300, B737-400, B737-500,
2-7680-2	FLOW RATE FUSE ASSEMBLY	B757, B767, B777, B737, B737-200, B737-
2-7681-1	FLOW RATE FUSE ASSEMBLY	B-777-200
2-7681-2	FLOW RATE FUSE ASSEMBLY	B737, B757, B777, B-777-200
2-7735-1	HYDRAULIC FUSE	B737,B777
2-7736-1	HYDRAULIC FUSE, NOSE GEAR	B777
2-7737-1	BRAKES HYDRAULIC FUSE ASSY	B737
2-7756-1	HYDRAULIC FUSE	B757
2-7807-1	FUSE AY	
278-1	REFRIGERATION COMPRESSOR	
278-10	REFRIGERATION COMPRESSOR	
278-11	REFRIGERATION COMPRESSOR	
278-12	REFRIGERATION COMPRESSOR	
278-13	REFRIGERATION COMPRESSOR	
278-14	REFRIGERATION COMPRESSOR	
278-15	REFRIGERATION COMPRESSOR	
278-16	REFRIGERATION COMPRESSOR	
278-17	REFRIGERATION COMPRESSOR	
278-18	REFRIGERATION COMPRESSOR	
278-19	REFRIGERATION COMPRESSOR	
278-2	REFRIGERATION COMPRESSOR	
278-20	REFRIGERATION COMPRESSOR	
278-21	REFRIGERATION COMPRESSOR	
278-22	REFRIGERATION COMPRESSOR	
278-3	REFRIGERATION COMPRESSOR	
278-4	REFRIGERATION COMPRESSOR	
278-5	REFRIGERATION COMPRESSOR	
278-6	REFRIGERATION COMPRESSOR	
278-7	REFRIGERATION COMPRESSOR	
278-8	REFRIGERATION COMPRESSOR	
278-9	REFRIGERATION COMPRESSOR	
27A10614-101-11	ACCUMULATORS	
2-8020-1	FUSE: VOLUMETRIC	B737,B757
2-8020-11	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-12	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-13	HYDRAULIC FUSE	B737, B757, B777
2-8020-14	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-15	HYDRAULIC FUSE	B737,B777,B757
2-8020-16	HYDRAULIC FUSE, NOSE GEAR	B747, B757, B777, B737,DC10
2-8020-18	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-2	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-24	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-25	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-26	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-27	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-28	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-29	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-3	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-5	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-6	FUSE ASSEMBLY QUANTITY MEASURING	
2804-1-000/1	HIGH SPEED OVEN	
2-8041-1	ANTISKID VOLUMETRIC FUSE ASSEMBLY	B737,B777-200
28107-1	SERVO INTERFACE	



P/N	DESCRIPTION	AIRCRAFT PARTS
282800-1007	AILERON ACTUATOR	
282900-1013	CONTROL UNIT RUDDER PWR	B767,B747
2840210-5	STATOR ASSEMBLY	
285N0053-4	Warning Electronics Unit Stall Warning Printed Circuit Assy	B-767,B-757
285N0053-SERIES	Warning Electronics Unit Stall Warning Printed Circuit Assy	B-767,B-757
285N0412	HANDSET ASSY	
285N0412-1	ATTENDANT HANDSET ASSY	B757
285N0412-10	ATTENDANT HANDSET	B757
285N0412-2	ATTENDANT HANDSET	B757
285N0412-28	ATTENDANT HANDSET	B757
285N0412-29	ATTENDANT HANDSET	B757
285N0412-3	ATTENDANT HANDSET ASSY	B757
285N0412-30	ATTENDANT HANDSET	B757
285N0412-4	ATTENDANT HANDSET	B757
285N0412-8	ATTENDANT HANDSET ASSY	B757
285N0412-9	ATTENDANT HANDSET ASSY	B757
285N0412-XX	ATTENDANT HANDSET	
285T0001-207	AUDIO ACCESSORY UNIT	
285T0001-209	AUDIO ACCESSORY UNIT	B767
285T0001-77	AUDIO ACCESSORY UNIT	B757, B767
285T0017-102	CSEU POWER SUPPLY	B757
285T0017-103	CSUPWRSUPPLYMOD	B757
285T0017-104	CSEU POWER SUPPLY	B757,B747, B767
285T0017-104 MOD A	CSEU POWER SUPPLY	
285T0017-104 MOD AB	CSEU POWER SUPPLY	
285T0017-104 MOD B	CSEU POWER SUPPLY	
285T0017-201	CSEU POWER SUPPLY ASSEMBLI	B-767,B-757,B-747
285T0017-201MOD A	CSEU POWER SUPPLY ASSEMBLI	B-767,B-757,B-747
285T0022-51	AUDIO PANEL CONTROL	
285T0022-51 MOD A	AUDIO PANEL CONTROL	
285T0022-51 MOD AB	AUDIO PANEL CONTROL	
285T0024-18	PILOT CALL PANEL	UNK, B757, B767
285T0024-19	PILOT CALL PANEL	UNK, B757, B767
285T0024-20	MODULE ASSY PILOT CALL PANEL	UNK, B757, B767
285T0024-21	PILOT CALL PANEL	UNK, B757, B767
285T0024-22	PILOT CALL PANEL	UNK, B757, B767
285T0024-23	PILOT CALL PANEL	UNK, B757, B767
285T0024-24	PILOT CALL PANEL	UNK, B757, B767
285T0024-25	PILOT CALL PANEL	UNK, B757, B767
285T0024-26	PILOT CALL PANEL	UNK, B757, B767
285T0024-27	PILOT CALL PANEL	UNK, B757, B767
285T0024-28	PILOT CALL PANEL	UNK, B757, B767
285T0024-29	PILOT CALL PANEL	UNK, B757, B767
285T0024-30	PILOT CALL PANEL	UNK, B757, B767
285T0024-41	PILOT CALL PANEL	B737, B757, B767
285T0024-8	PILOT CALL PANEL	
285T0024-9	PILOT CALL PANEL	UNK, B757, B767
285T0024-SERIES	PILOT CALL PANEL MODULE ASSEMBLY	B757, B767
285T0033-23	Warning Electronics Unit Stall Warning Printed Circuit Assy	B-767,B-757
285T0033-29	Warning Electronics Unit Stall Warning Printed Circuit Assy	B-767,B-757
285T0033-SERIES	Warning Electronics Unit Stall Warning Printed Circuit Assy	B-767,B-757



P/N	DESCRIPTION	AIRCRAFT PARTS
285T0035-10	MODULE WEU POWER SUPPLY	B747, B757, B767
285T0035-10 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-10 MOD AB	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-10A	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-10AB	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-11	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	B747, B757, B767
285T0035-11 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-11 MOD AB	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-11A	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-11AB	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-3	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	B747, B757, B767
285T0035-3 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-3A	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-9	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	B747, B757, B767
285T0035-9 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-9 MOD AB	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-9A	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-9AB	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0078-1	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	
285T0078-10	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	
285T0078-15	PLYTKA DRUKOWANA.WENTYL	B767
285T0078-16	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	
285T0078-8	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	
285T0093-11	PCAY PACK FLOW CONTROL	B757,B767
285T0093-11 MOD A	PACK FLOW CONTROL PCB	
285T0093-11A	PACK FLOW CONTROL PCB	
285T0093-8	PACK FLOW CONTROL PCB	B757
285T0096-13	ELECTRONIC ENGINE CONTROL DISCRETE PRINT	B767
285T0096-17	ELECTRONIC ENGINE CONTROL DISCRETE PRINT	
285T0096-5	ELECTRONIC ENGINE CONTROL DISCRETE PRINT	
285T0096-7	PC ASSY-EEC	B757,B767
285T0099-12	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-12 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-12A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-13	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-13 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-13 MOD B	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-13A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-13B	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-15	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-15 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-15A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17	MODULE-FLAP/STAB POSITIO	B757,B767
285T0099-17 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17 MOD B	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-17 MOD BC	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17B	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17BC	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-7	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-7 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-7A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0458	N2 ENGINE SPEED DISCRETE PRINTED CIRCUIT ASSEMBLY	
285T0458-	N2 ENGINE SPEED DISCRETE PRINTED CIRCUIT ASSEMBLY	
285T0458-17	PC ASSY-N2 ENGINE SPPED	



P/N	DESCRIPTION	AIRCRAFT PARTS
285T0458-SERIES	N2 ENGINE SPEED DISCRETE PRINTED CIRCUIT ASSEMBLY	
285T0471-17	P/C AY	
285T0496-1	EICAS DSPL SWITCH MODUL	B767,B757
285T0553-1	ILS CONTROL PANEL	B757, B767
285T0553-2	ILS CONTROL PANEL	B757, B767
285T0553-3	ILS CONTROL PANEL	B757, B767
285T0553-4	ILS CONTROL PANEL	B757, B767
285T0553-X	ILS CONTROL PANEL	
285T0554 SERIES	VOR CONTROL PANEL	
285T0554-3	VOR CONTROL PANEL	B757, B767
285T0554-3 MOD. A	VOR CONTROL PANEL	
285T0554-3 MOD. B	VOR CONTROL PANEL	
285T0554-3 MOD. C	VOR CONTROL PANEL	
285T0554-3 MOD. D	VOR CONTROL PANEL	
285T0554-3 MOD. E	VOR CONTROL PANEL	
285T0554-3A	VOR CONTROL PANEL	
285T0554-3B	VOR CONTROL PANEL	
285T0554-3C	VOR CONTROL PANEL	
285T0554-3D	VOR CONTROL PANEL	
285T0554-3E	VOR CONTROL PANEL	
285T0554-4	VOR CONTROL PANEL	B757, B767
285T0554-4 MOD. A	VOR CONTROL PANEL	
285T0554-4A	VOR CONTROL PANEL	
285T0554-5	VOR/DME CONTROL PANEL	B757, B767
285T0554-5 MOD. A	VOR CONTROL PANEL	
285T0554-5 MOD. B	VOR CONTROL PANEL	
285T0554-5 MOD. C	VOR CONTROL PANEL	
285T0554-5 MOD. D	VOR CONTROL PANEL	
285T0554-5 MOD. E	VOR CONTROL PANEL	
285T0554-5A	VOR CONTROL PANEL	
285T0554-5B	VOR CONTROL PANEL	
285T0554-5C	VOR CONTROL PANEL	
285T0554-5D	VOR CONTROL PANEL	
285T0554-5E	VOR CONTROL PANEL	
285T0554-6	VOR CONTROL PANEL	B757, B767
285T0554-6 MOD. A	VOR CONTROL PANEL	
285T0554-6 MOD. AB	VOR CONTROL PANEL	
285T0554-6A	VOR CONTROL PANEL	
285T0554-6AB	VOR CONTROL PANEL	
285T0554-6B	VOR CONTROL PANEL	
285T0557-1	ADF CONTROL PANEL	B757, B767
285T0557-2	ADF CONTROL PANEL	B757, B767
285T0557-X	DUAL ADF CONTROL PANEL	
285T0852	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0852-1	KEYPAD COKPIT DOOR ACCESS	B737,B757,B777
285T0852-1 MOD A	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0852-1 MOD AB	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0852-1A	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0852-1B	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0855-1	CONTROLLER DOOR ACCESS	B777,B757,B737,B767
285T0855-5	CONTROLLER FDAS	B777,B757,B737
285T1104-1	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-10	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-11	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-13	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757



P/N	DESCRIPTION	AIRCRAFT PARTS
285T1104-15	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17 MOD B	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17 MOD BC	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17 MOD C	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17B	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR	B-767,B-757
285T1104-17BC	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR	B-767,B-757
285T1104-17C	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR	B-767,B-757
285T1104-18	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-18 MOD A	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-18 MOD AB	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-18 MOD B	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-18A	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR	B-767,B-757
285T1104-18AB	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR	B-767,B-757
285T1104-18B	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR	B-767,B-757
285T1104-19	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-21	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-22	PC ASSY - STALL WARNING	B-767,B-757
285T1104-23	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-24	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-9	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-SERIES	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1111-1	Warning Electronics Unit Bite Display Printed Circuit Assy	B-767,B-757
285T1111-SERIES	Warning Electronics Unit Bite Display Printed Circuit Assy	B-767,B-757
28B135-126-A	AC GENERATOR	
28B135-133-A	AC GENERATOR	
28B135-29-A	AC GENERATOR	
28B141-17C	GENERATOR ALTERNATI	
28B141-17-C	AC GENERATOR	
28B141-51-A	AC GENERATOR	
28B141-9-A	AC GENERATOR	
28B263-13	GEN	B737
28B263-13A	AC GENERATOR	B747
28B263-13B	AC GENERATOR	B747
28B545-7	GENERATOR	B737,B707
28B545-7A	STARTER GENERATOR	B737
28B545-7B	STARTER GENERATOR	B737
28B545-9	STARTER/GENERATOR	
28B555-1	AC GENERATOR	
28B555-1-A	AC GENERATOR	
28B555-1-B	AC GENERATOR	
28B555-1-C	AC GENERATOR	
28B555-1-D	AC GENERATOR	
28B555-1-E	AC GENERATOR	
28B58-9A	ALTERNATING CURRENT GENERATOR	
28B58-9-A	AC GENERATOR	C-130
28B58-9B	AC GEN	



P/N	DESCRIPTION	AIRCRAFT PARTS
28B58-9-B	AC GENERATOR	C-130
28B95-15	AC GENERATOR	P3 ORION, P3 CONVERSION
28B95-15D	GENERATORAL TERNATI	
28B95-15-D	AC GENERATOR	
28B95-15DV	GENERATOR ASSY	P3 ORION, P3 CONVERSION
28B95-15D-V	GENERATORAL TERNATI	
28B95-15-SERIES	AC GENERATOR	
28B95-57	AC GENERATOR	
28B95-57-A	AC GENERATOR	
28B95-65A	GENERATOR ASSY	P3 ORION, P3 CONVERSION
28B95-9	AC GENERATOR	
28B95-9-SERIES	AC GENERATOR	
29000	VALVE VENTILATION FUEL	
291-10	NAVIGATION LIGHT	ATR-72
29145	ANTENNE DESMONTABLE	
292-00	ANTI-COLLISION LIGHT ASSEMBLY	ATR42, ATR72
292-01	ANTI-COLLISION LIGHT ASSEMBLY	ATR42, ATR72
292-12	STROBE LIGHT	ATR-42, ATR-72,B727
292-13	STROBE LIGHT	ATR-72,B727
292-23	STROBE LIGHT PS	ATR-42, ATR-72,B727
292-24	STROBE LIGHT	ATR-42, ATR-72,B727
292-25	POWER SUPPLY	ATR-42, ATR-72
293E775G40	GENERATOR CONVERTER UNIT	
2944T100-SERIES	POWER DRIVE UNIT	
2955640-3	STATOR	
2955T100-SERIES	POWER DRIVE UNIT	
2C7-4	CENTRIFUGAL FUEL BOOST PUMP	
2CM16SAB2	STATOR ASSY	
2CM16SAB3	STATOR ASSY	
2CM353CTH	AC GEN	
2LA007417-00	MODULE EQUIP READING LIGH	Saab340
300047-13001	CAPACITANCE FUEL QTY GAGING SYSTEM	
300047-13002	CAPACITANCE FUEL QTY GAGING SYSTEM	
30059-1471	BACKPLATE DAMPENER	
30059-1480	PLATE DAMPENER	
30076-2460	BACKPLATE DAMPENER	
30079-2460	BLACKPLATE DAMPENER	
30080-1080	PM STATOR	
30080-1090	STATOR EXCITER	
30081-001	DC GENERATOR	
30081-010	DC GENERATOR	
30-0837-1	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727
30-0837-11	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B727, B737, B707
30-0837-13	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, C-130, B707, B727,CRJ
30-0837-15	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, C-130, B707, B727,CRJ
30-0837-17	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-19	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-21	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B727, B737, B707
30-0837-23	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-25	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-29	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-3	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-31	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727
30-0837-33	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-35	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ



P/N	DESCRIPTION	AIRCRAFT PARTS
30-0837-39	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-41	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-47	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-5	LIGHT ASSY	B737, B707, B727
30-0837-7	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-9	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,DASH8
30086-010	DC GENERATOR	
30086-011	DC GENERATOR	
30-0881-1	STROBE LIGHT	
300-90496-0501	CIRCUIT CARD ASSEMBLY	
30-0906	STROBE LIGHT	
30-0906-104	STROBE LIGHT	B737, B727,MD80
30-0906-105	WING POS LIGHT	B737, B727,MD80
30-0906-SERIE	STROBE LIGHT	
30-0906-SERIES	HIGH- INTENSITY STROBE LIGHT	
30-0909-1	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737
30-0909-101	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737, B747,MD80
30-0909-103	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737,B727
30-0909-107	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737
30-0909-201	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737,B767
30-0909-203	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737
30-0909-207	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737
300SG SERIES	STARTER GENERATOR	
300SG1064	ARMATURE	
300SG1156	FIELD	
300SGL	STARTER GENERATOR	
300SGL SERIES	STARTER GENERATOR	
300SGL127Q	STARTER GENERATOR	DASH 8
300SGL153Q	STARTER GENERATOR	
30-1033	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-19	LIGHT-ANTI-COLLISION	C-212, CN-235, C-295,EMB
30-1033-3	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	EMB
30-1033-49	LIGHT	CN-235, C-295,EMB
30-1033-5	LIGHT ANTI COLLISION	CRJ700
30-1033-57	LIGHT-ANTI-COLLISION	CN-235, C-295,EMB
30-1033-SERIES	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	
30-1401-1	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30-1401-11	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30-1401-13	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30-1401-15	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30-1401-3	LIGHT ASSY	B737, B727,B767
30-1401-9	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30170	VALVE, LINEAR, DIRECT	
30-1738-3	WING POSITION LIGHT	C-295
30-1738-4	LIGHT-RIGHT POSITION(IR)	CN-235
30210	ACCUMULATOR HYDRAULIC	B737
30220	ACCUMULATOR HYDRAULIC	B747, B747-400, B737, B757
3024372	AUTOTRANSFORMER	
30-2505-3	UPPER FUSELAGE ANTI- COLLISION LIGHT	B737-800/900
30-2506-3	LOWER AIRCRAFT ANTICOLLISION FUSELAGE STROBE LIGHT	B737-800/900
30-2610-1	STROBE LIGHT	Dash8,CRJ
30-2722-01	STROBE LIGHT ASSY	
3029683-001	HYDRAULIC MOTORPUMP ASSEMBLY	A319, A320, A321, A330, A340
3029981-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASS	DC-9, MD-80, MD-90



P/N	DESCRIPTION	AIRCRAFT PARTS
3031863-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	B747, B757, B767, A320, A320-100
30527-320	CONTROL UNIT	A300, A300-600,A310
3057992	AUTOTRANSFORMER	
3058959	STATOR	
3059-1471	BACKPLATE DAMPENER	
3076518	STATOR ASSY BRAKE	
3076548	STATOR	
30B107-11-A	DC GENERATOR	
30B107-19-A	DC GENERATOR	
30B107-7-F	DC GENERATOR	
30E02-21-G	DC GENERATOR	
30E02-27-A	DC GENERATOR	
31008-1066	ROTOR	
31077-100	INBOARD SPOILER ACTUATOR	A300, A300-600, A310, A318, A319, A320,
31077-111	INBOARD SPOILER ACTUATOR	A300, A300-600, A310, A318, A319, A320,
31077-200	INBOARD SPOILER ACTUATOR	A300, A300-600, A310, A318, A319, A320,
31077-211	INBOARD SPOILER ACTUATOR	A300, A300-600, A310, A318, A319, A320,
3111317	AUTOTRANSFORMER ASSY	
31164 SERIES	AC GENERATOR	
31164-1350	ROTOR EXCITER	
31164-1420	STATOR PM	
31164-5532	ROTOR	
31216-001	5 KVA GENERATOR AC	
3121624	AUTOTRANSFORMER	
3121631	AUTOTRANSFORMER	
31220-004	AC GENERATOR	UNK, C-130
31220-1020	STATOR	
312BS101-1	ISFD DEDICATED BATTERY CHARGER (DBC)	B737, B757, B767
31340-1032	STATOR MAIN	
31342-001	ALTERNATOR	CN-235
31342-003	GENERATOR-AC26KVA	CN-235
31342-004	GENERATOR-AC	CN-235, C-295
31342-006	AC GENERATOR	CN-235, C-295
31342-007	AC GENERATOR	C-295
31342-352	ROTOR ASSEMBLY	CN-235, C-295
314195	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASS	DC-9, MD-80, MD-90
3142-003	AC GENERATOR (26KVA	
3-1486	WHEEL ASSEMBLY	
315344	FIELD ASSY	
315A1701-111	LH THRUST REVERSER ASSY	
315A1701-12	THRUST REVERSER ASSY, RH	
315A1701-40	Thrust reverser	
315A1701-48	THRUST REVERSER	
315A1701-6	THRUST REVERSER	
315A1701-64	THRUST REVERS	
315A1701-77	THRUST REVERSER	B737
315A1701-78	THRUST REVERSER	



P/N	DESCRIPTION	AIRCRAFT PARTS
315A1701-78A	THRUST REVERSER	
315A1701-79	THRUST REVERSER	B737
315A1701-81	THRUST REVERSER	
315A1701-83	THRUST REVERSER	
315A1701-84	THRUST REVERSER	
315A1701-9	LH THRUST REVERSER ASSY	
315A1801-14	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-15	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-18	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-19	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-22	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-23	THRUST REVERSER HYDRAU	B737
315A1801-26	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-27	THRUST REVERSER HYDRAU	B737
315A2800-1	THRUST REVERSER ACTUATOR	B737
315U2027-1	RESERVOIR ASSY-CF6-80C	MD80, MD90
31708-000	AC GENERATOR	
31708-000A	AC GENERATOR	
31708-001	AC GENERATOR	
31708-001A	AC GENERATOR	
31708-002	AC GENERATOR	
31708-002A	AC GENERATOR	
31708-003	AC GENERATOR	
31708-003A	AC GENERATOR	
31708-301	ROTOR	
31-7611-1	NAVIGATIONAL LIGHT SUBASSEMBLY	B-777-200
31-7611-2	NAVIGATIONAL LIGHT SUBASSEMBLY	B-777-200
3181-196-901	VACUUM AND PRESURE	
3181-233-901	VACUUM AND PRESURE	
3202142-1	CONDITIONED AIR CHECK VALVE	B737
3202142-2	CONDITIONED AIR CHECK VALVE	UNK, B767
32032-1900	HUB DAMPENER	
321-400-703-0	DOOR OPENING HYDRAULIC ACTUATOR	
321-400-704-0	DOOR OPENING HYDRAULIC ACTUATOR	
321-400-705-0	DOOR OPENING HYDRAULIC ACTUATOR	A320, A320-100
3214-31	BATTERY EXIT LIGHT	A320, B737, A330, A340, A300, A310
3250-70	BALLAST UNIT	A319, A320, A321, A320-100
3250-80	BALLAST UNIT	A319, A320, A321, A330, A340
3250-81	BALLAST	A320, A330, A340, A319
32700030-1	FIRE EXTINGUISHER	
3282970-2	STOP MECHANISM	A-319, A-320,A-321, A-330, A-340,
3282970-3	STOP MECHANISM	A-319, A-320,A-321, A-330, A-340,
3282970-4	STOP MECHANISM	A-319, A-320,A-321, A-330, A-340,
3283086-3	BRAKE LOCK ASSY THRUST REVERSE	UNK, B737, B747, B767
3290003-44	EQUIPO FLIR THERMOGRAPHY	
3302196-13	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3302196-15	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3302196-19	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3303591-1	STRUT ASSEMBLY NOSE LANDING GEAR	C130
33-065-1	NORMAL ANTISKID VALVE MODULE (AVM)	B747,B757,B767
33-065-2	NORMAL ANTISKID VALVE MODULE (AVM)	B747,B757,B767
33-067-1	ALTERNATE ANTISKID VALVE MODULE (AVM)	B747,B757,B767
33-067-2	ALTERNATE ANTISKID VALVE MODULE (AVM)	B747,B757,B767
3314203-3	STRUT ASSY NOSE LANDING GEAR	C-130
3316498-1	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES



P/N	DESCRIPTION	AIRCRAFT PARTS
3316498-7	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3316500-15	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
332587	SHAFT DRIVE	
332A67-5840-01	AIR CONDITIONING CONTROL PANEL	
33793-3	RECEIVER, TRANSMITTER	
33823-2	CONTROL, RADAR SET	
33824-1	INDICATOR, AZIMUTH	
33862	MODULAR TX / RX	
33A64-1612-010	CONTROL BOX	
3402292-1	PANEL CONTROL	
34-61-11	-	
34755-5	CONTROL RADAR SET	
350448-5	STARTER	
350571-6	STARTER	
350880-6	VARIABLE DISPLACEMENT HYDRAULIC PUMP	B757, B767, DC-10, MD-11, A300-
350880-7	HYD PUMP	B757, B767, A300-600,A310,DC10
35-825196-698	GEAR ASSY NOSE	
35H	EXTINTOR	
3600232-2	ACTUATOR	DC-10,A310
3605812-1	ELECTRICAL ENGINE STARTER	B737
3605812-10-1	ELECTRICAL ENGINE STARTER	B727,B737
3605812-11	ELECTRICAL ENGINE STARTER	B727
3605812-12	ELECTRICAL ENGINE STARTER	B727, C-130
3605812-13-1	ELECTRICAL ENGINE STARTER	B727, B737
3605812-14-1	ELECTRICAL ENGINE STARTER	B727, C-130,B737
3605812-16	ELECTRICAL ENGINE STARTER	B727, B737, C-130
3605812-17	ELECTRICAL ENGINE STARTER	B727, C-130,B737
3605812-18	ELECTRICAL ENGINE STARTER	B727, C-130
3605812-19	ELECTRICAL ENGINE STARTER	B727, B737
3605812-21	ELECTRICAL ENGINE STARTER	
3605812-2-1	ELECTRICAL ENGINE STARTER	B737
3605812-22	ELECTRICAL ENGINE STARTER	B727, B737, C-130
3605812-22-1	STARTER MOTOR ASSY	B-737-100/-200/-300/-400/-500, B727,
3605812-3	ELECTRICAL ENGINE STARTER	
3605812-4	ELECTRICAL ENGINE STARTER	
3605812-9	ELECTRICAL ENGINE STARTER	
360900	SWITCH	
3614278-1130	WEATHER CONTROL PANEL	
3617750-1	FCU APU	B727, B737, DC-8, DC-9, MD-80,MD80
3617750-2	TURBINE TYPE FUEL CONTROL UNIT	B737,B727, MD80
3617750-3	TURBINE TYPE FUEL CONTROL UNIT	B727, B737, DC-8, DC-9, MD-80
3617750-4	TURBINE TYPE FUEL CONTROL UNIT	B727, B737, DC-8, DC-9, MD-80
368-105	INTERRUPTOR, PULSADO	
36E135-2C	STARTER	
36E84	STARTER	
36E84-18F	STARTER	C-130
36E84-18QF	STARTER	C-130
3704-1-000/1	HIGH SPEED OVEN	
370438-1	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
371380	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
371688	FUEL CONTROL UNIT	
371688 SERIES	FUEL CONTROL UNIT	
371688-10	FUEL CONTROL UNIT	



P/N	DESCRIPTION	AIRCRAFT PARTS
372697-10	ELECTRICAL ENGINE STARTER	P3 ORION, P3 CONVERSION
372697-13	ELECTRICAL ENGINE STARTER	
372697-15	ELECTRICAL ENGINE STARTER	
372697-16	ELECTRICAL ENGINE STARTER	
372697-18	STARTER,ENGINE,ELECT	
372697-18-1	ELECTRICAL ENGINE STARTER	B727, C-130,B737
372697-21-1	ELECTRICAL ENGINE STARTER	B737
372697-22	ELECTRICAL ENGINE STARTER	B727, DC8
372697-24	ELECTRICAL ENGINE STARTER	B737
372697-6	ELECTRICAL ENGINE STARTER	
372697-9	ELECTRICAL ENGINE STARTER	B737
375322-10	ELECTRICAL ENGINE STARTER	
375322-7	ELECTRICAL ENGINE STARTER	
375322-8	ELECTRICAL ENGINE STARTER	
375322-9	ELECTRICAL ENGINE STARTER	C-130, B737
378055	ROTOR	
380258-1	PNEUMATIC AND SHAFT POWER GAS TURBINE ENGINE	
3804-1-000/1	HIGH SPEED OVEN	
3810-0101-0000	STATOR	A310
3810056-101	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-103	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-104	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-105	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-106	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-107	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-108	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-109	MODULE CONTROL VALVE THRUST REVERSER	B737
381116-1-7	ENGINE, GAS, TURBINE	C-130
381116-1-8	AUXILIARY POWER UNIT	C-130
381785	ROTOR	
38210-394	VARIOMETRE	
383534-2-1	STARTER	C-130
383534-2-2	STARTER	C-130
383900-1011	STEERING VALVE ASSY	B737
3862160-9	APU COOLING FAN	B747, B757, B767, A300, A310
388058-1	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
388058-19	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
388058-9	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3882350	FUEL CONTROL UNIT	
3882350 SERIES	FUEL CONTROL UNIT	
3883220-3	ACTUATOR IGV	A320, A320-100,B737
3888217-2	STARTER	A330, A340, B767,A310
3888217-3	APU STARTER	A330, A340, B767,A310
3888217-4	STARTER	A330, A340, B767,A310,MD80
3888217-X	STARTER	
3890010-102	PRESSURE RELIEF VALVE	B737
3890010-103	PRESSURE RELIEF VALVE	B737,B777
38E93-4	ANTI-ICING VALVE	A320, A340, A321, A319, A330, A318
38E93-5	ANTI-ICING VALVE	A320, A340, A321, A319, A330, A318
38E93-6	ANTI-ICING VALVE	A320, A340, A321, A319, A330, A318
38H	EXTINTOR	
3910-0101-0000	HOUSING MOTOR	
392200-11-1	VALVE BUTTERFLY	P3 ORION, P3 CONVERSION
39-249	DUAL PRESSURE CONTROL VALVE	DC-9
39-249-1	DUAL PRESSURE CONTROL VALVE	DC-9,B727



P/N	DESCRIPTION	AIRCRAFT PARTS
39-249-2	DUAL PRESSURE CONTROL VALVE	MD-80,DC9
3930-0100-0000	HOUSING ASSY	
393007-07869	INDICATOR ASSEMBLY CAPACITOR FUEL GAGE SYSTEM	P3 ORION, P3 CONVERSION
393007-07870	INDICATOR ASSEMBLY CAPACITOR FUEL GAGE SYSTEM	P3 ORION, P3 CONVERSION
393065-01858	INDICATOR	P3 ORION, P3 CONVERSION
394324	FLOW DIVIDER AND DRAIN	
394324 SERIES	FLOW DIVIDER AND DRAIN	
394390	FLOW DIVIDER AND DRAIN	
394390 SERIES	FLOW DIVIDER AND DRAIN	
394408	FLOW DIVIDER AND DRAIN	
394408 SERIES	FLOW DIVIDER AND DRAIN	
396064-1-1	FLOW CTRL VALVE	B737,B757
396362	ELECTRIC MOTOR ASSEMBLY	
396800	BLEED VALVE FUEL GEAR MOTOR	
396800-10	MOTOR GEAR HYDRAULIC	A318, A319, A320, A321
396800-11	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-12	MOTOR GEAR HYD	A318, A319, A320, A321,B717, MD90
396800-5	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-6	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-7	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-8	MOTOR GEAR HYDRAULIC	A318, A319, A320, A321
396800-9	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-SERIES	BLEED VALVE FUEL GEAR MOTOR	
398000-1	FUEL BOOSTER PUMP, SINGLE FUEL VOLUTE HOUSING &	
398648-1-1	VALVE, BUTTERFLY	
39900-303	VALVE	
399300-2	FUEL BOOSTER PUMP, SINGLE FUEL VOLUTE HOUSING &	
399500-1	FUEL BOOSTER PUMP, SINGLE FUEL VOLUTE HOUSING &	
3A41.32.20F.28.4.EP	ALTIMETER 2"	
3A41.32.20F28.4.EP	ALTIMETER 2" (NVIS GREEN B)	
3D3554-02	ISOLATION VALVE,DE-ICING	C-295
3H67-42-35F05-1BA	ALTIMETER, ENCODING	CN-235
3LO-453	SWITCH-INERTIA 4G	ATR
3LO-453-4	SWITCH INERTIAL	
3LO-453-6	SWITCH INERTIAL	
3M304-6-10-0	RECEPTACLE	
3P99-136	STATOR	
400-0073-000	CONTROL, RADIO SET	
4000504-0305	DRIVE,ANTENNA	C-295, P3 CONVERSION
4000695-6221	RECEIVER, RADIO NAVIG	
4009301840	WINDING STATOR SUB-ASSY	
400SG SERIES	STARTER-GENERATOR	
400SG1008-1	END BELL	
400SG1028	HEAD MOUNTING, DE	
400SG1064	ARMATURE	
400SG1064-XL	ARMATURE	
400SG1156-11	STATOR ASSY	
400SG1156-32	FIELD	
400SG1156-35	FIELD	
400SG1156-36	FIELD	
400SG1301	END BELL	
400SG138Q	STARTER GENERATOR	Learjet



P/N	DESCRIPTION	AIRCRAFT PARTS
400SG159Q	STARTER GENERATOR	Learjet
400SG2064	ARMATURE ASSY	
40109-1	AIRCRAFT BATTERY	CN-235, C-295, P3 CONVERSION
40143	PUMP & MOTOR PACKAGE ASSEMBLY	C-212
40180	ELECTRIC HYD PUMP	
4019305-901	CIRCUIT CARD ASSY	
4019501	HYDRAULIC PUMP	ATR-72,Saab340
40-195-01	AC ELECTRIC HYDRAULIC PUMP	ATR-42
40205-1	LANDING LIGHT	
40205-1-4559	LANDING LIGHT	
40205-2	LANDING LIGHT	
40205-2-4559	LANDING LIGHT	
40205-3	LANDING LIGHT	
40205-3-4559	LANDING LIGHT	
40205-3-Q4559	LANDING LIGHT	
40205-3-Q4559X	LANDING LIGHT	
40205-4	LANDING LIGHT	
40205-4-4559	LANDING LIGHT	
40205-5	LANDING LIGHT	
40205-5-4559	LANDING LIGHT	
40205-6	LANDING LIGHT	
40205-6-Q4559	LANDING LIGHT	
40205-7-4559	LANDING LIGHT	
40205-7-Q4559	LANDING LIGHT	
402306-3	NLG STEERING CYLINDER ASSY	C-130
402306-5	NLG STEERING CYLINDER ASSY	
402306-7	NLG STEERING CYLINDER ASSY	
4023400-0501	TRANSC. APX72	C-212
4037102	TAKE-OFF AND TAXI LIGHT	
4037132	TAKE-OFF AND TAXI LIGHT	
4049A	PUMP	C-212
4065713	WING ICING INSPECTION LIGHT	
4065729	WING ICING INSPECTION LIGHT	
407009-1	INDICATOR AZIMUTH	
4071-2	NICKEL-CADMIUM AIRCRAFT BATTERY	
4080224	ARMATURE	
41000740-103	THRUST REVERSER VALVE ASSEMBLY	
41000740-104	THRUST REVERSER VALVE ASSEMBLY	A300, A320, A330
4100149	LAVATORY/GALLEY VENT FAN	
4100149A	LAVATORY/GALLEY VENT FAN	B747, B747-400
4100149B	LAVATORY/GALLEY VENT FAN	B747, B747-400
4100149C	LAVATORY/GALLEY VENT FAN	B747
4100250	STATOR	
4100519	STATOR ASSEMBLY	
4100928	STATOR	
4101054	LAVATORY / GALLEY VENT FAN	B737,B757
4101099F	FAN	A310
4105DA	LANDING GEAR VALVE	B737
4122-009004	MOTOR PUMP	CN-235
4129RA	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA1	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA10	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA2	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA3	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA4	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737, B757, B767



P/N	DESCRIPTION	AIRCRAFT PARTS
4129RA5	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA6	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA7	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA8	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737,B747, B767
4129RA9	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737, B757, B767, B777
414469	ELECTRIC MOTOR ASSEMBLY	
415509	HYDRAULIC PUMP	
4173763	LANDING LIGHT	
418-00475-500	MODULE ANEMO-BAROME	
418-06104	OIL PRESS TRANS	B767
4191695	RETRACTABLE LANDING LIGHT	A300, A310, A320, A321
41C220-53	VALVE	P3 ORION, P3 CONVERSION
41EN49-6	SQUAT SWITCH	
4201	VARIABLE DELIVERYHYDRAULIC PUMP	
42011	VARIABLE DELIVERY HYDRAULIC PUMP	FOKKER 50
420496	STATOR	
42053	AUXILIARY HYDRAULIC ELECTRIC AC PUMP	ATR-42
4205601	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC	A319, A320, A321, A330, A340
4205602	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC	A319, A320, A321, A330, A340
4205603	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC	A319, A320, A321, A330, A340
4209939	AUTOTRANSFORMER, ASSY	
4209946	AUTOTRANSFORMER, ASSY	
4213966	LOGO LIGHT	ATR-42, ATR-72
4213973	LIGHT TAXI	ATR-42, ATR-72,ATR
4213989	LIGHT LANDING	ATR-42, ATR-72
4233488	TAKE OFF LIGHT	A318,A319,A320,A321
4236534	RUNWAY TURN OFF LIGHT	
4236564	TAXI LIGHT	A319, A321, A310, A320
424244	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
4254964	AUTOTRANSFORMER, ASSY	
426368-1	SCREEN	
426368-3	RECEIVER, TRANSMITTER	
4273511	TAKE-OFF AND TAXI LIGHT	
4273527	TAKE-OFF AND TAXI LIGHT	
4289452	WING SCAN LIGHT	A330, A340
4289468	WING SCAN LIGHT	A330, A340
4292209	LANDING LIGHT	A340
4292491	LOGO LIGHT	A330, A340
4292915	LIGHT LANDING	ATR-42, ATR-72
4295078	ENGINE SCAN LIGHT	A330, A340
4295085	ENGINE SCAN LIGHT	A330, A340
4295092	ENGINE SCAN LIGHT	A330, A340
4295107	ENGINE SCAN LIGHT	A330, A340
4295114	ENGINE SCAN LIGHT	A330, A340
4295121	ENGINE SCAN LIGHT	A330, A340
4295747	LIGHT TAXI	ATR-42, ATR-72
4298117	TAKE-OFF AND TAXI LIGHT	A330, A340
4299172	AUTOTRANSFORMER	A330, A340
430083	ENGINE DEDICATED ALTERNATOR	A330, A340
430084-1	CAJA	
430110	ENGINE DEDICATED ALTERNATOR	A330, A340
430116	ENGINE DEDICATED ALTERNATOR	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
430153	ENGINE DEDICATED ALTERNATOR	A320, A320-100
430201	ENGINE DEDICATED ALTERNATOR	A320, A320-100
430201-1	UNISON STATOR	A330, A340
430202	ENGINE DEDICATED ALTERNATOR	A330, A340
430202-1	STATOR ALTERNATOR	A330, A340
430219	ALTERNATOR STATOR	A330, A340
4315542	RETRACTABLE LANDING LIGHT	A319, A320
4319586	LIGHT LANDING	ATR-42, ATR-72
4325136	AUTO-TRANSFORMER, EQUIPPED	A330, A340
4325159	AUTOTRANSFORMER, EQUIPPED	A330, A340
4325173	AUTOTRANSFORMER	A330, A340
4328733	LOGO LIGHT	A330, A340
4331772	RETRACTABLE LANDING LIGHT	A321
4333302	LOGO LIGHT	B757
4333318	LOGO LIGHT	B757
4333325	LOGO LIGHT	B757
4333332	LOGO LIGHT	B757
435161-1	AMPLIFIER, ELECTRONIC	
4358532	LOGO LIGHT	A340, A330
4358548	AUTOTRANSFORMER	
438023-2	INDICATOR TORQUEMET	
4394188	AUTOTRANSFORMER	A330, A340
44090-3941-03	ANEMOMETRE	
443147-2	INDICATOR TORQUEMET	
44E64-8	VALVE	B737
45-0057-1	RETRACTABLE LANDING LIGHT ASSEMBLY	DC-9, MD-80, MD-90,DC10
45-0057-3	RETRACTABLE LANDING LIGHT ASSEMBLY	MD-80, MD-90, DC-9
45-0083-1	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757
45-0083-2	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757
45-0083-3	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757,B767
45-0083-5	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757,B767
45-0083-7	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757,B727
45-0212-1	AIRCRAFT RETRACTABLE LANDING LIGHT	C-212, CN-235
45-0350-4	RETRACTABLE LANDING LIGHT	A330, A340
45-0351-1	RETRACTABLE LANDING LIGHT	B737,CRJ
45-0351-2	RETRACTABLE LANDING LIGHT	B737,B757
45-0351-3	RETRACTABLE LANDING LIGHT	B737,CRJ
45-0351-4	RET LANDING LIGHT	B737,A300, B767
45-0351-5	RETRACTABLE LANDING LIGHT	CRJ100
45-0351-6	RETRACTABLE LANDING LIGHT	EMB
45040	STATOR & ROTOR ASSEMBLIES	B757
45040-1	UNISON STATOR	B757
45100	PERMANENT MAGNET ALTERNATOR	A330, A340
452T1201-16	STOP/LOCK	B757, B767
453665	HYD MOTOR PUMP	CN-235, CN-295
453665 / MPEV3-011-	PUMP-HYDR MOTOR DRIVEN	CN-235, CN-295
453665 / MPEV3-011-	PUMP-HYDR MOTOR DRIVEN	CN-235, CN-295
453665 / MPEV3-011-	PUMP-HYDR MOTOR DRIVEN	CN-235, CN-295
4538	HYDRAULIC PRIORITY RELIEF CARTRIDGE VALV	B737, B707
45-521212-605242CW	ACTUATOR FLAP 2VALVE 6	
4564-5A6-1	TRANSMITTER POSITION	
461940-2	VALVE SAFETY RELIEF	CN-235



P/N	DESCRIPTION	AIRCRAFT PARTS
46241-2	STATOR ASSY-MOTOR	A330, A340
462760	VALVE CHECK	
46354	STATOR & ROTOR ASSEMBLIES	B757
46380-1	STATOR ASSY-MOTOR	A330, A340
4690135	FIELD	
4704-1-000/1	HIGH SPEED OVEN	A330, A340
47228-2	END BELL	DC-10,A310
47229-9	DC STATOR	A330, A340
47330-2	END BELL	A330, A340
47369	STATOR & ROTOR ASSEMBLIES	B757
47369-1	STATOR	B757
4750	BALLAST	
476W2220-2G	ATTENDANT HANDSET CRADLE ASSEMBLY	A330, A340
476W2220-2H	ATTENDANT HANDSET CRADLE ASSEMBLY	A330, A340
476W2220-2K	ATTENDANT HANDSET CRADLE ASSEMBLY	A330, A340
476W2220-2L	ATTENDANT HANDSET CRADLE ASSEMBLY	A330, A340
4804-1-000/1	HIGH SPEED OVEN	A330, A340
48111-58	ARMATURE	A330, A340
4812 SERIES	MOTOR PUMP FILTER UNIT ASSY	A330, A340
4812-71	STATOR	B737
48285-SERIES	AIRCRAFT DIRECT CURRENT MOTORS	A330, A340
48315-2	FIELD	B737
48315-3	MOTOR FIELD	A330, A340
48316-11	ARMATURE	A330, A340
48316-12	ARMATURE	B737
48316-15	ARMATURE	A330, A340
48316-6	ARMATURE ASSY MOTOR	A330, A340
48348	STARTER MOTOR	A330, A340
48363-1-1	ENGINE STARTER MOTOR	B727
48363-1-3	ENGINE STARTER MOTOR	B727, C-130
48364-1-SERIES	ENGINE STARTER MOTOR	A330, A340
48378	ENGINE STARTER MOTOR	
48378-SERIES	ENGINE STARTER MOTOR	A330, A340
48-5-1009-1	SHROUD ASSY. FRONT	A330, A340
48-6	ELECTRIC MOTOR	A330, A340
48-6-1	SHROUD ASSEMBLY, REAR	
48-6-1016	SHROUD ASSY. REAR	A330, A340
48-6-2000	ARMATURE	A330, A340
48-6-4000	END BELL	A330, A340
48-6-5000	FIELD	A330, A340
48-6-5000-1	FIELD	A330, A340
48-6-5000-SERIES	FIELD HOUSING ASSEMBLY	A330, A340
490A-TS-DF-14-28	FUENTE DE POTENCIA	
4950136	STARTER MOTOR	A330, A340
4950136-37	DRIVE END HOUSING ASSEMBLY	A330, A340
4950136-43	ARMATURE ASSY	A330, A340
4951957	APU STARTER	B707, B717, B723, B737
4952164	STARTER MOTOR	A330, A340
49740	RAMP CONTROL MANIFOLD VALVE	C-130
4A16.42.40F.05.1.K	INDICATOR, RATE OF CLIMB	A330, A340
4A164240F051K	INDICATOR RATE OF CL	
4A16-42-40F05-1K	INDICATOR, RATE OF CLIMB	CN-235, C-295
4E4025-1	RUDDER BIAR HEATER ACTUATOR	CN-235, C-295
4U4059	AFT ARGO DOOR LOCK CILINDER	C-130
50-0024	LIGHT	



P/N	DESCRIPTION	AIRCRAFT PARTS
50-0024-1	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-11	LIGHT	CN-235, C-295
50-0024-13	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-15	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-17	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-19	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-21	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-23	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-25	LIGHT TAXI	C-295
50-0024-3	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-5	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-7	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-9	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
500040-03	BATTERY	C-295
50-0176-1	LIGHT: TAKE-OFF	A319, A321, A320-100, A320
5003174	FUEL BOOST PUMP	A330, A340
5003588	MAIN WHEEL ASSEMBLY	A330, A340
5004236	BRAKE ASSEMBLY	A330, A340
5004236-2	BRAKE ASSEMBLY	A330, A340
5004236-3	BRAKE ASSEMBLY	A330, A340
5006473	BRAKE ASSY	
5006484	BRAKE ASSEMBLY	C-212
5006484-1	BRAKE ASSEMBLY	C-212
5006484-2	BRAKE ASSEMBLY	C-212
5006484-3	BRAKE ASSY	C-212
5006586	MAIN WHEEL ASSEMBLY	A330, A340
5006586-1	HUB ASSY	C-212
5006586-2	MAIN WHEEL ASSEMBLY	C-212
500702-5211	AXIVANE FAN	DC-9, MD-80
5009904-5	BREAK UNIT	
501-1	HOUSING ASSY	A330, A340
501-1075-07	EMERGENCY POWER SUP	A330, A340
501-1-13775-004	STARTER MOTOR	A330, A340
501-1-13775-006	STARTER MOTOR	A330, A340
501-1-13775-008	STARTER MOTOR TYPE C6120A8	A330, A340
501-1-13775-06A	STARTER MOTOR	A330, A340
501-1-14469-000	ARMATURE	A330, A340
501-1-14484-004	STATOR	A330, A340
501-1-14561	STARTER MOTOR	A330, A340
501-1-14561-004	STARTER MOTOR TYPE C3616B11	A330, A340
501-1-14944-000	STATOR	A330, A340
501-1-14966-000	HOUSING ASSEMBLY	A330, A340
501-1-14968-000	HOUSING ASSEMBLY	A330, A340
501-1-14972-001	END BELL	A330, A340
501-1-15094-000	ARMATURE	A330, A340
501-1-15094-001	ARMATURE	A330, A340
501-1-15094-SERIES	ARMATURE ASSY	A330, A340
501-1228-03	FUENTE ALIMT EMERGENCIA	CRJ100
501-1228-04	BATTERY	CN-235, C-295, B707, B727, B737, MD80
501-1568-04	ST-BY ATT INDICATOR	CN-235
50130-1	SNUBBER	B737-600/700/700C/800/900/900ER
50150	THREE WAY, 2 POSITION SOLENOID OPERATED HYD VALVE	C-130



P/N	DESCRIPTION	AIRCRAFT PARTS
50150-20	VALVE, LINEAR, DIREC	C-130
50150-28	THREE WAY, 2 PPOSITION SOLENOID OPERATED HYD VALVE	C-130
50150-3	THREE WAY, 2 PPOSITION SOLENOID OPERATED HYD VALVE	C-130
5020-102-00-10	TRANSMITER TEMPERATURE	
50304ARG	WATER BOILER	
5030999-5511	LH MAIN LANDING GEAR	
5030999-5512	RH MAIN LANDING GEAR	
5030999-5519	LH MAIN LANDING GEAR	
5030999-5520	RH MAIN LANDING GEAR	
503-1-06061-003	PM STATOR	A330, A340
503-1-06081-002	EXCITER STATOR	A330, A340
503-1-06197-003	ARMATURE WOUND	A330, A340
503-1-06680-003	40/50 kVA AC GENERATOR	A330, A340
503-1-06710-000	IDG	BAe146
503-1-06955-000	GENERATOR AND ADAPTOR ASSEMBLY	A330, A340
503-1-07018-001	STATOR STACK	A330, A340
503-1-09029-001	STATOR	A330, A340
503-1-09044-001	ROTOR	A330, A340
503-1-09144-000	ARMATURE AND ROTOR ASSY	A330, A340
503455	ARMATURE	
5060809	HOUSING ASSEMBLY	
506115	FIELD COIL INDUIT	
506569-1	STATOR ASSEMBLY	CFM56-5A/B/C; CFM56-7B
5095-1-1	AMPLIFIER	CN-235, C-295
5101484-9	CIRCUIT CARD ASSY	S330, S340
510846-1	STATOR ASSEMBLY	CFM56-5A/B/C; CFM56-7B
5115	BALLAST	
51154-02	PUMP MOTOR PACKAGE	A319, A320, A321
51154-03	PUMP MOTOR PACKAGE	A319, A320, A321
51154-04	PUMP MOTOR PACKAGE	A319, A320, A321
51154-05	PUMP MOTOR PACKAGE	A319, A320, A321
51164-02	ENGINE DRIVEN PUMP	ERJ 170/190
51164-03	PUMP-EDP ENGINE DRIVEN PUMP	ERJ 170/190
51164-04	PUMP-EDP ENGINE DRIVEN PUMP	ERJ 170/190
51166	PUMP MOTOR PACKAGE	ERJ 170/190
51166-01	PUMP MOTOR PACKAGE	ERJ 170/190
51166-02	PUMP MOTOR PACKAGE	ERJ 170/190
51166-03	PUMP MOTOR PACKAGE	ERJ 170/190
51166-04	PUMP MOTOR PACKAGE	ERJ 170/190
51166-1	PUMP MOTOR PACKAGE	A330, A340
51166-2	PUMP MOTOR PACKAGE	A330, A340
51166-3	PUMP MOTOR PACKAGE	A330, A340
5120D114-1	FIELD	A330, A340
51224-127	FIREWIRE ELEMENT ASSY, MEDIUM TEM	S330, S340
5127-1-1	JACK BOX	C-212, CN-235, C-295
5136-215-91-10	INDICATOR TEMPERATURE	A330, A340
5136-217-91-10	BATTERY TEMP IND.	A330, A340
5141-1	AUDIO CONTROL PANEL	
5141-1-25	AUDIO PANEL CONTROL	A330, A340
5145-1	AUDIO PANEL CONTROL	
5145-1-42	AUDIO CONTROL PANEL	A330, A340
5145-1-60	PANEL - AUDIO S	B737
5145-1-61	AUDIO CONTROL PANEL	B737
5145-1-64	AUDIO CONTROL PANEL	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
5145-1-66	PANEL-AUDIO SELECTOR	A330, A340
5145-1-69	AUDIO CONTROL PANEL	A330, A340
5145-1-77	AUDIO CONTROL PANEL	A330, A340
5145-1-77 MOD A	AUDIO CONTROL PANEL	A330, A340
5145-1-77 MOD B	AUDIO CONTROL PANEL	A330, A340
5145-1-SERIES	AUDIO PANEL CONTROL	B737
51509-002	DC STATIC VOLTAGE REGULATOR AND PROTECTION PANEL	C-212
51509-002R	DC STATIC VOLTAGE REGULATOR	
515090-4	ALTERNATING CURRENT GEARED MOTOR	B747
515090-5	ALTERNATING CURRENT GEARED MOTOR	B747
515090-6	ALTERNATING CURRENT GEARED MOTOR	B747
51530-001EI	VOLTAGE REGULATOR	
515986-3	ARMATURE ASSEMBLY MOTOR	A330, A340
515986-4	ARMATURE ASSEMBLY MOTOR	A330, A340
515986-5	ARMATURE	A330, A340
515986-6	ARMATURE ASSEMBLY MOTOR	A330, A340
516023-1	ALTERNATING CURRENT MOTOR	B727, B737, B747
516023-2	ALTERNATING CURRENT MOTOR	B737, B727, B747
51634-001	CONTROL -AC GENERATOR UNIT	CN-235, C-295
516492-3	STATOR	A330, A340
516492-5	STATOR	A330, A340
516548-	CASING / STATOR ASSY	
516548-1	ARMATURE	A330, A340
516562-1	ALTERNATING CURRENT MOTOR	B747
517CUF12-1	SELECTOR, MODE, AUTOP	
518001-1	END BELL	B737
518003-2	END BELL	B737
518020-1	ARMATURE ASSY	B737
518020-3	ARMATURE	B737
518096-13	ARMATURE ASSY MOTOR	DC-10
518150	HYDRAULIC MOTORPUMP ASSEMBLY	A319, A320, A321, A330, A340
518157	HYDRAULIC MOTORPUMP ASSY	A330, A340
518196-3	FIELD	B737
518290-2	STATOR ASSY	A330, A340
518811-1	STATOR ASSY	A330, A340
518954-1	DIRECT CURRENT MOTOR	A330, A340
518962-2	ARMATURE ASSY-MOTOR	DC-10
519022-3	ALTERNATING CURRENT GEARED MOTOR	B747
519022-4	ALTERNATING CURRENT GEARED MOTOR	B747
519022-5	ALTERNATING CURRENT GEARED MOTOR	B747
519022-6	ALTERNATING CURRENT GEARED MOTOR	B747
519022-7	ALTERNATING CURRENT GEARED MOTOR	B747
519022-8	ALTERNATING CURRENT GEARED MOTOR	B747
519806	DIRECT CURRENT MOTOR	
519806-SERIES	DIRECT CURRENT MOTOR	A330, A340
519852-2	ENGINE STARTER MOTOR	A300, MD-11, DC-10, B767
519852-3	ENGINE STARTER MOTOR	A300, MD-11, DC-10, A310
519852-4	ENGINE STARTER MOTOR	A300, MD-11, DC-10, A310
519852-SERIES	STARTER MOTOR	
519858-1	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-2	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-3	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-4	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-5	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-6	ENGINE STARTER MOTOR	B757, B767, A310, A300



P/N	DESCRIPTION	AIRCRAFT PARTS
519858-7	STARTER MOTOR	B757, B767, A310, A300,B727
519858-8	ENGINE STARTER MOTOR	B757, B767, A310, A300,B727
519892-1-2	ENGINE STARTER MOTOR	A330, A340
519892-2-3	ENGINE STARTER MOTOR	A330, A340
519892-3	ENGINE STARTER MOTOR	A330, A340
519892-3-1	ENGINE STARTER MOTOR	A330, A340
519892-3-3	ENGINE STARTER MOTOR	BAe146/BAe146-300
519892-4	ENGINE STARTER MOTOR	A330, A340
519892-4-1	ENGINE STARTER MOTOR	CL-600/CL-601
519892-5	ENGINE STARTER MOTOR	A330, A340
519892-5-1	ENGINE STARTER MOTOR	DHC-5
519892-6	ENGINE STARTER MOTOR	A330, A340
519892-6-1	ENGINE STARTER MOTOR	G-II/G-III
519892-6-2	ENGINE STARTER MOTOR	LAGPU-30
519892-6-3	ENGINE STARTER MOTOR	A330, A340
521603	INDICATOR OIL TEMP	
522-0688-003	ANTENNA	
522-1501-000	HF RT	B707, B727, B747, DC-10, MD-80
522-1501-041	TRANSCEIVER	B707, B727, B737, B747
522-1660-031	TRANSCEIVER, HF	B707, B727, B747
522-2213-00	CONTROL	
522-2377-003	IND HEADING	
522-24447-251	CONTROL BOX	
522-2587-00	ADF	
522-2996-00	MARKER BEACON	
522-4088-203	VHF TRAN	B737, DC-8,B727
522-4114-003	INDICATOR, HEIGHT	B737
522719	INDICATOR POTABLE WATE	
524-03	STARTER GENERATOR	A330, A340
524-03*	STARTER GENERATOR	A330, A340
524-031	STARTER GENERATOR	A330, A340
524-032	STARTER GENERATOR	A330, A340
524-060	STARTER GENERATOR	A330, A340
524-061	STARTER GENERATOR	A330, A340
528-20	WING TIP NAVIGATION LIGHT	A319-A320-A321
528-30	LIGHT-NAVIGATION, FORWARD SINGLE	A320
5283D100-1	STARTER APU	
5283D100-11	STARTER APU	
5283D100-13	STARTER APU	
5283D100-15	STARTER APU	
5283D100-17	STARTER APU	
5283D100-19	STARTER APU	
5283D100-21	STARTER MOTOR	B737,B777,B757,B727, B767
5283D100-23	STARTER MOTOR	B737,B777,B757
5283D100-25	STARTER MOTOR	
5283D100-27	STARTER MOTOR	A330, A340
5283D100-3	STARTER APU	
5283D100-5	STARTER APU	
5283D100-9	STARTER ELECTRIC	
5283D100-SERIES	MOTOR STARTER	
528-70	LIGHT-NAVIGATION, FORWARD DUAL (RH)	A318,A319,A320,A321
528-80	LIGHT-NAVIGATION, FORWARD DUAL (LH)	A318,A319,A320,A321
53150-1	VALVE LINEAR DIRECTI	C-130
53150-2	PRESSURE VALVE	A330, A340
53718-04	GENERATOR, ALTERNATING CURRENT	F15



P/N	DESCRIPTION	AIRCRAFT PARTS
53721-3	STRUT ASSY-NLG DOOR	B767
540200-3	ACTUATOR, ELECTRO-MECH	
549460 SERIES	CYLINDRAL HYD PRESS ACCUM	A330, A340
5506L-S	ALTITUDE ALERTER	A330, A340
5506L-SG512	ALTITUDE ALERTER	CN-235
5506-S SERIES	SERVOED ENCODING ALTIMETER	A330, A340
5506SG5	INDICATOR HEIGHT	CN-235
5506SG53	ALTIMETER, PRESSURE	CN-235, C-295
5506-SG53	SERVOED ENCODING ALTIMETER	CN-235
5506-SG5-Y	SERVOED ENCODING ALTIMETER	CN-235
55-1000-200D9	TRANSMITTER,PRESSUR	CN-235
551050 SERIES	CYLINDRAL HYD PRESS ACCUM	A330, A340
551200 SERIES	CYLINDRAL HYD PRESS ACCUM	A330, A340
552430 SERIES	CYLINDRAL HYD PRESS ACCUM	A330, A340
5543001-8	SHIMMY DAMPER	
56102	MANO-CONTACT	
5617-352-91-11	INDICATOR ASSEMBLY	A330, A340
5617-352-91-12	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340
5617-353-99-10	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340
5617-355-91-11	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340
5617-358-91-10	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340
5617-359-80-10	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340
5618-1	MANO-CONTACT	A330, A340
568-1-25665-001	FUEL PUMP TYPE 7902 MK.1	A330, A340
568-1-26713 SERIES	LIGHTWEIGHT FUEL BOOST PUMP	A330, A340
568-1-27292-000	STATOR	A330, A340
568-1-28300-SERIES	FUEL BOOST PUMP	A330, A340
568-1-28390-000	STATOR ASSY	A330, A340
568-1-29914-000	MOTOR HOUSING ASSY	A330, A340
569653	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
569911	STATOR AND COOLING JACKET	B757
5701802	SCREWJACK	B737
5704-1-000/1	HIGH SPEED OVEN	A330, A340
57186	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-001	PUMP MOTOR PACKAGE	A330, A340
57186-01	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-02	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-03	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-04	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-05	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-06	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-07	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-10	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57377	SERVOED ALTITUDE INDICATOR	
5804-1-000/1	HIGH SPEED OVEN	A330, A340
58057-82	GYRO COMPAS	
5821-01-3924589	RECEIVER TRANSMITTER	
5-87199-3001	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX	B707



P/N	DESCRIPTION	AIRCRAFT PARTS
5-87199-3002	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX	B707
5-87199-3003	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX	B707
5-87199-3004	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX	A330, A340
5-87199-3005	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX	B707
5-87448-3001	FLAP DRIVE POWER UNIT ASSEMBLY	B707
5-87448-3002	FLAP DRIVE POWER UNIT ASSEMBLY	A330, A340
5-87448-3006	FLAP DRIVE POWER UNIT ASSEMBLY	A330, A340
5-87448-3007	FLAP DRIVE POWER UNIT ASSEMBLY	B707
5906732	AC GENERATOR	A319, A321, A320
5909006	AC GENERATOR	A319, A321, A320
5910047	AC GENERATOR	A319, A321, B717, A320
5910139	APU GENERATOR	A330, A340
5910447-5059	NLG	B737
5910447-5161/3920208-	NLG ASSY/DRAG BRACE	
5910447-5561/3920208-	NLG ASSY/DRAG BRACE	
59111	FLAP POSITION INDICATOR	
5912833	APU GENERATOR	A330, A340
5913667	AC GENERATOR	A330, A340
5913667-1	AC GENERATOR	A320
5913667-2	AC GENERATOR	A320
5913667-3	APU GENERATOR	A320
5913667-4	APU GENERATOR	A320,ATR42
59141	FLAP POSITION INDICATOR	
5930999-5501	MLG	
5930999-5502	MLG	
5930999-5503	MLG	MD-80
5930999-5504	MLG	MD-80
5930999-5519	LH MLG	
5930999-5520	RH MLG	
5935848-501	FIXED SIDE BRACES	DC-9
5936970-413008	FLAP CTRL VLV	
5937036-5501	MLG ACTUATING CYLINDER	B717, MD-80, MD-90, DC-9
5C5791	CYLINDER ASSEMBLY AC	C-130
5C5792	CYLINDER ASSEMBLY	C130
5C5792-1	CYLINDER ASSEMBLY, AC	A330, A340
5C5794	CYLINDER ASSEMBLY, AC	C-130
6001419-3	CONTROL BOX ANTISKID	
6002869	ANTI SKID MANIFOLD	
60-1321-1	POWER-SUPPLY-BTRY-EMER-LT	B727, B737, B747,EMB170, EMB190
60-1321-1LB	EMERGENCY EXIT LIGHT POWER SUPPLY	B747,B707, B727, B737
60-1321-5	EMERGENCY EXIT LIGHT POWER SUPPLY	B727, B747
60-1321-5LB	EMERGENCY EXIT LIGHT POWER SUPPLY	B727, B747
60-1321-7	EMERGENCY EXIT LIGHT POWER SUPPLY	B727, B747
60-1321-7LB	EMERGENCY EXIT LIGHT POWER SUPPLY	B727, B747
60-2650-1	POWER SUPPLY	P3 ORION, P3 CONVERSION
60-3274-5	POWER-SUPPLY	
60-3757-5	STROBE LIGHT	Q400
60-3895-1	POWER-SUPPLY-BTRY-EMER-LT	C-212, CN-235, C-295
604260	FIELD	A330, A340
60-4983-3	POWER SUPPLY ANTI-COLLISION SYSTEM	B737, B767,B777,B747
60-4983-5	STROBE POWER SUPPLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
605146-4	STATOR	A330, A340
605290	MOTOR DRIVEN VANEAXIAL FAN	
605290-SERIES	MOTOR DRIVEN VANEAXIAL FAN	A330, A340
605457-2	MOTOR DRIVEN CENTRIFUGAL FAN	DC-10, B747, B767, MD-11
605457-3	MOTOR DRIVEN CENTRIFUGAL FAN	B767, DC-10, MD-11, MD-80, B747
605457-7	FAN	B767, MD-80, B747, B737, B767, B777
605457-8	MOTOR DRIVEN CENTRIFUGAL FAN	B767, DC-10, MD-11, B747, B757
605675-1	MOTOR DRIVEN VANEAXIAL FAN	B727, B747, DC-8, B737, B757
605675-2	MOTOR DRIVEN VANEAXIAL FAN	B727, B747, DC-8
6058003-X	STARTER GENERATOR	Learjet
606173-00	BOX-THERMOCOUPLE JUNCTION	A330, A340
606173-01	BOX-THERMOCOUPLE JUNCTION	A330, A340
606622-1	CABIN AIR RECIRCULATION FAN	B747/300, B767/200, B767/300,
606622-2	CABIN AIR RECIRCULATION FAN	B747/300, B767/200, B767/300,
606622-3	CABIN AIR RECIRCULATION FAN	B747/300, B767/200, B767/300,
606622-4	CABIN AIR RECIRCULATION FAN	B747/300, B767/200, B767/300,
606635-2	STATOR ASSY - MOTOR	A330, A340
606707-1	FWD CARGO COMP VENT FAN	B747-400, B767, B777-200, B777-300,
606772-1	CABIN AIR RECIRCULATION FAN	B757, MD-11
606772-2	CABIN AIR RECIRCULATION FAN	B757, MD-11
606772-3	CABIN AIR RECIRCULATION FAN	B757, MD-11, B737
606772-4	CABIN AIR RECIRCULATION FAN	B757, MD-11
606772-5	CABIN AIR RECIRCULATION FAN	
606772-6	CABIN AIR RECIRCULATION FAN	B757, MD-11
606772-7	CABIN AIR RECIRCULATION FAN	B757, MD-11
606802-2	WASTE SYSTEM VACUUM BLOWER	B777-200, B757, B737, B767
607518-2	CONTROL TEMPERATURE	B737, B777, B757
607518-2 SERIES 2	TEMPERATURE CONTROL	B737
607518-2 SERIES 3	TEMPERATURE CONTROL	B737
607518-2 SERIES 4	TEMPERATURE CONTROL	B737
60-755 SERIES	FUEL BOOST PUMP	A330, A340
607618	MOTORPUMP ASSEMBLY	A330, A340
607618-1	BOMBA HIDRAULICA	P3 ORION, P3 CONVERSION
607976-00	BOX-THERMOCOUPLE JUNCTION	A330, A340
607976-01	BOX-THERMOCOUPLE JUNCTION	A330, A340
609200-01	THERMOCOUPLE CABLE ASSEMBLIES	A330, A340
609201-01	LOWER HARNESS	A330, A340
60-989 SERIES	FUEL BOOST PUMP	A330, A340
60B00263-1	AUTOBRAKE CONTROL MODULE	B727, B737, B747, B757
60B00263-2	AUTOBRAKE CONTROL MODULE	B727, B737, B747, B757
60B00263-3	AUTOBRAKE CONTROL MODULE	B727, B737, B747, B757
60B00263-4	AUTOBRAKE CONTROL MODULE	B727, B737, B747, B757
60B40125-208	SEAT ELECTRONICS BOX	S330, S340
610120-103	CONTROL ASSY LIGHT	P3
6111	MANIFOLD PRESSURE GAGE	A330, A340
611N0000009Y	CONTROL, INTERCOMMUNICATOR	CN-235, C-295
611N615A000	UNIDAD VALIDACIÓN	CN-235, C-295
61-2276-1	HOUSING ASSEMBLY	A330, A340
61-36-2	BALLAST	A330, A340
6146-1-6MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	
6146-1-7MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	
61474-108-1	TACHOMETER IND	A330, A340
61474-108-2	TACHOMETER IND	A330, A340
614937-10	AMPLIFIER COMPASS RACK	B707, B727, B737, DC-8, MD-80, B747



P/N	DESCRIPTION	AIRCRAFT PARTS
61533-102-1	TEMPERATURE IND	A330, A340
61533-103-1	INDICATOR TEMPERATURE	A330, A340
61533-104-1	TEMPERATURE IND	A330, A340
61533-106-1	INDICATOR TEMPERATURE	A330, A340
61533-107-1	TEMPERATURE IND	A330, A340
61533-109-1	TEMPERATURE IND	A330, A340
61533-111-1	TEMPERATURE IND	A330, A340
61533-121-1	TEMPERATURE IND	A330, A340
615600-1003	ELECTRIC MOTORPUMP	CRJ700 & ERJ
617-069-17	CONTROL ASSY PARKING	
62176 SERIES	LIQUID COOLED MOTOR	A330, A340
621T100	ACTUATOR ELECTRO-ME	
622-0555-003	INDICATOR SUBASSY	
622100	COUPLING	
622-1234-003	DME INDIC. MOD. 339-F12	
622199	VAR. DISPLACEMENT HYDRAULIC MOTOR PUMP	B757, B767, B747
622-2360-001	CONTROL	A330, A340
622-2506-008	INDICATOR, RADIO MAGNETIC	C-212, CN-235, C-295
622-2551-002	CONTROL EQUIP RADAR	CN-235
622280-3	INDICATOR RPM	
622-2938-001	RADIO ALTITUDE INDICATOR	A330, A340
622-3890-020	TRANSCEIVER	B737, B757
622-4176-001	INDICATOR, HORIZONTAL	S330, S340
622-4177-003	GYROSCOPE, DISPLACEMENT	CN-235
622-4542-103	RADIO ALTIMETER TRANSCEIVER	B757
622-5222-120	ADF RECEIVER	B737
622-5486-001	SELECTOR	
622-5799-104	PANEL, INDICATOR	CN-235
622-6137-001	COLLINS VIR-32	C-212, CN-235
622-6523-005	CONTROL NAVIGATION	
62270	HOLDER LINEAR ACTUATOR	
622-8680-001	PANEL, INDICATOR	C-212, CN-235
623272	VARIABLE DISPLACEMENT HYDRAULIC PUMP	DC-10, B747, B757, B767
623303	VAR. DISPLACEMENT HYDRAULIC MOTOR PUMP	B757, B767, B747
623337	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
623339	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
623977	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	A330, A340
624372	ELECTRIC MOTOR ASSEMBLY	A330, A340
62461 SERIES	LIQUID COOLED MOTOR	A330, A340
625868-1	SELECTOR CABIN ZONE TEMP	B757, B737
625868-1 SERIES	CABIN ZONE TEMPERATURE SELECTOR	A330, A340
62735	LIQUID COOLED MOTOR	B737
6300	INFLIGHT REFUELING PUMP	A330, A340
6300-1	PUMP FUEL TRANSFER	C-130
6301	3 INCH FUEL VALVE	
6301 SERIES	3 INCH FUEL VALVE	
6301-1	MOTOR OPERATED FUEL SHUTOFF VALVE 3 INCH	C-130
632176-53	VALVE	A330, A340
64050-661-1	AIRSPPEED	CN-235, C-295
64110-010-1	ALTIMETRO BAROMETRICO	
64141-361-1	BAROMETRIC ALTIM. STANDBY	CN-235, C-295
64191-203-1	DIAL MANOMETER	A330, A340
64191-204-1	PRESSURE GAUGE	
64191-214-1	PRESSURE GAUGE	
64191-217-1	PRESSURE GAUGE	



P/N	DESCRIPTION	AIRCRAFT PARTS
64191-225-1	PRESSURE GAUGE	
6430497-1	EXCITER ROTOR	A330, A340
6430580-1	STATOR RESOLVER	A330, A340
6430580-2	ROTOR RESOLVER	
6430580-3	STATOR RESOLVER	A330, A340
6430595-1	MAGNET-PERMANENT, GENERATOR	A330, A340
6430603-1	END BELL	S330, S340
6430603-2	END BELL	A330, A340
6430612-1	EXCITER STATOR	A330, A340
6430624-1	ROTOR	B737
6430624-2	ROTOR	B737
6430624-3	ROTOR AC GENERATOR	A330, A340
6430624-4	AC GENERATOR ROTOR	A330, A340
6430657-1	RESISTOR BOBBIN	A330, A340
6430800-3	STATOR	
6430800-4	STATOR AND HOUSING ASSY	A330, A340
6431000-3	ROTOR	A330, A340
6431000-4	ROTOR	A330, A340
6431000-5	ROTOR	A330, A340
6431000-6	ROTOR	
6431000-7	ROTOR ASSY	A330, A340
6431001-2	STATOR AND HOUSING ASSY	A330, A340
6431006-1	EXCITER ROTOR	A330, A340
6431006-2	EXCITER ROTOR	A330, A340
645172-1	VACUUM BLOWER	B737, B747, B757, B767, B777
645172-2	VACUUM BLOWER	B737, B777
645405-1	CABIN AIR RECIRCULATION FAN	B737, B747
645405-X	CABIN AIR RECIRCULATION FAN	B737, B747
645423-2	ROTOR & SHAFT ASSY	A330, A340
645423-3	ROTOR & SHAFT ASSY	A330, A340
645458-2	IMPELLER-FAN	
645705-1	CABIN AIR RECIRCULATION FAN	B757, MD-11
645705-2	CABIN AIR RECIRCULATION FAN	B757, MD-11
645705-3	CABIN AIR RECIRCULATION FAN LH	MD-11, B757, B747
645705-4	CABIN AIR RECIRCULATION FAN	B757, MD-11
648 50 00	SELF CONTAINED ANTICOLLISION LIGHT	A330, A340
64809-416-1	PRESSURE INDICATOR	A330, A340
64809-418-1	PRESSURE INDICATOR	A330, A340
64809-428-1	INDICPRESSION CARB	
64809-606-1	INDIC PRESSION HUI	A330, A340
6485000	ANTICOLLISION LIGHT	
64905-006-1	POWER INDICATOR	A330, A340
64975-003-1	ELECTRIC TACHOMETER	A330, A340
65-0294	INDICATOR LIGHT	
65-0294-1	INDICATOR LIGHT ASSEMBLY	B737
65-0294-11	INDICATOR LIGHT ASSEMBLY	B737
65-0294-13	INDICATOR LIGHT ASSEMBLY	B737, EMB170
65-0294-15	INDICATOR LIGHT ASSEMBLY	B737, CRJ700
65-0294-17	INDICATOR LIGHT ASSEMBLY	B737, CRJ
65-0294-19	INDICATOR LIGHT ASSEMBLY	B737, ATR



P/N	DESCRIPTION	AIRCRAFT PARTS
65-0294-21	INDICATOR LIGHT ASSEMBLY	B737
65-0294-23	INDICATOR LIGHT ASSEMBLY	B737,ATR72
65-0294-25	INDICATOR LIGHT ASSEMBLY	B737,ATR72
65-0294-3	INDICATOR LIGHT ASSEMBLY	B737,B757
65-0294-5	INDICATOR LIGHT ASSEMBLY	B737,B757
65-0294-7	INDICATOR LIGHT ASSEMBLY	B737,B757
65-0294-9	INDICATOR LIGHT ASSEMBLY	B737,CRJ
6519009-71-1	STEP ASSY	
65-20846-1	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20846-2	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20846-3	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20846-4	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20846-8	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20848-1	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	A330, A340
65-20848-2	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	A330, A340
65-20848-3	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	A330, A340
65-20848-4	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	B707
65-20848-5	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	B707
65-20848-6	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	B707
65-20848-7	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	A330, A340
65-20848-8	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	B707
65-20852-1	INBOARD FLAP DRIVE TEE GEARBOX ASSEMBLY	A330, A340
65-20852-2	INBOARD FLAP DRIVE TEE GEARBOX ASSEMBLY	B707
65-20852-3	INBOARD FLAP DRIVE TEE GEARBOX ASSEMBLY	B707
65-3693	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-10	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-11	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-16	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-19	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-20	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-22	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-3	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-4	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-5	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-6	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-7	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-8	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-9	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-44561-10	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-11	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-12	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-13	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-14	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-15	ACTUATOR AY	B737
65-44561-5	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-6	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-7	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-8	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-9	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44625-18	NOSE GEAR LOCK ACTUATOR ASSEMBLY	B737-300, B737-400, B737-500
65-44691-3	LANDING GEAR MODULAR PACKAGE ASSEMBLY	B737, B747, B757
65-44691-4	LANDING GEAR MODULAR PACKAGE ASSEMBLY	B737, B747, B757
65-44691-5	LANDING GEAR MODULAR PACKAGE ASSEMBLY	B737, B747, B757
65-44691-6	LANDING GEAR MODULAR PACKAGE ASSEMBLY	B737, B747, B757
65-44725-101	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-44725-102	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-103	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-104	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-105	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-45	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-47	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-48	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-50	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-52	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-54	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-55	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-57	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-58	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-59	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-60	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-61	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-62	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-63	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-64	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-65	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-76	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-77	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-79	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-85	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-86	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-87	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-88	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-89	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-90	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-91	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-92	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-93	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-94	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-95	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-96	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-97	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-98	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-99	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44761-10	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-12	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-15	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-16	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-18	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-19	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-21	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-22	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44960-23	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44960-24	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44960-25	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44960-27	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44960-28	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44975-3	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B737
65-44975-5	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B737
65-46203-24	STEERING COLLAR	B737
65-46428-1	OUTBOARD FLAP TRACK ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-46428-11	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-14	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-15	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-16	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-17	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-18	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-19	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-2	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-20	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-21	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-22	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-23	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-24	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-25	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-26	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-27	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-3	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-30	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-31	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-32	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-33	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-34	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-35	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-36	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-4	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-5	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-6	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-7	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-8	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46428-9	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-46481-1	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-200, B737-300, B737-400, B737-
65-46481-101	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-102	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-103	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-104	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-105	FLAP CARRIAGE ASSY	B737, B737-300, B737-400, B737-500
65-46481-106	FLAP CARRIAGE ASSY	B737, B737-300, B737-400, B737-500
65-46481-107	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-108	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-109	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-11	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-110	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-111	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-112	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-113	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-114	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-115	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-116	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-117	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-118	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-119	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-12	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-120	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-121	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500



P/N	DESCRIPTION	AIRCRAFT PARTS
65-46481-122	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-123	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-124	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-13	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-133	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-134	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-135	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-136	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-137	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-200
65-46481-138	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-200
65-46481-139	OUTBOARD FLAP CARRIAGE ASSEMBLY	A330, A340
65-46481-14	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-143	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-144	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-145	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-146	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-147	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-148	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-149	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-15	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-150	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-16	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-17	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-18	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-19	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-20	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-21	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-22	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-23	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-24	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-25	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-26	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-27	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-28	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-31	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-32	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-33	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-34	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-37	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-38	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-39	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-40	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-41	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-42	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-45	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-46	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-47	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-48	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-49	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-50	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-51	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-52	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-53	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-54	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-46481-55	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-56	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-57	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-58	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-59	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-60	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-61	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-62	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-63	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-64	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-65	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-66	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-67	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-200, B737-300, B737-400, B737-
65-46481-68	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-69	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-70	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-72	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-73	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-74	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-75	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-76	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-8	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-81	SPINDLE	B737
65-46481-82	SPINDLE	B737
65-46481-83	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-84	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-85	SPINDLE	B737
65-46481-86	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-87	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-88	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-89	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-90	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-91	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-92	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-93	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-94	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-95	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-96	SPINDLE	B737
65-46481-97	FLAP CARRIAGE ASSY	B737, B737-300, B737-400, B737-500
65-46481-98	FLAP CARRIAGE ASSY	B737, B737-300, B737-400, B737-500
65-4829	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-1	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-3	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-4	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-5	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-9	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-49580-11	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-12	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-13	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-14	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-15	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-16	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-17	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-18	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-19	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-49580-20	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-21	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-52807-76	FLAP&SLAT INDICATION MODULE	B737
65-63663-4	BELL CRANK	B737
65-67158-1	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67158-2	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67158-3	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67158-4	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67158-5	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67158-6	OUTBOARD FLAP TRACK ASSEMBLY	B737
6577 SERIES	VANEAXIAL FAN ASSEMBLY	A330, A340
65-79949-1	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-10	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-2	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-3	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-4	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-5	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-6	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-7	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-8	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-9	OUTBOARD FLAP CARRIAGE ASSEMBLY	A330, A340
65806-002-1	CLOCK	B757,A319
65C26833-2	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B747, B737
65C26833-3	DEPRESSURIZATION VALVE	B747, B737
65C26864-3	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65C-26864-3	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	A330, A340
65C26885-5	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B747, B737
65C26885-6	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B747, B737
65C27501-1	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B747, B737
65C27501-2	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B747, B737
65C27501-3	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B747, B737
65C27503-1	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27503-2	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27503-3	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27506-1	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27506-2	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27506-3	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27508-1	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B737
65C27508-2	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B737
65C27508-3	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B737
65C31099-1	NLG LOCK ACTUATOR	B747, B737-300, B737-400, B737-500
65C31099-2	NOSE GEAR LOCK ACTUATOR ASSEMBLY	B737-300, B737-400, B737-501
65C34812-2	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C34812-3	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C34812-4	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C34812-5	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C34812-6	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C34812-7	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C34812-8	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C35387-4	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C35615-2	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C35616-5	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C37053-9	RUDDER PCU	B737
65C38058-10	L/E ACTUADOR	B747, B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65C38059-13	ACTUATOR ASSY	B747, B737
65C38059-14	LEADING EDGE SLAT HYD ACT ASSEM	B727,B737
65C38059-15	ACTUATOR ASSY	B747, B737
66005	VARIABLE DELIVERY HYDRAULIC PUMP	A330, A340
66005-01	VARIABLE DELIVERY HYDRAULIC PUMP	A330, A340
66007	VARIABLE DELIVERY HYDRAULIC PUMP	A330, A340
66007-01	VARIABLE DELIVERY HYDRAULIC PUMP	A330, A340
66068-05	VARIABLE DELIVERY HYDRAULIC PUMP	B757,B767
66068-06	VARIABLE DELIVERY HYDRAULIC PUMP	B757,B767,B727
66068-07	VARIABLE DELIVERY HYDRAULIC PUMP	B747,B757,B767,B777
66068-08	VARIABLE DELIVERY HYDRAULIC PUMP	B747,B757,B767,B777
6607A1-73	SWITCH, PRESSURE	
6608201-X	STARTER GENERATOR	Learjet
6608268-X	STARTER GENERATOR	Learjet
6608458-XXX	STARTER GENERATOR	Learjet
6608512-XXX	STARTER GENERATOR	Learjet
66087	VARIABLE DELIVERY HYDRAULIC PUMP	B737-300/400/500, B737-800/900,B727
66172-01	PUMP HYDRAULIC	
66173-03	HYDRAULIC PUMP	Dash8
662136-1	VALVE	
662136-1/81755	VALVE	
66390-000-2	POWER LOSS MODULE	A330, A340
66390-000-3	POWER LOSS MODULE	A330, A340
6639-000-3	CIRCUIT CARD	
66432 SERIES	LIQUID COOLED MOTOR	A330, A340
66760-1	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
66760-2	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
66760-3	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
66760-4	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
66760-5	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
67054	SERVOED MACH AIRSPEED IND	
670750-107	ACTUATOR ELECTRO -ME	
670764-103	GENERATOR TACHOMETE	
67085	SERVOED MACH AIRSPEED IND	
67115	SERVOED MACH AIRSPEED IND	
6805307L	VIBRATOR, IGNITION CO	
6805387	FILTER ASSY FUEL	
693335	HYDRAULIC MOTORPUMP ASSEMBLY	A319, A320, A321, A330, A340
693337	HYDRAULIC MOTORPUMP ASSY	A320, A340
69-37307-112	ENGINE APU FIRE MODULE	B737
69-37315-300	GEN DRIVE MODULE	B737
695001-9A	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
695040	NLG STEERING CYLINDER ASSY	A330, A340
695457-3	NLG STEERING CYLINDER ASSY	A330, A340
695568-1	NLG STEERING CYLINDER ASSY	A330, A340
695568-3	CYLINDER AND PISTON	C-130
695568-5	NLG STEERING CYLINDER ASSY	A330, A340
697749-17	INDICATOR, LIQUID QUA	
70.AA6.511	FAN ASSEMBLY	A330, A340
70.AA6.521	FAN ASSEMBLY	A330, A340
7002353-901	AZ 649 AIR DATA SENSOR	A330, A340
7002353-902	AZ 649 AIR DATA SENSOR	A330, A340
7002353-911	AZ 649 AIR DATA SENSOR	C-212, CN-235



P/N	DESCRIPTION	AIRCRAFT PARTS
7002353-912	AZ 649 AIR DATA SENSOR	A330, A340
7002353-913	AZ 649 AIR DATA SENSOR	A330, A340
7002493-906	INDICATOR, ATTITUDE	C-212
70-0366-1	BALLAST	B737,B757
70-0366-11	BALLAST	B767
70-0366-3	FLUORESCENT LAMP BALLAST ASSY	A330, A340
70-0366-5	FLUORESCENT LAMP BALLAST ASSY	B737
70-0366-7	BALLAST UNIT	B737,B757
70-0366-9	FLUORESCENT LAMP BALLAST ASSY	A330, A340
700842	CONSTANT SPEED DRIVE	B727, B747
700842A	CONSTANT SPEED DRIVE	B747
7008FS-972-P3	GT RING	
701284	STROBE LIGHT	
701285	POWER SUPPLY	
702200-1	FUEL BOOSTER PUMP, SINGLE FUEL VOLUTE HOUSING &	A330, A340
702300-1	FUEL BOOSTER PUMP, SINGLE FUEL VOLUTE HOUSING &	A330, A340
70277-10	ROTARY HYDRAULIC SNUBBER	B747
70277-16	ROTARY HYDRAULIC SNUBBER	B747
70277-17	ROTARY HYDRAULIC SNUBBER	B747
70277-18	ROTARY HYDRAULIC SNUBBER	B747
70277-20	ROTARY HYDRAULIC SNUBBER	B747
70277-21	ROTARY HYDRAULIC SNUBBER	B747
70277-24	ROTARY HYDRAULIC SNUBBER	B747
70277-25	ROTARY HYDRAULIC SNUBBER	B747
70277-26	ROTARY HYDRAULIC SNUBBER	B747
70277-27	ROTARY HYDRAULIC SNUBBER	B747
70277-30	ROTARY HYDRAULIC SNUBBER	B747
70277-34	ROTARY HYDRAULIC SNUBBER	B747
70277-35	ROTARY HYDRAULIC SNUBBER	B747
70277-36	ROTARY HYDRAULIC SNUBBER	B747
70277-37	ROTARY HYDRAULIC SNUBBER	B747
70277-38	ROTARY HYDRAULIC SNUBBER	B747
70277-39	ROTARY HYDRAULIC SNUBBER	B747
70277-50	ROTARY HYDRAULIC SNUBBER	B747
70277-51	ROTARY HYDRAULIC SNUBBER	B747
70277-52	ROTARY HYDRAULIC SNUBBER	B747
70277-53	ROTARY HYDRAULIC SNUBBER	B747
70277-8	ROTARY HYDRAULIC SNUBBER	B747
70277-9	ROTARY HYDRAULIC SNUBBER	B747
70304	SHUTTLE VALVE	
7040	IND-CLIMB	
705117K	CONSTANT SPEED DRIVE	B747,B727
705-15V9	IND STAND HORIZON	
7052-1	STATOR ASSEMBLY	B737
7052-2	STATOR ASSEMBLY	B737
70577-10	ROTARY HYDRAULIC SNUBBER	B747
70577-16	ROTARY HYDRAULIC SNUBBER	B747
70577-17	ROTARY HYDRAULIC SNUBBER	B747
70577-18	ROTARY HYDRAULIC SNUBBER	B747
70577-20	ROTARY HYDRAULIC SNUBBER	B747
70577-21	ROTARY HYDRAULIC SNUBBER	B747
70577-24	ROTARY HYDRAULIC SNUBBER	B747
70577-25	ROTARY HYDRAULIC SNUBBER	B747
70577-26	ROTARY HYDRAULIC SNUBBER	B747
70577-27	ROTARY HYDRAULIC SNUBBER	B747



P/N	DESCRIPTION	AIRCRAFT PARTS
70577-30	ROTARY HYDRAULIC SNUBBER	B747
70577-34	ROTARY HYDRAULIC SNUBBER	B747
70577-35	ROTARY HYDRAULIC SNUBBER	B747
70577-36	ROTARY HYDRAULIC SNUBBER	B747
70577-37	ROTARY HYDRAULIC SNUBBER	B747
70577-38	ROTARY HYDRAULIC SNUBBER	B747
70577-39	ROTARY HYDRAULIC SNUBBER	B747
70577-40	ROTARY HYDRAULIC SNUBBER	B747
70577-41	ROTARY HYDRAULIC SNUBBER	B747
70577-42	ROTARY SNUBBER	B747,B757,B777
70577-43	ROTARY SNUBBER	B747, B757
70577-44	ROTARY HYDRAULIC SNUBBER	B747,B757,MD80
70577-45	ROTARY SNUBBER LH DOOR	B747, B757,A320
70577-50	ROTARY HYDRAULIC SNUBBER	B747
70577-51	ROTARY HYDRAULIC SNUBBER	B747
70577-52	ROTARY HYDRAULIC SNUBBER	B747
70577-53	ROTARY HYDRAULIC SNUBBER	B747
70577-8	ROTARY HYDRAULIC SNUBBER	B747
70577-9	ROTARY HYDRAULIC SNUBBER	B747
7061M31G04	VALVE-TURBINE CLEARANCE	B737
706400-2	BLEED VALVE FUEL GEAR MOTOR	B737
706400-3	BLEED VALVE FUEL GEAR MOTOR	B737,A300, B767
706400-4	BLEED VALVE FUEL GEAR MOTOR	B737,B727
706786-2	DUAL CHANNEL FUEL GAGE AMPLIFIER	A330, A340
706786-3	DUAL CHANNEL FUEL GAGE AMPLIFIER	A330, A340
707304D	CONSTANT SPEED AC GENERATOR	DC-10,B727
707304E	CSD	A300, DC-10,B727
71404	DUAL BRAKE METERING VALVE	B757
71404-1	DUAL BRAKE METERING VALVE	B747, B747-400, B737,B777,B757
71404-2	DUAL BRAKE METERING VALVE	A330, A340
7151133E	DRIVE CONSTANT SPEED	
715776	ELECTRIC MOTOR ASSEMBLY	A330, A340
716675-2	CENTRALE INDICATION	
717042	TUBE	
717324	CHARGE FILTER CAP ASSEMBLY	A330, A340
717324A	CHARGE FILTER CAP ASSEMBLY	A330, A340
718644A	STATOR	A330, A340
720845	GENERATOR ASSEMBLY	CRJ100,200
720845 SERIES	GENERATOR ASSEMBLY	CRJ100,200
720845E	GENERATOR ASSEMBLY	CRJ100,200,B777,B767
720845-SERIES	GENERATOR ASSEMBLY	CRJ100,200
721429	STATOR HOUSING ASSEMBLY	A330, A340
721429A	STATOR HOUSING ASSEMBLY	A330, A340
721429B	STATOR HOUSING ASSEMBLY	A330, A340
721429C	STATOR HOUSING ASSEMBLY	A330, A340
721429D	STATOR HOUSING ASSEMBLY	A330, A340
721429E	STATOR HOUSING ASSEMBLY	A330, A340
721432	ROTOR ASSEMBLY	A330, A340
721432A	ROTOR ASSEMBLY	A330, A340
721432B	ROTOR ASSEMBLY	A330, A340
721432C	ROTOR ASSEMBLY	A330, A340
721432D	ROTOR	A330, A340
721435	SHAFT AND ROTOR ASSEMBLY	A330, A340
721437	EXCITER ROTOR ASSEMBLY	A330, A340
721643	PMG AND SUPPORT ASSEMBLY	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
72266-3	FUEL BOOSTER CANISTER PUMP	A330, A340
72390-2	FUEL BOOSTER CANISTER PUMP	A330, A340
725923	RACE - ROLLER BEARING	
725933	GEAR SHAFT	
725953	SHAFT	
7-26-4	INDICATOR, HOMIG	
726473	EXCITER STATOR	B757
726506	ROTOR ASSEMBLY EXCITER	B757
726506Y1	EXCITER ROTOR	
726828	PMG STATOR	B757
727429E	IDG	A330, A340
727792C	IDG	B757
727792D	IDG	B757
727792E	IDG	B757
727792F	IDG	B757
727792G	IDG	B757,B767
727792H	IDG	B757
727792J	IDG	B757,A300
727792K	IDG	B757,A300
727792L	IDG	B757
727792M	IDG	B757
727792N	IDG	B757
727810A	AUXILIARY GENERATOR	B757
727810B	AUXILIARY GENERATOR	B757, B767
727810C	AUXILIARY GENERATOR	B757, B767,A320, A340
728403	APU GENERATOR ADAPTER	A330, A340
728403A	APU GENERATOR ADAPTER	A330, A340
728403B	APU GENERATOR ADAPTER	A330, A340
728403C	APU GENERATOR ADAPTER	A330, A340
728471	CONSTANT SPEED DRIVE	A330, A340
728471A	CONSTANT SPEED DRIVE	A330, A340
728471B	CONSTANT SPEED DRIVE	A330, A340
728471C	CONSTANT SPEED DRIVE	A330, A340
728749	RACE - OUTER ROLLER	
728843	ROTOR BALANCE ASSEMBLY	B757
728843 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
728843D	ROTOR	B757, B767, B747, A300
728843E	ROTOR	B757, B767, B747, A300
728843F	ROTOR	B757, B767, B747, A300
728843G	ROTOR	B757, B767, B747, A300
728843GY5	ROTOR BALANCE ASSEMBLY	B757, B767, B747, A300
728843H	ROTOR	B757, B767, B747, A300,A310
728843-SERIES	ROTOR BALANCE ASSEMBLY	
728905	STATOR	B757
728915B	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN GENERATOR	B737,B757
728915C	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN GENERATOR	B737,B757
728915D	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN GENERATOR	B737,B757
728915E	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN GENERATOR	B737,B757
728915-SERIES	WOUND ASSEMBLY	
729208	ELECTRICAL HARNESS	B757
729208A	ELECTRICAL HARNESS	B757



P/N	DESCRIPTION	AIRCRAFT PARTS
729208B	ELECTRICAL HARNESS	B757
729346	STATOR HOUSING ASSEMBLY	B757, B767
729346A	STATOR HOUSING ASSEMBLY	B757, B767
729346B	STATOR HOUSING ASSEMBLY	B757, B767
729346C	STATOR HOUSING ASSEMBLY	B757, B767
729346D	STATOR HOUSING ASSEMBLY	B757, B767
729346E	STATOR HOUSING ASSEMBLY	B757, B767
729346F	STATOR HOUSING ASSEMBLY	B757, B767
729355	ROTOR BALANCE ASSEMBLY	B757
729355 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
729355F	ROTOR	B757, B767, B747, A300, A310
729355G	ROTOR	B757, B767, B747, A300, A310
729355-SERIES	ROTOR BALANCE ASSEMBLY	
729714A	INTEGRATED DRIVE GENERATOR	A300, A310, B747
729714B	INTEGRATED DRIVE GENERATOR	A300, A310, B747
729714C	INTEGRATED DRIVE GENERATOR	A300, A310
729714D	INTEGRATED DRIVE GENERATOR	A300, A310
729714E	INTEGRATED DRIVE GENERATOR	A300, A310, B747
729722	AUXILIARY GENERATOR	A300, A310
729722A	AUXILIARY GENERATOR	A300, A310
729722B	AUXILIARY GENERATOR	A300, A310, B757
729722C	AUXILIARY GENERATOR	A300, A310, B757
729825	INTEGRATED DRIVE GENERATOR	B757, B767
729825A	INTEGRATED DRIVE GENERATOR	B757, B767
729825B	INTEGRATED DRIVE GENERATOR	B757, B767
729825C	INTEGRATED DRIVE GENERATOR	B757, B767
729825D	INTEGRATED DRIVE GENERATOR	B757, B767
729825E	INTEGRATED DRIVE GENERATOR	B757, B767
729825F	INTEGRATED DRIVE GENERATOR	B757, B767
729825G	INTEGRATED DRIVE GENERATOR	B757, B767
729825H	INTEGRATED DRIVE GENERATOR	B757, B767
729825J	INTEGRATED DRIVE GENERATOR	B757, B767, B747
729825K	INTEGRATED DRIVE GENERATOR	B757, B767
729825L	INTEGRATED DRIVE GENERATOR	B757, B767, B737
729825M	INTEGRATED DRIVE GENERATOR	B757, B767
730732	HOUSING - WOBBLER	
731488D	PORT PLATE ASSEMBLY	
731489C	PORT PLATE ASSEMBLY	
731681	EXCITER ROTOR ASSEMBLY	A330, A340
731753	CONSTANT SPEED DRIVE	B727, B747
731966	VAR. DISPLACEMENT HYDRAULIC MOTOR PUMP	B747-400, B757, B767, B747, B777
732036	MOTOR HOUSING AND STATOR SUBASSEMBLY	A330, A340
732591	AIR COOLING FAN	A330, A340
732591 SERIES	AIR COOLING FAN	A330, A340
732591E	FAN	B747, B767, B757
732591F	FAN	B747, B767, B757
732591G	AIR COOLING FAN	B747, B767, B757
732591-SERIES	AIR COOLING FAN	A330, A340
733492	WOBBLER CONTROL ARM	
733742 SERIES	STATOR HOUSING	A330, A340
734556A	DRIVE CONSTANT SPEED HYDRAULIC	
735243	RACE - ROLLER BEARING	
735511A	CONSTANT SPEED DRIVE TRANSMISSION	B737, B727, B747
735874	INTEGRATED DRIVE GENERATOR	A300, A310
735874A	INTEGRATED DRIVE GENERATOR	A300, A310



P/N	DESCRIPTION	AIRCRAFT PARTS
735874B	INTEGRATED DRIVE GENERATOR	A300, A310
735874C	INTEGRATED DRIVE GENERATOR	A300, A310
735874D	INTEGRATED DRIVE GENERATOR	A300, A310
736692 SERIES	STATOR HOUSING	A330, A340
737060	IDG	
737852A	INTEGRATED DRIVE GENERATOR	F50, F60
738131	STATOR ASSEMBLY - PMG	DC-10
738156B	AC GENERATOR	A330, A340
738158A	AC GENERATOR	A330, A340
738229A	STATOR ASSEMBLY - AC GENERATOR	A330, A340
738290	STATOR HOUSING ASSEMBLY	
738290-SERIES	STATOR HOUSING ASSEMBLY	A330, A340
738292	DUAL FUAEL GAGE AMPLIFIER	A330, A340
738299	ROTOR	A330, A340
738299 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
738299A	ROTOR BALANCE ASSEMBLY	A330, A340
738299B	ROTOR	B717
738299-SERIES	ROTOR BALANCE ASSEMBLY	
738301	SHAFT AND ROTOR ASSEMBLY	A330, A340
738316A	STATOR HOUSING ASSEMBLY	A330, A340
738690	INPUT HOUSING ASSEMBLY	A330, A340
738690 SERIES	INPUT HOUSING ASSEMBLY	A330, A340
738690-SERIES	INPUT HOUSING ASSEMBLY	
738955	EXCITER STATOR, ASSEMBLY	A330, A340
739515	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767, A320, A340
739515A	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767, B757
739515B	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
739515C	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
739515D	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
740119	INTEGRATED DRIVE GENERATOR	A330, A340
740119 SERIES	INTEGRATED DRIVE GENERATOR	A330, A340
740119A	INTEGRATED DRIVE GENERATOR	A320
740119B	INTEGRATED DRIVE GENERATOR	A320
740119C	INTEGRATED DRIVE GENERATOR	A320
740119D	INTEGRATED DRIVE GENERATOR	A320, A319, A300
740119E	INTEGRATED DRIVE GENERATOR	A320, A319
740119F	INTEGRATED DRIVE GENERATOR	A320, A319
740119G	INTEGRATED DRIVE GENERATOR	A320, A319
740119H	INTEGRATED DRIVE GENERATOR	A319, A320, A321
740508	INTEGRATED DRIVE GENERATOR	A330, A340
740510	INTEGRATED DRIVE GENERATOR	
740510F	IDG	
740510G	IDG	
74-110-3	TRANSMITTER OIL QUANTITY	A-319, A-320, A-321, A-340
74-110-4	TRANSMITTER OIL QUANTITY	A-319, A-320, A-321, A-340
741434	ELECTRICAL HARNESS	A330, A340
741434A	ELECTRICAL HARNESS	A330, A340
741434B	ELECTRICAL HARNESS	A330, A340
741439	STATOR HOUSING ASSEMBLY	A330, A340
741756	STATOR HOUSING ASSEMBLY	A330, A340
741756 SERIES	STATOR HOUSING ASSEMBLY	A330, A340
741756A	STATOR HOUSING ASSEMBLY	A330, A340
741788	ASSEMBLY-EXCITER STATOR	A330, A340
741901	IDG	
742051	ROTOR	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
742051 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
742051A	ROTOR BALANCE ASSEMBLY	A330, A340
742051B	ROTOR BALANCE ASSEMBLY	A330, A340
742051SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
744041	INTEGRATED DRIVE GENERATOR	B757, B767,CRJ100
744041A	INTEGRATED DRIVE GENERATOR	B757, B767
744041B	INTEGRATED DRIVE GENERATOR	B757, B767
745329	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329A	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329B	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329C	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329D	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329E	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329F	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
746277 SERIES	STATOR HOUSING	A330, A340
747194	IDG	A330, A340
747194A	IDG	B747, B767
747194B	IDG	B747, B767
747194C	IDG	B747, B767
747194D	IDG	B747, B767
747194E	IDG	B747, B767
747194F	IDG	A330, A340
747532	HOUSING - WOBBLER - VARIABLE	
747533	PLATE - BEARING	
747536	PLATE - BEARING	
747542	HOUSING - WOBBLER - VARIABLE	
747-5750-1-0	AC MOTOR WITH BRAKE ASSEMBLY	A330, A340
747739	COVER	
747740	STATOR HOUSING	A330, A340
747740 SERIES	STATOR HOUSING	A330, A340
747768	ROTOR BALANCE ASSEMBLY	B757
747768 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
747768C	ROTOR	B757, B767, B747, A300,A310
747768D	ROTOR	B757, B767, B747, A300,A310
747768-SERIES	ROTOR BALANCE ASSEMBLY	
748036-1	MAIN TANK INDICATING PANEL	A330, A340
748036-2	MAIN TANK INDICATING PANEL	A330, A340
749436	DEAERATOR	
750860	INTEGRATED DRIVE GENERATOR	MD-11
750875	INTEGRATED DRIVE GENERATOR	MD-11
751341	EXCITER STATOR	A330, A340
751344	ROTOR ASSEMBLY, EXCITER	A330, A340
751344A	ROTOR ASSEMBLY, EXCITER	A330, A340
752063	ROTOR BALANCE ASSEMBLY	A330, A340
752063A	ROTOR BALANCE ASSEMBLY	A330, A340
752157	INTEGRATED DRIVE GENERATOR	A340
752157 SERIES	INTEGRATED DRIVE GENERATOR	A340
752157B	INTEGRATED DRIVE GENERATOR	A340
752157C	INTEGRATED DRIVE GENERATOR	A340
752157D	IDG	A340, A330
752168	INTEGRATED DRIVE GENERATOR	A330
752168A	INTEGRATED DRIVE GENERATOR	A330
752168B	INTEGRATED DRIVE GENERATOR	A330,B737
7522-1-1	VHF RADIO TUNNING PANEL	
752685 SERIES	STATOR HOUSING ASSEMBLY	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
753088	HOUSING ASSY	
753129A	EXCITER ROTOR	B757
753129AY1	EXCITER ROTOR	
753129B	EXCITER ROTOR	B757
753129-SERIES	ROTOR ASSEMBLY EXCITER	
753367	ROTOR BALANCE ASSEMBLY	A330, A340
753367A	ROTOR BALANCE ASSEMBLY	A340
753383	STATOR ASSEMBLY-GENERATOR	A330, A340
753386	STATOR ASSEMBLY, PMG	A330, A340
753490A	STATOR AND PMG HOUSING ASSEMBLY	A340
753490B	STATOR AND PMG HOUSING ASSEMBLY	A340
753490C	STATOR AND PMG HOUSING ASSEMBLY	A340
754257	RESISTOR	
754661-10	SWITCH THERMOSTATIC	CN-235
755017	INTEGRATED DRIVE GENERATOR	A330
755017A	INTEGRATED DRIVE GENERATOR	A330
755017B	INTEGRATED DRIVE GENERATOR	A330
755057	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057A	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057B	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057C	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057D	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057E	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755359	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
755359A	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
755359B	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
755359C	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
755359D	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
755469	IDG	CRJ100/200
755961	ROTOR BALANCE ASSEMBLY	
755961 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
755961E	ROTOR BALANCE ASSEMBLY	A330, A340
755961H	ROTOR BALANCE ASSEMBLY	A330, A340
755961L	ROTOR BALANCE ASSEMBLY	A330, A340
756066B	EXCITER ROTOR	A330, A340
756420	PMG STATOR	
756589	APU GENERATOR	B777
756589A	APU GENERATOR	B777 ,A320, A340
756642	WOUND ASSEMBLY	B757
756690	ROTOR ASSEMBLY EXCITER	B757
756692	ROTOR BALANCE ASSEMBLY	B757, B767, B747, A300
756829 SERIES	STATOR HOUSING	A330, A340
756910 SERIES	STATOR HOUSING ASSEMBLY	A330, A340
756911	EXCITER AND PMG HOUSING ASSEMBLY	A330
756911A	EXCITER AND PMG HOUSING ASSEMBLY	A330
756911B	EXCITER AND PMG HOUSING ASSEMBLY	A330
756911C	EXCITER AND PMG HOUSING ASSEMBLY	A330
756911D	EXCITER AND PMG HOUSING ASSEMBLY	A330
757030	ROTOR BALANCE ASSEMBLY	
757030 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
757050	EXCITER STATOR	
757066A	VSCF GEN	B777
757066B	VSCF GEN	B777
757066C	VSCF GEN	B777
757066D	VSCF GEN	B777



P/N	DESCRIPTION	AIRCRAFT PARTS
757066E	VSCF GEN	B777
757066F	VSCF GEN	B777
757066G	VSCF GEN	B777
757066H	VSCF GEN	B777
757068 SERIES	STATOR HOUSING ASSEMBLY	A330, A340
757068G	STATOR HOUSING ASSEMBLY	A330, A340
757483	WOBBLER - VARIABLE	
757484	WOBBLER - VARIABLE	
757485	WOBBLER - FIXED	
757557	COIL WEDGE	
757652B	EXCITER ROTOR	A330, A340
757811	ELECTRICAL HARNESS	B757
758922	INTEGRATED DRIVE GENERATOR	A330, A340
758922A	INTEGRATED DRIVE GENERATOR	A330, A340
758926	AC GENERATOR	A330, A340
759467 SERIES	STATOR HOUSING	A330, A340
759768	INTEGRATED DRIVE GENERATOR	A300, A310
759770	INTEGRATED DRIVE GENERATOR	A300, A310
7609-37M52	TRANSMITTER	
7613-551-91-13	TERMOMETER	A330, A340
7613-551-91-14	T4 INDICATOR	A330, A340
761574	INTEGRATED DRIVE GENERATOR	B737
761574A	INTEGRATED DRIVE GENERATOR	B737
761574B	INTEGRATED DRIVE GENERATOR	B737,B747
762067A	STATOR HOUSING ASSEMBLY	B737
762067B	STATOR HOUSING ASSEMBLY	B737
762067C	STATOR HOUSING ASSEMBLY	B737
762067D	STATOR HOUSING ASSEMBLY	B737
762067E	STATOR HOUSING ASSEMBLY	B737
762067F	STATOR HOUSING ASSEMBLY	B737
762067G	STATOR HOUSING ASSEMBLY	B737
762109	STATOR ASSEMBLY - MAIN GENERATOR	A330, A340
762109A	STATOR ASSEMBLY - MAIN GENERATOR	A330, A340
762359	ROTOR BALANCE ASSEMBLY	B737
762359 SERIES	ROTOR	
762359A	ROTOR BALANCE ASSEMBLY	B737
762359AY3	ROTOR	
762359B	ROTOR BALANCE ASSEMBLY	B737
762359C	ROTOR BALANCE ASSEMBLY	B737
762359D	ROTOR BALANCE ASSEMBLY	B737
762359E	ROTOR BALANCE ASSEMBLY	B737
762359F	ROTOR BALANCE ASSEMBLY	B737
762359Y3	ROTOR	
762367	GENERATOR MAIN FIELD WOUND ASSEMBLY	A330, A340
762367A	GENERATOR MAIN FIELD WOUND ASSEMBLY	A330, A340
762367B	GENERATOR MAIN FIELD WOUND ASSEMBLY	A330, A340
762517A	STATOR	A330, A340
762620	VSCF	B777
762620A	VSCF	B777
762620B	VSCF	B777
762620C	VSCF	B777
762620D	VSCF	B777
762620E	VSCF	B777
762620F	VSCF	B777
762888B	INTEGRATED DRIVE GENERATOR	B717



P/N	DESCRIPTION	AIRCRAFT PARTS
763226-12	SEMICONDUCTOR	A330, A340
763457	INTEGRATED DRIVE GENERATOR	MD-11
763775	ELECTRICAL HARNESS	B767,B757
763775A	ELECTRICAL HARNESS	B767,B757
764294	STATOR ASSEMBLY-PMG	B737
764294A	STATOR ASSEMBLY-PMG	B737
764685-2	SWITCH AIRSPEED	
764821-2	NACELLE PRECOLLER	CN-235, C-295
764821-3	NACELLE PRECOLLER	A330, A340
764855	CYLINDER BLOCK	
764861-2	PRECOOLER	
764930 SERIES	STATOR HOUSING ASSEMBLY	A330, A340
764939	IDG	B777
764939A	IDG	B777
764939B	IDG	B777
765592-13	VALVE	
766088	INTEGRATED DRIVE GENERATOR	A330, A340
766088A	INTEGRATED DRIVE GENERATOR	CRJ700
766088B	INTEGRATED DRIVE GENERATOR	A330, A340
766088C	INTEGRATED DRIVE GENERATOR	A330, A340
766091	Cylinder Block and Piston	A330, A340
766219	INTEGRATED DRIVE GENERATOR	A320
766277A	IDG	CRJ
766277B	IDG	CRJ,CRJ700
766282B	APU GENERATOR	CRJ700
766288	GENERATOR ASSEMBLY	CRJ700, ERJ 170/190
766461	STATOR HOUSING	A330, A340
766461 SERIES	STATOR HOUSING	A330, A340
767091A	7.5 HP 6-POLE AC MOTOR	CRJ700, ERJ
767110 SERIES	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110A	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110B	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110C	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110D	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110E	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110F	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110G	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110H	ROTOR BALANCE ASSEMBLY	B777, B767-400
767146A	INTEGRATED DRIVE GENERATOR	B777,MD11
767173	STATOR HOUSING	A330, A340
767173 SERIES	STATOR HOUSING	A330, A340
767188	ROTOR BALANCE ASSEMBLY	A330, A340
767188 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
767188A	ROTOR BALANCE ASSEMBLY	A330, A340
767910	STATOR ASSEMBLY, GENERATOR	A330, A340
767912 SERIES	ROTOR BALANCE ASSEMBLY	
767912B	ROTOR BALANCE ASSEMBLY	B737
767912C	ROTOR BALANCE ASSEMBLY	B737
767912D	ROTOR BALANCE ASSEMBLY	B737,A310
767912E	ROTOR BALANCE ASSEMBLY	B737
767912F	ROTOR BALANCE ASSEMBLY	A330, A340
767912G	ROTOR BALANCE ASSEMBLY	B737
767916	STATOR HOUSING	B737
768342	ROTOR BALANCE ASSEMBLY	A330, A340
769068A	INTEGRATED DRIVE GENERATOR	B767/B777



P/N	DESCRIPTION	AIRCRAFT PARTS
769437D	ROTOR BALANCE ASSEMBLY	A330, A340
769437E	ROTOR BALANCE ASSEMBLY	A330, A340
769438	SHAFT ASSY	
769883	EXCITER STATOR	A330, A340
770401	EXCITER ROTOR	A330, A340
770404	STATOR ASSEMBLY, EXCITER	B737, B777
7704-1-000/1	HIGH SPEED OVEN	A330, A340
770604	ROTOR BALANCE ASSEMBLY	B777
772181	INTEGRATED DRIVE GENERATOR	A318, A320, A340
772181A	INTEGRATED DRIVE GENERATOR	A318, A320, A340
772292	INTEGRATED DRIVE GENERATOR	A320
772294	STATOR HOUSING ASSEMBLY	A330, A340
772294A	STATOR HOUSING ASSEMBLY	A330, A340
772-5370-003	INDICATOR	S330, S340
777-1492-001	RECEIVER	B747, B777
778-2996-004	AMPLIFIER	
778695-2	VALVE-PRESSURE REGULATOR	CN-235
78035-01118	INDICATOR ELECTRICAL	
7804-1-000/1	HIGH SPEED OVEN	A330, A340
78169-01	AUTO BRAKE MODULE	B727, B737, B747, B757
78169-02	AUTO BRAKE MODULE	B727, B737, B747, B757
78169-03	AUTO BRAKE MODULE	B727, B737, B747, B757
78169-04	AUTO BRAKE MODULE	B727, B737, B747, B757
78-17515-1	STATOR	A330, A340
782630-2	AIR CYCLE MACHINE	CN-235
782630-3	AIR CYCLE MACHINE	CN-235
782630-4	AIR CYCLE MACHINE	CN-235
782630-5	AIR CYCLE MACHINE	CN-235, C-212, C-295
782640-1	EXCHANGER	CN-235
782640-2	EXCHANGER	CN-235
783670-1	CONDENSER AND MIXER	C-212, CN-235
783670-2	CONDENSER AND MIXER	A330, A340
783670-3	CONDENSER AND MIXER	A330, A340
783670-4	CONDENSER AND MIXER	A330, A340
785804-1	HIGH PRESSURE BLEED VALVE	A330, A340
785804-2	HIGH PRESSURE BLEED VALVE	A330, A340
785804-3	HIGH PRESSURE BLEED VALVE	A330, A340
785804-X	HIGH PRESSURE BLEED VALVE	
785922	INTEGRATED DRIVE GENERATOR	A330, A340
785922A	INTEGRATED DRIVE GENERATOR	A330, A340
7901067F	3/4 INCH SPV WITH PRESSURE RELIEF	C-212
7923227/F	VALVE-3/4 TWIN MOTORIZED	CN-235
7923227F	3/4 INCH MOTORIZED SPHERICAL PLUG PRESSURE RELIEF	CN-235, C-295
7923245/M	VALVE-2" MOTORIZED	
7923245M	2 INCH MOT. SPHERIC. PLUG VALVE	CN-235, C-295
7923245-M	FUEL GRAVITY TRANSFER VALVE	
7923327F	VALVE 3/4" TWIN MOTORIZED	A330, A340
792A0000-04	ACTUATOR	A319
792A0000-06	ACTUATOR	A319
792PG/SB	SWITCH ASSEMBLY, DIF	
7930-327-403	INSTRUMENT SWITCH UNIT	A330, A340
793C0000-01	ACTUATOR-FLAP NO3	A340
794C0000-01	ROTARY ACTUATOR	A319
795242	RACE - ROLLER BEARING	



P/N	DESCRIPTION	AIRCRAFT PARTS
7970-161-401	SWITCHING UNIT, AUDIO	
80000000-12	STAB TRIM LIM SW & POS XMTR	B757,B767
8000282Y00	TAXI LIGHT	A320
8000283Y00	TAKE OFF LIGHT	A318,A319,A320,A322
8000351Y00	AUTOTRANSFORMER, EQUIPPED	A330, A340
8001580	STATOR	A330, A340
801240-3	FAN ASSY-TURBINE DRIVEN	B737,A300
8-060-02	PRINTED CIRCUIT ASSY	DC-10,B737
8060-140	STARTER GENERATOR	A330, A340
8060-140-1	STARTER GENERATOR	A330, A340
8060-141	STARTER GENERATOR	A330, A340
8060-141-1	STARTER GENERATOR	A330, A340
8060-3	STARTER GENERATOR	A330, A340
8060-300	STARTER GENERATOR	A330, A340
8060-300-1	STARTER GENERATOR	A330, A340
8060-3-1	STARTER GENERATOR	A330, A340
8060-320	STARTER GENERATOR	A330, A340
8060-320-1	STARTER GENERATOR	A330, A340
8060-3-300	STARTER GENERATOR	
8060-3-300-1	STARTER GENERATOR	
8060-3-320	STARTER GENERATOR	
8060-3-320-1	STARTER GENERATOR	
8060-XXX	STARTER GENERATOR	
81000-15001	LOGO LIGHT ASSEMBLY	A330, A340
81000-15002	LOGO LIGHT ASSEMBLY	A330, A340
81000-15003	LOGO LIGHT ASSEMBLY	A330, A340
81000-15004	LOGO LIGHT ASSEMBLY	A330, A340
81000-15005	LOGO LIGHT ASSEMBLY	A330, A340
81000-15006	LOGO LIGHT ASSEMBLY	A330, A340
81000-17501	LIGHT ASSY	B737, B747
81000-17502	MAP LIGHT	B737
81000-37601	LOGO LIGHT ASSY	B737,CRJ
81000-37602	LOGO LIGHT ASSY	B737,CRJ
81204433	5 SHAFT	
81204471	STATOR ASSEMBLY, MAIN EXCITER	A330, A340
81204654	ROTOR ASSEMBLY MAIN EXCITER	
81205155	PE HOUSING AND STATOR ASSEMBLY	A330, A340
81205162	ROTOR AND SHAFT ASSEMBLY, MACHINED	A320
81205162/S1	ROTOR AND SHAFT ASSEMBLY, MACHINED	A330, A340
81205691	STATOR ASSEMBLY, WOUND, ME	A330, A340
81205820	HOUSING AND STATOR ASSEMBLY	
81205821	STATOR ASSEMBLY, WOUND MAIN	A320
81205961	ROTOR ASSEMBLY, FINISHED	A320
81207093	STATOR AND HOUSING ASSEMBLY, PE	A330, A340
81207174	MACHINED ROTOR & SHAFT ASSEMBLY	A330, A340
81207213	ROTOR ASSEMBLY, FINISHED ME	A330, A340
81207321	ROTOR ASSY	
81207327	EXCITER ROTOR	A320
81207367	ROTOR ASSEMBLY, FINISHED	A320
81207367/S1	FINISHED ROTOR ASSEMBLY	A320
81207408S2S3	ROTOR	
81207412	HOUSING AND STATOR ASSEMBLY	A330, A340
81207425	ROTOR ASSEMBLY, FINISHED	A320
81207425/S1	ROTOR ASSEMBLY, FINISHED	A330, A340
81207425-S1	ROTOR ASSEMBLY FINISHED	



P/N	DESCRIPTION	AIRCRAFT PARTS
81207426	ROTOR AND SHAFT ASSEMBLY, MACHINED	A320
81207444	HOUSING AND STATOR ASSEMBLY	A330, A340
81207461	MACHINED ROTOR & SHAFT ASSEMBLY	A330, A340
81207474	ROTOR ASSEMBLY, FINISHED	
81207474/S8	FINISHED ROTOR ASSEMBLY	A330, A340
81207485	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207485/S1	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207485-S1	STATOR ASSEMBLY MAIN WOUND	
81207491	MAIN FRAME, STATOR ASSEMBLY	A330, A340
81207540	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207540/S1	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207540-S1	STATOR ASSEMBLY MAIN WOUND	
81207552	ROTOR ASSEMBLY, FINISHED ME	A330, A340
81207562	ROTOR ASSEMBLY, FINISHED	A330, A340
81207562/S7	ROTOR ASSEMBLY, FINISHED	A330, A340
81207562/S8	ROTOR ASSEMBLY, FINISHED	A330, A340
81207563	ROTOR ASSEMBLY FINISHED	A330, A340
81207571	ROTOR ASSEMBLY, FINISHED	A330, A340
81207571/S7/S8	FINISHED ROTOR ASSEMBLY	A330, A340
81207571/S7S8	ROTOR	
81207571/S8	FINISHED ROTOR ASSEMBLY	A330, A340
81207587	MAIN WOUND STATOR ASSEMBLY	A330, A340
81207597	APU GEN ROTOR	A320,A319, A321
81207613	ROTOR AND SHAFT ASSEMBLY, MACHINED	A330, A340
81207659	EXCITER ROTOR	A330, A340
81207660	ROTOR ASSEMBLY, FINISHED	A330, A340
81207690	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207690/S1	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207690-S1	STATOR ASSEMBLY MAIN WOUND	
81207704	ROTOR ASSEMBLY, FINISHED	A330, A340
81207706	ROTOR ASSEMBLY, FINISHED	A330, A340
81207706/S8	ROTOR ASSEMBLY, FINISHED	A330, A340
81207707	ROTOR ASSEMBLY, FINISHED ME	A330, A340
8160-530	STARTER GENERATOR	CN-235, C-295
81703416	ARMATURE ASSEMBLY	A330, A340
81703416/S1	ARMATURE ASSEMBLY	A330, A340
81703416-S1	ARMATURE	
81704611	ARMATURE ASSEMBLY	A330, A340
81704611/S1	ARMATURE ASSEMBLY	A330, A340
81704611-S1	ARMATURE	
81704875	YOKE, POLESHOE AND FIELD COILS ASSEMBLY	A330, A340
81706312	ARMATURE ASSEMBLY	A330, A340
8171-1	DIMMABLE ELECTRONIC FLUORESCENT LAMP BALLAST	B737,B777,B757
8171-1 MOD A	DIMMABLE ELECTRONIC FLUORESCENT LAMP BALLAST	A330, A340
8171-1A	DIMMABLE ELECTRONIC FLUORESCENT LAMP BALLAST	
8177-1	BALLAST UNIT	
8178-1	BALLAST	B737, B757, B767,B777
8184-1	BALLAST UNIT	B737, B757, B767,B777,EMB
8184-1 MOD A	BALLAST UNIT	EMB170
8184-1 MOD A	BALLAST UNIT	
8184-1 MODA	BALLAST UNIT	



P/N	DESCRIPTION	AIRCRAFT PARTS
8184-1A	ELECTRONIC BALLAST	
8184-1MODA	BALLAST	
8204-16-0000-01	STEAM OVEN ASSY	A330, A340
8204-16-0000-XX	STEAM OVEN ASSY	A330, A340
8204-66-0000-01	STEAM OVEN ASSY	A330, A340
8204-66-0000-XX	STEAM OVEN ASSY	A330, A340
820507-1	BRUSH BLOCK HOUSING ASSEMBLY	A330, A340
821386	CONDENSER/MIXER HEAT EXCHANGER	A330, A340
821386-1	HEAT EXCHANGER CONDENSER MIXER	C-295
821386-2	HEAT EXCHANGER CONDENSER MIXER	C-295
822-1046-001	RECEIVER-TRANSMITTER	S330, S340
822-1114-001	RECEIVER, TRANSMITTER	
822-1383-101	EMETTEUR/RECEPTEUR	
82410605	ICE PROTECTION PANEL ASSEMBLY	A330, A340
82410605-023	ICE PROTECTION PANEL ASSEMBLY	A330, A340
82410615-005	ADVISORY SIGN/PASSENGER WARNING PANEL ASSEMBLY	DASH8
82410615-007	ADVISORY SIGN/PASSENGER WARNING PANEL ASSEMBLY	A330, A340
82410924-001	EXTERIOR LIGHTS,AND TAIL LOGO LIGHTS PANEL ASSEMBLY	DASH 8 SERIE 400
82410924-003	EXTERIOR LIGHTS,AND TAIL LOGO LIGHTS PANEL ASSEMBLY	DASH 8 SERIE 400
82410924-007	EXTERIOR LIGHTS,AND TAIL LOGO LIGHTS PANEL ASSEMBLY	DASH 8 SERIE 400
82410924-009	EXTERIOR LIGHTS,AND TAIL LOGO LIGHTS PANEL ASSEMBLY	DASH 8 SERIE 400,EMB900
824375-2-002	CONTROL PROP ELECTRONIC	CN-235, C-295
824972-2-010	EEC FADEC	
8260-120	STARTER GENERATOR	ATR-42, ATR-72
8260-121	STARTER GENERATOR	ATR-42, ATR-72,B737
8260-123	STARTER GENERATOR	ATR-42, ATR-72,B747
8260-150	STARTER GENERATOR	CN-235, C-295
8260-XXX	STARTER GENERATOR	
8295-1	OIL COOLER FLAP ACTUATOR	A330, A340
83000-0502	HEAT CONTROL UNIT	
83000-0503	HEAT CONTROL UNIT	
83000-0504	HEAT CONTROL UNIT	
83000-05601	HEAT CONTROL UNIT	B737,MD80
83000-05602	WINDOW HEAT CONTROL	B737,ATR
83000-05603	HEAT CONTROL UNIT	B737,B707
83000-05604	HEAT CONTROL UNIT	B737
83000-0564	HEAT CONTROL UNIT	
83115-05601	TRANSFORMER	
83427	COFFE/LAVATORY PUMP	Q400
8347	GEARBOX ASSEMBLY, AIR	
8348M1	GEARBOX, LANDING	C-130
835760-401	ALTERNATING CURRENT MOTOR	A330, A340
837900-401	ALTERNATING CURRENT MOTOR	A330, A340
8402	STEAM OVEN	A319-A320-A330
841923	AC ROTOR ASSEMBLY	A330, A340
8423-001	ACCUMULATOR HYDRAULIC	A330, A340
8423-030	ACCUMULATOR HYDRAULIC	A330, A340
8423-030-1	ACCUMULATOR HYDRAULIC	A330, A340
8424-001	ACCUNULATOR HYDRAULIC	C-130
8425-030	ACCUMULATOR HYDRAULIC	A330, A340
8426-001	ACCUMULATOR HYDRAULIC	A330, A340
84498	ARMATURE	
848354	VARIABLE DISPLACEMENT	A330, A340
848847	HYDRAULIC PUMP	



P/N	DESCRIPTION	AIRCRAFT PARTS
849589	VARIABLE DISPLACEMENT HYDRAULIC PUMP	B737
8503310	STATOR	
85384	FIELD	
85464-2	AC GENERATOR	A330, A340
85465-1	ROTOR ASSEMBLY	B737
85465-2	ROTOR ASSEMBLY	B737
85465-3	ROTOR	B737
85569-1	STATOR	A330, A340
85569-2	STATOR	A330, A340
85570-1	ROTOR ASSY	A330, A340
855D100-9	SENSOR-BRAKE AND POSITION UNIT	
856NC2	TUBE, PITOT	CN-235, C-295
8-614-01	SENSOR PROX. LEAD. EDGE	
861555	AC DRIVEN MOTORPUMP ASSEMBLY	DC-10, A300, A310, MD-80, MD-11, MD-90
861561	MOTOR HOUSING AND STATOR SUBASSEMBLY	A330, A340
8680-045-401	VACUUM AND PRESURE	
8680-045-403	VACUUM AND PRESURE R	
86815-1	AC GENERATOR	A330, A340
869843	FLUID PRESSURE REGULATING VALVE	
869843 SERIES	FLUID PRESSURE REGULATING VALVE	
87006	STATOR	
87006-1	STATOR AC GEN	A330, A340
87006-10	STATOR AC GEN	A330, A340
87006-11	STATOR AC GEN	A330, A340
87006-12	STATOR AC GEN	B737
87006-2	STATOR-GEN AC	A330, A340
87006-3	STATOR AC GEN	A330, A340
87006-4	ALTERNATOR STATOR	A330, A340
87006-5	STATOR AC GEN	A330, A340
87006-9	STATOR	A330, A340
87006-SERIES	STATOR/HOUSING ASSEMBLY	
87006-X	STATOR ALTERNATOR	
8701000000	REP Y CALIBRACION EQ MEDIDA	
87014-1	STATOR	B737
87014-2	STATOR	B737
8704-1-000/1	HIGH SPEED OVEN	A330, A340
871829	ARMATURE ASSEMBLY	A330, A340
8804-1-000/1	HIGH SPEED OVEN	A330, A340
887111	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
887477	AC DRIVEN MOTORPUMP ASSEMBLY	B737, B727
887673	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	B757
890409-1000	VALVE REGULATING	
890411-02	VALVE SOLENOID	
8-930	KDM 706 A DISTANCE MEASURING EQUIPMENT	A330, A340
8-930-03	BATTERY CHARGER	B747, B757, B767, B737
8-930-03 MOD A	BATTERY CHARGER	A330, A340
8940	PUMP, WATER	
895-20077	OXYGEN CYLINDER AND REGULATOR ASSEMBLY	
895380-1	TORQUE LIMITER ASSEMBLY	C-212-200,JET PROP 690,MU-2,METRO 23,
895380-2	TORQUE LIMITER ASSEMBLY	C-212-200,JET PROP 690,MU-2,METRO 23,
895380-3	TORQUE LIMITER ASSEMBLY	C-212-200,JET PROP 690,MU-2,METRO 23,
895380-4	TORQUE LIMITER ASSEMBLY	C-212-200,JET PROP 690,MU-2,METRO 23,
896380	TORQUE LIMITER ASSEMBLY	
896380 SERIES	TORQUE LIMITER ASSEMBLY	
897260-5M	PRESS TRANSDUCER	
897390	FUEL PUMP ASSEMBLY	
897390 SERIES	FUEL PUMP ASSEMBLY	
8C25-1	ARMATURE ASSY	A330, A340
8DJ100WAD22	INDICATOR	
8DJ100WAD3	TITIND	
8DJ179	T INDIICATOR	
8DJ185WAA1	EGT INDICATOR	DC-10
8DJ81CAN4	INDICATOR ELECTRICA	B727, B737
8DJ81CBD4	INDICATOR	C-212, C-295
8DJ81CDW4	INDICATOR	B727, B737
8DJ81CER4	IND, SPEED	B727, B737
8DJ81CFA4	INDICATOR	C-212, CN-235
8DW84LAN1	DC AMMETER ANTI-ICING HEATER	DC-9, MD-80, MD-90
8ES002769-03	POWER SUPPLY UNIT, BEACON LIGHTS (A300, A318, A319, A320, A321,CRJ100
8ES005045-	POWER SUPPLY UNIT	A320-100, A330, A340, A320
8ES005045 SERIES	ENERGY BOX	A330, A340
8ES005045-00	POWER SUPPLY UNIT	A319, A320, A321, A330, A340
8ES005045-SERIES	POWER SUPPLY UNIT	A320-100, A330, A340, A320
8ES005236-13	POWER UNIT, SINGLE (REPL. F. -03)	
8ES005238-	POWER UNIT	A319, A320, A321, A320-100
8ES005238-03	POWER UNIT (N/P, USE -13)	A319, A320, A321
8ES005238-13	POWER UNIT, TRIPLE (REPL. F. -03)	A319, A320, A321, A320-100
8ES005238-SERIES	POWER UNIT	A319, A320, A321, A320-100
8ES005304-	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES005304 SERIES	ENERGY BOX	A319, A321, A330, A340, A320
8ES005304-00	POWER SUPPLY UNIT, SINGLE FLASH	A319, A321, A330, A340, A320
8ES005304-SERIES	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES005309	ENERGY BOX	A330, A340
8ES005309 SERIES	ENERGY BOX	A330, A340
8ES005309-00	POWER SUPPLY UNIT	A319, A320, A321, A330, A340
8ES005421-09	CONTROLLER, POWER SUPPLY UNIT, STR	EMB
8ES455012-	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES455012 SERIES	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES455012-SERIES	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES455438-07	POWER SUPPLY UNIT	A320, A320-100,A340, A330
8F106-1	ARMATURE ASSEMBLY	A330, A340
8G1414	SWITCH, PRESSURE	CN-235
8TJ50GAS5	TRANSMITTER, RATE OF	B727, B737
8TJ99GGE1	TRANSMITTER OIL QUANTITY	B767



P/N	DESCRIPTION	AIRCRAFT PARTS
90000581-1	WHEEL N ASSY	
90-0215-1	CONVASSY MOTOR LH	B767
900-700-039-04	PORTABLE OXYGEN CYLINDER ASSEMBLY MODEL 4113	A330, A340
900-700-039-06	PORTABLE OXYGEN CYLINDER ASSEMBLY MODEL 4113	A330, A340
900-700-039-12	PORTABLE OXYGEN CYLINDER ASSEMBLY MODEL 4113	A330, A340
9008D07-1	ALTERNATING CURRENT MOTOR	A300
90-10072-1	ENTRY DOOR SNUBBER ASSEMBLY	B737, B727, B707
90-10072-2	SNUBBER	B737,DC10
901020-1	STRUT ASSEMBLY, MLG SHOCK	P3 ORION
901573-3	RUDDER BOOSTER ACTUATING CYLINDER ASSEMBLY	P-3
901918-105	SHOCK STRUT ASSEMBLY	P3 ORION
901918-5	SHOCK STRUT ASSEMBLY	P3 ORION
9021D08-2	EXCITER STATOR	B737
902607-1	CYLINDER ASSEMBLY AC	P3 ORION, P3 CONVERSION
90421-2	CONNECTORS	
9050422	7.5 HP 6-POLE AC MOTOR	CRJ700
9050422	ELECTRIC MOTORPUMP	CRJ700 & ERJ
907D547-1	EXCITER STATOR	B737
909269-3	CARTRIDGE	P3 ORION, P3 CONVERSION
912072-1	CARTRIDGE	A330, A340
915F197-1	ARMATURE-ROTOR	B737
915F213-3	BUS PROTECTION PANEL	B737
915F213-4	BUS PROTECTION PANEL	B737
915F251-1	EXCITER STATOR	B737
915F466-1	STATOR	B737
915F466-2	STATOR	B737
915F499-1	STATOR	B707, B727, B747, B737
915F500-1	EXCITER STATOR	B737
915F517-1	ROTOR	B737
915F716-1	SEMICONDUCTOR DEVICE SET	A330, A340
915F716-2	SEMICONDUCTOR DEVICE SET	A330, A340
915F718-1	ARMATURE ROTOR ASSEMBLY	A330, A340
915F718-2	ARMATURE ROTOR ASSEMBLY	A330, A340
915F718-3	ARMATURE ROTOR ASSEMBLY	A330, A340
9201000-198	VALVE REGULATING	
9201000-206	GA CONTENTS TRANSMITTER	
9210M42P03	STATOR ASSY	A330, A340
9210M42P05	STATOR ASSY	A330, A340
9238M66P07	IGNITION EXCITER	DC9
933402	HYD MOTOR PUMP	CN-235, CN-295
933402 / MPEV3-011-	PUMP-HYDR MOTOR DRIVEN	CN-235, CN-295
933402 / MPEV3-011-	PUMP-DC ELEC MOTOR	CN-235, CN-295
93-343	PLATE PRESSURE BRAK	
93560-07	ISOLATOR VIBRATION L REA	B767
937958-103	STRUT ASSEMBLY, MLG SHOCK	P3 ORION
9387M16P01	ROTOR ASSEMBLY	B737
9387M16P02	ROTOR ASSEMBLY	B737
9387M16P02 (85465-2)	ROTOR	
9387M17P	STATOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
9387M17P SERIES	STATOR/HOUSING ASSEMBLY	
9387M17P06	STATOR AND HOUSING ASSEMBLY	A330, A340
9387M17P06 (87006-3)	FADEC STATOR	
9387M17P08	STATOR AND HOUSING ASSEMBLY	A330, A340
9387M17P08 (87006-5)	FADEC STATOR	
9387M17P09	STATOR AND HOUSING ASSEMBLY	A330, A340
9387M17P09 (87006-9)	FADEC STATOR	
9387M17P12	AC GENERATOR	A330, A340
93A100-80	VOICE RECORDER	CN-235,B737,A310,B757,Beech
940D046-1	STATOR, EXCITER, GENERATOR	A330, A340
940D047-1	ARMATURE, WOUND	A330, A340
940D412-2	EXCITER ROTOR	A330, A340
940D531-2	STATOR	A330, A340
940D531-4	STATOR, GENERATOR	A330, A340
941D586-1	EXCITER ROTOR	B737
942D262-1	ARMATURE, WOUND	B737
943D367	SEMICONDUCTOR DEVICE SET	A330, A340
943D367-SERIES	SEMICONDUCTOR DEVICE SET	A330, A340
943D469-2	STATOR PERMANENT MAGNET	DC-10
943D703-1	EXCITER ROTOR	DC-10
943D724-2	STATOR EXCITER	A330, A340
943D724-4	STATOR EXCITER	A330, A340
9-464-06	FUEL FLOW / FUEL USED INDICATOR	CN235
9-464-40	FUEL FLOW / FUEL USED IND.	CN-235, C-295
9-464-40 MOD B	INDICATOR, LIQUID QTY	
9-464-40 MOD D	INDICATOR, RATE OF FL	
946F013-1	ARMATURE-ROTOR	A330, A340
946F177	SEMICONDUCTOR DEVICE SET	A330, A340
946F177-1	SEMICONDUCTOR	B737
946F177-SERIES	SEMICONDUCTOR DEVICE SET	A330, A340
946F339-1	STATOR, EXCITER	DC-10
946F486-3	ROTOR	DC-10
946F506-3	STATOR PERMANENT MAGNET	A330, A340
946F932-1	ARMATURE ROTOR	A330, A340
946F960-1	ARMATURE-ROTOR, GENERATOR	DC-10
946F979-1	PMG STATOR	A330, A340
946J498-2	AC GENERATOR	
946J598-1	AC GENERATOR	
947F226-3	EXCITER ARMATURE CAPACITOR AND DIODE ASSEMBLY	A330, A340
948F463-4	10 KVA GENERATOR	
948F723-1	STATOR GENERATOR	A330, A340
948F723-2	STATOR GENERATOR	A330, A340
949F283	SEMICONDUCTOR DEVICE SET	A330, A340
949F283-1	SEMICONDUCTOR	A330, A340
949F283-2	SEMICONDUCTOR DEVICE SET	A330, A340
949F283-SERIES	SEMICONDUCTOR DEVICE SET	A330, A340
949F309-1	ARMATURE ROTOR	A330, A340
949F309-2	ARMATURE ROTOR	A330, A340
949F380-1	END BELL, ELEC. ROTATING	A330, A340
9506111-501	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-502	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-503	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-504	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-505	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-506	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)



P/N	DESCRIPTION	AIRCRAFT PARTS
9506111-507	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-508	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-509	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-510	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-511	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-512	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-513	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-514	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-515	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-516	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-517	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-518	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-519	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-520	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-521	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-522	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-523	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-524	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-525	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-526	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-527	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-528	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-529	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-530	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-531	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-532	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
950F190-1	STATOR, MAIN	A330, A340
950F236-5	ARMATURE ASSEMBLY	A330, A340
9535416	PLATE BACKING BRAKE	
9542719	WHEEL DRIVEN UNIT	A330, A340
9542719-1	WHEEL DRIVEN UNIT	A330, A340
9542719-2	WHEEL DRIVEN UNIT	A330, A340
9542719-3	WHEEL DRIVEN UNIT	A330, A340
9542732-2	CONTROL VALVE ASSEMBLY	C-212
9543476	NOSE WHEEL ASSEMBLY	A330, A340
9544-3-300	ARMATURE	A330, A340
9550170900	STARTER MOTOR	B707, B717, B723, B737
9550493-1	WHEEL LANDING GEAR	
9560685	BRAKE MULTIPLE DISK	C-130
9560685-1	BRAKE MULTIPLE DISK	C-130
95-61260-0005	CONTROL -DSPLAY UNIT	C-295
95-61295-0001	FLIGHT CONTROL GROUP	C-295
95-94064-0001	DOUBLE SEAT	C-295
95-94064-0001B05	DOUBLE SEAT	A330, A340
9600-15-0000	CEILING LIGHT ASSEMBLY	B737
9600-26-0000	CEILING LIGHT ASSEMBLY	B737
9600-32-0000	CEILING LIGHT ASSEMBLY	B737
9600-40-0000	CEILING LIGHT ASSEMBLY	B737
9600-44-0000	CEILING LIGHT ASSEMBLY	B737
9600-51-0000	CEILING LIGHT ASSEMBLY	B737
9600-55-0000	CEILING LIGHT ASSEMBLY	B737
9600-58-0000	CEILING LIGHT ASSEMBLY	B737
9601-15-0000	CEILING LIGHT ASSEMBLY	B737
9601-26-0000	CEILING LIGHT ASSEMBLY	B737
9601-32-0000	CEILING LIGHT ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
9601-40-0000	CEILING LIGHT ASSEMBLY	B737
9601-44-0000	CEILING LIGHT ASSEMBLY	B737
9601-51-0000	CEILING LIGHT ASSEMBLY	B737
9601-55-0000	CEILING LIGHT ASSEMBLY	B737
9601-58-0000	CEILING LIGHT ASSEMBLY	B737
96109-31-107	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	A400M
96109-31-109	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	A400M
96109-32-107	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	A400M
96109-32-109	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	A400M
96109-33-101	AFT MOUNT - PYLON FASTENERS	A400M
96109-33-103	AFT MOUNT - PYLON FASTENERS	A400M
96109-33-105	AFT MOUNT - PYLON FASTENERS	A400M
9615-300	ARMATURE	A330, A340
965C380-2	STATOR MOTOR	B737
971533	DC ELECTRIC MOTORPUMP ASSEMBLY	A330, A340
971808	HIDRAULIC PUMP	EMB-135/-145
971844	VARIABLE DISPLACEMENT	A330, A340
971E325G1	GENERATOR CONVERTER UNIT	A330, A340
972630	VARIABLE DISPLACEMENT	A330, A340
973545	MOTOR HOUSING AND STATOR SUBASSEMBLY	A330, A340
974947	VARIABLE DISPLACEMENT	A330, A340
974976	VARIABLE DISPLACEMENT	A330, A340
97607-102	TRANSCVR, VHF	C-212
976J063-2	AC GENERATOR	B707, B727
976J118-10	AC GENERATOR	B737
976J118-11	AC GENERATOR	B737,B707
976J118-6	AC GENERATOR	B737
976J118-8	AC GENERATOR	B737
976J118-X	AC GENERATOR	
976J118-XX	AC GENERATOR	
976J119-11	AC GENERATOR	B727, B707
976J119-12	AC GENERATOR	B727, B707
976J119-6	AC GENERATOR	B727, B707,B737
976J119-8	AC GENERATOR	B727, B707,B737,DC9, MD80
976J119-X	AC GENERATOR	
976J252	AC GENERATOR	MD-80, DC-9
976J252-6	GENERATOR	MD-80, DC-9,B747, B767
976J252-8	GENERATOR	MD-80, DC-9,B757
976J252-SERIES	AC GENERATOR	MD-80, DC-9
976J252-X	AC GENERATOR	MD-80, DC-9
976J255-5	AC GENERATOR	A330, A340
976J366-2	AC GENERATOR	A330, A340
976J449-1	AC GENERATOR	B727, B737
976J497-1	AC GENERATOR	B737
976J498-1	AC APU GENERATOR	B727, B737,MD80
976J498-1R	AC GENERATOR	B737
976J498-2	AC GENERATOR	B737,MD80
976J498-X	AC GENERATOR	
976J597-1	AC GENERATOR	B737
976J598-1	AC GENERATOR	B737
976J889-5	AC GENERATOR	DC-10, MD-11
976J889-6	AC GENERATOR	DC-10,MD11
976J931-3	GCU	
977J024-3	AC GENERATOR	A330, A340
977J024-4	AC GENERATOR	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
977J024-4S	AC GENERATOR	A330, A340
977J024-4T	AC GENERATOR	A330, A340
977J150-1	AC GENERATOR	A300, DC-10, MD-11
977J150-2	AC GENERATOR	A300, DC-10, MD-11
977J150-3	AC GENERATOR	A300, DC-10, MD-11
977J150-4	AC GENERATOR	MD-11, A300, MD-10, DC-10,B767
977J150-X	AC GENERATOR	
977J330-2	AC GENERATOR	A330, A340
977J330-3	AC GENERATOR	
977J413-2	STATOR	A330, A340
979806-11	VALVE ASSY	B757, B767, A300, A310, B747,CRJ100
980-4100DXUS	DFDR	DC-10,B737,A310,B757
9808-20	INDICATOR VOR	
9886068G004	STATOR	B737
9886068G006	STATOR ASSY	B737
9900-26-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-26-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
99003-3	GYRO DIRECTION	
9900-40-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-40-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-44-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-44-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-51-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-51-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-55-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-55-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9910059-3	AIR MIXER MOTOR	
9912147-26	FUEL QTY INDICATOR	
9912147-27	FAN INDICATOR	
9A1164	BRAKE ASSEMBLY	A330, A340
9B72-1	STATOR	
9C30	STATOR ASSY	A330, A340
9F83-7	STATOR	
A15580-P1	CLOCK	S330, S340
A15586	FE CLOCK	DC-10
A24A9430-1	CONTROL BOX	
A26877-10-001	INDICATOR RATE OF C	P3 ORION, P3 CONVERSION
A3410-2	FAN COWL HOLD OPEN ROD	A319, A320,A321
A-440	HORIZONTE ARTI	
A489-5	ACTUATOR ELECTRO-MECH	C-130
A853550-1	COMPRESSOR	A330, A340
A853550-31	COMPRESSOR	A330, A340
A853561-1	BOSS STATOR	A330, A340
A853790-11	FAN MOTOR	A330, A340
A853792-11	STATOR MOTOR	A330, A340
AAU24A	ALTIMETER PRESSURE	
AC210015C	VALVE	CN-235
AC30-0003-3	AUTOBRAKE SELECTOR SWITCH ASSEMBLY	B757, B747, B767
AC30-0003-4	AUTOBRAKE SELECTOR SWITCH ASSEMBLY	B757, B747, B767
AC62982	BRAKE CONTROL VALVE	S330, S340
AC63880	BRAKE CONTROL VALVE	
AC900085	OXYGEN REGULATOR ASSEMBLY	A330, A340
ACG7301-5505	ACTUATOR ASSY-SIDE CARGO DOOR	DC-10
ACM18048	SEPARATOR PIPELINE	
ACM22070	PRESSURE REGULATOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
ACM26230	COCK ISOLATING	
ACM28766	VALVE REDUCING	
ACP2788AD01	AUDIO CONTROL PANEL	A330, A340
AD-2758	AIRCRAFT BATTERY	A330, A340
AG10113AA02	LIGHT	
AG1013AA02	LIGHT ASSEMBLY	DC-10,B737
AG34-109	DRIVE SHAFT	
AG34-20	GENERATOR ROTOR ASSY	
AH.9033	NOSE WHEEL	A330, A340
AH091476	HEAT PACK ASSEMBLY	
AH9033	WHEEL, NLG	C-212
AHA1292	BRAKE UNIT	CN-235
AHA1802	BRAKE UNIT	CN-235
AR-204A-SERIES	FUEL RATE INDICATOR	A330, A340
AR-207	FUEL RATE INDICATOR	A330, A340
AR-207-SERIES	FUEL RATE INDICATOR	A330, A340
AR4701-1	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AR4701-13	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	B767
AR4701-15	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AR4701-17	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AR4701-3	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AR4701-5	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AS664111LS666	HYDRAULIC PUMP	
AT-1108/ARC	ANTENA VHF/UHF	
AV16B1350	VALVE	B737,DC10
AV16B1464C	VALVE	C-130
AV16B2106B	VALVE FUEL	C-212, CN-235
AV24B1119B	VALVE	
AV24B13225C	VALVE HIDRAULIC	
AW2-33A1	GAUGE PRESSURE DIAL	P3 ORION, P3 CONVERSION
AW-2-33A1	GAUGE PRESSURE INDICATING DIAL	A330, A340
AW-2-33-A1	GAGE, DIFFERENTIAL, DI	
AYG7323-5507	VALVE FLAP LOCK	DC-10
AYG7323-5509	VALVE FLAP LOCK	DC-10, MD-11,B717, MD80, MD90
B0700-10006	SENSOR SOBREVE	C-212
B1390	CYLINDER COMPRESSED	
B16138	TRANSDUCER	
B-26-138-00	COMMUTATOR	
B40812001-107	TERMINAL BOX	
B4154210003	ALTIMETER PRESSURE	
B43617-10-001	ALTITUDE INDICATOR	
B709-4	SENSOR SOBREVE	
B709-7	INDICADOR, TORQUEMET	
BA03600	AC GENERATOR	A330, A340
BA03603	A320 APU GENERATOR	A319, A321, A320
BA03603A	AC GENERATOR	A319, A321, A320
BA03604	A320 APU GENERATOR	A320-100, A320,A330
BA04103	APU GENERATOR	A330, A340
BA04104	APU GENERATOR	A330, A340
BA04105	APU GENERATOR	A330, A340
BA16501-01	AC APU GENERATOR	A330, A340
BACB30LE6-36	BOLT	
BH138XAH	CONTACTOR C.ALTERNA 50A	CN-235
BH185R-307	INDICATOR TEMPERATU	
BPF-5/8	COVER	



P/N	DESCRIPTION	AIRCRAFT PARTS
BPS7-3	BATTERY POWER SUPPLY	B747, B757, B767, B737,B777
C13070AA06	ELECTRONIC MODULE, ST	C-295, P3 ORION, P3 CONVERSION
C16298AA	TEMPERATURE IND	A330, A340
C17053FA02	COMPUTER AIR DATA	A330 MRTT, CN-235, C-295, P3 ORION
C23097-106	SHOCK ABSORBER	
C2536310002	INDICATOR TEMPERATU	
C2-96000-8	ACTUATOR, WINDSHIELD WIPER	A330, A340
C2-96100-8	MOTOR , WIPER, WINDSHI	S330, S340
C3495100084	SENSOR-OVERSPEED	CN-235
C4033E	PUMP-MOTOR OUTLET	C-212
C4154210003	INDICATOR TEMPERATU	
C450-000217	ARMATURE ASSY	
C5116-03	STARTER MOTOR TYPE C5116 SERIES	B747-400
C5116-04	STARTER MOTOR TYPE C5116 SERIES	B747-400
C5116-05	STARTER MOTOR TYPE C5116 SERIES	B747-400
C5116-06	STARTER MOTOR TYPE C5116 SERIES	B747-400
C5116-07	STARTER MOTOR TYPE C5116 SERIES	B747-400
C5116-08	STARTER MOTOR TYPE C5116 SERIES	B747-400
C5116-09	STARTER MOTOR TYPE C5116 SERIES	B747-400
C5116-10	STARTER MOTOR TYPE C5116 SERIES	B747-400
C5116-11	STARTER MOTOR TYPE C5116 SERIES	B747-400
C5120-1	STARTER MOTOR	A330, A340
C5120-2	STARTER MOTOR	A330, A340
C5120-3	STARTER MOTOR	A330, A340
C661063-0107	AIRSPEED INDICATOR	
CA.24200.1	PNEUDRALIC ACCUMULATOR 0.75 LITER	A330, A340
CA.24200.3	PNEUMATIC ACCUMULATOR 0.75 LITER	A330, A340
CA.24600.1	1/4 INCH HYDRAULIC RELIEF VALVE	A330, A340
CA.24600.3	1/4 INCH HYDRAULIC RELIEF VALVE	A330, A340
CA.24800.3	PRESELECTOR CE DIRECCION	A330, A340
CA.38800.1	MANUAL HYDRAULIC STOPCOCK	A330, A340
CA24200.3	PNEUDRALIC ACCUMULATOR 0.75 LITER	A330, A340
CA242001	PNEUDRALIC ACCUMULATOR 075 LITER	
CA242003	PNEUDRALIC ACCUMULATOR 075 LITER	
CA242-3	ACCUMULATOR	C-212
CA246	VALVE-1/4" RELEASING	
CA246001	1/4 INCH HYDRAULIC RELIEF VALVE	
CA24600-1	VALVE-1/4" RELEASING	C-212
CA246003	1/4 INCH HYDRAULIC RELIEF VALVE	
CA246-1E	VALVE-1/4" RELEASING	
CA248003	PRESELECTOR CE DIRECCION	
CA24800-3	PRESELECTOR-STEERI	C-212
CA388001	MANUAL HYDRAULIC STOPCOCK	
CA38800-1	VALVE	C-212
CA-B0614-0003	ORDENADOR,DIGITAL	CN-235
CP1200-2	CONTROL PENDANT	CN-235, C-295
CP3938AA02	COMMUTATEUR PRINCIPAL	
D102740	MOTOR TYPE 160-45-511	A330, A340
D105102	FUEL BOOSTER PUMP	A330, A340
D105300-4	ARMATURE	A330, A340
D107318	CENTRIFUGAL FUEL BOOSTER PUMP	A330, A340
D107318-14	ARMATURE	A330, A340
D107318D	CENTRIFUGAL FUEL BOOSTER PUMP	A330, A340
D107318D1	CENTRIFUGAL FUEL BOOSTER PUMP	A330, A340
D126111-501	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)



P/N	DESCRIPTION	AIRCRAFT PARTS
D126111-503	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
D1443-100A	COOLER, OIL	C-212, CN-235
D1443-32C	VALVE	C-212, CN-235
D1834	AIR COOLED OIL COOLER	A330, A340
D1834 SERIES	AIR COOLED OIL COOLER	A330, A340
D1834-100	OIL COOLER	A330, A340
D1834-100A	OIL COOLER	C-212
D1834-SERIES	OIL COOLER	A330, A340
D25050	GCU	CN-235
D25-050	G.C.U	A330, A340
D25-050	GCU	
D25-051	CONTROL-GENERATOR DC	C-212, CN-235, C-295
D455-07-001	ENGINE FIRE SHUT-OFF SWITCH	A330, A340
D455-08-001	ENGINE FIRE SHUT-OFF SWITCH	A330, A340
D5528000100551	ELEVATOR ASSY	
D6000-5	HYDRAULIC ACTUATOR WINDSHIELD WIPER	A330, A340
D717-01-001	EMERGENCY POWER SUPPLY	A330, A340
D717-02-001	EMERGENCY POWER SUPPLY	B737
D7-9	MOTOR	A330, A340
D94412	FAN	A330, A340
DL404-38	TRIPLE RPM INDICATOR	
DL412	INDICADOR DE NI	
DM ELT14-1-1	TRANSMITTER EMERGENCY LOCATOR	A330, A340
DMELT14-1-1	TRANSM-EMER LOCATOR	C-212, CN-235
DSI 421/106	DIRECT READING PRESSURE GAGE	A330, A340
DSI1421/106	INDICATOR	
DSI421/106	DIRECT READING PRESS	A330, A340
DSI-421/106	DIRECT READING PRESSURE GAGE	A330, A340
E2588M42	ARMATURE	
E709-01-001	CEILING LIGHT	B737, B757
E709-03-001	CEILING LIGHT	B737, B757
E709-04-001	CEILING LIGHT	B737, B757
EA1045-037-2	PUMP MOTOR HYD SYSTEM	C-130
EA148ANH95H	INDICATOR VERTICAL	
ECT130544-1NVG	CABIN AIR PRESSURE CONTROL UNIT	CN-235, C-295
ECT15-0015-15NVG	LIGHT-COCKPIT UTILITY	CN-235, C-295
ECT-185S157 NVG	INDICATOR, ATTITUDE	S330, S340
ECT185S157REV-C-NVG	INDICATOR, ATTITUDE	CN-235
ECT-SETL-OC420YNVG	INDICADOR CABIN	
ECT-SETL-OC420Y-NVG	IND. CABIN PRESSURE	CN-235, C-295
EM48-6	ELECTRIC MOTOR	CN-235/CN-295
EM48-6-1	ELECTRIC MOTOR	CN-235/CN-295
EM91-79	2 WAY 2 POSITION SHUTOFF BALL VALVE	B737, B757, B767
EM91-79-1	2 WAY 2 POSITION SHUTOFF BALL VALVE	B737, B757, B767
EM91-79-3	2 WAY 2 POSITION SHUTOFF BALL VALVE	B737, B757, B767
EM91-79-4	2 WAY 2 POSITION SHUTOFF BALL VALVE	B737, B757, B767
EM91-79-5	2 WAY 2 POSITION SHUTOFF BALL VALVE	B737, B757, B767, A310
EVCTA740C	FAN-RECIRCULATION	CN-235, C-295
EVT174-2	BRAKE COOLING FAN	A300, A310, A318, A319, A320
EVT174-2E	BRAKE COOLING FAN	A310, A318, A319, A320
EVT174-2E SERIES	BRAKE COOLING FAN	A300, A310, A318, A319, A320
EVT174-2E1	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E2	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E3	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E31	BRAKE COOLING FAN	A300, A310, A320



P/N	DESCRIPTION	AIRCRAFT PARTS
EVT174-2E31AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E31AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E31AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E3AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E3AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E3AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E4	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E41	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E41AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E41AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E41AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E4AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E4AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E4AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E5	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E51	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E51AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E51AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E51AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E5AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E5AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E5AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E6	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E6AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E6AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E6AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E7	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E7AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E7AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E7AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8AmdtABC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E9	BRAKE COOLING FAN	A300, A310, A320
EVT174-500E	BRAKE FAN MOTOR	A320, A310
EVT174-M	BRAKE COOLING FAN	A330, A340
EVT3454G	AVIONICS FAN	A319, A320, A321
EVT3454H	AVIONICS FAN	A330, A340
EVT3454HC	AVIONICS FAN	A330, A340
EVTA103	FAN	CN-235, C-295
EVTA103A	ELECTROFAN	CN-235
EVTA103B	TECHNOFAN	CN-235, C-296
F1001940-00	LED LOADING AREA LIGHT	A330, A340
F100940-00	LED LOADING AREA LIGHT	A330, A340
F11QB3121	TRANSFORMER - RECTIFIER	A300, A310, A300-600
F11QB3121-020	TRANSFORMER RECTIFIER	A330, A340
F11QY3121	TRANSFORMER - RECTIFIER	A300, A310, A300-600
F11QY3714	TRANSFORMER-RECTIFIER	A300, A310, A300-600
F34PB6224	FAN	A300
F34PB6224-019	STATOR	A330, A340
F34PC6224	FAN	A310
F34PC6224-012	STATOR WOUND	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
F62B0050M1	VALVE SOLENOID	
FC103063N2	CONTROL SELECTOR S	
FE174-004	DOOR DAMPER	A319, A320, A321
G4-1505-1429	LIGHT ANTI-COLLISION	ATR-42, ATR-72
G4710A19	LOGO LIGHT	C-212, CN-235
G5944	CONTROL INTERCOM	
G7490-33	FLIGHT ID/ATC/TCAS Control Panel	A330, A340
G8400A37-24	LIGHT	ATR
G-8400A-37-24	AIRCRAFT NAVIGATIONAL ROTATING WARNING LIGHT	A330, A340
G-8895-1	LANDING LIGHT	A330, A340
G-8895-4559	LANDING LIGHT	A330, A340
H10-56	HEADSET CABIN INTERCOMM	C-212, CN-235, C-295
H138JFM	GYRO HORIZON	
HTE920010	VALVE	C-212, CN-235, C-295
ID663B/U	INDICATOR, BEARING	
IFD9-464-40	INDICATOR, LIQUID QTY	
IPTE-27-1000-4000SG	TRANSMITTER-	S330, S340
IS15092A	ARMATURE	A330, A340
J1-150-27	PRESSURE HEAD	
K99-38-207	DEFUELLING ADAPTOR	A330, A340
L2889	SOLENOID, ELECTRICAL	
LM320SA12	BRACKET SIDE	C-212, CN-235
LM320-SA12	BRACKET-SIDE	
LM-320-SA12	FRONT SIDE MOUNTING ASSEMBLY	A330, A340
LM320SA13	BRACKET-ENGINE FRONT TOP	CN-235
LM-320-SA13	FRONT TOP MOUNTING ASSEMBLY	A330, A340
LM320SA14	BRACKET-UPPER	CN-235
LM320SA18	MOUNTING-REAR	CN-235
LM-320-SA18	FRONT LEFT AND RIGHT SIDE MOUNT BRACKET ASSEMBLY	A330, A340
LM320SA19	MOUNTING-REAR	CN-235, C-295
LM-320-SA19	MOUNTING-REAR	A330, A340
LT-100	DC TO DC CONVERTER	A330, A340
LT103	POWER SUPPLY	
LT-103	DC TO DC CONVERTER	A330, A340
LT52A	CONVERTER	C-212, CN-235, C-295
LT-52A	DC TO DC CONVERTER	A330, A340
LT-53	DC TO DC CONVERTER	A330, A340
LT53A	CONVERTER	
LT-70	DC TO DC CONVERTER	A330, A340
LT-73	DC TO DC CONVERTER	A330, A340
M4070-2	ACCELEROMETRO, MECANI	
M422M15	MOTOR ASSEMBLY	A330, A340
M422M15-1	MOTOR ASSEMBLY	A330, A340
M422M15-2	MOTOR ASSEMBLY	A330, A340
M729825C	INTEGRATED DRIVE GENERATOR	B757, B767
M732591	AIR COOLING FAN	A330, A340
M732591 SERIES	AIR COOLING FAN	A330, A340
M732591DF	FAN ASSEMBLY-AIR COOLING	B747, B767, DASH8
M762620C	VSCF	B777
M83383/04-10	CIRCUIT BREAKER	CN-235
M83383-04-10	CIRCUIT BREAKERS	CN-235
MF30-3913-30ZE5	MOTOR HYDRAULIC	C130
MGE23-400A	MOTOR-GENERATOR	C-130
MI585161	XMTR TRANSMITTER	



P/N	DESCRIPTION	AIRCRAFT PARTS
MK14LL	INDICATOR	A330, A340
MODEL 5318	ALTERNATING CURRENT GENERATOR	A330, A340
MPEV3-011-8UK2B	PUMP-HYDR.MOTOR DRIV	CN-235, C-295
MPEV3-011-8UK2C	PUMP-HYDR.MOTOR DRIV	CN-235, C-295
MPEV3-012-2B	HYDRAULIC PUMP	CRJ
MPEV3-032-2	PUMP HYD. MOTOR	C-130
MPEV3-032-2A	HYDRAULIC MOTORPUMP ASSEMBLY	C130
MS14218T4-12	REMACHE	
MS17401-1	ALTIMETER PRESSURE	
MS28008-1	INDICATOR, TEMPERATURE	
MS3452W14S-7S	CONECTOR RECEPTACULO	
N/A	WHEEL RIMS, SHOCK ABSORBERS, MOTOR HOUSINGS &	A330, A340
NB0075-2325	THERMAL CONTROLLER	CN-235
NC6-P-1A	ROTOR	
NTX138-100	VHF FM TRANSCEIVER	
P042823-2R	FIELD	A330, A340
P044147	FRAME ASSY	A330, A340
P044180	COMMUTATOR, BEARING	A330, A340
P044312	BEARING FLANGED	A330, A340
P044340-2R	FIELD	A330, A340
P044380	FIELD	A330, A340
P047070	FIELD	A330, A340
P055742-4	ARMATURE	A330, A340
P055742-7	ARMATURE	A330, A340
P057374A	EXCITER ROTOR	A330, A340
P11487	RELAY, ELECTROMAGNETIC	
P500383	FIELD	A330, A340
P500395	ARMATURE	A330, A340
P600365	HOUSING BEARING UNIT	A330, A340
P602457A	ROTOR	A330, A340
P602882	ARMATURE	A330, A340
P603245	STATOR	A310
P603531	BEARING, FLANGED	A330, A340
P603744A	ROTOR	
P604305-1	ARMATURE	A330, A340
P604305-2	ARMATURE	A330, A340
P604305-2R	ARMATURE	A330, A340
P604823-2	ARMATURE	A330, A340
P604823-3	ARMATURE	A330, A340
P604823-4	ARMATURE	A330, A340
P94C16-606	PUMP, FUEL	
P99C38-601	ENGINE FEED PUMP	A320, A321, A320-100, A319
P99C38-605	ENGINE FEED PUMP	A320, A321, A320-100, A319
PC250-1C	CONVERTER	C-212
PC-610	FUEL FLOW COMPUTER UNIT	A330, A340
PC610-0136	SIGNAL CONDIT UNIT	C-212
PC610-0172	FUEL FLOW COMPUTER UNIT	A330, A340
PC-610-SERIES	FUEL FLOW COMPUTER UNIT	A330, A340
PMP05VC040	MOTOR C7BBA. HID.	C-212
PMP3V-3-05	VARIABLE DELIVERY HYDRAULIC PUMP	B757,B767
PMP3V-3-06	VARIABLE DELIVERY HYDRAULIC PUMP	B757,B767
PMP3V-3-07	VARIABLE DELIVERY HYDRAULIC PUMP	B747,B757,B767,B777
PMP3V-3-08	VARIABLE DELIVERY HYDRAULIC PUMP	B747,B757,B767,B777
PTG9/16A	GEARBOX	
PTG9/16B	GEARBOX	



P/N	DESCRIPTION	AIRCRAFT PARTS
PV3-044-48	HYDRAULIC PUMP	CRJ,CRJ200
R1624-4	ROTARY ACTUATOR ASSEMBLY	A330, A340
R5294	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M2	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M2-1	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M2-2	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M4	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M4-2	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5303-3	ELECTROMECHANICAL LINEAR ACTUATOR	B727, B737
R5303-5	ELECTROMECHANICAL LINEAR ACTUATOR	B727, B737,DC10
R5303-51	ELECTROMECHANICAL LINEAR ACTUATOR	B727, B737,B777
R5320	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5320-1	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5320-12	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
RB56423	BRUSH	
RBC6	U.P.S. SALA FUSION	
RCS60-1L	INDICATOR AIR SPEED	
RG12240-1	CENTRIFUGAL FUEL BOOST PUMP	A330, A340
RG12240D	CENTRIFUGAL FUEL BOOST PUMP	A330, A340
RG56829	ARMATURE	A330, A340
RG56869	ARMATURE	A330, A340
RR12550A	ENGINE START PUMP INSTALLATION	DC-9, MD-80
RR54080A	CENTRIFUGAL FUEL BOOST PUMP	A330, A340
S231T260-1	INDICATOR PRESSURE OXYG	
S274T120-10	ANTISKID	B757, B767, B737
S369-100	ACCUMULATORS	A330, A340
S369-50	ACCUMULATORS	A330, A340
S417A501-609	CEILING LIGHT ASSEMBLY	B737
S417A501-610	CEILING LIGHT ASSEMBLY	B737
S417A501-611	CEILING LIGHT ASSEMBLY	B737
S417A501-612	CEILING LIGHT ASSEMBLY	B737
S417A501-613	CEILING LIGHT ASSEMBLY	B737
S417A501-614	CEILING LIGHT ASSEMBLY	B737
S417A501-615	CEILING LIGHT ASSEMBLY	B737
S417A501-616	CEILING LIGHT ASSEMBLY	B737
S417T102-1	WASTE SYSTEM VACUUM BLOWER	B777-200
S462-25	ACCUMULATORS	A330, A340
S462-50	ACCUMULATORS	A330, A340
S463-100	ACCUMULATORS	A330, A340
S463-50	ACCUMULATORS	A330, A340
S477-100	ACCUMULATORS	A330, A340
S477-200	ACCUMULATORS	A330, A340
S477-50	ACCUMULATORS	A330, A340
S512-25	ACCUMULATORS	A330, A340
S513-100	ACCUMULATORS	A330, A340
S-513-100-2	ACCUMULATOR, HYDRAULIC	C-130
S513-200	ACCUMULATORS	A330, A340
S513-50	ACCUMULATORS	A330, A340
S618-A	ACCUMULATORS	A330, A340
SA716961	PUMP, VAR. DISPLACEM ENT	
SAS261-019	FLUID PRESS REG VALVE	
SETL-OC420G	CABIN PRESSURIZATION INDICATOR	CN-235,B757
SLZ8122	INDICATOR, VERTICAL V	C-295
SLZ9028E	INDICADOR, ANGLE	P3 ORION, P3 CONVERSION



P/N	DESCRIPTION	AIRCRAFT PARTS
SLZ9028G	INDICATOR ANGLE	P3 ORION, P3 CONVERSION
SLZ9696	INDICATOR ANGLE	P3 ORION, P3 CONVERSION
SPC38B	INVERTER STATIC	
SPL5568-3	ACTUATOR, MECHANICAL	S330, S340
SPL5568-5	ACTUATOR, MECHANICAL	
SPL5569-3	FLAP BOST SENSOR LH	P3 ORION, P3 CONVERSION
SRD-9B	INDICATOR, PRESSURE	S330, S340
SRL0C7EM	INDICATOR HYD BRAKE PRSS	B737
SRL-0C7EM	INDICATOR	
SRL-0C7EM	HYDRAULIC PRESS IND	B737
SSD120-30A	ENCODER-DECODER, COM	S330, S340
ST104A	INDICATOR	C-130
ST-106AB	TRASNMITTER DUCT PRESSURE	B727, A300, B737, B747
ST107R	BRAKE PRESSURE TRANSMITTER	B737
ST-107R	HYDRAULIC PRESSURE TRANSMITTER	B737, B727, B767, B777
STM3758V08-4 / 7	REMACHE/PASADOR	
SYLZ50684	CONTROL BOX, ELECTRIC	C-130
TG 255-001	TACHOMETER GENERATOR	P3 ORION
TG 255-002	TACHOMETER GENERATOR	P3 ORION
TG 255-003	TACHOMETER GENERATOR	P3 ORION
TG 255-004	TACHOMETER GENERATOR	P3 ORION
TG 255-005	TACHOMETER GENERATOR	P3 ORION
TG 255-006	TACHOMETER GENERATOR	P3 ORION
TG 255-007	TACHOMETER GENERATOR	P3 ORION
TG 255-008	TACHOMETER GENERATOR	P3 ORION
TYPE200-CV	AUTOTRANSFORMADOR VARIABLE	A330, A340
V1-4360-2	HYD VALVE FUSE	B767
V2-4360-2	HYD VALVE FUSE	B767
VA4110	EXTRACTION FAN	A330, A340
VD3810	MIXED FLOW FAN	A330, A340
VD3820	MIXED FLOW FAN	A300, A300-600, A310, A318, A319, A320, A321, A330, A330F
VD3820-01	MIXED FLOW FAN	A300, A300-600, A310, A318, A319, A320, A321, A330, A330F
VD3820MOD1	MIXED FLOW FAN	A300, A300-600, A310, A318, A319, A320, A321, A330, A330F
VR3910	EXTRACTION FAN	A330, A340
VT442-2	WATER QUANTITY INDICATOR	A318, A319, A320, A321, A330, A340
VT442-2 AMENDT. A	WATER QUANTITY INDICATOR	A318, A319, A320, A321, A330, A340
WL 102AMS1	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL 102AMS2	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL 102AMS3	ALTIMETER AIRSPEED INDICATOR	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
WL 102AMS4	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL 102AMS5	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL 102AMS6	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL102AMS1	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300
WL102AMS2	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300,CRJ
WL102AMS3	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-
WL102AMS4	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300,CRJ
WL102AMS5	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-
WL102AMS6	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300,CRJ
WMETH100-27-1	SLANGSAMENTEL, GEL	A330, A340
X00142-401	CONTROL ELECTRICO	
Z212H0000110	CONTROL UNIT	A330, A340
Z212H0001110	CONTROL UNIT	A330, A340
Z212H0002110	CONTROL UNIT	A330, A340
Z212H0003110	CONTROL UNIT	A330, A340
Z212H0004110	CONTROL UNIT	A330, A340
Z212H0005110	CONTROL UNIT	A330, A340
Z212H0007110	CONTROL UNIT	A330, A340
Z212H0009110	CONTROL UNIT	A330, A340
Z212H0010110	CONTROL UNIT	A330, A340