



P/N	DESCRIPTION	AIRCRAFT PARTS
00-103552	STATOR	
00-200-1482	NUT, UPPER CARDAN	A320
00-200-1520	NUT, LOWER CARDAN	A320
00-200-611	HOSE ASSY., FLEXIBLE	A320
00-200-627	HOSE ASSY., FLEXIBLE	A320
021-922-001	AFORADOR	CN-235
021-922-011	GAGE-FUEL CONTENTS	CN-235
024147-000	Mainship Battery	
026101-11	DRIVE SHAFT	
02-6101-11	DRIVE SHAFT	
0304HRA/1	RADIOALTIMETRO	
03-1802-2001	ANTI COLLISION LIGHT	ATR,EMB
03-1802-2001-1	STROBE LIGHT	ATR-42, ATR-72,CRJ700
03-6101-13	DRIVE SHAFT	
04-1505-1429	STROBE LIGHT PS	ATR-72,EMB
0555-11	DC GEAR MOTOR	
0618910G	ADAPTER BELL OUTPUT BAL ASSY	
0623006D	ADAPTER BELL OUTPUT BAL ASSY	
064-01054-30	VHF COMMUNICATIONS TRANSCEIVERS	
064-1047-61	RECEIVER, TRANSMITTER	
06-5010-6500	ENGINE OIL SERVICE UNIT	CN-235
066-01066 SERIES	KDM 706 A DISTANCES MEASURING EQUIPMENT	
066-01067-0000	RADAR RECEIVER	
066-03063	KI227 ADF INDICATOR	
066-03063-SERIES	KI227 ADF INDICATOR	
066-1055-70	AUDIO SELECTOR PANEL AND INTERPHONE SYSTEM KMA 24H	
066-1093 SERIES	KDM 706 A DISTANCES MEASURING EQUIPMENT	
066-1093-30	DME INTERROGATOR	
066-1105-00	ADF RECEIVER	
066-3016-00	INDICADOR DE DISTANCIA	
066-3031-00	RADAR ALTIMETER INDICATOR	
066-3031-01	INDICATOR RADAR	C-212
066-3031-02	RADAR ALTIMETER INDICATOR	
066-3031-03	RADAR ALTIMETER INDICATOR	
066-3059-00	INDICATOR ADF	
069-1024	VHF NAV/COMM TRANSCEIVER	
069-1024-SERIES (KX155)	VHF NAV/COMM TRANSCEIVER	
069-1025	VHF NAV/COMM TRANSCEIVER	
069-1025-SERIES (KX165)	VHF NAV/COMM TRANSCEIVER	
0704-1-000/1	HIGH SPEED OVEN	
071-1377-01	NAV 1	
0711480-001	VALVE, SHUTOFF HYDRAULIC	A320, A340
0711480-003	VALVE, SHUTOFF HYDRAULIC	A320, A340
0711480-004	VALVE, SHUTOFF HYDRAULIC	A320, A340
0726150	REFUELLING UNIT	
0804-1-000/1	HIGH SPEED OVEN	
088256-04644	ACCUMULATOR	A320
08-8422-010	ACCUMULATOR, HYDRAULI	
1.241.078	INDICATOR HYDRAULIC PRESSURE	
10-0055	EMERGENCY EXIT LIGHT	EMB135
10-0055 SERIES	EMERGENCY EXIT LIGHT	
10-0055-1	EMERGENCY EXIT LIGHT	



P/N	DESCRIPTION	AIRCRAFT PARTS
10-0055-11	LIGHT, EMERGENCY	C-212, CN-235, C-295,Q400
10-0055-13	EMERGENCY EXIT LIGHT	
10-0055-15	EMERGENCY EXIT LIGHT	
10-0055-17	EMERGENCY EXIT LIGHT	
10-0055-19	EMERGENCY EXIT LIGHT	
10-0055-21	EMERGENCY EXIT LIGHT	
10-0055-23	EMERGENCY EXIT LIGHT	
10-0055-25	EMERGENCY EXIT LIGHT	
10-0055-3	LIGHT, EMERGENCY	C-212,EMB
10-0055-5	EMERGENCY EXIT LIGHT	
10-0055-7	EMERGENCY EXIT LIGHT	
10-0055-9	EMERGENCY EXIT LIGHT	
1-001-0102-0083	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-001-0102-0084	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-001-0102-0085	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-001-0102-0086	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-001-0102-0095	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-001-0102-0129	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-001-0102-0296	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-001-0102-1000	STATIC INVERTER	B737-300,400,500,600,700,700C,800 AND 900 AND 747-400 SERIES 757,767AND 777.
1-002-0102-0265	INVERTER ASSY-STATIC	
1-002-0102-0434	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-002-0102-0542	SERIES LIGHT DIMMER	
1-002-0102-0597	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-002-0102-0714	STATIC INVERTER	B737,B757,B777
1-002-0102-0742	SERIES LIGHT DIMMER	
1-002-0102-0780	STATIC INVERTERS	
1-002-0102-0781	SERIES LIGHT DIMMER	
1-002-0102-0784	SERIES LIGHT DIMMER	
1-002-0102-0811	SERIES LIGHT DIMMER	
1-002-0102-0812	SERIES LIGHT DIMMER	
1-002-0102-0813	SERIES LIGHT DIMMER	
1-002-0102-0814	SERIES LIGHT DIMMER	
1-002-0102-0815	SERIES LIGHT DIMMER	
1-002-0102-0816	SERIES LIGHT DIMMER	



P/N	DESCRIPTION	AIRCRAFT PARTS
1-002-0102-0817	SERIES LIGHT DIMMER	
1-002-0102-0818	SERIES LIGHT DIMMER	
1-002-0102-0824	SERIES LIGHT DIMMER	
1-002-0102-0901	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-002-0102-0912	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-002-0102-1000	STATIC INVERTER	B737,B777,B707, B727, B747, B757, B767
1-002-0102-1001	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-002-0102-1002	SERIES LIGHT DIMMER	CN-235
1-002-0102-1011	STATIC INVERTERS	
1-002-0102-1012	STATIC INVERTERS	
1-002-0102-1013	STATIC INVERTERS	
1-002-0102-1014	STATIC INVERTERS	
1-002-0102-1015	STATIC INVERTERS	
1-002-0102-1016	STATIC INVERTERS	CN-235, C-295, P3 ORION, P3 CONVERSION
1-002-0102-1017	STATIC INVERTERS	
1-002-0102-1018	STATIC INVERTERS	
1-002-0102-1019	STATIC INVERTERS	
1-002-0102-1020	STATIC INVERTERS	C-212, CN-235
1-002-0102-1021	STATIC INVERTERS	
1-002-0102-1022	STATIC INVERTERS	
1-002-0102-1023	STATIC INVERTERS	
1-002-0102-1024	STATIC INVERTERS	
1-002-0102-1025	STATIC INVERTERS	C-212, CN-235, C-295
1-002-0102-1027	STATIC INVERTERS	
1-002-0102-1028	STATIC INVERTERS	
1-002-0102-1029	STATIC INVERTERS	
1-002-0102-1030	STATIC INVERTERS	
1-002-0102-1031	STATIC INVERTERS	
1-002-0102-1032	STATIC INVERTERS	
1-002-0102-1033	STATIC INVERTERS	
1-002-0102-1034	STATIC INVERTERS	C-295
1-002-0102-1035	STATIC INVERTERS	C-295, P3 CONVERSION
1-002-0102-1036	STATIC INVERTERS	
1-002-0102-1037	STATIC INVERTERS	
1-002-0102-1038	STATIC INVERTERS	
1-002-0102-1039	STATIC INVERTERS	
1-002-0102-1040	STATIC INVERTERS	
1-002-0102-1041	STATIC INVERTERS	
1-002-0102-1179	SERIES LIGHT DIMMERS	
1-002-0102-1180	SERIES LIGHT DIMMERS	
1-002-0102-1229	SERIES LIGHT DIMMERS	
1-002-0102-1231	SERIES LIGHT DIMMERS	
1-002-0102-1233	SERIES LIGHT DIMMERS	
1-002-0102-1245	SERIES LIGHT DIMMERS	C-212, CN-235, C-295, P3 ORION, P3 CONVERSION
1-002-0102-1254	SERIES LIGHT DIMMERS	
1-002-0102-1342	SERIES LIGHT DIMMERS	



P/N	DESCRIPTION	AIRCRAFT PARTS
1-002-0102-1346	STATIC INVERTERS	
1-002-0102-1449	STATIC INVERTERS	
1-002-0102-1551	STATIC INVERTERS	
1-002-0102-1635	STATIC INVERTERS	
1-002-0102-1652	SERIES LIGHT DIMMER	
1-002-0102-1657	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-002-0102-2044	STATIC INVERTERS	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
1-002-0102-2090	STATIC INVERTER	B737-300,400,500,600,700,700C,800 AND 900, B747-400 SERIES,B757,B767,B777,B707, B727, B737, B747
10026-0000-02	FUEL QTY IND	ATR-72,ATR
10027-0000-01	FUEL QTY RP	ATR-72,DASH8
10037-0750	INDICATOR FUEL QUANTITY	B737
10037-0770	FUEL QTY INDICATOR	B737
10037-1000-0156	INDICATOR FUEL QTY	B737, B747,B757, B767
1005080-12-1	VALVE PRESSURE REDUCE RELIEF	DC-9, MD-80, MD-90,B737, B757
10079-01	LOAD SELECT CONTROL UNIT	B767-200, B300, B400, B737-300, B400, B500, B747-300
1008700 SERIES	CYLINDRAL HYD PRESS ACCUM	
1008700-4	ACCUMULATOR, HYDRAULIC	C-130
101-000-137	RECEIVER, RADIO	
10-100101-014	GEAR-NOSE LANDING	A340
10-100101-015	GEAR-NOSE LANDING	A340
10-100101-023	GEAR-NOSE LANDING	A340
10-100101-024	GEAR-NOSE LANDING	A340
10-100101-025	GEAR-NOSE LANDING	A340
10-100101-026	GEAR-NOSE LANDING	A340
10-100101-027	GEAR-NOSE LANDING	A340
10-100101-028	GEAR-NOSE LANDING	A340
10-100101-029	GEAR-NOSE LANDING	A340
10-100101-030	GEAR-NOSE LANDING	A340
10-100101-031	GEAR-NOSE LANDING	A340
10-100101-032	GEAR-NOSE LANDING	A340
10-100101-033	GEAR-NOSE LANDING	A340
10-100101-034	GEAR-NOSE LANDING	A340
10-100101-035	GEAR-NOSE LANDING	A340
10-100101-036	GEAR-NOSE LANDING	A340
10-100101-037	GEAR-NOSE LANDING	A340
10-100101-038	GEAR-NOSE LANDING	A340
10-100101-039	GEAR-NOSE LANDING	A340
10-100101-040	GEAR-NOSE LANDING	A340
10-100101-041	GEAR-NOSE LANDING	A340
10-100101-042	GEAR-NOSE LANDING	A340
10-100102	NOSE LANDING GEAR	A340
10-100102-001	NOSE LANDING GEAR (WV101)	A340
10-100102-002	NOSE LANDING GEAR (WV101)	A340
10-100102-003	NOSE LANDING GEAR (WV101)	A340
10-100102-004	NOSE LANDING GEAR (WV101)	A340
10-100102-005	NOSE LANDING GEAR (WV101)	A340
10-100102-006	NOSE LANDING GEAR (WV101)	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
10-100102-007	NOSE LANDING GEAR	A340
10-100103-000	GEAR-NOSE LANDING	A340
10-100103-001	GEAR-NOSE LANDING	A340
10-100103-002	GEAR-NOSE LANDING	A340
10-100103-003	GEAR-NOSE LANDING	A340
10-100103-004	GEAR-NOSE LANDING	A340
10-100103-005	GEAR-NOSE LANDING	A340
10-100103-006	GEAR-NOSE LANDING	A340
10-100103-007	GEAR-NOSE LANDING	A340
10-100103-008	GEAR-NOSE LANDING	A340
10-100103-009	GEAR-NOSE LANDING	A340
10-100103-010	GEAR-NOSE LANDING	A340
10-100103-011	GEAR-NOSE LANDING	A340
10-100103-012	GEAR-NOSE LANDING	A340
10-100103-013	GEAR-NOSE LANDING	A340
10-100103-014	GEAR-NOSE LANDING	A340
10-100103-015	GEAR-NOSE LANDING	A340
10-100103-016	GEAR-NOSE LANDING	A340
10-100103-017	GEAR-NOSE LANDING	A340
10-100103-018	GEAR-NOSE LANDING	A340
10-100103-019	GEAR-NOSE LANDING	A340
10-100103-020	GEAR-NOSE LANDING	A340
10-100103-021	GEAR-NOSE LANDING	A340
10-100103-022	GEAR-NOSE LANDING	A340
10-100103-023	GEAR-NOSE LANDING	A340
10-100103-024	GEAR-NOSE LANDING	A340
10-100103-025	GEAR-NOSE LANDING	A340
10-100103-026	GEAR-NOSE LANDING	A340
10-100201-012	LEG-NLG	A340
10-100201-013	LEG-NLG	A340
10-100201-020	NOSE LANDING GEAR LEG	A340
10-100201-021	NOSE LANDING GEAR LEG	A340
10-100201-022	NOSE LANDING GEAR LEG	A340
10-100201-023	NOSE LANDING GEAR LEG	A340
10-100201-024	NOSE LANDING GEAR LEG	A340
10-100201-025	NOSE LANDING GEAR LEG	A340
10-100201-026	NOSE LANDING GEAR LEG	A340
10-100201-027	NOSE LDG	A340
10-100201-028	NOSE LANDING GEAR LEG	A340
10-100201-029	NOSE LANDING GEAR LEG	A340
10-100201-030	LEG-NLG	A340
10-100201-031	LEG-NLG	A340
10-100201-032	LEG-NLG	A340
10-100202	NOSE LANDING GEAR LEG	A340
10-100202-001	NLG LEG (WV101)	A340
10-100202-002	NLG LEG (WV101)	A340
10-100202-003	NLG LEG (WV101)	A340
10-100202-004	NLG LEG (WV101)	A340
10-100202-005	NLG LEG	A340
10-100203-000	LEG-NLG	A340
10-100203-001	LEG-NLG	A340
10-100203-002	LEG-NLG	A340
10-100203-003	LEG-NLG	A340
10-100203-004	LEG-NLG	A340
10-100203-005	LEG-NLG	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
10-100203-006	LEG-NLG	A340
10-100203-007	LEG-NLG	A340
10-100203-008	LEG-NLG	A340
10-100203-009	LEG-NLG	A340
10-100203-010	LEG-NLG	A340
10-100203-011	LEG-NLG	A340
10-100203-012	LEG-NLG	A340
10-100203-013	LEG-NLG	A340
10-100203-014	LEG-NLG	A340
10-100203-015	LEG-NLG	A340
10-100203-016	LEG-NLG	A340
10-100203-017	LEG-NLG	A340
10-100203-018	LEG-NLG	A340
101003-04-01	MECHANISM ASSY	
10-100401-000	STEERING ACTUATOR	A340
10-100401-001	STEERING ACTUATOR	A340
10-100501	CHANGE OVER VALVE	A340
10-100501-001	CHANGE OVER VALVE	A340
10-100501-003	CHANGE OVER VALVE	A340
10-100501-004	CHANGE OVER VALVE	A340
10-100601	SHUT-OFF SWIVEL VALVE	A340
10-100601-000	SHUT-OFF VALVE	A340
10-100601-001	SHUT-OFF VALVE	A340
10-100802	LEG DRESSING	A340
10-100802-000	LEG DRESSING (WV101)	A340
10-100901	1M UPPER HARNESS	A340
10-100901-003	HARNESS, 1M UPPER	A340
10-100901-004	HARNESS, 1M UPPER	A340
10-100901-005	HARNESS, 1M UPPER	A340
10-101001	2M UPPER HARNESS	A340
10-101001-003	HARNESS, 2M UPPER	A340
10-101001-004	HARNESS, 2M UPPER	A340
10-101001-005	HARNESS, 2M UPPER	A340
10-101101	1M LOWER ELECTRICAL HARNESS	A340
10-101101-000	HARNESS, 1M LOWER ELECTRICAL	A340
10-1014-1	INTERIOR ILLUMINATED EMERGENCY EXIT SING	
10-1014-3	INTERIOR ILLUMINATED EMERGENCY EXIT SING	
10-1014-5	INTERIOR ILLUMINATED EMERGENCY EXIT SING	
10-1014-7	INTERIOR ILLUMINATED EMERGENCY EXIT SING	
10-101702-000	UPPER DRAG STAY	A340
10-101902	LOCK LINK	A340
10-101902-000	LOCK LINK	A340
10-102001-001	UNLOCKING ACTUATOR	A340
10-102101-000	DOWNLOCK SPRING	A340
10-102701-002	RETRACTION ACTUATOR ASSEMBLY	A340
10-102701-003	RETRACTION ACTUATOR ASSEMBLY	A340
10-102701-004	RETRACTION ACTUATOR ASSEMBLY	A340
10-102701-005	RETRACTION ACTUATOR ASSEMBLY	A340
10-103002	TOWING FITTING	A340
10-103002-000	TOW FITTING	A340
10-103002-001	TOW FITTING	A340
10-103301-003	HARNESS, NLG LEFT GS ANTENNA	A340
10-103301-004	HARNESS, NLG LEFT GS ANTENNA	A340
10-103501-003	HARNESS, NLG RIGHT GS ANTENNA	A340
10-103501-004	HARNESS, NLG RIGHT GS ANTENNA	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
10-104201	ELECTRICAL BOX	A340
10-104201-000	ELECTRICAL BOX	A340
10-104901	ELECTRICAL BOX	A340
10-104901-000	ELECTRICAL BOX	A340
1010530 SERIES	CYLINDRAL HYD PRESS ACCUM	
10-110105	CENTER LANDING GEAR	A340
10-110105-002	CENTER LANDING GEAR	A340
10-110105-003	CENTER LANDING GEAR	A340
10-110105-004	CENTER LANDING GEAR	A340
10-110105-005	CENTER LANDING GEAR	A340
10-110105-006	CENTER LANDING GEAR	A340
10-110105-007	CENTER LANDING GEAR	A340
10-110105-008	CENTER LANDING GEAR	A340
10-110105-009	CENTER LANDING GEAR	A340
10-110207	MAIN FITTING SHOCK ABSORBER, S	A340
10-110207-002	MAIN STRUT AND DRESSINGS	A340
10-110207-003	MAIN STRUT AND DRESSINGS	A340
10-110207-004	MAIN STRUT AND DRESSINGS	A340
10-110207-005	MAIN STRUT AND DRESSINGS	A340
10-110207-006	MAIN STRUT AND DRESSINGS	A340
10-110302	DRAG STAY COMPLETE	A340
10-110302-000	DRAG STAY COMPLETE	A340
10-110501-006	MAIN FITTING SHOCK ABSORBER	A340
10-110501-007	MAIN FITTING SHOCK ABSORBER	A340
10-110501-014	MAIN FITTING SHOCK ABSORBER	A340
10-110501-015	MAIN FITTING SHOCK ABSORBER	A340
10-110501-016	MAIN FITTING SHOCK ABSORBER	A340
10-110501-017	MAIN FITTING SHOCK ABSORBER	A340
10-110501-018	MAIN FITTING SHOCK ABSORBER	A340
10-110501-019	MAIN FITTING SHOCK ABSORBER	A340
10-110501-020	MAIN FITTING SHOCK ABSORBER	A340
10-110501-021	MAIN FITTING SHOCK ABSORBER	A340
10-110501-022	MAIN FITTING SHOCK ABSORBER	A340
10-110502-000	MAIN FITTING SHOCK ABSORBER	A340
10-110502-001	MAIN FITTING SHOCK ABSORBER	A340
10-110502-002	MAIN FITTING SHOCK ABSORBER	A340
10-110502-003	MAIN FITTING SHOCK ABSORBER	A340
10-110502-004	MAIN FITTING SHOCK ABSORBER	A340
10-110502-005	MAIN FITTING SHOCK ABSORBER	A340
10-110503	MAIN FITTING SHOCK ABSORBER ST	A340
10-110504	MAIN FITTING SHOCK ABSORBER	A340
10-110504-001	MAIN FITTING SHOCK ABSORBER	A340
10-110504-002	MAIN FITTING SHOCK ABSORBER	A340
10-110504-003	MAIN FITTING SHOCK ABS STRUCTU	A340
10-110504-004	MAIN FITTING SHOCK ABS STRUCTU	A340
10-110504-103	MAIN FITTING SHOCK ABS STRUCTU	A340
10-110504-104	MAIN FITTING SHOCK ABS STRUCTU	A340
10-110507	MAIN FITTING SHOCK ABSORBER ST	A340
10-110605	MAIN FITTING SHOCK ABSORBER DR	A340
10-110605-001	MAIN FITTING SHOCK ABS DRESSIN	A340
10-110605-002	MAIN FITTING SHOCK ABS DRESSIN	A340
10-110803	BOGIE BEAM DRESSING	A340
10-110803-000	BOGIE BEAM DRESSING	A340
10-110803-001	BOGIE BEAM DRESSING	A340
10-111102	LOCK LINK	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
10-111102-000	LOCK LINK	A340
10-111201-000	LOCK SPRING	A340
10-111301-002	ACTUATOR-UNLOCK,CLG	A340
10-111301-003	UNLOCK ACTUATOR	A340
10-111301-004	UNLOCK ACTUATOR	A340
10-111402	DRAG STAY DRESSING	A340
10-111402-000	DRAG STAY DRESSING	A340
10-111702	1M STRUT HARNESS	A340
10-111702-000	1M STRUT HARNESS	A340
10-111702-001	1M STRUT HARNESS	A340
10-111703	1M STRUT HARNESS	A340
10-111703-000	1M STRUT HARNESS	A340
10-111704	1M STRUT HARNESS	A340
10-111704-000	1M STRUT HARNESS	A340
10-111801	2M STRUT HARNESS	A340
10-111801-002	2M STRUT HARNESS	A340
10-111801-003	2M STRUT HARNESS	A340
10-111802	2M STRUT HARNESS	A340
10-111802-000	2M STRUT HARNESS	A340
10-111803	2M STRUT HARNESS	A340
10-111803-000	2M STRUT HARNESS	A340
10-111901-002	1M BOGIE HARNESS	A340
10-111901-003	1M BOGIE HARNESS	A340
10-111901-004	1M BOGIE HARNESS	A340
10-111901-005	1M BOGIE HARNESS	A340
10-111902-000	1M BOGIE HARNESS	A340
10-112001-001	2M BOGIE HARNESS	A340
10-112001-002	2M BOGIE HARNESS	A340
10-112001-003	2M BOGIE HARNESS	A340
10-112001-004	2M BOGIE HARNESS	A340
10-112002-000	2M BOGIE HARNESS	A340
10-112302	BOGIE AND DRESSING	A340
10-112302-000	BOGIE AND DRESSING	A340
10-112302-001	BOGIE AND DRESSING	A340
10-112302-002	BOGIE AND DRESSING	A340
10-112303	BOGIE AND DRESSING	A340
10-113001-001	RETRACTION ACTUATOR ASSY	A340
10-113001-002	RETRACTION ACTUATOR ASSEMBLY	A340
10-113001-003	RETRACTION ACTUATOR ASSEMBLY	A340
10-113001-004	RETRACTION ACTUATOR ASSEMBLY	A340
10-113001-005	RETRACTION ACTUATOR ASSEMBLY	A340
10-113101-011	CENTER LANDING GEAR LEG	A340
10-113101-012	CENTER LANDING GEAR LEG	A340
10-113101-028	CENTER LANDING GEAR LEG	A340
10-113101-029	CENTER LANDING GEAR LEG	A340
10-113101-030	CENTER LANDING GEAR LEG	A340
10-113101-031	CENTER LANDING GEAR LEG	A340
10-113101-032	CENTER LANDING GEAR LEG	A340
10-113101-033	CENTER LANDING GEAR LEG	A340
10-113101-034	CENTER LANDING GEAR LEG	A340
10-113101-035	CENTER LANDING GEAR LEG	A340
10-113101-036	CENTER LANDING GEAR LEG	A340
10-113101-037	CENTER LANDING GEAR LEG	A340
10-113101-038	CENTER LANDING GEAR LEG	A340
10-113101-039	CENTER LANDING GEAR LEG	A340





P/N	DESCRIPTION	AIRCRAFT PARTS
10-113101-040	CENTER LANDING GEAR LEG	A340
10-113101-041	CENTER LANDING GEAR LEG	A340
10-113101-042	CENTER LANDING GEAR LEG	A340
10-113101-043	CENTER LANDING GEAR LEG	A340
10-113101-044	CENTER LANDING GEAR LEG	A340
10-113101-045	CENTER LANDING GEAR LEG	A340
10-113101-046	CENTER LANDING GEAR LEG	A340
10-113101-047	CENTER LANDING GEAR LEG	A340
10-113101-048	CENTER LANDING GEAR LEG	A340
10-113101-049	CENTER LANDING GEAR LEG	A340
10-113101-050	CENTER LANDING GEAR LEG	A340
10-113101-051	CENTER LANDING GEAR LEG	A340
10-113101-052	CENTER LANDING GEAR LEG	A340
10-113101-053	CENTER LANDING GEAR LEG	A340
10-113101-054	CENTER LANDING GEAR LEG	A340
10-113101-055	CENTER LANDING GEAR LEG	A340
10-113101-056	CENTER LANDING GEAR LEG	A340
10-113101-057	CENTER LANDING GEAR LEG	A340
10-113101-058	CENTER LANDING GEAR LEG	A340
10-113102-003	CENTER LANDING GEAR LEG	A340
10-113102-004	CENTER LANDING GEAR LEG	A340
10-113102-020	CENTER LANDING GEAR LEG	A340
10-113102-021	CENTER LANDING GEAR LEG	A340
10-113102-022	CENTER LANDING GEAR LEG	A340
10-113102-023	CENTER LANDING GEAR LEG	A340
10-113102-024	CENTER LANDING GEAR LEG	A340
10-113102-025	CENTER LANDING GEAR LEG	A340
10-113102-026	CENTER LANDING GEAR LEG	A340
10-113102-027	CENTER LANDING GEAR LEG	A340
10-113102-028	CENTER LANDING GEAR LEG	A340
10-113102-029	CENTER LANDING GEAR LEG	A340
10-113102-030	CENTER LANDING GEAR LEG	A340
10-113102-031	CENTER LANDING GEAR LEG	A340
10-113102-032	CENTER LANDING GEAR LEG	A340
10-113102-033	CENTER LANDING GEAR LEG	A340
10-113102-034	CENTER LANDING GEAR LEG	A340
10-113102-035	CENTER LANDING GEAR LEG	A340
10-113102-036	CENTER LANDING GEAR LEG	A340
10-113102-037	CENTER LANDING GEAR LEG	A340
10-113102-038	CENTER LANDING GEAR LEG	A340
10-113102-039	CENTER LANDING GEAR LEG	A340
10-113102-040	CENTER LANDING GEAR LEG	A340
10-113102-041	CENTER LANDING GEAR LEG	A340
10-113102-042	CENTER LANDING GEAR LEG	A340
10-113102-043	CENTER LANDING GEAR LEG	A340
10-113102-044	CENTER LANDING GEAR LEG	A340
10-113102-045	CENTER LANDING GEAR LEG	A340
10-113102-046	CENTER LANDING GEAR LEG	A340
10-113102-047	CENTER LANDING GEAR LEG	A340
10-113102-048	CENTER LANDING GEAR LEG	A340
10-113102-049	CENTER LANDING GEAR LEG	A340
10-113102-050	CENTER LANDING GEAR LEG	A340
10-113105	CENTER LANDING GEAR LEG	A340
10-113105-002	CENTER LANDING GEAR LEG	A340
10-113105-003	CENTER LANDING GEAR LEG	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
10-113105-004	CENTER LANDING GEAR LEG	A340
10-113105-005	CENTER LANDING GEAR LEG	A340
10-113105-006	CENTER LANDING GEAR LEG	A340
10-113105-007	CENTER LANDING GEAR LEG	A340
10-113105-008	CENTER LANDING GEAR LEG	A340
10-113105-009	CENTER LANDING GEAR LEG	A340
10-113107-000	CENTER LANDING GEAR LEG	A340
10-113107-001	CENTER LANDING GEAR LEG	A340
10-113107-002	CENTER LANDING GEAR LEG	A340
10-113107-003	CENTER LANDING GEAR LEG	A340
10-113107-004	CENTER LANDING GEAR LEG	A340
10-113107-005	CENTER LANDING GEAR LEG	A340
10-113107-006	CENTER LANDING GEAR LEG	A340
10-113107-007	CENTER LANDING GEAR LEG	A340
10-113107-008	CENTER LANDING GEAR LEG	A340
10-113107-009	CENTER LANDING GEAR LEG	A340
10-113107-010	CENTER LANDING GEAR LEG	A340
10-113108-000	CENTER LANDING GEAR LEG	A340
10-113108-001	CENTER LANDING GEAR LEG	A340
10-113108-002	CENTER LANDING GEAR LEG	A340
10-113108-003	CENTER LANDING GEAR LEG	A340
10-113108-004	CENTER LANDING GEAR LEG	A340
10-113108-005	CENTER LANDING GEAR LEG	A340
10-113108-006	CENTER LANDING GEAR LEG	A340
10-113108-007	CENTER LANDING GEAR LEG	A340
10-113108-008	CENTER LANDING GEAR LEG	A340
10-113108-009	CENTER LANDING GEAR LEG	A340
10-113108-010	CENTER LANDING GEAR LEG	A340
10-1175	EMERGENCY EXIT LIGHT	
10-1175-1	EMERGENCY EXIT LIGHT	
10-1175-11	EMERGENCY EXIT LIGHT	
10-1175-13	EMERGENCY EXIT LIGHT	
10-1175-15	EMERGENCY EXIT LIGHT	
10-1175-17	EMERGENCY EXIT LIGHT	
10-1175-19	EMERGENCY EXIT LIGHT	
10-1175-21	EMERGENCY EXIT LIGHT	
10-1175-23	EMERGENCY EXIT LIGHT	
10-1175-25	EMERGENCY EXIT LIGHT	
10-1175-27	EMERGENCY EXIT LIGHT	
10-1175-29	EMERGENCY EXIT LIGHT	
10-1175-3	EMERGENCY EXIT LIGHT	
10-1175-31	EMERGENCY EXIT LIGHT	
10-1175-33	EMERGENCY EXIT LIGHT	
10-1175-35	EMERGENCY EXIT LIGHT	
10-1175-37	EMERGENCY EXIT LIGHT	
10-1175-39	EMERGENCY EXIT LIGHT	
10-1175-41	EMERGENCY EXIT LIGHT	
10-1175-43	EMERGENCY EXIT LIGHT	
10-1175-45	EMERGENCY EXIT LIGHT	
10-1175-47	EMERGENCY EXIT LIGHT	
10-1175-49	EMERGENCY EXIT LIGHT	
10-1175-5	EMERGENCY EXIT LIGHT	
10-1175-51	EMERGENCY EXIT LIGHT	
10-1175-53	EMERGENCY EXIT LIGHT	
10-1175-55	EMERGENCY EXIT LIGHT	



P/N	DESCRIPTION	AIRCRAFT PARTS
10-1175-57	EMERGENCY EXIT LIGHT	
10-1175-7	EMERGENCY EXIT LIGHT	
10-1175-9	EMERGENCY EXIT LIGHT	
10-118301	BOGIE PITCH TRIMMER ASSEMBLY	A340
10-118301-003	BOGIE PITCH TRIMMER	A340
10-118301-004	BOGIE PITCH TRIMMER	A340
10-118301-005	BOGIE PITCH TRIMMER	A340
10-118301-006	BOGIE PITCH TRIMMER	A340
10-118301-007	BOGIE PITCH TRIMMER	A340
10-118302	BOGIE PITCH TRIMMER ASSEMBLY	A340
10-118302-000	PITCH TRIMMER ASSEMBLY	A340
10-118501-003	PITCH TRIMMER MANIFOLD	A340
10-118501-004	PITCH TRIMMER MANIFOLD	A340
10-118501-005	PITCH TRIMMER MANIFOLD	A340
10-118501-006	PITCH TRIMMER MANIFOLD	A340
10-118502-000	PITCH TRIMMER MANIFOLD	A340
10-118801-001	1M DRAG STAY HARNESS	A340
10-118802-000	1M DRAG STAY HARNESS	A340
10-118901-001	2M DRAG STAY HARNESS	A340
10-118902-000	2M DRAG STAY HARNESS	A340
10-120102-025	GEAR-COMPLETE MAIN LANDING	A340
10-120102-026	GEAR-COMPLETE MAIN LANDING	A340
10-120102-027	GEAR-COMPLETE MAIN LANDING	A340
10-120102-028	GEAR-COMPLETE MAIN LANDING	A340
10-120102-029	GEAR-COMPLETE MAIN LANDING	A340
10-120102-030	GEAR-COMPLETE MAIN LANDING	A340
10-120102-031	GEAR-COMPLETE MAIN LANDING	A340
10-120102-032	GEAR-COMPLETE MAIN LANDING	A340
10-120102-033	GEAR-COMPLETE MAIN LANDING	A340
10-120102-034	GEAR-COMPLETE MAIN LANDING	A340
10-120102-035	GEAR-COMPLETE MAIN LANDING	A340
10-120102-036	GEAR-COMPLETE MAIN LANDING	A340
10-120102-037	GEAR-COMPLETE MAIN LANDING	A340
10-120102-038	GEAR-COMPLETE MAIN LANDING	A340
10-120102-039	GEAR-COMPLETE MAIN LANDING	A340
10-120102-040	GEAR-COMPLETE MAIN LANDING	A340
10-120102-041	GEAR-COMPLETE MAIN LANDING	A340
10-120102-042	GEAR-COMPLETE MAIN LANDING	A340
10-120102-043	GEAR-COMPLETE MAIN LANDING	A340
10-120102-044	GEAR-COMPLETE MAIN LANDING	A340
10-120102-045	GEAR-COMPLETE MAIN LANDING	A340
10-120102-046	GEAR-COMPLETE MAIN LANDING	A340
10-120102-047	GEAR-COMPLETE MAIN LANDING	A340
10-120102-048	GEAR-COMPLETE MAIN LANDING	A340
10-120102-049	GEAR-COMPLETE MAIN LANDING	A340
10-120102-050	GEAR-COMPLETE MAIN LANDING	A340
10-120102-051	GEAR-COMPLETE MAIN LANDING	A340
10-120103-013	MAIN LANDING GEAR COMPLETE	A340
10-120103-014	MAIN LANDING GEAR COMPLETE	A340
10-120103-015	MAIN LANDING GEAR COMPLETE	A340
10-120103-016	MAIN LANDING GEAR COMPLETE	A340
10-120103-017	MAIN LANDING GEAR COMPLETE	A340
10-120103-018	MAIN LANDING GEAR COMPLETE	A340
10-120103-019	MAIN LANDING GEAR COMPLETE	A340
10-120103-020	MAIN LANDING GEAR COMPLETE	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
10-120103-021	MAIN LANDING GEAR COMPLETE	A340
10-120103-022	MAIN LANDING GEAR COMPLETE	A340
10-120103-023	MAIN LANDING GEAR COMPLETE	A340
10-120103-024	LH MLG COMPLETE	A340
10-120103-025	MAIN LANDING GEAR COMPLETE	A340
10-120103-026	MAIN LANDING GEAR COMPLETE	A340
10-120103-027	MAIN LANDING GEAR COMPLETE	A340
10-120103-028	MAIN LANDING GEAR COMPLETE	A340
10-120103-029	MAIN LANDING GEAR COMPLETE	A340
10-120103-030	MAIN LANDING GEAR COMPLETE	A340
10-120103-031	MAIN LANDING GEAR COMPLETE	A340
10-120103-032	GEAR-COMPLETE MAIN LANDING	A340
10-120103-033	GEAR-COMPLETE MAIN LANDING	A340
10-120103-034	GEAR-COMPLETE MAIN LANDING	A340
10-120103-035	GEAR-COMPLETE MAIN LANDING	A340
10-120104	MLG COMPLETE,LH	A340
10-120104-000	MLG COMPLETE (LH)	A340
10-120104-001	MLG COMPLETE (LH)	A340
10-120104-002	MLG COMPLETE (LH)	A340
10-120203-013	MAIN LANDING GEAR COMPLETE	A340
10-120203-014	MAIN LANDING GEAR COMPLETE	A340
10-120203-015	MAIN LANDING GEAR COMPLETE	A340
10-120203-016	MAIN LANDING GEAR COMPLETE	A340
10-120203-017	MAIN LANDING GEAR COMPLETE	A340
10-120203-018	MAIN LANDING GEAR COMPLETE	A340
10-120203-019	MAIN LANDING GEAR COMPLETE	A340
10-120203-020	MAIN LANDING GEAR COMPLETE	A340
10-120203-021	MAIN LANDING GEAR COMPLETE	A340
10-120203-022	MAIN LANDING GEAR COMPLETE	A340
10-120203-023	MAIN LANDING GEAR COMPLETE	A340
10-120203-024	RH MLG COMPLETE	A340
10-120203-025	MAIN LANDING GEAR COMPLETE	A340
10-120203-026	MAIN LANDING GEAR COMPLETE	A340
10-120203-027	MAIN LANDING GEAR COMPLETE	A340
10-120203-028	MAIN LANDING GEAR COMPLETE	A340
10-120203-029	MAIN LANDING GEAR COMPLETE	A340
10-120203-030	MAIN LANDING GEAR COMPLETE	A340
10-120203-031	MAIN LANDING GEAR COMPLETE	A340
10-120204	MLG COMPLETE,RH	A340
10-120204-000	MLG COMPLETE (RH)	A340
10-120204-001	MLG COMPLETE (RH)	A340
10-120204-002	MLG COMPLETE (RH)	A340
10-120502-017	MAIN STRUT AND DRESSINGS	A340
10-120502-018	MAIN STRUT AND DRESSINGS	A340
10-120502-019	MAIN STRUT AND DRESSINGS	A340
10-120502-020	MAIN STRUT AND DRESSINGS	A340
10-120502-021	MAIN STRUT AND DRESSINGS	A340
10-120502-022	MAIN STRUT AND DRESSINGS	A340
10-120502-023	MAIN STRUT AND DRESSINGS	A340
10-120502-024	MAIN STRUT AND DRESSINGS	A340
10-120502-025	MAIN STRUT AND DRESSINGS	A340
10-120502-026	MAIN STRUT AND DRESSINGS	A340
10-120502-027	MAIN STRUT AND DRESSINGS	A340
10-120503-008	MAIN STRUT AND DRESSINGS	A340
10-120503-009	MAIN STRUT AND DRESSINGS	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
10-120503-010	MAIN STRUT AND DRESSINGS	A340
10-120503-011	MAIN STRUT AND DRESSINGS	A340
10-120503-012	MAIN STRUT AND DRESSINGS	A340
10-120503-013	MAIN STRUT AND DRESSINGS	A340
10-120503-014	MAIN STRUT AND DRESSINGS	A340
10-120503-015	MAIN STRUT AND DRESSINGS	A340
10-120503-016	MAIN STRUT AND DRESSINGS	A340
10-120503-017	MAIN STRUT AND DRESSINGS	A340
10-120503-018	MAIN STRUT AND DRESSINGS	A340
10-120504	LH MAIN STRUT AND DRESSINGS	A340
10-120504-000	MAIN STRUT & DRESSINGS (LH)	A340
10-120602-017	MAIN STRUT AND DRESSINGS	A340
10-120602-018	MAIN STRUT AND DRESSINGS	A340
10-120602-019	MAIN STRUT AND DRESSINGS	A340
10-120602-020	MAIN STRUT AND DRESSINGS	A340
10-120602-021	MAIN STRUT AND DRESSINGS	A340
10-120602-022	MAIN STRUT AND DRESSINGS	A340
10-120602-023	MAIN STRUT AND DRESSINGS	A340
10-120602-024	MAIN STRUT AND DRESSINGS	A340
10-120602-025	MAIN STRUT AND DRESSINGS	A340
10-120602-026	MAIN STRUT AND DRESSINGS	A340
10-120602-027	MAIN STRUT AND DRESSINGS	A340
10-120603-008	MAIN STRUT AND DRESSINGS	A340
10-120603-009	MAIN STRUT AND DRESSINGS	A340
10-120603-010	MAIN STRUT AND DRESSINGS	A340
10-120603-011	MAIN STRUT AND DRESSINGS	A340
10-120603-012	MAIN STRUT AND DRESSINGS	A340
10-120603-013	MAIN STRUT AND DRESSINGS	A340
10-120603-014	MAIN STRUT AND DRESSINGS	A340
10-120603-015	MAIN STRUT AND DRESSINGS	A340
10-120603-016	MAIN STRUT AND DRESSINGS	A340
10-120603-017	MAIN STRUT AND DRESSINGS	A340
10-120603-018	MAIN STRUT AND DRESSINGS	A340
10-120604	RH MAIN STRUT AND DRESSINGS	A340
10-120604-000	MAIN STRUT & DRESSINGS (RH)	A340
10-121103-002	SHOCK STRUT ASSEMBLY	A340
10-121103-003	SHOCK STRUT ASSEMBLY	A340
10-121103-004	SHOCK STRUT ASSEMBLY	A340
10-121302	BOGIE AND DRESSINGS	A340
10-121303	BOGIE AND DRESSINGS	A340
10-121304	BOGIE AND DRESSING	A340
10-121304-000	BOGIE & DRESSINGS	A340
10-121702-000	BOGIE ASSEMBLY	A340
10-121702-001	BOGIE ASSEMBLY	A340
10-121702-002	BOGIE ASSEMBLY	A340
10-121702-003	BOGIE ASSEMBLY	A340
10-121702-004	BOGIE ASSEMBLY	A340
10-121702-005	BOGIE ASSEMBLY	A340
10-121901	SIDE STAY COMPLETE	A340
10-121902	SIDE STAY COMPLETE	A340
10-121902-000	SIDE STAY COMPLETE (LH)	A340
10-121902-001	SIDE STAY COMPLETE (LH)	A340
10-122001	SIDE STAY COMPLETE	A340
10-122002	SIDE STAY COMPLETE	A340
10-122002-000	SIDE STAY COMPLETE (RH)	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
10-122002-001	SIDE STAY COMPLETE (RH)	A340
10-122102	SIDE STAY BASIC	A340
10-122102-000	SIDE STAY BASIC	A340
10-122102-001	SIDE STAY BASIC	A340
10-122301	LOCK LINK	A340
10-122301-000	LOCK LINK	A340
10-122301-001	LOCK LINK	A340
10-122901-001	BOGIE PITCH TRIMMER	A340
10-122902	MLG PITCH TRIMMER	A340
10-122902-000	MLG PITCH TRIMMER	A340
10-123101-001	ACTUATOR-RETRACTION	A340
10-123101-003	ACTUATOR-RETRACTION MLG	A340
10-123101-004	RETRACTION ACTUATOR ASSY	A330
10-124102	1M LEFT HAND ELECTRICAL HARNES	A340
10-124102-002	1M STRUT HARNESS (LH)	A340
10-124103	1M LEFT HAND ELECTRICAL HARNES	A340
10-124103-002	1M STRUT HARNESS (LH)	A340
10-124103-003	1M STRUT HARNESS (LH)	A340
10-124203	1M RIGHT HAND ELECTRICAL HARNE	A340
10-124203-003	1M STRUT HARNESS (RH)	A340
10-124204	1M RIGHT HAND ELECTRICAL HARNE	A340
10-124204-002	1M STRUT HARNESS (RH)	A340
10-124204-003	1M STRUT HARNESS (RH)	A340
10-124302	2M LEFT HAND ELECTRICAL HARNES	A340
10-124302-001	2M STRUT HARNESS (LH)	A340
10-124302-002	2M STRUT HARNESS (LH)	A340
10-124303	2M LEFT HAND ELECTRICAL HARNES	A340
10-124303-000	2M STRUT HARNESS (LH)	A340
10-124303-001	2M STRUT HARNESS (LH)	A340
10-124403	2M RIGHT HAND ELECTRICAL HARNE	A340
10-124403-001	2M STRUT HARNESS (RH)	A340
10-124403-002	2M STRUT HARNESS (RH)	A340
10-124404	2M RIGHT HAND ELECTRICAL HARNE	A340
10-124404-000	2M STRUT HARNESS (RH)	A340
10-124404-001	2M STRUT HARNESS (RH)	A340
10-124405	2M RIGHT HAND ELECTRICAL HANRE	A340
10-124405-000	2M STRUT HARNESS (RH)	A340
10-124501-000	1M BOGIE HARNESS	A340
10-124501-001	1M BOGIE HARNESS	A340
10-124501-002	1M BOGIE HARNESS	A340
10-124502-000	1M BOGIE HARNESS	A340
10-124701	2M ELECTRICAL HARNESS	A340
10-124701-000	2M BOGIE HARNESS	A340
10-124701-001	2M BOGIE HARNESS	A340
10-124701-002	2M BOGIE HARNESS	A340
10-124701-003	2M BOGIE HARNESS	A340
10-124702	2M ELECTRICAL HARNESS	A340
10-124702-000	2M BOGIE HARNESS	A340
10-1327-1	FLUORESCENT WINDOW LIGHT	B757, B737,DC8, DC9, MD80
10-1327-10	FLUORESCENT WINDOW LIGHT	B757, B737
10-1327-2	LIGHT ASSY	B757, B737,DC10, MD11
10-1327-3	LIGHT ASSY	B757, B737,B717, DC9, MD90
10-1327-4	FLUORESCENT WINDOW LIGHT	B757, B737
10-1327-7	FLUORESCENT WINDOW LIGHT	B757, B737
10-1327-8	FLUORESCENT WINDOW LIGHT	B757, B737



P/N	DESCRIPTION	AIRCRAFT PARTS
10-1327-9	FLUORESCENT WINDOW LIGHT	B757, B737
101-380096-1	MAIN LANDING GEAR BRAKE ASSEMBLY	
10-1733-1	FLUORESCENT WINDOW LIGHT	B-757-200,B-737-100, B-737-500, B-737-900, B-737-300, B-737-600, B-737-400, B-737-800, B-757-700,B-737-200, B-757-300,B757, B767
10-1733-2	FLUORESCENT WINDOW LIGHT	B-757-200,B-737-100, B-737-500, B-737-900, B-737-300, B-737-600, B-737-400, B-737-800, B-757-700,B-737-200, B-757-300,B757, B767
10-1733-3	FLUORESCENT WINDOW LIGHT	B-757-200,B-737-100, B-737-500, B-737-900, B-737-300, B-737-600, B-737-400, B-737-800, B-757-700,B-737-200, B-757-300,CRJ100
10-1733-4	FLUORESCENT WINDOW LIGHT	B-757-200,B-737-100, B-737-500, B-737-900, B-737-300, B-737-600, B-737-400, B-737-800, B-757-700,B-737-200, B-757-300
10-210101-001	GEAR-COMPLETE MAIN LANDING	A330
10-210101-002	GEAR-COMPLETE MAIN LANDING	A330
10-210101-003	MLG, COMPLETE LH	A330
10-210101-004	GEAR-COMPLETE MAIN LANDING	A330
10-210101-005	MLG, COMPLETE LH	A330
10-210101-006	MLG, COMPLETE LH	A330
10-210101-007	MLG, COMPLETE LH	A330
10-210101-008	MLG, COMPLETE LH	A330
10-210101-009	MLG, COMPLETE LH	A330
10-210101-010	MLG, COMPLETE LH	A330
10-210101-011	MLG, COMPLETE LH	A330
10-210101-012	MLG, COMPLETE LH	A330
10-210101-013	MLG, COMPLETE LH	A330
10-210101-014	MLG, COMPLETE LH	A330
10-210101-015	MLG, COMPLETE LH	A330
10-210201-001	GEAR-COMPLETE MAIN LANDING	A330
10-210201-002	GEAR-COMPLETE MAIN LANDING	A330
10-210201-003	MLG, COMPLETE RH	A330
10-210201-004	GEAR-COMPLETE MAIN LANDING	A330
10-210201-005	MLG, COMPLETE RH	A330
10-210201-006	MLG, COMPLETE RH	A330
10-210201-007	MLG, COMPLETE RH	A330
10-210201-008	MLG, COMPLETE RH	A330
10-210201-009	MLG, COMPLETE RH	A330
10-210201-010	MLG, COMPLETE RH	A330
10-210201-011	MLG, COMPLETE RH	A330
10-210201-012	MLG, COMPLETE RH	A330
10-210201-013	MLG, COMPLETE RH	A330
10-210201-014	MLG, COMPLETE RH	A330
10-210201-015	MLG, COMPLETE RH	A330
10-210501-001	MAIN STRUT AND DRESSINGS, LH	A330
10-210501-002	MAIN STRUT AND DRESSINGS, LH	A330
10-210501-003	MAIN STRUT AND DRESSINGS, LH	A330
10-210501-004	MAIN STRUT AND DRESSINGS, LH	A330
10-210501-005	MAIN STRUT AND DRESSINGS, LH	A330
10-210501-006	MAIN STRUT AND DRESSINGS, LH	A330
10-210501-007	MAIN STRUT AND DRESSINGS, LH	A330



P/N	DESCRIPTION	AIRCRAFT PARTS
10-210601-001	MAIN STRUT AND DRESSINGS, RH	A330
10-210601-002	MAIN STRUT AND DRESSINGS, RH	A330
10-210601-003	MAIN STRUT AND DRESSINGS, RH	A330
10-210601-004	MAIN STRUT AND DRESSINGS, RH	A330
10-210601-005	MAIN STRUT AND DRESSINGS, RH	A330
10-210601-006	MAIN STRUT AND DRESSINGS, RH	A330
10-210601-007	MAIN STRUT AND DRESSINGS, RH	A330
10-210901-001	SHOCK STRUT ASSEMBLY	A340
10-210901-002	SHOCK STRUT ASSEMBLY	A340
10-210901-003	SHOCK STRUT ASSEMBLY	A330
10-210901-004	SHOCK STRUT ASSEMBLY	A330
10-211301-001	ACTUATOR, MLG RETRACTION	A330
10-211501-001	BOGIE AND DRESSINGS, MLG	A330
10-211501-002	BOGIE AND DRESSINGS, MLG	A330
10-211501-004	BOGIE AND DRESSINGS, MLG	A330
10-211701-000	BOGIE ASSEMBLY	A330-300
10-211701-001	BOGIE ASSEMBLY	A330
10-211701-002	BOGIE ASSEMBLY	A330
10-211701-003	BOGIE ASSEMBLY	A330
10-211701-004	BOGIE ASSEMBLY	A330
10-211901-000	STAY, LH COMPLETE SIDE	A330
10-211901-001	STAY, LH COMPLETE SIDE	A330
10-212001-000	STAY, RH COMPLETE SIDE	A330
10-212001-001	STAY, RH COMPLETE SIDE	A330
10-212101-000	SIDE STAY BASIC	A340
10-212101-001	SIDE STAY BASIC	A330
10-212701-000	TRIMMER, MLG BOGIE PITCH	A330
10-212701-001	TRIMMER, MLG BOGIE PITCH	A330
10-212702-000	TRIMMER, MLG BOGIE PITCH	A330
10-212703-000	TRIMMER, MLG BOGIE PITCH	A330
10-212901-000	1M STRUT HARNESS	A330
10-213101-001	LEG HARNESS, 2M ELECTRICAL, LH	A330-300
1024-4	DIMMER CONTROL UNIT	B737,B747,B777
1024-4A	DIMMER CONTROL UNIT	B737,B747,B777
1024-4B	DIMMER CONTROL UNIT	B737,B747,B777
1024-4C	DIMMER CONTROL UNIT	B737,B747,B777
1034540	ACTUATOR ELECTRO-ME	
1034540-1	ROTARY ACTUATOR ASSEMBLY	C-130
103696-1	CABIN AIR PRESS OUTFLOW / SAFETY VALVE	
1037-0770	PRESELECTOR INDICATOR	
10-376501-000	SLEEVE ASSY-AXLE PROTECTIVE	
1055-82-0ZZ-A	V/UHF ANTENNA	
1056350	PRESSURE CONTROL VALVE	B737
10-60556-10	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-12	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-15	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-16	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-17	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-18	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-19	PUMP MOTOR PACKAGE	
10-60556-20	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-30	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60556-6	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
10-60599-1	HYDRAULIC PRIORITY RELIEF CART	B737
10-61213-1	LANDING GEAR SELECTOR VALVE ASSEMBLY	B-737





P/N	DESCRIPTION	AIRCRAFT PARTS
10-61329-31	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH BRUSHLESS MOTOR	B737
10-61329-32	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH BRUSHLESS MOTOR	B737
10-61329-37	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH BRUSHLESS MOTOR	B737
10-61329-38	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH BRUSHLESS MOTOR	B737
10-61329-39	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH BRUSHLESS MOTOR	B737
10-61329-40	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH BRUSHLESS MOTOR	B737
10-61329-41	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH BRUSHLESS MOTOR	B737
10-61329-42	WINDSHIELD WIPER MOTOR CONVERTER ASSEMBLY WITH BRUSHLESS MOTOR	B737
10-62204-17	ANTISKID VOLUMETRIC FUSE ASSEMBLY	B777-200
107-120	ARMATURE	
1103480-121	SEAT ELECTRONICS BOX	
1103860-120-02	SEAT ELECTRONIC BOX	
1-111-0102-0714	STATIC INVERTER	B737,B757,B777,B767
1112358	ROTOR	
1112359	ARMATURE ASSEMBLY	
1120-3	CYLINDER ASSEMBLY, AC	C-130
113A3943-1	TRACK ASSY-NO. 4	B-737
1140-0110	ROCKWELL-COLLINS	
1140-0110-SERIES	ROCKWELL-COLLINS	
114079001	ELECTRO-HYDRAULIC SELECTOR	A318
114079002	ELECTRO-HYDRAULIC SELECTORS	A318
114079005	ELECTRO-HYDRAULIC SELECTORS	A318
114079006	ELECTRO-HYDRAULIC SELECTORS	A318
114079009	ELECTRO-HYDRAULIC SELECTORS	A318
114079010	ELECTRO-HYDRAULIC SELECTORS	A318
114079012	ELECTRO-HYDRAULIC SELECTORS	A318
114079013	ELECTRO-HYDRAULIC SELECTORS	A318
114079014	ELECTRO-HYDRAULIC SELECTORS	A318
114079015	ELECTRO-HYDRAULIC SELECTORS	A318
114079016	SELECTOR-DOOR,ELECTRO-HYDRAULI	A318
114079017	ELECTRO-HYDRAULIC SELECTORS	A318
114079018	ELECTRO-HYDRAULIC SELECTORS	A318
114079019	ELECTRO-HYDRAULIC SELECTORS	A318
114087001	BYPASS VALVE	A318
114087002	BYPASS VALVE	A318
114087003	BYPASS VALVE	A318
114087004	BYPASS VALVE	A318
114087005	BYPASS VALVE	A318
114087006	BYPASS VALVE	A318
114087007	BYPASS VALVE	A318
114087008	VALVE, BYPASS	A318
114087009	BYPASS VALVE	A318
114087010	BYPASS VALVE	A318
114095001	MLG LOCK STAY ACTUATOR	A318
114095002	LOCK STAY ACTUATOR	A318
114095003	LOCK STAY ACTUATOR	A318
114095004	LOCK STAY ACT.	A318



P/N	DESCRIPTION	AIRCRAFT PARTS
114095004-010	ACTUATOR-LOCK STAY	A320/321
114122002	MLG DOOR ACTUATOR	
114122003	MLG DOOR ACTUATOR	
114122004	MLG DOOR ACTUATOR	
114122006	MLG DOOR ACTUATOR	
114122007	MLG DOOR ACTUATOR	
114122008	MLG DOOR ACTUATOR	
114122009	MLG DOOR ACTUATOR	
114122010	MLG DOOR ACTUATOR	
114122011	MLG DOOR ACTUATOR	
114122012	MLG DOOR ACTUATOR	
114122014	MLG DOOR ACTUATOR	
114193001	MLG RETRACTION ACTUATOR	A318
114193002	RETRACTION ACTUATOR	A318
114193003	RETRACTION ACTUATOR	A318
114193004	RETRACTION ACTUATOR	A318
114193005	RETRACTION ACTUATOR ASSY	A318
114193006	RETRACTION ACTUATOR	A318
114193007	RETRACTION ACTUATOR	A318
114193008	RETRACTION ACTUATOR	A318
114193009	RETRACTION ACTUATOR	A318
114193010	RETRACTION ACTUATOR	A318
114193601	PISTON ROD	A320
114193603	PISTON HEAD	A320
114193604	NUT,PISTON HEAD	A320
114193610	PIN	A320/321
114193612	SHAFT,LUBRICATING	A320
114193637	RETRACTION ACTUATOR-PIN	A320/321
114202001	STEERING CONTROL VALVE	A330
114202002	STEERING CONTROL VALVE	A330
114202003	STEERING CONTROL VALVE	A330
114256002	RETRACTION ACTUATOR	A330
114256002-010	RETRACTION ACTUATOR	A330
114256002-020	RETRACTION ACTUATOR	A330
114256002-030	RETRACTION ACTUATOR	A330
114256002-035	RETRACTION ACTUATOR	A330
114256002-040	RETRACTION ACTUATOR	A330
114256002-045	RETRACTION ACTUATOR	A330
114256002-055	MLG RETRACTION ACTUATOR	A330
114256003	RETRACTION ACTUATOR	A330
114256004	RETRACTION ACTUATOR	A330
114256004-000	RETRACTION ACTUATOR	A330
114256004-005	RETRACTION ACTUATOR	A330
114256004-010	RETRACTION ACTUATOR	A330
114256005	RETRACTION ACTUATOR	A330
114256320	CYLINDER	A340
114A7522-7	TRACK ASSY-MAIN, INBD SS 282.91	B-737
1152106-2	DC STARTER GENERATOR	Dash8
1152106-2 SERIES	DC STARTER GENERATOR	Dash8
1152106-3	STARTER GENERATOR	Dash8
1152106-3 SERIES	DC STARTER GENERATOR	CN-235, C-295, Dash8
1152106-X	DC STARTER GENERATOR	Dash8
115218	IND BATT DC AMMETER	
115220	INDICATOR AC VOLTMETER	
1152218-5	AC GENERATOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
1152218-6	AC GENERATOR	DHC-8-400
1152218-SERIES	AC GENERATOR	Dash8
1152218-X	AC GENERATOR	Dash8
115230	INDICATOR CABIN TEMPERATURE	
1152400-2	APU STARTER GENERATOR ASSEMBLY	Dash8
1152400-2 SERIES 1	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-3	APU STARTER GENERATOR ASSEMBLY	Dash8
1152400-3 SERIES 1	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-4	APU STARTER GENERATOR ASSEMBLY	Dash8
1152400-4 SERIES 1	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-4 SERIES 2	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-5	APU STARTER GENERATOR ASSEMBLY	Dash8
1152400-5 SERIES 1	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-5 SERIES 1, SERIES 2	APU SARTER GENERATOR ASSEMBLY	
1152400-5 SERIES 2	APU STARTER GENERATOR ASSEMBLY	DHC-8-402Q
1152400-X	APU STARTER GENERATOR ASSEMBLY	Dash8
1153-1	ELECTRIC MOTOR	
115A297	AMMETER	CN-235
115A5260-1	FUSE PIN - TRUNNION SUPP - FWD	
11-6537-1	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-300, B-737-600, B-737, B-737-400, B-737-800, B-737-700, B-757-300,EMB
11-6537-3	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-300, B-737-600, B-737, B-737-400, B-737-800, B-737-700, B-757-300,B727
11-6537-5	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-300, B-737-600, B-737, B-737-400, B-737-800, B-737-700, B-757-300,B727
11-6537-7	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-300, B-737-600, B-737, B-737-400, B-737-800, B-737-700, B-757-300,B727, B737
11-6537-9	PASSENGER SERVICE UNIT CIRCUIT CARD ASSEMBLY	B-757-200,B-737-500, B-737-900, B-737-300, B-737-600, B-737, B-737-400, B-737-800, B-737-700, B-757-300,B737
1185237	AUDIO PANEL CONTROL	
121-1001	STATOR	
1211179-003	ACTUATOR	
1211180-004	ACTUATOR	
121210-3	SCREW	B727, A300
122-4508	FIELD ASSEMBLY	
122-6607	ARMATURE	
122723-SERIES	FUEL BOOST PUMP	
124.1006-1	IND-ENGINE OIL TEM/PRES	
124.1007-1	IND PROP OIL TEM/PRESS	
124.1078	INDICATOR HYDRAULIC PRESSURE	
124.833	DC VOLTMETER	
124536	FUEL CONTROL UNIT	
124536 SERIES	FUEL CONTROL UNIT	
124833	DC VOLTMETER	
12507G-13	HEADSET ELECTRICAL	
1251-1	MOTOR	
1251-2	MOTOR	
126.177	INDICATOR, GAS GENERATOR SPEED	



P/N	DESCRIPTION	AIRCRAFT PARTS
126.178	INDICATOR, PROPELLER RPM	
126.179-1	INDICATOR, INTER-TURBINE TEMPERATURE	
126.179-2	INDICATOR, INTER-TURBINE TEMPERATURE	
126177	INDICATOR GAS GENERATOR SPEED	
126178	INDICATOR PROPELLER RPM	
126-178	INDICATOR NP	CN-235, C-295
1272	INDICATOR, HEIGHT	
1272-2700	INDICATOR, HEIGHT	
128182	PRESSURE SENSOR	
1303-1	STARTER	A330, A340, B767
1303-2	STARTER	A330, A340, B767
1303-3	STARTER	A330, A340, B767
130544-1	CONTROL, FREQUENCY SET	CN-235
1316200-3	BRAKE METERING VALVE	B737,B757
1321M39P02	STATOR ALTERNATOR	
133-255	DISC, BRAKE	
1338-1450	PRESSURE TRANSDUCER	A318
1386112-4	STATOR	
140180-01-01	GYROSWITCH, RATE	
1404001-1	SPRING-STRUT, MLG UPLOCK	A330
1404020-1	SPRING-STRUT ASSY,MLG UPLOCK	A330
141A6105-1	PASSENGER DOOR SNUBBER ASSEMBLY	B737
141A6105-11	PASSENGER DOOR SNUBBER ASSEMBLY	B737
141A6105-12	PASSENGER DOOR SNUBBER ASSEMBLY	B737
141A6105-2	PASSENGER DOOR SNUBBER ASSEMBLY	B737
141A6105-3	PASSENGER DOOR SNUBBER ASSEMBLY	B737
141A6105-6	PASSENGER DOOR SNUBBER ASSEMBLY	B737
141A6105-7	PASSENGER DOOR SNUBBER ASSEMBLY	B737
14300-010	MOTOR PUMP FILTER ASSEMBLY	A320
14300-061	HOUSING AND STATOR ASSY WITH CONNECTOR LEADS	
14300-084	MOTOR PUMP FILTER ASSEMBLY	A320
14300-092	MOTOR PUMP FILTER ASSEMBLY	A320
14300-136	MOTOR PUMP FILTER ASSEMBLY	
14300-137	MOTOR PUMP FILTER ASSEMBLY	A320
14330-350	VACCUM GENERATOR ASSEMBLY	A318, A319, A320, A321
14401-085	WATER SEPARATOR	
14403-003	LIQUID LEVEL TRANSMITTER	A318, A319, A320, A321
14403-003A	LIQUID LEVEL TRANSMITTER	A318, A319, A320, A321
14403-003B	LIQUID LEVEL TRANSMITTER	A318, A319, A320, A321
14403-003C	LIQUID LEVEL TRANSMITTER	A318, A319, A320, A321
14403-085	LIQUID LEVEL SENSOR	A320
14403-125	Liquid level sensor	
14-40605-09	PISTON LANDING GEAR STRUT	
14-41607-3	CYLINDER PISTON ASSY LANDING GEAR	
1462	BALLAST UNIT	
1473M38G18	MANIFOLD	
147831A2	OIL TEMP	
15-0007-1	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-101	COCKPIT UTILITY LIGHT	B717, DC-9, MD-90
15-0007-103	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-105	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-107	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-109	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-11	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-111	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90



P/N	DESCRIPTION	AIRCRAFT PARTS
15-0007-113	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-115	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-117	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-119	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-121	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-123	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-125	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-127	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-129	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-13	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-131	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-133	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-135	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-137	LIGHT ASSY, COCKPIT	A300, B717, DC-9, MD-90, B757
15-0007-15	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-17	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-19	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-21	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-23	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-25	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-27	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-29	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-3	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-31	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-33	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-35	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-37	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-39	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-41	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-43	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-45	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-47	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-49	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-5	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-51	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-53	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-55	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-57	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-59	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-61	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-63	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-65	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-67	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-69	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-7	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-71	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-73	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-75	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-77	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-79	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-81	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-83	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-85	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-87	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-89	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90



P/N	DESCRIPTION	AIRCRAFT PARTS
15-0007-9	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-91	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-93	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-95	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-97	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
15-0007-99	COCKPIT UTILITY LIGHT	A300, B717, DC-9, MD-90
150015-15	LIGHT COCKPIT UTILITY	
15-0015-15	LIGHT COCKPIT	CN-235
15-0069	SPOTLIGHT	
15-0069-1	SPOTLIGHT	B727, B737
15-0069-13	SPOTLIGHT	B737
15-0069-17	SPOTLIGHT	B747, B737
15-0069-19	SPOTLIGHT	B737
15-0069-21	SPOTLIGHT	B737
15-0069-23	SPOTLIGHT	B737
15-0069-25	SPOTLIGHT	B737
15-0069-3	SPOTLIGHT	B727, B737
15-0069-5	SPOTLIGHT	B727, B737
150SG	STARTER GENERATOR	
150SG SERIES	STARTER GENERATOR	
150SG1064	ARMATURE	
150SG1073	PLATE DAMPENER	
150SG1103-7	DRIVE SHAFT	
150SG1156	STATOR SUB-ASSY	
150SG117Q	STARTER GENERATOR	
150SG122Q	STARTER GENERATOR	
15100-101	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-1051	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-1071	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-1091	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-1111	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-1131	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-1151	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-1161	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-1171	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-131	CENTERLINE GEAR SHOCK STRUT DR	A340
15100-141	CENTERLINE GEAR SHOCK STRUT DR	A340
15101-101	CENTERLINE GEAR SHOCK STRUT AS	A340
15101-1031	CENTERLINE GEAR SHOCK STRUT AS	A340
15101-1041	CENTERLINE GEAR SHOCK STRUT AS	A340
15101-1051	CENTERLINE GEAR SHOCK STRUT AS	A340
15101-1071	CENTERLINE GEAR SHOCK STRUT AS	A340
15101-1091	CENTERLINE GEAR SHOCK STRUT AS	A340
15101-1111	CENTERLINE GEAR SHOCK STRUT AS	A340
15101-1121	CENTERLINE GEAR SHOCK STRUT AS	A340
15101-1131	CENTERLINE GEAR SHOCK STRUT AS	A340
15101-121	CENTERLINE GEAR SHOCK STRUT AS	A340
15105-101	CENTERLINE GEAR SHOCK STRUT DR	A340
15105-1051	CENTERLINE GEAR SHOCK STRUT DR	A340
15105-1071	CENTERLINE GEAR SHOCK STRUT DR	A340
15105-1091	CENTERLINE GEAR SHOCK STRUT DR	A340
15105-1111	CENTERLINE GEAR SHOCK STRUT DR	A340
15105-1131	CENTERLINE GEAR SHOCK STRUT DR	A340
15105-1151	CENTERLINE GEAR SHOCK STRUT DR	A340
15105-1161	CENTERLINE GEAR SHOCK STRUT DR	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
15105-1171	CENTERLINE GEAR SHOCK STRUT DR	A340
15105-131	CENTERLINE GEAR SHOCK STRUT DR	A340
15105-141	CENTERLINE GEAR SHOCK STRUT DR	A340
1523200-3	ACTUATOR NOSE GEAR	
1531428-2	EXCITER ROTOR	
1531442-2	ROTOR	
1531442-3	ROTOR ASSEMBLY	
1532269	STATOR	
1532362-3	EXCITER STATOR	
1546-1-1	DIMMER LIGHT CONTROL	B757, B767
1546-1-2	DIMMER LIGHT CONTROL	B767
1546-1-3	DIMMER LIGHT CONTROL	B767,B757
1546-1-4	DIMMER LIGHT CONTROL	B757
1546-1-5	DIMMER LIGHT CONTROL	B757
1546-1-5 MOD A	DIMMER LIGHT CONTROL	
1546-1-5A	DIMMER LIGHT CONTROL	
1546-1-6	DIMMER CONTROL	B757
1546-1-6 MOD A	DIMMER LIGHT CONTROL	B757
1546-1-6A	DIMMER LIGHT CONTROL	
1546-1-SERIES	DIMMER LIGHT CONTROL	B737, B757, B767
1547143-1	EXC. STATOR	
1547154-1	STATOR C.W.	
1547162-1	EXC. ROTOR	
1547750-1	STATOR R.W.	
1549583-1	END BELL ASSY	
15500-1011	CLG RETRACTION ACTUATOR	A340
15500-103	CLG RETRACTION ACTUATOR	A340
15500-1031	CLG RETRACTION ACTUATOR	A340
15500-1051	CLG RETRACTION ACTUATOR	A330/340
1571589-1	ROTOR	C130
15809889-1	STATOR	
1581594-1	STATOR	
1582363-1	STATOR	
1583816-2	ROTOR	
1583827-1	HOUSING	
15840-1	AIR/OIL COOLER	C-212
15840-3	AIR/OIL COOLER	C-212
1589889-1	STATOR ASSEMBLY GENERATOR	C-130
160SG1103-3	DRIVE SHAFT	
161A1100-10	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-100	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-13	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-14	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-15	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-16	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-19	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-20	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-23	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-24	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-27	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-28	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-31	LH MLG ASSY	B737
161A1100-32	RH MLG ASSY	B737
161A1100-35	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-36	MAIN LANDING GEAR COMPONENT IN	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
161A1100-39	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-40	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-41	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-42	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-45	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-46	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-49	MAIN LANDING GEAR	B737
161A1100-5	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-50	MAIN LANDING GEAR	B737
161A1100-53	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-54	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-6	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-63	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-64	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-67	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-68	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-71	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-72	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-75	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-76	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-83	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-84	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-87	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-88	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-9	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-91	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-92	MAIN LANDING GEAR COMPONENT IN	B737
161A1100-99	MAIN LANDING GEAR COMPONENT IN	B737
161A1130-1	AXLE MLG	B737NG
161A1130-2	AXLE MLG	B737NG
161A1130-3	AXLE MLG	B737NG
161A1130-4	AXLE MLG	B737NG
161A1130-7	AXLE MLG	B737NG
161A1130-8	AXLE MLG	B737NG
161A2128-2	MAIN LANDING GEAR INSTALLATION	B737
161A2128-2	MAIN LANDING GEAR INSTALLATION	B737
161A7000-11	MLG WALKING BEAM	B737
161A7000-12	MLG WALKING BEAM	B737
161A7000-3	MLG WALKING BEAM	B737
161A7000-4	MLG WALKING BEAM	B737
161A7100-1	NLG WALKING BEAM	B737
161A7100-10	MLG WALKING BEAM	B737
161A7100-12	MLG WALKING BEAM	B737
161A7100-2	MLG WALKING BEAM	B737
161A7100-3	MLG WALKING BEAM	B737
161A7100-4	MLG WALKING BEAM	B737
161A7100-5	MLG WALKING BEAM	B737
161A7100-6	MLG WALKING BEAM	B737
161A7100-7	MLG WALKING BEAM	B737
161A7100-8	MLG WALKING BEAM	B737
161A7100-9	MLG WALKING BEAM	B737
161A7119-1	MLG WALKING BEAM	B737
161A7301-1	MLG WALKING BEAM	B737
161A7301-2	MLG WALKING BEAM	B737
161A7303-1	MLG WALKING BEAM	B737





P/N	DESCRIPTION	AIRCRAFT PARTS
161A7304-1	MLG WALKING BEAM	B737
161A7304-2	MLG WALKING BEAM	B737
161A7304-3	MLG WALKING BEAM	B737
161N0001-115	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-116	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-136	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-147	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-148	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-54	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161N0001-55	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
161T6005-4	SPINDLE	B767
161W1160-1	AXLE MLG	B777
161W1160-12	AXLE MLG	B777
161W1160-5	AXLE MLG	B777
161W1160-6	AXLE MLG	B777
161W1162-11	AXLE MLG	B777
161W1162-13	AXLE MLG	B777
161W1162-14	AXLE MLG	B777
161W1162-5	AXLE MLG	B777
161W1162-7	AXLE MLG	B777
161W1163-1	AXLE MLG	B777
161W1163-13	AXLE MLG	B777
161W1163-14	AXLE MLG	B777
161W1163-15	AXLE MLG	B777
161W1163-17	AXLE MLG	B777
161W1163-19	AXLE MLG	B777
161W1163-21	AXLE MLG	B777
161W1163-22	AXLE MLG	B777
161W1163-3	AXLE MLG	B777
161W1163-4	AXLE MLG	B777
161W1163-5	AXLE MLG	B777
161W1163-7	AXLE MLG	B777
161W1163-9	AXLE MLG	B777
161W2160-1	AXLE MLG	B777
161W2160-3	AXLE MLG	B777
161W2160-4	AXLE MLG	B777
161W2162-3	AXLE MLG	B777
1627608-1	TOGGLE	
162A0301-1	LH TRUNNION PIN ASSEMBLY	B737
162A0301-3	LH TRUNNION PIN ASSEMBLY	B737
162A0301-301	LH TRUNNION PIN ASSEMBLY	B737
162A0302-1	RH TRUNNION PIN ASSEMBLY	B737
162A0302-3	RH TRUNNION PIN ASSEMBLY	B737
162A0302-301	RH TRUNNION PIN ASSEMBLY	B737
162A0303-1	SPACER-TRUNNION	B737
162A0303-2	SPACE-TRUNNION	B737
162A0303-3	SPACER-TRUNNION	B737
162A0303-301	SPACER-TRUNNION	B737
162A0303-302	SPACER-TRUNNION	B737
162A0303-303	SPACER-TRUNNION	B737
162A0303-304	SPACER-TRUNNION	B737
162A0303-307	SPACE-TRUNNION	B737
162A0303-308	SPACE-TRUNNION	B737
162A0303-309	SPACE-TRUNNION	B737
162A0303-310	SPACER-TRUNNION	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
162A0303-311	SPACER-TRUNNION	B737
162A0303-4	SPACER-TRUNNION	B737
162A0303-5	SPACER-TRUNNION	B737
162A0303-6	SPACER-TRUNNION	B737
162A0303-7	SPACER-TRUNNION	B737
162A0303-8	SPACER-TRUNNION	B737
162A0303-9	SPACER-TRUNNION	B737
162A1100-10	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-11	NLG ASSY	B737
162A1100-12	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-13	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-14	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-15	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-16	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-17	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-301	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-302	NOSE LANDING GEAR COMPONENT I	B737
162A1100-4	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-5	NOSE LANDING GEAR	B737
162A1100-6	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-7	NOSE LANDING GEAR COMPOINENT I	B737
162A1100-8	NOSE LANDING GEAR COMPONENT IN	B737
162A1100-9	NOSE LANDING GEAR COMPONENT IN	B737
162A1404-3	COLLAR	B737
162A1404-4	COLLAR	
162A2118-1	LOCK LINK SHAFT	B737
162A2118-2	LOCK LINK SHAFT	B737
162A2118-301	LOCK LINK SHAFT	B737
162A2301-1	NOSE LANDING	B737
162A2301-3	NOSE LANDING	B737
162A2301-301	NOSE LANDING	B737
162A2301-302	NOSE LANDING	B737
162A2302-1	NOSE LANDING	B737
162A2302-3	NOSE LANDING	B737
162A2302-301	NOSE LANDING	B737
162A2302-302	NOSE LANDING	B737
162A2304-1	WASHER	B737
162A2304-301	WASHER	B737
162A2305-1	NUT	B737
162A2305-301	NUT	B737
162B203F	INDICATOR TEMPERATURE	
162B243	INDICATOR OIL TEMPERATURE	C-212
162B2G	TEMPERATURE	
162B3F	INDICATOR OIL	
162B48	INDICATOR TEMPERATURE	C-212
162BL SERIES	ELECTRICAL RESISTANCE THERMOMETER INDICA	
162BL602	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL701	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727, B707
162BL701A	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B727, B707, B737
162BL702	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B727, B707, B737
162BL703	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B727, B707, B737
162BL704	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704A	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704C	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704D	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727



P/N	DESCRIPTION	AIRCRAFT PARTS
162BL704F	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704H	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704K	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL704L	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737
162BL704N	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL802	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727, B747
162BL802A	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727, MD80
162BL803	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
162BL803A	ELECTRICAL RESISTANCE THERMOMETER INDICATORS	B737, B727
1646-1-6	DIMMABLE FLUORESCENT LAMP CONTROLLER	B737
1646-1-6 MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-6 MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-6A	FLUORESCENT LAMP CPNTROLLER	
1646-1-6B	FLUORESCENT LAMP CPNTROLLER	
1646-1-6MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-7	FLUORESCENT LAMP CONTROL	B737
1646-1-7 MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-7 MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	
1646-1-7A	FLUORESCENT LAMP CPNTROLLER	
1646-1-7B	FLUORESCENT LAMP CPNTROLLER	
1646-1-7MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	
16M002-5	DRIVE UNIT HYDRAULIC	
16M002-815	DRIVE UNIT HYDRAULIC	
16M002-821	DRIVE UNIT HYDRAULIC	
1700089	ROTOR BALANCE ASSEMBLY	B777, B767-400
1700089 SERIES	ROTOR BALANCE ASSEMBLY	B777, B767-400
1700089A	ROTOR BALANCE ASSEMBLY	B777, B767-400
1700089B	ROTOR BALANCE ASSEMBLY	B777, B767-400
1700586	VSCF GEN	B777
1701317	INTEGRATED DRIVE GENERATOR	CRJ700, CRJ900, CRJ1000, EMB170/EMB190
1701317A	INTEGRATED DRIVE GENERATOR	CRJ700, CRJ900, CRJ1000, EMB170/EMB190
1701320	GENERATOR ASSEMBLY	CRJ700/900, ERJ 170/190
1701320B	GENERATOR ASSEMBLY	CRJ700/900, ERJ 170/190
1701320C	GENERATOR ASSEMBLY	CRJ700/900, ERJ 170/190
1701410	ROTOR BALANCE ASSEMBLY	
1701410 SERIES	ROTOR BALANCE ASSEMBLY	
1701410A	ROTOR BALANCE ASSEMBLY	
1701422	ROTOR BALANCE ASSEMBLY	
1701422 SERIES	ROTOR	
1701422A	ROTOR	B737
1701469	PMG AND SUPPORT ASSEMBLY	
1701482	STATOR	
1701483	STATOR ASSEMBLY	B757, A310
1701487	STATOR ASSEMBLY-PMG	
1701766	VSCF GEN	B777
1701768	VSCF GEN	B777
1701863	ROTOR BALANCE ASSEMBLY	
1702369	EXCITER ROTOR ASSEMBLY	
1702370	EXCITER ROTOR ASSEMBLY	
1702377	ROTOR ASSEMBLY, EXCITER	
1702690	STATOR ASSEMBLY - AC GENERATOR	
1702711	STATOR ASSEMBLY, ALTERNATING CURRENT	A320
1702713	STATOR ASSEMBLY, EXCITER	B757, A310



P/N	DESCRIPTION	AIRCRAFT PARTS
1702714	STATOR ASSEMBLY - MAIN GENERATOR	
1702715	STATOR ASSEMBLY, GENERATOR	
1702719	STATOR	
1702719A	STATOR	
1702726	STATOR ASSEMBLY - EXCITER	
1702733	EXCITER ROTOR ASSEMBLY	
1703381-01	DIODE PACK	
1703938	DEAERATOR	
1704-1-000/1	HIGH SPEED OVEN	
1704600-1	VALVE PRESSURE REDUCING 8	B737,B747
1706903	INTEGRATED DRIVE GENERATOR	A318, A319, A320, A321, A340
1706907	ROTOR BALANCE ASSEMBLY	B737
1708054A	DIODE PACKAGE ASSEMBLY	
1708897	INTEGRATED DRIVE GENERATOR	A318, A319, A320, A321, A340
1708899	ROTOR BALANCE ASSEMBLY	B737
1708899A	ROTOR BALANCE ASSEMBLY	B737
1709121	IDG	A320
171001-30	PLACA, CIRCUITOS C	
1718201	IDG	A319 NEO, A320 NEO, A321 NEO
1718205	IDG	A319 NEO, A320 NEO, A321 NEO
171851-01	PCU	
1721000	EXCITER STATOR HOUSING ASSEMBLY	
1721000A	EXCITER STATOR HOUSING ASSEMBLY	
173227-502	VIDEO DISTRIBUTION BOX	
173595-02	DISPLAY	
1784389-653	COMPASS, GYROSYN	
1784460-656	RMI COMPASS INDICATOR	B727, DC-8, DC-9, MD-80
179120-2	STARTER MOTOR	T-62T-47C1, T62T-46C1, 46C2, 46C2A, 46C3, 46C3A, 46C7, 46C7A, 46C14, 46C16
179120-3	STARTER MOTOR	B707, B717, B723, B737
17TE165	P.D.D.UNIT	CN-235
1804-1-000/1	HIGH SPEED OVEN	
18-1299-6	FLAP POSITION INDICATOR	B727, B737
181RA71R206C	CARGO- POWERED DRIVE UNITS	B767
1820M55P01	STATOR ASSEMBLY	
18282G-02	HEADSET ELECTRICAL	CN-235, C-295
18300-1001	CLG DRAG STAY DRESSED	A340
18300-1021	CLG DRAG STAY DRESSED	A340
18300-1041	CLG DRAG STAY DRESSED	A340
183990-0001	CONTROL UNIT, COCKPI	
185689	MOTOR HYDRAULIC	
1904-1-1	BALLAST	
1905A0000-01	VALVE SAFETY	A318
1914-1-1	BALLAST	
1942T100-1	SENSOR CABINA	
19689	TRANSDUCER	
1A081-0155-1	TOILET FLUSH	B737,B757
1A081-0155-11	FLUSH TIMER SWITCH	B737,B757
1A3000-1A-HR	INVERTER POWER	
1B0712	PERMANENT MAGNET ALTERNATOR	
1B7997	PERMANENT MAGNET ALTERNATOR	
1FA01134-1	VALVE SELECTOR RETRACTION/EXTENSION CONTROL, LANDING GEAR	
1FA01134-2	SELECTOR VALVE	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
1FA14012-6	ACTUATOR, THRUST REVERSER COWL OPENING	B737
1FA14012-7	ACTUATOR, THRUST REVERSER COWL OPENING	B737
1FA14012-8	ACTUATOR, THRUST REVERSER COWL OPENING	B737
1G390	SWITCH	
1U1084	DOOR OPERATED GEAR VALVE	B737
1U1085	DOOR LOCK OPERATED SEQUENCE VA	B737
1U1169	TAIL SKID ACTUATOR	B737
1U1243-1	GRAVEL DEFLECTOR ACTUATOR	B737
1U1243-2	GRAVEL DEFLECTOR ACTUATOR	B737
1X2005097-00	LOGO LIGHT	A320
200-01062	INDICATOR TEMP	
2000866-1	MOTOR-STARTER	A320
2000866-2	MOTOR-STARTER	A320
2000866-3	MOTOR-STARTER	A320
2000866-4	MOTOR-STARTER	A320
20032-2	AC GENERATOR	ATR-72,B737
20033	ALTERNATEUR	
200SG1064	ARMATURE	
200SG1103-9	DRIVE SHAFT	
200SGL	STARTER GENERATOR	
200SGL SERIES	STARTER GENERATOR	
200SGL111Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL111Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL111Q-3	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL112Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL114Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL115Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL115Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL117Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE



P/N	DESCRIPTION	AIRCRAFT PARTS
200SGL118Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL120Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL121Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL124Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(1)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(3)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(4)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(5)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q(8)	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL129Q1	STARTER GENERATOR	
200SGL130Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL131Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL131Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE



P/N	DESCRIPTION	AIRCRAFT PARTS
200SGL131Q-5	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q-3	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q-4	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL132Q-5	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL142Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL144Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL145Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL147Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL147Q-2	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL147Q-3	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
200SGL151Q	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE



P/N	DESCRIPTION	AIRCRAFT PARTS
200SGL-SERIES	STARTER GENERATOR	HUGHES 530, SIKORSKY S76, SAC-180, PILATUS PC-7, EMB110, CESSNA 208, PILATUS PC-9, BELL 206, BELL 230, AGUSTA A129, CHEYENNE
20101420	AUTOBRAKE ASSEMBLY VALVE MODULE	B-757, B-767
20101420-001	AUTOBRAKE ASSEMBLY VALVE MODULE	B-757, B-767
20101420-002	AUTOBRAKE ASSEMBLY VALVE MODULE	B-757, B-767
20101420-003	AUTOBRAKE ASSEMBLY VALVE MODULE	B-757, B-767
20101420-004	AUTO BRAKE VALVE MODULE	B757, B767
20101420-005	AUTOBRAKE ASSEMBLY VALVE MODULE	B-757, B-767
20101420-006	AUTOBRAKE ASSEMBLY VALVE MODULE	B-757, B-767
20101420-007	MODULE ASSY, VALVE	B757, B767
20102060-101	AUTOBRAKE ASSEMBLY VALVE MODULE	B-737, B-747
20102060-102	AUTOBRAKE ASSEMBLY VALVE MODULE	B-737, B-747
20102060-103	MODULE	B747, B747-400, B737
201042017	HOSE ASSY HYDRAULIC	A320
201042106	AFT PINTLE SPHERICAL BEARING	A320
201042176	HOSE ASSEMBLY	A330/340
201042177	HOSE ASSEMBLY	A330/340
201042178	HOSE ASSEMBLY	A330
201042180	HOSE ASSEMBLY	A330
201042193	HOSE ASSEMBLY	A330
201042194	HOSE ASSEMBLY	A330/340
201042195	HOSE ASSY	A330
201042197	HOSE ASSEMBLY	A330/340
201042198	HOSE ASSY	A330/340
201042201	HOSE ASSEMBLY	A320
201042203	HOSE ASSY	A330/340
201042298	HOSE ASSEMBLY	A330
201042322	HOSE ASSY	A330/340
201042538	DELAY VALVE	A330
201042559	DELAY VALVE	A330
201042561	DELAY VALVE	A330
201042565	AFT PINTLE SPHERICAL BEARING	A330
201042569	HARNESS-MAIN STRUT, LH, 1M	A330
201042570	HARNESS-MAIN STRUT, RH, 1M	A330
201042575	MAIN STRUT & BALANCE HARNESS	A330
201042576	MAIN STRUT WEIGHT & BALANCE HA	A330
201042577	MAIN STRUT WEIGHT & BALANCE HA	A330
201042578	MAIN STRUT WEIGHT & BALANCE HA	A330
201042579	HARNESS, ELECTRICAL, 1M	A330
201042580	HARNESS-ELECTRICAL, 2M	A330
201042587	HARNESS-ELECTRICAL, 1M	A330
201042588	HARNESS-ELECTRICAL, 2M	A330
201042589	HARNESS-MAIN STRUT, LH, 2M	A330
201042590	HARNESS-MAIN STRUT, RH, 2M	A330
201056909	PIN, LOCK STAY CARDAN	A320
201057306	TRIANGULATION LINK	A320
201057611	UPPER PIN (SPRINGS)	A320
201057623	CUFF PIN	A320
201057624	TRIANGULATION LINK PIN	A320
201057625	LOWER PIN (SPRINGS)	A320
201057627	LOCK LINK LOWER PIN	A320
201057634	CUFF	A320
201057644	PIN (LOCK LINK/BANANA LINK)	A320





P/N	DESCRIPTION	AIRCRAFT PARTS
201058001	LOCK STAY	A318
201058002	LOCK STAY	A318
201058003	LOCK STAY	B737
201058304	LOCK STAY CARDAN	A320
201058305	LOWER LOCK LINK	A320
201058306	LOCK STAY CARDAN	A320
201058310	UPPER LOCK LINK	A320
201058608	PIN, LOCK LINK CENTER	A320
201058611	PIN,UPPER LOCK LINK	A320
201059001	LOCK SPRING	A318
201122009	DOOR UPLOCK	A318
201134007	HARNESSES - MAIN LANDING GEAR	A318
201134008	HARNESSES - MAIN LANDING GEAR	A318
201134015	IHARNESSES - MAIN LANDING GEAR	A318
201134016	HARNESSES - MAIN LANDING GEAR	A318
201158001	HANRESSES - MAIN LANDING GEAR	A318
201158002	HARNESSES - MAIN LANDING GEAR	A318
201158003	HARNESSES - MAIN LANDING GEAR	A318
201158004	HARNESSES - MAIN LANDING GEAR	A318
201158007	HARNESSES - MAIN LANDING GEAR	A318
201158008	HARNESSES - MAIN LANDING GEAR	A318
201159001	HARNESSES - MAIN LANDING GEAR	A318
201159002	HARNESSES - MAIN LANDING GEAR	A318
201159003	HARNESSES - MAIN LANDING GEAR	A318
201159004	HARNESSES - MAIN LANDING GEAR	A318
201159007	HARNESSES - MAIN LANDING GEAR	A318
201159008	HARNESSES - MAIN LANDING GEAR	A318
2011600-1	ARMATURE	
2011600-2	ARMATURE	
201160300	MAIN FITTING -LH	A320
201160301	MAIN FITTING (RH)	A320
201160302	SLIDING TUBE	A320
201160304	CARDAN BRACKET (LH)	A320
201160305	Cardan Bracker (RH)	A320
201160325	LOWER TORQUE LINK	A320
201160330	MAIN FITTING (RH)	A320
201160331	MAIN FITTING (LH)	A320
201160332	MAIN FITTING (RH)	A320
201160601	TORQUE LINK APEX	A320
201160602	LOWER TORQUE LINK PIN	A320
201160603	UPPER TORQUE LINK PIN	A320
201160681	TORQUE LINK APEX PIN	A320
201160689	Upper Torque Link	A320
201160690	UPPER TORQUE LINK	A320
201160697	TORQUE LINK APEX PIN	A320
201160700	TOQUE LINK APEX PIN NUT	A320
201160702	FORWARD PINTLE PIN LOCK BOLT	A320
201161001	DRESSING-MLG	A318
201161002	DRESSING-MLG	A318
201161003	DRESSING-MLG	A318
201161004	DRESSING-MLG	A318
201161005	LH MLG DRESSINGS	A320
201161006	RH MLG DRESSING	A320
201161007	DRESSING-MLG	A318
201161008	DRESSING-MLG	A318



P/N	DESCRIPTION	AIRCRAFT PARTS
201161009	LH MLG DRESSING	A320
201161010	RH MLG DRESSINGS	A320
201161011	DRESSING-MLG	A318
201161012	DRESSING-MLG	A318
201161013	DRESSING-MLG	A318
201161014	DRESSING-MLG	A318
201161015	DRESSING-MLG	A318
201161016	DRESSING-MLG	A318
201161616	BRACKET,LH	A320
201163001	BASIC SIDE STAY	B737
201163002	BASIC SIDE STAY	B737
201163003	BASIC SIDE STAY	B737
201163004	BASIC SIDE STAY	B737
201163300	UPPER SIDE STAY	A320
201163301	LOWER SIDE STAY	A320
201163305	UPPER CARDAN	A320
201163307	LOWER CARDAN	A320
201163309	CUFF	A320
201163605	UPPER CARDAN	A320
201163608	SIDE STAY LOWER CARDAN PIN	A320
201163609	SIDE STAY PIVOT PIN	A320
201163618	SIDE STAY UPPER CARDAN PIN	A320
201163619	SIDE STAY LOWER CARDAN PIN	A320
201163620	UPPER CARDAN	A320
201163948	UPPER CARDAN	A320
201163949	UPPER CARDAN	A320
201166001	SIDE STAY	A318
201166002	SIDE STAY	A318
201166003	SIDE STAY	A318
201166004	SIDE STAY	A318
201166005	SIDE STAY	A318
201166006	SIDE STAY	A318
201166007	SIDE STAY	A318
201166008	SIDE STAY	A318
201166009	SIDE STAY	A318
201166010	SIDE STAY	A318
201166011	SIDE STAY	A318
201166012	SIDE STAY	A318
201166013	SIDE STAY COMPLETE	B737
201166013-020	LH MLG SIDE STAY ASSY	A320
201166014	SIDE STAY COMPLETE	B737
201168007	HARNESSES - MAIN LANDING GEAR	A318
201168008	HARNESSES - MAIN LANDING GEAR	A318
201168014	HARNESSES - MAIN LANDING GEAR	A318
201168015	HARNESSES - MAIN LANDING GEAR	A318
201168018	HARNESSES - MAIN LANDING GEAR	A318
201168019	HARNESSES - MAIN LANDING GEAR	A318
201168020	HARNESSES - MAIN LANDING GEAR	A318
201168021	HARNESSES - MAIN LANDING GEAR	A318
201168022	HARNESSES - MAIN LANDING GEAR	A318
201172712	CABLE BONDING	A320
201173600	PIN, FWD PINTLE	A320
2012-1	CHARGER	B757, B767, B737,A318, A321
201252001	MAIN LANDING GEAR COMPLETE	A340
201252002	MAIN LANDING GEAR COMPLETE	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
201252003	MAIN LANDING GEAR COMPLETE	A330
201252004	MAIN LANDING GEAR COMPLETE	A330
201252005	MAIN LANDING GEAR COMPLETE	A330
201252006	MAIN LANDING GEAR COMPLETE	A330
201252007	MAIN LANDING GEAR COMPLETE	A330
201252008	MAIN LANDING GEAR COMPLETE	A330
201252009	MAIN LANDING GEAR COMPLETE	A330
201252010	MAIN LANDING GEAR COMPLETE	A330
201252011	MAIN LANDING GEAR COMPLETE	A330
201252012	MAIN LANDING GEAR COMPLETE	A330
201252013	MAIN LANDING GEAR COMPLETE	A330
201252014	MAIN LANDING GEAR COMPLETE	A330
201252015	MAIN LANDING GEAR COMPLETE	A330
201252016	MAIN LANDING GEAR COMPLETE	A330
201252017	MAIN LANDING GEAR COMPLETE	A330
201252018	MAIN LANDING GEAR COMPLETE	A330
201252019	MAIN LANDING GEAR COMPLETE	A340
201252020	MAIN LANDING GEAR COMPLETE	A340
201252021	LH MAIN LANDING GEAR	A330
201252022	RH MAIN LANDING GEAR	A330
201252023	MAIN LANDING GEAR COMPLETE	A330
201252024	MAIN LANDING GEAR COMPLETE	A330
201252025	MAIN LANDING GEAR COMPLETE	A330
201252026	MAIN LANDING GEAR COMPLETE	A330
201252027	MAIN LANDING GEAR COMPLETE	A330
201252028	MAIN LANDING GEAR COMPLETE	A330
201252029	MAIN LANDING GEAR COMPLETE	A330
201252030	MAIN LANDING GEAR COMPLETE	A330
201252031	MAIN LANDING GEAR COMPLETE	A330
201252032	MAIN LANDING GEAR COMPLETE	A330
201252033	MAIN LANDING GEAR COMPLETE	A330
201252034	MAIN LANDING GEAR COMPLETE	A330
201252035	MAIN LANDING GEAR COMPLETE	A330
201252036	MAIN LANDING GEAR COMPLETE	A330
201269699	TORQUE LINK APEX PIN NUT	A330
201270730	RECOIL NUT	A330
201272001	BOFIE ASSEMBLY	A330
201272003	BOGIE ASSEMBLY	A330
201272004	BOGIE ASSEMBLY	A330
201272248	BOGIE BEAM AND AXLE SUBASSEMBL	A330
201272300	BOGIE BEAM	A330
201272302	BOGIE BEAM	A330
201272304	BOGIE BEAM	A330
201272305	BEAM, BOGIE	A330
201272306	BEAM, BOGIE	A330
201272307	BEAM, BOGIE	A330
201272308	BEAM, BOGIE	A330
201272309	BEAM, BOGIE	A330
201272649	WHEEL AXLE	A330
201275895	LOCK BOLT, FWD PINTLE PIN	A330
201355610	UPPER DIAPHRAGM TUBE	A320
201371001	MAIN LANDING GEAR LEG	A318
201371002	MAIN LANDING GEAR LEG	A318
201371003	MAIN LANDING GEAR LEG	A318
201371004	MAIN LANDING GEAR LEG	A318



P/N	DESCRIPTION	AIRCRAFT PARTS
201371005	MAIN LANDING GEAR LEG	A318
201371006	RH MAIN LANDING GEAR	A318
201371007	MAIN LANDING GEAR LEG	A318
201371008	MAIN LANDING GEAR LEG	A318
201371219	SLIDING TUBE	A320/321
201371270	SLIDING TUBE SUBASSY	A320
201371281	SHOCK ABSORBER SUBASSY	A320/321
201371300	SLIDING TUBE	A320
201371301	SLIDING TUBE	A320
201371302	SLIDING TUBE	A320
201371304	SLIDING TUBE	A320
201371307	SLIDING TUBE	A320
201371600	UPPER DIAPHRAGM TUBE	A320
201371623	TOQUE LINK APEX PIN NUT	A320
201373007-020	LH LEG ASSY MLG	A320
201373008-040	RH LEG ASSY MLG	A320
201374001	MAIN LANDING GEAR	A320
201374002	MAIN LANDING GEAR	A320
201375001	MAIN LANDING GEAR	A318
201375002	MAIN LANDING GEAR	A318
201375003	MAIN LANDING GEAR	A318
201375004	MAIN LANDING GEAR	A318
201375005	MAIN LANDING GEAR	A318
201375006	MAIN LANDING GEAR	A318
201375007	MAIN LANDING GEAR	A318
201375007-010	MAIN LANDING GEAR	A318
201375007-020	LH MAIN LANDING GEAR	A318
201375007-030	LH LEG ASSY MLG	A318
201375007-035	MAIN LANDING GEAR	A318
201375007-040	LH MLG	A318
201375008	R/H MAIN LDG	A318
201375008-010	RH LEG ASSEMBLY NLG	A318
201375008-020	RH LEG ASSEMBLY MLG	A318
201375008-030	RH LEG ASSY MAIN LG	A318
201375008-035	RH LEG ASSEMBLY MLG	A318
201375008-040	RH MAIN LANDING GEAR	A318
201375009	MAIN LANDING GEAR ASSY	A318
201375009-010	MLG L/H	A318
201375009-020	MLG RH	A318
201375009-035	MLG LH	A318
201375009-040	MLG LH	A318
201375009-050	MLG LH	A318
201375009-060	MLG LH	A318
201375009-070	MLG LH	A318
201375009-080	MLG LH	A318
201375009-090	LH LEG ASSY MLG	A318
201375009-100	MLG LH	A318
201375009-110	MLG LH	A318
201375009-120	MLG LH	A318
201375009-130	MLG LH	A318
201375009-140	MLG LH	A318
201375009-150	MLG LH	A318
201375009-160	MLG LH	A318
201375009-170	MLG LH	A318
201375009-180	MLG LH	A318



P/N	DESCRIPTION	AIRCRAFT PARTS
201375009-190	MLG LH	A318
201375009-200	MLG LH	A318
201375010	MLG RH	A318
201375010-010	MLG R/H	A318
201375010-020	MLG RH	A318
201375010-030	MLG RH	A318
201375010-035	MLG RH	A318
201375010-040	MLG RH	A318
201375010-050	MLG RH	A318
201375010-060	MLG RH	A318
201375010-070	MLG RH	A318
201375010-080	MLG RH	A318
201375010-090	RH LEG ASSY MLG	A318
201375010-100	MLG RH	A318
201375010-110	MLG RH	A318
201375010-120	RH DRESSED MLG	A318
201375010-130	MLG RH	A318
201375010-140	MLG RH	A318
201375010-150	MLG RH	A318
201375010-160	MLG RH	A318
201375010-170	MLG RH	A318
201375010-180	MLG RH	A318
201375010-190	MLG RH	A318
201375010-200	MLG RH	A318
201375052	R/H MLG LEG ASSY	A320
201376001	MAIN LANDING GEAR	A320
201376002	MAIN LANDING GEAR	A320
201383001	MAIN LANDING GEAR LEG	A321
201383002	MAIN LANDING GEAR LEG	A321
201383209	LINK SUBASSEMBLY, SLAVE	A320
201383304	Cardan bracket (LH)	A320
201383305	Cardan Bracket (RH)	A320
201383604	Upper torque link pin	A320
201383605	LOWER TORQUE LINK PIN	A320
201383606	APEX PIN	A320
201383615	APEX PIN NUT	A320
201383628	FORWARD PINTLE PIN LOCK BOLT	A320
201387001	MLG LEG AND DRESSINGS	A321
201387001-010	MLG LEG AND DRESSINGS	A321
201387001-020	MLG LEG AND DRESSINGS	A321
201387001-030	LH MLDG	A320
201387001-040	MLG LEG AND DRESSINGS	A321
201387001-050	MLG LEG AND DRESSINGS	A321
201387001-060	MLG LEG AND DRESSINGS	A321
201387001-070	MLG LEG AND DRESSINGS	A321
201387001-080	MLG LEG AND DRESSINGS	A321
201387001-090	LH MLG	A321
201387001-100	MLG LEG AND DRESSINGS	A321
201387001-110	MLG LEG AND DRESSINGS	A321
201387001-120	MLG LEG AND DRESSINGS	A321
201387002	MLG LEG AND DRESSINGS	A321
201387002-010	MLG LEG AND DRESSINGS	A321
201387002-020	MLG LEG AND DRESSINGS	A321
201387002-030	RH MLDG	A320
201387002-040	MLG LEG AND DRESSINGS	A321



P/N	DESCRIPTION	AIRCRAFT PARTS
201387002-050	MLG LEG AND DRESSINGS	A321
201387002-060	MLG LEG AND DRESSINGS	A321
201387002-070	MLG LEG AND DRESSINGS	A321
201387002-080	MLG LEG AND DRESSINGS	A321
201387002-090	RH LNG	A321
201387002-100	MLG LEG AND DRESSINGS	A321
201387002-110	MLG LEG AND DRESSINGS	A321
201387002-120	MLG LEG AND DRESSINGS	A321
201388001	MAIN LANDING GEAR INST.L	A321
201388002	R/H MAIN LANDING GEAR INTL.L	A321
201389001	SIDE STAY BASIC	A320
201390001	SIDE STAY COMPLETE	A321
201390002	SIDE STAY COMPLETE	A321
201399001	LEG HARNESS	A321
201399002	LEG HARNESS	A321
201399003	LEG HARNESS	A321
201399004	LEG HARNESS	A321
201399005	HARNESS 1M AND 2M	A321
201399006	HARNESS 1M AND 2M	A321
201399007	MLG HARNESS	B737
201399008	MLG HARNESS	B737
201399200	ENHANCED HARNESS	A318
201399201	ENHANCED HARNESS	A318
201400001	LEG HARNESS	A321
201400002	LEG HARNESS	A321
201400003	HARNESS 1M AND 2M	A320
201400004	HARNESS 1M AND 2M	A321
201400005	MLG HARNESS	B737
201400006	MLG HARNESS	B737
201400200	ENHANCED HARNESS	A318
201400201	ENHANCED HARNESS	A318
201401001	AXLE HARNESS	A321
201401002	AXLE HARNESS	A321
201401003	AXLE HARNESS 1M AND 2M	A321
201401004	AXLE HARNESS 1M AND 2M	A321
201401005	1M AXLES ENHANCED HARNESS	A318
201401006	2M AXLES ENHANCED HARNESS	A318
201401200	AXLE HARNESS	A318
201401201	1M AXLES ENHANCED HARNESS	A320
201401202	AXLE HARNESS 1M AND 2M	A321
201401203	AXLE HARNESS 1M AND 2M	A321
201401204	AXLE HARNESS	A321
201401205	AXLE HARNESS	A321
201401206	MAIN LDG & AXLE HARNESS	A318
201401207	MAIN LDG & AXLE HARNESS	A318
201402001	AXLE HARNESS	A321
201402002	AXLE HARNESS	A321
201402003	AXLE HARNESS 1M AND 2M	A321
201402004	AXLE HARNESS 1M AND 2M	A321
201402200	AXLE HARNESS	A318
201402201	2M AXLES ENHANCED HARNESS	A320
201402202	AXLE HARNESS 1M AND 2M	A321
201402203	AXLE HARNESS	A321
201402204	AXLE HARNESS	A321
201402205	MAIN LDG & AXLE HARNESS	A318



P/N	DESCRIPTION	AIRCRAFT PARTS
201402206	MAIN LDG & AXLE HARNESS	A318
201402207	AXLE HARNESS 1M AND 2M	A321
201403300	LOWER LOCK LINK	A320
201419001	DAMPER	B737
201419001-020	DAMPER	A320
201441602	UPPER SPRING BRACKET	A330
201441604	LOWER SPRING BRACKET	A330
201441610	WASHER	A330
201442606	CONNECTING LINK	A330
201442609	PIVOT LINK	A330
201442613	LOWER SPRING/PIVOT LINK PIN	A330
201442615	CONNECTING LINK/PIVOT LINK PIN	A330
201442633	CONNECTING LINK/LOCK LINK UPPE	A330
201442651	PIVOT LINK CENTER PIN	A330
201478252	LH RETRACTION BRACKET ASSEMB	A330/340
201478253	RETRACTION BRACKET ASSEMBLY	A330/340
201479001	ADJUSTABLE LINK	A340
201480002	BOGIE PITCH TRIMMER	A330
201480002-010	BOGIE PITCH TRIMMER	A330
201480002-015	BOGIR PITCH TRIMMER	A330
201480002-020	BOGIE PITCH TRIMMER	A330
201481001	UNLOCK ACTUATOR	A330
201481001-005	UNLOCK ACTUATOR	A330
201482001	LOCK LINK	A330
201482305	LOWER LOCK LINK	A330
201482609	LOCK LINK/SIDE STAY PIN	A330
201483001	SIDE STAY	A330
201483214	BRACKET ASSEMBLY	A330
201484001	SIDE STAY LH	A330
201484001-005	STAY-COMPLETE SIDE LH	A330
201484001-010	STAY-COMPLETE SIDE LH	A330
201484001-015	STAY-COMPLETE SIDE LH	A330
201484002	SIDE STAY RH	A330
201484002-005	MLG SIDE STAY COMPLETE	A330
201484606	BRACKET,SINGLE TARGET	A330
201485001	BOGIE ASSEMBLY	A330
201486001	BOGIE & DRESSINGS	A330
201486002	BOGIE & DRESSINGS	A330
201486003	BOGIE & DRESSINGS	A330
201486003-005	BOGIE AND DRESSINGS	A330
201486004	BOGIE & DRESSINGS	A330
201487001	SHOCK STRUT	A330
201487001-010	STRUT-SHOCK	A330
201487214	PISTON ASSY	A330
201487216	PISTON SLIDING	A330
201487219	PISTON SLIDING	A330
201487300	SLIDING PISTON	A330
201487307	SLIDING PISTON	A330
201487309	PISTON SLIDING	A330
201488002	RH MAIN STRUT	A330
201488204	LINK SUBASSEMBLY, LOWER	A330
201488337	MAIN FITTING (LH)	A330
201488650	PIN SM9	A330
201488651	PIN SM8	A330
201489001	MAIN STRUT & DRESSINGS	A330



P/N	DESCRIPTION	AIRCRAFT PARTS
201489001-002	MAIN STRUT AND DRESSINGS	A330
201489001-005	MAIN STRUT AND DRESSINGS	A330
201489001-010	MAIN STRUT AND DRESSINGS	A330
201489001-015	MAIN STRUT AND DRESSINGS	A330
201489001-020	MAIN STRUT AND DRESSINGS	A330
201489001-025	MAIN STRUT AND DRESSINGS	A330
201489001-030	MAIN STRUT AND DRESSINGS	A330
201489001-035	MAIN STRUT AND DRESSINGS	A330
201489001-040	STRUT-MAIN & DRESSINGS LH	A330
201489001-045	MAIN STRUT AND DRESSINGS	A330
201489001-050	MAIN STRUT AND DRESSINGS	A330
201489001-055	MAIN STRUT AND DRESSINGS	A330
201489001-060	MAIN STRUT AND DRESSINGS	A330
201489001-065	MAIN STRUT AND DRESSINGS	A330
201489001-100	MAIN STRUT AND DRESSINGS	A330
201489001-150	LANDING GEAR MAIN L/H	A330
201489002	MAIN STRUT & DRESSINGS	A330
201489002-002	MAIN STRUT AND DRESSINGS	A330
201489002-005	MAIN STRUT AND DRESSINGS	A330
201489002-010	MAIN STRUT AND DRESSINGS	A330
201489002-015	MAIN STRUT AND DRESSINGS	A330
201489002-020	MAIN STRUT AND DRESSINGS	A330
201489002-025	MAIN STRUT AND DRESSINGS	A330
201489002-030	MAIN STRUT AND DRESSINGS	A330
201489002-035	MAIN STRUT AND DRESSINGS	A330
201489002-040	STRUT-MAIN AND DRESSINGS (RH)	A330
201489002-045	MAIN STRUT AND DRESSINGS	A330
201489002-050	MAIN STRUT AND DRESSINGS	A330
201489002-055	MAIN STRUT AND DRESSINGS	A330
201489002-060	MAIN STRUT AND DRESSINGS	A330
201489002-065	MAIN STRUT AND DRESSINGS	A330
201489002-100	MAIN STRUT AND DRESSINGS	A330
201489002-150	MAIN LDG R/H	A330
201489003	MAIN STRUT & DRESSINGS	A330
201489004	MAIN STRUT & DRESSINGS	A330
201489242	SLEEVE SUBASSEMBLY LUBRICATION	A330
201489304	LOWER TORQUE LINK	A330
201489315	LH RETRACTION LINK	A330
201489316	RETRACTION LINK (RH)	A330
201489751	BOGIE BEAM PIVOT PIN	A330
201489780	ROLLER, UPLOCK	A330
201490001	LH MLG COMPLETE	A330
201490002	RH MLG COMPLETE	A330
201490003	MAIN LANDING GEAR COMPLETE LH	A330
201490004	MAIN LANDING GEAR COMPLETE RH	A330
201520001	MAIN LDG & AZLE HARNESS	A318
201520002	MAIN LDG & AXLE HARNESS	A318
201520003	MAIN LDG & AXLE HARNESS	A318
201520004	MAIN LDG & AXLE HARNESS	A318
201520005	MAIN LDG & AXLE HARNESS	A318
201520006	MAIN LDG & AXLE HARNESS	A318
201520007	MAIN LDG & AXLE HARNESS	A318
201520008	MAIN LDG & AXLE HARNESS	A318
201521001	MAIN LANDING GEAR COMPLETE	A318
201521002	MAIN LANDING GEAR COMPLETE	A318





P/N	DESCRIPTION	AIRCRAFT PARTS
201521003	MAIN LANDING GEAR COMPLETE	A321
201521004	MAIN LANDING GEAR COMPLETE	A321
201522001	MAIN LANDING GEAR LEG	A321
201522002	MAIN LANDING GEAR LEG	A321
201522003	MAIN LANDING GEAR LEG	A321
201522004	MAIN LANDING GEAR LEG	A321
201522265	LINK SUBASSEMBLY LOWER	A320
201522300	MAIN FITTING (LH)	A320
201522301	MAIN FITTING (RH)	A320
201522302	UPPER TORQUE LINK	A320
201522303	LOWER TORQUE LINK	A320
201522351	MAIN FITTING (LH)	A320
201522352	MAIN FITTING (RH)	A320
201522353	SLIDING TUBE	A320
201522356	SLIDING TUBE	A320
201522357	MAIN FITTING (LH)	A320
201522358	MAIN FITTING (RH)	A320
201522359	MAIN FITTING (LH)	A320
201522360	MAIN FITTING (RH)	A320
201522600	FORWARD PINTLE PIN	A320/321
201522651	UPPER DIAPHRAGM TUBE	A320
201523001	MLG LEG AND DRESSINGS	A321
201523002	RH MLG	A321
201523003	MAIN LANDING GEAR LEG AND DRES	A321
201523004	MAIN LANDING GEAR LEG AND DRES	A321
201524001	STAY ASSY-SIDE,MLG	A321
201524001-030	SIDE STAY COMPLETE	A318
201524002	STAY ASSY-SIDE,MLG	A321
201525001	STAY-SIDE	A321
201525300	UPPER SIDE STAY	A320
201525301	LOWER SIDE STAY	A320
201525302	LOWER CARDAN	A320
201525605	SIDE STAY PIVOT PIN	A320
201525607	UPPER CARDAN	A320/321
201525612	LOWER CARDAN NUT	A320
201525618	SIDE STAY UPPER CARDAN PIN	A320
201525619	UPPER CARDAN NUT	A320
201525620	SIDE STAY LOWER CARDAN PIN	A320
201525621	SIDE STAY LOWER CARDAN PIN	A320
201531001	STAY-LOCK	A320/321
201531300	UPPER LOCK LINK	A320
201531600	UPPER LOCK LINK	A320
201540001	MLG LEG	A318
201540001-040	MLG LEG	A320
201540001-080	MLG LEG	A320
201540002	MLG LEG	A318
201540002-040	MLG LEG	A320
201540002-080	MLG LEG	A320
201540003	MAIN LANDING GEAR LEG	A318
201540004	MAIN LANDING GEAR LEG	A318
201540005	MAIN LANDING GEAR LEG	A318
201540006	MAIN LANDING GEAR LEG	A318
201540007	MAIN LANDING GEAR LEG	A318
201540008	MAIN LANDING GEAR LEG	A318
201540241	LH MAIN FITTING SUBASSEMBLY	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
201540300	MAIN FITTING (LH)	A320
201540301	RH MAIN FITTING	A320
201540302	LOWER TORQUE LINK	A320
201540303	UPPER TORQUE LINK	A320
201540308	MAIN FITTING (LH)	A320
201540309	MAIN FITTING (RH)	A320
201540609	BOLT	A320
201540616	FORWARD PINTLE PIN STUB BOLT	A320
201581001	MAIN LANDING GEAR	A320
201581002	MAIN LANDING GEAR	A320
201581003	MLG COMPLETE	A318
201581004	MLG COMPLETE	A318
201581005	MLG COMPLETE	A318
201581006	MLG COMPLETE	A318
201581007	MAIN LANDING GEAR COMPLETE	A318
201581008	MAIN LANDING GEAR COMPLETE	A318
201582001	MLG LEG AND DRESSINGS	A318
201582001-010	L/H MLG LEG & DRESSINGS	A318
201582001-030	LH MLG LEG & DRESSINGS	A319/320
201582002	MLG LEG AND DRESSINGS	A318
201582002-010	RH MLG LEG & DRESSINGS	A318
201582003	MAIN LANDING GEAR LEG AND DRES	A318
201582004	MAIN LANDING GEAR LEG AND DRES	A318
201582005	MAIN LANDING GEAR LEG AND DRES	A318
201582006	MAIN LANDING GEAR LEG AND DRES	A318
201582007	MAIN LANDING GEAR LEG AND DRES	A318
201582008	MAIN LANDING GEAR LEG AND DRES	A318
201584001	LH MLG GEAR COMPLETE	A320
201584002	RH MLG GEAR COMPLETE	A320
201585001	MLG LEG AND DRESSINGS, LH	A318
201585002	RH MLG LED & DRESSINGS	A318
201585003	LEG AND DRESSINGS-MLG-LH	A321
201585004	LEG AND DRESSINGS-MLG-RH	A321
201585004-080	LEG & DRESSING	A321
201585005	MLG LEG AND DRESSINGS	A321
201585006	MLG LEG AND DRESSINGS	A321
201585007	MLG LEG AND DRESSINGS	A321
201585008	MLG LEG AND DRESSINGS	A321
201587001	MAIN LANDING GEAR LEG	A321
201587002	MAIN LANDING GEAR LEG	A320
201587003	MAIN LANDING GEAR LEG	A321
201587004	MAIN LANDING GEAR LEG	A321
201587005	MAIN LANDING GEAR LEG	A321
201587006	MAIN LANDING GEAR LEG	A321
201587007	MAIN LANDING GEAR LEG	A321
201587008	MAIN LANDING GEAR LEG	A321
201587303	UPPER TORQUE LINK	A320
201587304	LOWER TORQUE LINK	A320
201587602	FORWARD PINTLE PIN STUB BOLT	A320
201587608	FORWARD PINTLE PIN STUB BOLT	A320
201587610	FORWARD PINTLE PIN STUB BOLT	A320
201587611	FORWARD PINTLE PIN STUB BOLT	A320
201587612	APEX PIN NUT	A320
201590001	RETRACTION ACTUATOR	B737
201590002	RETRACTION ACTUATOR	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
201590002-020	RETRACTION ACTUATOR	A320
201590003	RETRACTION ACTUATOR	B737
201590004	RETRACTION ACTUATOR	B737
201590900	PIN-RETRACTION ACTUATOR	A320
201590901	PIN-REAR SPAR SIDE	A320
201590906	CYLINDER	A320
201590908	PISTON ROD	A320
201590909	PISTON	A320
201590910	NUT	A320
201590913	GLAND	A320
201659001	MAIN LANDING GEAR	A320
201659002	MAIN LANDING GEAR	A320
201659003	MAIN LANDING GEAR COMPLETE	A321
201659004	MAIN LANDING GEAR COMPLETE	A321
201660001	SIDE STAY COMPLETE	A321
201660001-010	STAY ASSY-SIDE,MLG	A320/321
201660002	STAY ASSY-SIDE,MLG	A321
201660002-010	STAY ASSY-SIDE,MLG	A320/321
201661001	STAY-SIDE	A321
201661300	UPPER SIDE STAY	A320
201661301	LOWER SIDE STAY	A320
201661302	CUFF	A320
201661304	BANANA LINK	A320
201661601	SIDE STAY PIVOT PIN	A320
201661602	CUFF	A320
201661603	SIDE STAY LOWER CARDAN PIN	A320
201661610	UPPER CARDAN NUT	A320
201661611	LOWER CARDAN NUT	A320
201661613	CUFF	A320
201676210	ROLLER SUBASSEMBLY UPLOCK	A330
201676215	LINK ASSEMBLY	A330/340
201676216	LINK ASSEMBLY	A330
20219-0101	HYDRAULIC OIL QUANTITY TRANSMITTER	B737
20220-01	COMPENSATOR	
20220-0101	QTY TRANSMITTER	B737
2030781	MODULE ANTI-SKID SHUTTLE DISCONNECT	
2041207-2	STATOR	
2045M53P01	ALTERNATOR	
2045M53P02	ALTERNATOR	
204790-1-1	TURBINE DRIVEN CENTRIFUGAL COMPRESSOR	
204790-2-1	COMPRESSOR CENTRIFUGA	
2056-01-01	SERVOED ALTITUDE INDICATOR	B737
2056-01-1	INDICATOR	
2057-01-1	ALTIMETER	B737
2057-02-1	SERVOED ALTITUDE INDICATOR	B737
2061-11-1	FLAP POSITION INDICATOR	B727, B737
2061-12-1	FLAP POSITION INDICATOR	B727, B737
2061-13-1	FLAP POSITION INDICATOR	B727,B737
2061-14-1	FLAP POSITION INDICATOR	B737
206400-3-1B	COMPRESSOR ROTARY	P3 ORION, P3 CONVERSION
2067593-2657	VHF NAV RECEIVER	
2070724-3206	ILS RECEIVER	
2070943-0101	ANTENNA COP	
2083-08-1	MACH INDICATOR	B727, B737
2083-09-1	MACH INDICATOR	B727, B737



P/N	DESCRIPTION	AIRCRAFT PARTS
2083-10-1	MACH INDICATOR	B727, B737
2083-11-1	MACH AIRSPEED INDICATOR	B727, B737
20900110	CONTROL UNIT-INTE	
209A10	CONTROL UNIT-INTE	
210TS07Y01	CONTROL LEVER	A318
2113	CASING / STATOR ASSY	
211C223-175	HYDRAULIC PRESSURE SWITCH	B747, B767, B757
211C223-176	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-177	HYDRAULIC PRESSURE SWITCH	B757, B747, B767, B737
211C223-178	HYDRAULIC PRESSURE SWITCH	B757
211C223-200	HYDRAULIC PRESSURE SWITCH	B757
211C223-203	HYDRAULIC PRESSURE SWITCH	B757, B737
211C223-208	HYDRAULIC PRESSURE SWITCH	B757, B777
211C223-209	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-211	HYDRAULIC PRESSURE SWITCH	B757
211C223-214	HYDRAULIC PRESSURE SWITCH	B757
211C223-216	HYDRAULIC PRESSURE SWITCH	B757, B777
211C223-252	HYDRAULIC PRESSURE SWITCH	B737, B757
211C223-253	HYDRAULIC PRESSURE SWITCH	B737, B757
211C223-278	HYDRAULIC SWITCH PRESSURE	B737, B757, B767
211C223-296	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-297	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-301	HYDRAULIC PRESSURE SWITCH	B757, B777
211C223-312	HYDRAULIC PRESSURE SWITCH	B737, B757
211C223-319	HYDRAULIC PRESSURE SWITCH	B757, B747, B767, B737, B777
211C223-320	HYDRAULIC PRESSURE SWITCH	B737, B757
211C223-321	HYDRAULIC PRESSURE SWITCH	B757, B767, B777
211C223-322	HYDRAULIC PRESSURE SWITCH	B757
211C223-323	HYDRAULIC PRESSURE SWITCH	B757, B777
211C223-326	HYDRAULIC PRESSURE SWITCH	B757, B767, B737, B777
211C223-327	HYD PRESSURE SWITCH	B757, B767, B737, B777
211C223-341	HYDRAULIC SWITCH PRESSURE	B737, B757, B777
211C223-461A	SWITCH-PRESSURE	CRJ200, ATR
211C223-516	HYD PRESSURE SWITCH	B767, B747, B757, B777, B737
211C223-518	HYDRAULIC PRESSURE SWITCH	B757, B767, B777, B737
211C223-519	HYDRAULIC PRESSURE SWITCH	B757, B767, B777, B737, B747
211C223-520	HYDRAULIC PRESSURE SWITCH	B757, B767, B777, B737
211C223-521	HYDRAULIC PRESSURE SWITCH	B757, B767, B777, B737
211C223-522	HYDRAULIC PRESSURE SWITCH	B757, B767, B777, B737
211C223-523	HYDRAULIC PRESSURE SWITCH	B757, B767, B777, B737
211C223-524	HYDRAULIC PRESSURE SWITCH	B757, B767, B777, B737
211C223-525	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-527	HYDRAULIC PRESSURE SWITCH	B757, B767, B777, B737
211C223-528	HYDRAULIC PRESSURE SWITCH	B757, B767
211C223-534	HYDRAULIC PRESSURE SWITCH	B767, B757, B777, B737
211C223-XXX	HYDRAULIC PRESSURE SWITCH	
2123M63P02	STATOR ASSEMBLY	CFM56-5A/B/C; CFM56-7B, A320
2123M63P03	STATOR ASSEMBLY	CFM56-5A/B/C; CFM56-7B, A320
212EAP	GYRO UNIT	
214001-10	PANEL CONTROL, ELECTRIC	
214C40-1-115	ALTITUDE SWITCH	B737-200, B757-200, B767-200, B767-300
214C40-1-71	SWITCH	B737-200, B757-200, B767-200, B767-300



P/N	DESCRIPTION	AIRCRAFT PARTS
214C40-1-75	PRUSSURE SPARE PARTS	B737-200, B757-200, B767-200, B767-300
214C40-1-77	ALTITUDE SWITCH	B737-200, B757-200, B767-200, B767-300
2-1576	MAIN LANDING GEAR BRAKE ASSEMBLY	BEECH 200, 300, 350, C-12
215TS07Y00	LEVER	A318
217-04111	IND PRESSURE COMBU	C-212
217-05112	INDICATOR	C-212
218066-1	APU FUEL PUMP	B737-200, B737-300, B737-400, B737-500, B737-600, B737-700, B737-800, B737-900
218066-2	APU FUEL PUMP	B737-200, B737-300, B737-400, B737-500, B737-600, B737-700, B737-800, B737-900
218066-3	APU FUEL PUMP	B737-200, B737-300, B737-400, B737-500, B737-600, B737-700, B737-800, B737-900, DC10
218513	STATOR, ASSEMBLY	
21C1-1-16B	PRESSURE SWITCH	A-300
21C1-3-21	FUEL PRESS SWITCH	B757
21C1-3-22	FUEL PRESS SWITCH	B757
21SN04-104A	PRESSURE SWITCH	B737, B757, B767, B747, B777
21SN04-104B	PRESSURE SWITCH	B737, B767, B757, B747, B777
21SN04-104D	SCAVENGE OIL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320
21SN04-104E	PRESSURE SWITCH	B737, B767, B757, B747, B777
21SN04-104F	PRESSURE SWITCH	B737, B767, B757, B747, B777
21SN04-158A	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320
21SN04-158B	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320
21SN04-158C	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320
21SN04-158D	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320
21SN04-159	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-159A	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-159B	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-159C	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-159D	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-209A	SWITCH-OIL	B737
21SN04-211	PRESSURE SWITCH	B767, B737
21SN04-211A	PRESSURE SWITCH	B767, B737
21SN04-223	FUEL PRESSURE SWITCH	B767, B747
21SN04-224	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B767, B747, B737
21SN04-225	SWITCH-OIL PRESSURE	A300, A310, B767, B747
21SN04-226	PRESSURE SWITCH	B767, B737
21SN04-226A	PRESSURE SWITCH	B767, B737
21SN04-23F	PRESSURE SWITCH	B737, B757, B767, B747, B777
21SN04-23G	PRESSURE SWITCH	B737, B757, B767, B747, B777
21SN04-23H	PRESSURE SWITCH	B737, B757, B767
21SN04-23J	LOW OIL PRESS WRNG SWITCH	B737, B757, B767, B747, B777
21SN04-23K	PRESSURE SWITCH	B737, B757, B767, B747, B777
21SN04-24F	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
21SN04-24G	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320
21SN04-24H	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320
21SN04-24J	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320
21SN04-24K	ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	A320
21SN04-25F	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-25G	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-25H	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-25J	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-25K	ENGINE FUEL LOW PRESSURE SWITCH ASSEMBLY	A320
21SN04-26E	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	
21SN04-26F	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	A320
21SN04-26G	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	A320
21SN04-26H	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	A320
21SN04-26J	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	A320
21SN04-26K	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	A320
21SN04-275A	LOW OIL PRESSURE SWITCH	UNKNOWN
21SN04-298A	SCAVENGE FILTER PRESSURE SWITCH	
21SN04-300B	HYDRAULIC PRESSURE SWITCH	B767, A320
21SN04-306	LP OIL WARNING PRESSURE SWITCH ASSEMBLY	A320
21SN04-306A	LP OIL WARNING PRESSURE SWITCH ASSEMBLY	A320
21SN04-306B	LP OIL WARNING PRESSURE SWITCH ASSEMBLY	A320
21SN04-323A	FUEL PRESSURE SWITCH	B737, B757, B767
21SN04-324	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B737, B757, B767, B747
21SN04-325	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B737, B757, B767
21SN04-333	FUEL PRESSURE SWITCH	B737, B757, B767, B747
21SN04-334	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B767, B747
21SN04-422A	LOW OIL DIFFERENTIAL PRESSURE SWITCH	ATR
21SN04-422B	LOW OIL DIFFERENTIAL PRESSURE SWITCH	MD88, MD90
21SN04-466	FUEL PRESSURE SWITCH	B737, B757, B767
21SN04-467	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B737, B757, B767
21SN04-468	DIFFERENTIAL PRESSURE SWITCH	A300, A310, B737, B757, B767
21SN04-XXX	SCAVENGE OIL FILTER DIFFERENTIAL PRESSURE SWITCH ASSEMBLY	
21SN41-42	PRESSURE SWITCH	B747, B767, B737
21SN41-52	SWITCH-THERMAL ANTI ICE	B747, B767, B737
21SN41-84	PRESSURE SWITCH	B747, B767, B737
22052	STATOR	
22216	STATOR	
2249956	STARTER GENERATOR	
229432	SUMERGED FUEL BOOSTER PUMP	
23032	DC STARTER GENERATOR	
23032-	GENERATOR	
23032-018	GENERATOR	
23032-048	STARTER GENERATOR	
230321910	PLATE DAMPENER	
23032-1910	PLATE DAMPENER	
23032-2711	BLACKPLATE DAMPENER	
23032-2844	DRIVE SHAFT	
23032-3210	PLATE & SENSOR DAMPENER	
23032-SERIES	DC STARTER GENERATOR	
23046 SERIES	DC STARTER GENERATOR	Corporate



P/N	DESCRIPTION	AIRCRAFT PARTS
23046-020	STARTER GENERATOR	Corporate
23046-SERIES	DC STARTER GENERATOR	Corporate
23065	DC STARTER GENERATOR	Heli/Corporate
23065 SERIES	DC STARTER GENERATOR	Heli/Corporate
23065-1520	DRIVE SHAFT	
23069 SERIES	DC STARTER GENERATOR	
23076-001	DC STARTER GENERATOR	
23076-001-1	DC STARTER GENERATOR	
23076-004	DC STARTER GENERATOR	
23076-004-1	DC STARTER GENERATOR	
23076-005	DC STARTER GENERATOR	
23076-312	STATOR AND HOUSING ASSY	
23078-003	DC STARTER GENERATOR	
23078-003-1	DC STARTER GENERATOR	
23078-005	DC STARTER GENERATOR	
23078-005-1	DC STARTER GENERATOR	
23078-006	DC STARTER GENERATOR	
23078-007	DC STARTER GENERATOR	
23078-008	DC STARTER GENERATOR	
23078-009	DC STARTER GENERATOR	
23078-010	DC STARTER GENERATOR	
23078-011	DC STARTER GENERATOR	
23078-012	DC STARTER GENERATOR	
23078-020	STARTER GENRATOR	
23079	DC STARTER GENERATOR	Heli/Corporate
23085-001	DC STARTER GENERATOR	
23085-002	DC STARTER GENERATOR	
23085-003	DC STARTER GENERATOR	
23085-004	DC STARTER GENERATOR	
23085-004-1	DC STARTER GENERATOR	
23085-006	DC STARTER GENERATOR	
23085-009	DC STARTER GENERATOR	
23085-012	DC STARTER GENERATOR	
23085-013	DC STARTER GENERATOR	
23085-014	DC STARTER GENERATOR	
23085-015	DC STARTER GENERATOR	
23085-1352	DRIVE SHAFT	
23085-1500	ARMATURE	
23085-A	BANDAS	
23088-001	DC STARTER GENERATOR	Dash 8
23088-001A	DC STARTER GENERATOR	Dash 8
23088-001B	DC STARTER GENERATOR	Dash 8
23088-002	DC STARTER GENERATOR	Dash 8
23088-002A	DC STARTER GENERATOR	Dash 8
23088-002B	DC STARTER GENERATOR	Dash 8
23088-003	DC STARTER GENERATOR	Dash 8
23088-003A	DC STARTER GENERATOR	Dash 8
23088-003B	DC STARTER GENERATOR	Dash 8
23088-004	DC STARTER GENERATOR	Dash 8
23088-004A	DC STARTER GENERATOR	Dash 8
23088-004B	DC STARTER GENERATOR	Dash 8
23088-006	DC STARTER GENERATOR	Dash 8
23088-006A	DC STARTER GENERATOR	Dash 8
23088-006B	DC STARTER GENERATOR	Dash 8
23088-008	STARTER GENERATOR	Dash 8



P/N	DESCRIPTION	AIRCRAFT PARTS
23088-SERIES	DC STARTER GENERATOR	Dash 8
2313M347-1	WIPER MOTOR CONVERTER	B737
2313M-347-1	WIPER MOTOR CONVERTER ASSY	B737
2313M347-2	WIPER MOTOR CONVERTER	B737
2313M-347-2	WIPER MOTOR CONVERTER ASSY	B737
2313M347-3	WIPER MOTOR CONVERTER	B737
2313M-347-3	WIPER MOTOR CONVERTER ASSY	B737
2313M347-4	WIPER MOTOR CONVERTER	B737
2313M-347-4	WIPER MOTOR CONVERTER ASSY	B737
2313M348-1	WIPER MOTOR CONVERTER	B737
2313M-348-1	WIPER MOTOR CONVERTER ASSY	B737
2313M348-2	WIPER MOTOR CONVERTER	B737
2313M-348-2	WIPER MOTOR CONVERTER ASSY	B737
2313M348-3	WIPER MOTOR CONVERTER	B737
2313M-348-3	WIPER MOTOR CONVERTER ASSY	B737
2313M348-4	WIPER MOTOR CONVERTER	B737
2313M-348-4	WIPER MOTOR CONVERTER ASSY	B737
233A3201	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-11	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-12	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-13	WINDOW/PITOT HEAT MODULE ASSY	
233A3201-14	WINDOW/PITOT HEAT MODULE ASSY	
233A3201-2	WINDOW PITOT HEAT MODULE	B737
233A3201-302	WINDOW PITOT HEAT MODULE	
233A3201-305	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-306	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-307	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-307 MOD A	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-309	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-309 MOD A	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-311	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-311 MOD A	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-312	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-312 MOD A	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-313	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-313 MOD A	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-314	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-314 MOD A	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-5	WINDOW PITOT HEAT MODULE	B737
233A3201-6	WINDOW/PITOT HEAT MODULE ASSY	B737
233A3201-7	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233A3201-8	WINDOW/PITOT HEAT MODULE ASSY	B737
233A3201-9	WINDOW AND PITOT HEAT MODULE ASSEMBLY	
233N3205-27	HYDRAULIC CONTROL PANEL	B757
233N3209-20	CONTROL PANEL	B757, B767
233N3211-1036	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1037	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1038	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1039	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1040	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1041	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1042	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1046	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1300	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1301	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767





P/N	DESCRIPTION	AIRCRAFT PARTS
233N3211-1302	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1303	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1304	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1305	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1306	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1307	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1308	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1309	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-1311	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-300	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-301	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-302	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-303	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-304	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-305	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-306	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-307	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-308	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-309	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-311	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-312	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-313	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-315	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-316	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-317	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-319	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-321	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-36	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-37	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-38	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-39	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-40	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-41	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-42	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3211-46	BATTERY/STANDBY POWER PANEL ASSEMBLY	B757, B767
233N3215-20	BLEED AIR PANEL	B757
233N6203-1007	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1009	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1012	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1013	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1021	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1023	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1024	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-103	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1032	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1035	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1036	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-104	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1045	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1046	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1047	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1048	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-105	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1053	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1056	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767



P/N	DESCRIPTION	AIRCRAFT PARTS
233N6203-1067	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1070	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1073	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1075	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1077	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1079	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1082	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1085	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1086	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-109	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-110	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1103	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1104	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1105	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1109	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-111	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1110	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1111	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1161	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1162	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1163	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1164	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1165	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1169	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1170	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1171	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1172	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1187	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1188	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1189	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1190	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1191	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1192	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1193	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1194	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1195	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1196	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1197	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1198	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-12	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1200	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1202	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1203	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1206	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1219	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1220	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1221	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1226	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-13	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1301	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1302	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1303	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1304	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1305	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1347	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767



P/N	DESCRIPTION	AIRCRAFT PARTS
233N6203-1348	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1349	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1350	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1351	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1352	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1353	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1354	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1356	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1358	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1359	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1381	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1382	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	
233N6203-1383	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1384	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1385	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1386	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1389	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1398	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1400	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1401	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1402	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1403	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1404	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1405	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1406	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1407	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1409	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1411	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1412	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1413	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1414	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1415	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1416	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1417	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1418	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1419	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1420	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1421	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-1422	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-161	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-162	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-163	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-164	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-165	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-169	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-170	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-171	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-172	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-187	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-188	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-189	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-190	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-191	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-192	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-193	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767



P/N	DESCRIPTION	AIRCRAFT PARTS
233N6203-194	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-195	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-196	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-197	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-198	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-200	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-202	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-203	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-206	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-21	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-219	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-220	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-221	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-226	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-23	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-24	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-301	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-302	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-303	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-304	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-305	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-32	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-35	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-355	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-356	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-36	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-360	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-45	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-46	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-47	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-48	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-53	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-56	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-67	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-7	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-70	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-73	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-75	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-77	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-79	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-82	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-85	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-86	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-9	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233N6203-SERIES	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY	B-757, B-767
233T3210-306	LIGHT PANEL ASSY	B767, B757
233T3235-10	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1005	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1007	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1010	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1011	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1012	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1013	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1015	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-11	FUEL MANAGEMENT PANEL ASSY M10055	B767



P/N	DESCRIPTION	AIRCRAFT PARTS
233T3235-12	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-13	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1300	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1301	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1302	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1303	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1304	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1305	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1306	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-1307	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-15	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-17	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-20	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-21	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-23	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-300	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-301	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-5	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T3235-7	FUEL MANAGEMENT PANEL ASSY M10055	B767
233T4246-1	SQUIB TEST PANEL ASSEMBLY M32	B757, B767
233T4246-11	SQUIB TEST PANEL ASSEMBLY M36	B757, B767
233T4246-18	SQUIB TEST PANEL ASSEMBLY M37	B757, B767
233T4246-4	SQUIB TEST PANEL ASSEMBLY M33	B757, B767
233T4246-7	SQUIB TEST PANEL ASSEMBLY M34	B757, B767
233T4246-8	SQUIB TEST PANEL ASSEMBLY M35	B757, B767
244-642-3	CARRIER LINNING	
2473-1B	CONTROL BOX ELECTRIC	
25038	ELECTRIC MOTORPUMP	CRJ700 & ERJ
250SG1 SERIES	STARTER GENERATOR	
251A1240-3	ACTUATOR FLICHT SPOILER	B737
251A1240-5	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY(SUB ASSY PN 251A1270-4, -5, -6)	
251A1240-6	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY(SUB ASSY PN 251A1270-4, -5, -6)	
251A1270-4	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	B-707,B717,B727,B737,B747,B757,B767,B787-DC-8,DC-9,DC-10,KC-10,KDC-10,MD10,MD11,MD80,MD88,MD90,P-8A
251A1270-5	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	B-707,B717,B727,B737,B747,B757,B767,B787-DC-8,DC-9,DC-10,KC-10,KDC-10,MD10,MD11,MD80,MD88,MD90,P-8A
251A1270-6	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	B-707,B717,B727,B737,B747,B757,B767,B787-DC-8,DC-9,DC-10,KC-10,KDC-10,MD10,MD11,MD80,MD88,MD90,P-8A
251A1510-3	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
251A4510-3	STAB ACTUATOR	
2524038	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524057-2	FLOW DIVIDERS	E-26 TAMIZ
2524088-2	FLOW DIVIDERS	E-26 TAMIZ
2524115-2	FLOW DIVIDERS	E-26 TAMIZ



P/N	DESCRIPTION	AIRCRAFT PARTS
2524120-2	FLOW DIVIDERS	E-26 TAMIZ
2524148-3	FLOW DIVIDERS	E-26 TAMIZ
2524158-2	FLOW DIVIDERS	E-26 TAMIZ
2524164-2	FLOW DIVIDERS	E-26 TAMIZ
2524166-2	FLOW DIVIDERS	E-26 TAMIZ
2524172-2	FLOW DIVIDERS	E-26 TAMIZ
2524177-2	FLOW DIVIDERS	E-26 TAMIZ
2524188-1	FLOW DIVIDERS	E-26 TAMIZ
2524218-2	FLOW DIVIDERS	E-26 TAMIZ
2524219-2	FLOW DIVIDERS	E-26 TAMIZ
2524220-2	FLOW DIVIDERS	E-26 TAMIZ
2524221-2	FLOW DIVIDERS	E-26 TAMIZ
2524222-2	FLOW DIVIDERS	E-26 TAMIZ
2524223-2	FLOW DIVIDERS	E-26 TAMIZ
2524224-2	FLOW DIVIDERS	E-26 TAMIZ
2524225-2	FLOW DIVIDERS	E-26 TAMIZ
2524226-2	FLOW DIVIDERS	E-26 TAMIZ
2524227-2	FLOW DIVIDERS	E-26 TAMIZ
2524232-2	FLOW DIVIDERS	E-26 TAMIZ
2524240-2	FLOW DIVIDERS	E-26 TAMIZ
2524248-2	FLOW DIVIDERS	E-26 TAMIZ
2524265-2	FLOW DIVIDERS	E-26 TAMIZ
2524273	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524298	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524302-2	FLOW DIVIDERS	E-26 TAMIZ
2524327-2	FLOW DIVIDERS	E-26 TAMIZ
2524342-2	FLOW DIVIDERS	E-26 TAMIZ
2524366	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524397-2	FLOW DIVIDERS	E-26 TAMIZ
2524416-2	FLOW DIVIDERS	E-26 TAMIZ
2524420	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524421-2	FLOW DIVIDERS	E-26 TAMIZ
2524422	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524477	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524491	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524492	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524500	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524534	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524556	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524571-2	FLOW DIVIDERS	E-26 TAMIZ
2524586-2	FLOW DIVIDERS	E-26 TAMIZ
2524601	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524610-2	FLOW DIVIDERS	E-26 TAMIZ
2524693	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524709	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524733	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524811	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524846	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524859	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
2524880	SERVO FUEL INJECTOR	USED ON LYCOMING ENGINES
252T2110-3	ROD	B767
25615C27A26A1	INDICATOR PRESSURE	
25615-C27A-26-A1	DUAL AUTOSYN SYNCHRO INDICATOR	P3 ORION, P3 CONVERSION
25615-C29A-26-A1	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C29A-26-A3	DUAL AUTOSYN SYNCHRO INDICATOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
25615-C32A-24-A1	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C32A-24-A2	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C32C-26-A2	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C32D-26-A3	DUAL AUTOSYN SYNCHRO INDICATOR	
25615-C33B-70-A3	DUAL AUTOSYN SYNCHRO INDICATOR	
256A3510-2	POWER DRIVE UNIT	B737
256A3515-1	FLAP ACTUATION GEABOX ASSEMBLY	B737
256A3515-2	FLAP ACTUATION GEABOX ASSEMBLY	B737
256A3515-3	FLAP ACTUATION GEABOX ASSEMBLY	B737
256A3515-4	FLAP ACTUATION GEABOX ASSEMBLY	B737
2588420-906	FLIGHT DIRECTOR CTRL	B737
2593604-222	CONTROL-FLIGHT DIRECTOR	C-212
2594618-901	INDICATOR TRUE	
2607483	SLEEVE-AXLEMLG	
26-1000-250G	TRANSMITTER,PRESSUR	
2610-07-1	CLOCK ASSY	B737
2610-13-1	DAY / DATE CLOCK	A319, A320, A321, A330, A340, A320-100
2610181-3	MAIN WHEEL ASSEMBLY	A330
2610181-4	MAIN WHEEL ASSEMBLY	A330
2610181-5	MAIN WHEEL ASSEMBLY	A330
2611124	FAN AXLE KIT, MOTOR	A330
26130010	VALVE, SOLENOID	C-130
26130010-01	VALVE, SOLENOID	C-130
26130010-01A	SHUT-OFF VALVE	C-130
26130011	SHUT-OFF VALVE	
26130011-01	SHUT-OFF VALVE	C-130
2613552	AXLE SLEEVE	A330-340
261D1380-005	EMERGENCY LOCATOR TRANSMITTER SYSTEM DM ELT 8.1	A-320
261D1380-006	EMERGENCY LOCATOR TRANSMITTER SYSTEM DM ELT 8.1	A-320
261D1380-007	EMERGENCY LOCATOR TRANSMITTER SYSTEM DM ELT 8.1	A-320
261D1380-008	EMERGENCY LOCATOR TRANSMITTER SYSTEM DM ELT 8.1	A-320
261D1389	EMERGENCY LOCATOR TRANSMITTER SYSTEM DM ELT 8.1	A-320
2670288-4	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	
2670288-5	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757
2670288-6	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757
2670288-7	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757,MD11
2670288-8	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757
2670288-9	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	B757,B737
267-989-001	INDICATOR-FUEL QNTY	C-212, CN-235
267-989-002	FUEL QUANTITY INDICATOR	
26B263-13B	AC GENERATOR	
2704-1-000/1	HIGH SPEED OVEN	
2704202-1	ALTERNATING CURRENT GEARED MOTOR	B747
2704202-2	ALTERNATING CURRENT GEARED MOTOR	B747
2704202-3	ALTERNATING CURRENT GEARED MOTOR	B747
2704202-4	ALTERNATING CURRENT GEARED MOTOR	B747
2704202-5	ALTERNATING CURRENT GEARED MOTOR	B747
2704442-3	DIRECT CURRENT MOTOR	B777
2704442-4	DIRECT CURRENT MOTOR	B777
2704442-5	DIRECT CURRENT MOTOR	B777
2704470-3	ACTUATOR MOTOR	
2704506-1	MOTOR-STARTER	A319, A321, A320
2704506-2	MOTOR-STARTER	A319, A321, A320-100, A321
2704506-3	MOTOR-STARTER	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
2704506-4	MOTOR-STARTER	A319, A320, A321, CS100, CS301
2704506-5	MOTOR-STARTER	A320
2707905-3	HOUSING ASSY STATOR	
2709813-1	ARMATURE	
2709951-1	ARMATURE ASSY	B777
2709960-1	FIELD ASSY	B777
2709969-1	FRONT END BELL ASSEMBLY	
27-1000-4000SG	TRANSMITER	CN-235, C-295
2710772-1	FIELD	B757
271N6113-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
271N6113-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273A1120-1	WASHER	B737
273A1120-2	NUT	B737
273A1120-3	NUT	B737
273A1120-4	NUT	B737
273A1120-5	NUT	B737
273A1121-1	PIN	B737
273A1121-2	PIN	B737
273A1121-3	PIN	B737
273A1121-4	PIN	B737
273A1122-1	NUT	B737
273A1125-1	RETAINER	B737
273A1301-1-1	LANDING GEAR HYDRAULIC TRANSFE	B737
273A2101-10	MLG RETRACT ACTUATOR ASSEMBLY	B737
273A2101-101	MLG RETRACT ACTUATOR ASSEMBLY	B737
273A2101-2	MLG RETRACT ACTUATOR ASSEMBLY	B737
273A2101-3	MLG RETRACT ACTUATOR ASSY	B737
273A2101-4	MLG RETRACT ACTUATOR ASSEMBLY	B737
273A2101-5	MLG RETRACT ACTUATOR ASSEMBLY	B737
273A2101-6	MLG RETRACT ACTUATOR ASSEMBLY	B737
273A2101-7	MLG RETRACT ACTUATOR ASSEMBLY	B737
273A2101-8	MLG RETRACT ACTUATOR ASSEMBLY	B737
273A2101-9	MLG RETRACT ACTUATOR ASSEMBLY	B737
273A2310-1	LANDING GEAR HYDRAULIC TRANSFE	B737
273A2501-1	ACTUATOR	B737, B727
273A3610-1	MAIN GEAR SHIMMY DAMPER ASSEMB	B737
273A3610-2	MAIN GEAR SHIMMY DAMPER ASSEMB	B737
273A3610-3	MAIN GEAR SHIMMY DAMPER ASSEMB	B737
273A3610-4	MAIN GEAR SHIMMY DAMPER ASSEMB	B737
273A3610-5	MAIN GEAR SHIMMY DAMPER ASSEMB	B737
273A3610-6	MAIN GEAR SHIMMY DAMPER ASSEMB	B737
273A3610-7	MAIN GEAR SHIMMY DAMPER ASSEMB	B737
273N2000-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2000-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2000-7	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2000-8	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-2	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273N2006-5	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	B757
273T1102-8	ACTUATOR	B767
273T4112-4	ACTUATOR NLG RETRACT	B767
273T4561-9	ACTUATOR ASSY	B767
273T4702-1	TAILSKID ACTUATOR ASSEMBLY	B737





P/N	DESCRIPTION	AIRCRAFT PARTS
273T4702-2	TAILSKID ACTUATOR ASSEMBLY	B737
273T6201-3	ACTUATOR BEAR	B727, B767
2-7457-11	MLG DOOR ACTUATOR	B757, B737, B767, B777
2-7457-9	MLG DOOR ACTUATOR	B757
2-7460-5	ANTI SKID	B747, B747-400, B757, B767, B737
2-7460-SERIES	MODULE, ANTI-SKID SHUTTLE DISCONNECT	
2-7464-5	NLG DOOR ACTUATOR	B757
2-7464-7	NLG DOOR ACTUATOR	B757, B737
274N1003-10	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1003-13	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1003-15	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1003-4	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1003-5	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1003-6	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1003-7	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1003-8	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1028-4	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1028-5	BRAKE ACCUMULATOR ISOLATION VA	B737
274N1028-6	BRAKE ACCUMULATOR ISOLATION VA	B737
274U0003-4	BRAKE ACCUMULATOR ISOLATION VA	B737
274U0003-8	BRAKE ACCUMULATOR ISOLATION VA	B737
27531	VALVE, SHUTTLE	C130
2758	AIRCRAFT BATTERY	A320
275N1211-2	NLG STEERING ACTUATOR	B757
275T6221-1	NOSE GEAR STEERING ACTUATOR ASSEMBLY	B767
275T6221-2	NOSE GEAR STEERING ACTUATOR ASSEMBLY	B767
275T6221-3	STEERING ACTUATOR	B767
2-7679-1	FUSE ASSEMBLY, FLOW RATE	B-747, B-767, B-777
2-7679-2	FUSE ASSEMBLY, FLOW RATE	B-747, B-767, B-777
2-7680-1	FLOW RATE FUSE ASSEMBLY	B737-200, B737-300, B737-400, B737-500, B757, B767, B777, B737, B737-200, B737-300, B737-400, B737-500
2-7680-2	FLOW RATE FUSE ASSEMBLY	B-777-200
2-7681-1	FLOW RATE FUSE ASSEMBLY	B-777-200
2-7681-2	FLOW RATE FUSE ASSEMBLY	B737, B757, B777, B-777-200
2-7735-1	HYDRAULIC FUSE	B737, B777
2-7736-1	HYDRAULIC FUSE, NOSE GEAR	B777
2-7737-1	BRAKES HYDRAULIC FUSE ASSY	B737
2-7756-1	HYDRAULIC FUSE	B757
2-7807-1	FUSE AY	
278-1	REFRIGERATION COMPRESSOR	
278-10	REFRIGERATION COMPRESSOR	
278-11	REFRIGERATION COMPRESSOR	
278-12	REFRIGERATION COMPRESSOR	
278-13	REFRIGERATION COMPRESSOR	
278-14	REFRIGERATION COMPRESSOR	
278-15	REFRIGERATION COMPRESSOR	
278-16	REFRIGERATION COMPRESSOR	
278-17	REFRIGERATION COMPRESSOR	
278-18	REFRIGERATION COMPRESSOR	
278-19	REFRIGERATION COMPRESSOR	
278-2	REFRIGERATION COMPRESSOR	
278-20	REFRIGERATION COMPRESSOR	
278-21	REFRIGERATION COMPRESSOR	
278-22	REFRIGERATION COMPRESSOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
278-3	REFRIGERATION COMPRESSOR	
278-4	REFRIGERATION COMPRESSOR	
278-5	REFRIGERATION COMPRESSOR	
278-6	REFRIGERATION COMPRESSOR	
278-7	REFRIGERATION COMPRESSOR	
278-8	REFRIGERATION COMPRESSOR	
278-9	REFRIGERATION COMPRESSOR	
27A10614-101-11	ACCUMULATORS	
2-8011-1	FUSE ASSEMBLY, FLOW RATE	B-777
2-8020-1	FUSE: VOLUMETRIC	B737,B757
2-8020-11	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-12	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-13	HYDRAULIC FUSE	B737, B757, B777
2-8020-14	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-15	HYDRAULIC FUSE	B737,B777,B757
2-8020-16	HYDRAULIC FUSE, NOSE GEAR	B747, B757, B777, B737,DC10
2-8020-18	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-2	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-24	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-25	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-26	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-27	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-28	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-29	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-3	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-5	FUSE ASSEMBLY QUANTITY MEASURING	
2-8020-6	FUSE ASSEMBLY QUANTITY MEASURING	
2804-1-000/1	HIGH SPEED OVEN	
2-8041-1	ANTISKID VOLUMETRIC FUSE ASSEMBLY	B737,B777-200
28107-1	SERVO INTERFACE	
2-8181-2	FUSE ASSEMBLY, FLOW RATE	A330, A330F, A340
282800-1007	AILERON ACTUATOR	
285N0412	HANDSET ASSY	
285N0412-1	ATTENDANT HANDSET ASSY	B757
285N0412-10	ATTENDANT HANDSET	B757
285N0412-2	ATTENDANT HANDSET	B757
285N0412-28	ATTENDANT HANDSET	B757
285N0412-29	ATTENDANT HANDSET	B757
285N0412-3	ATTENDANT HANDSET ASSY	B757
285N0412-30	ATTENDANT HANDSET	B757
285N0412-4	ATTENDANT HANDSET	B757
285N0412-8	ATTENDANT HANDSET ASSY	B757
285N0412-9	ATTENDANT HANDSET ASSY	B757
285N0412-XX	ATTENDANT HANDSET	
285T0001-207	AUDIO ACCESSORY UNIT	
285T0001-209	AUDIO ACCESSORY UNIT	B767
285T0001-77	AUDIO ACCESSORY UNIT	B757, B767
285T0017-102	CSEU POWER SUPPLY	B757
285T0017-103	CSUPWRSUPPLYMOD	B757
285T0017-104	CSEU POWER SUPPLY	B757,B747, B767
285T0017-104 MOD A	CSEU POWER SUPPLY	
285T0017-104 MOD AB	CSEU POWER SUPPLY	
285T0017-104 MOD B	CSEU POWER SUPPLY	
285T0017-201	CSEU POWER SUPPLY ASSEMBLI	B-767,B-757,B-747
285T0017-201MOD A	CSEU POWER SUPPLY ASSEMBLI	B-767,B-757,B-747



P/N	DESCRIPTION	AIRCRAFT PARTS
285T0022-51	AUDIO PANEL CONTROL	
285T0022-51 MOD A	AUDIO PANEL CONTROL	
285T0022-51 MOD AB	AUDIO PANEL CONTROL	
285T0024-18	PILOT CALL PANEL	UNK, B757, B767
285T0024-19	PILOT CALL PANEL	UNK, B757, B767
285T0024-20	MODULE ASSY PILOT CALL PANEL	UNK, B757, B767
285T0024-21	PILOT CALL PANEL	UNK, B757, B767
285T0024-22	PILOT CALL PANEL	UNK, B757, B767
285T0024-23	PILOT CALL PANEL	UNK, B757, B767
285T0024-24	PILOT CALL PANEL	UNK, B757, B767
285T0024-25	PILOT CALL PANEL	UNK, B757, B767
285T0024-26	PILOT CALL PANEL	UNK, B757, B767
285T0024-27	PILOT CALL PANEL	UNK, B757, B767
285T0024-28	PILOT CALL PANEL	UNK, B757, B767
285T0024-29	PILOT CALL PANEL	UNK, B757, B767
285T0024-30	PILOT CALL PANEL	UNK, B757, B767
285T0024-41	PILOT CALL PANEL	B737, B757, B767
285T0024-8	PILOT CALL PANEL	
285T0024-9	PILOT CALL PANEL	UNK, B757, B767
285T0024-SERIES	PILOT CALL PANEL MODULE ASSEMBLY	B757, B767
285T0033-23	Warning Electronics Unit Stall Warning Printed Circuit Assy	B-767,B-757
285T0033-29	Warning Electronics Unit Stall Warning Printed Circuit Assy	B-767,B-757
285T0033-SERIES	Warning Electronics Unit Stall Warning Printed Circuit Assy	B-767,B-757
285T0035-10	MODULE WEU POWER SUPPLY	B747, B757, B767
285T0035-10 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-10 MOD AB	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-10A	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-10AB	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-11	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	B747, B757, B767
285T0035-11 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-11 MOD AB	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-11A	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-11AB	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-3	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	B747, B757, B767
285T0035-3 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-3A	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-9	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	B747, B757, B767
285T0035-9 MOD A	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-9 MOD AB	WARNING ELECTRONIC UNIT POWERSUPPLY ASSY	
285T0035-9A	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0035-9AB	WARNING ELECTRONIC UNIT POWER SUPPLY ASSY	
285T0078-1	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	
285T0078-10	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	
285T0078-15	PLYTKA DRUKOWANA.WENTYL	B767
285T0078-16	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	
285T0078-8	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	
285T0093-11	PCAY PACK FLOW CONTROL	B757,B767
285T0093-11 MOD A	PACK FLOW CONTROL PCB	
285T0093-11A	PACK FLOW CONTROL PCB	
285T0093-8	PACK FLOW CONTROL PCB	B757
285T0096-13	ELECTRONIC ENGINE CONTROL DISCRETE PRINT	B767
285T0096-17	ELECTRONIC ENGINE CONTROL DISCRETE PRINT	



P/N	DESCRIPTION	AIRCRAFT PARTS
285T0096-5	ELECTRONIC ENGINE CONTROL DISCRETE PRINT	
285T0096-7	PC ASSY-EEC	B757,B767
285T0099-12	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-12 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-12A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-13	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-13 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-13 MOD B	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-13A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-13B	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-15	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-15 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-15A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17	MODULE-FLAP/STAB POSITIO	B757,B767
285T0099-17 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17 MOD B	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-17 MOD BC	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17B	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-17BC	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0099-7	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-7 MOD A	FLAP/STAB POSITION MODULE ASSEMBLY	B757, B767
285T0099-7A	FLAP/STAB POSITION MODULE ASSEMBLY	
285T0471-17	P/C AY	
285T0496-1	EICAS DSPL SWITCH MODUL	B767,B757
285T0553-1	ILS CONTROL PANEL	B757, B767
285T0553-2	ILS CONTROL PANEL	B757, B767
285T0553-3	ILS CONTROL PANEL	B757, B767
285T0553-4	ILS CONTROL PANEL	B757, B767
285T0553-X	ILS CONTROL PANEL	
285T0554 SERIES	VOR CONTROL PANEL	
285T0554-3	VOR CONTROL PANEL	B757, B767
285T0554-3 MOD. A	VOR CONTROL PANEL	
285T0554-3 MOD. B	VOR CONTROL PANEL	
285T0554-3 MOD. C	VOR CONTROL PANEL	
285T0554-3 MOD. D	VOR CONTROL PANEL	
285T0554-3 MOD. E	VOR CONTROL PANEL	
285T0554-3A	VOR CONTROL PANEL	
285T0554-3B	VOR CONTROL PANEL	
285T0554-3C	VOR CONTROL PANEL	
285T0554-3D	VOR CONTROL PANEL	
285T0554-3E	VOR CONTROL PANEL	
285T0554-4	VOR CONTROL PANEL	B757, B767
285T0554-4 MOD. A	VOR CONTROL PANEL	
285T0554-4A	VOR CONTROL PANEL	
285T0554-5	VOR/DME CONTROL PANEL	B757, B767
285T0554-5 MOD. A	VOR CONTROL PANEL	
285T0554-5 MOD. B	VOR CONTROL PANEL	
285T0554-5 MOD. C	VOR CONTROL PANEL	
285T0554-5 MOD. D	VOR CONTROL PANEL	
285T0554-5 MOD. E	VOR CONTROL PANEL	
285T0554-5A	VOR CONTROL PANEL	
285T0554-5B	VOR CONTROL PANEL	
285T0554-5C	VOR CONTROL PANEL	
285T0554-5D	VOR CONTROL PANEL	



P/N	DESCRIPTION	AIRCRAFT PARTS
285T0554-5E	VOR CONTROL PANEL	
285T0554-6	VOR CONTROL PANEL	B757, B767
285T0554-6 MOD. A	VOR CONTROL PANEL	
285T0554-6 MOD. AB	VOR CONTROL PANEL	
285T0554-6A	VOR CONTROL PANEL	
285T0554-6AB	VOR CONTROL PANEL	
285T0554-6B	VOR CONTROL PANEL	
285T0557-1	ADF CONTROL PANEL	B757, B767
285T0557-2	ADF CONTROL PANEL	B757, B767
285T0557-X	DUAL ADF CONTROL PANEL	
285T0852	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0852-1	KEYPAD COKPIT DOOR ACCESS	B737,B757,B777
285T0852-1 MOD A	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0852-1 MOD AB	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0852-1A	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0852-1B	FLIGHT DECK ACCESS MODULE KEYPAD	
285T0855-1	CONTROLLER DOOR ACCESS	B777,B757,B737,B767
285T0855-5	CONTROLLER FDAS	B777,B757,B737
285T0855-6	FLIGHT DECK ACCESS SYSTEM CONTROLLER MODULE ASSEMBLY COMPONENT	
285T1104-1	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-10	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-11	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-13	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-15	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17 MOD B	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17 MOD BC	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17 MOD C	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-17B	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR PRINTED CIRCUIT ASSEMBLY	B-767,B-757
285T1104-17BC	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR PRINTED CIRCUIT ASSEMBLY	B-767,B-757
285T1104-17C	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR PRINTED CIRCUIT ASSEMBLY	B-767,B-757
285T1104-18	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-18 MOD A	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-18 MOD AB	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-18 MOD B	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-18A	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR PRINTED CIRCUIT ASSEMBLY	B-767,B-757
285T1104-18AB	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR PRINTED CIRCUIT ASSEMBLY	B-767,B-757
285T1104-18B	WARNING ELECTRONIC UNIT STALL WARNING/WIND SHEAR PRINTED CIRCUIT ASSEMBLY	B-767,B-757
285T1104-19	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-21	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-22	PC ASSY - STALL WARNING	B-767,B-757
285T1104-23	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-24	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-9	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1104-SERIES	WARNING ELECT UNIT STALL WARN/WIND SHEAR	B-767,B-757
285T1111-1	Warning Electronics Unit Bite Display Printed Circuit Assy	B-767,B-757



P/N	DESCRIPTION	AIRCRAFT PARTS
285T1111-SERIES	Warning Electronics Unit Bite Display Printed Circuit Assy	B-767,B-757
28B135-126-A	AC GENERATOR	
28B135-133-A	AC GENERATOR	
28B135-29-A	AC GENERATOR	
28B263-13A	AC GENERATOR	
28B545-7	GENERATOR	B737,B707
28B545-7A	STARTER GENERATOR	B737
28B545-7B	STARTER GENERATOR	B737
28B545-9	STARTER/GENERATOR	
28B555-1	AC GENERATOR	
28B555-1-A	AC GENERATOR	
28B555-1-B	AC GENERATOR	
28B555-1-C	AC GENERATOR	
28B555-1-D	AC GENERATOR	
28B555-1-E	AC GENERATOR	
28B58-9A	ALTERNATING CURRENT GENERATOR	
28B58-9-A	AC GENERATOR	C-130
28B58-9B	AC GEN	
28B58-9-B	AC GENERATOR	C-130
28B95-15	AC GENERATOR	P3 ORION, P3 CONVERSION
28B95-15D	GENERATORAL TERNATI	
28B95-15-D	AC GENERATOR	
28B95-15DV	GENERATOR ASSY	P3 ORION, P3 CONVERSION
28B95-15D-V	GENERATORAL TERNATI	
28B95-15-SERIES	AC GENERATOR	
28B95-57	AC GENERATOR	
28B95-57-A	AC GENERATOR	
28B95-65A	GENERATOR ASSY	P3 ORION, P3 CONVERSION
28B95-9	AC GENERATOR	
28B95-9-SERIES	AC GENERATOR	
29000	VALVE VENTILATION FUEL	
291-10	NAVIGATION LIGHT	ATR-72
29-1205246-00	DELAY VALVE	A340
29145	ANTENNE DESMONTABLE	
292-00	ANTI-COLLISION LIGHT ASSEMBLY	ATR42, ATR72
292-01	ANTI-COLLISION LIGHT ASSEMBLY	ATR42, ATR72
292-12	STROBE LIGHT	ATR-42, ATR-72,B727
292-13	STROBE LIGHT	ATR-72,B727
292-23	STROBE LIGHT PS	ATR-42, ATR-72,B727
292-24	STROBE LIGHT	ATR-42, ATR-72,B727
292-25	POWER SUPPLY	ATR-42, ATR-72
2944T100-SERIES	POWER DRIVE UNIT	
2955T100-SERIES	POWER DRIVE UNIT	
2CM16SAB2	STATOR ASSY	
2CM353CTH	AC GEN	
2LA005303-01	TAIL STROBE LIGHT	A318, A319, A320, A321, A330, A330F, A340
2LA005303-05	TAIL STROBE LIGHT	A318, A319, A320, A321, A330, A330F, A340
2LA005308-01	WING STROBE LIGHT	A318, A319, A320, A321, A330, A330F, A340
2LA005308-05	WING STROBE LIGHT	A318, A319, A320, A321, A330, A330F, A340
2LA007417-00	MODULE EQUIP READING LIGH	Saab340



P/N	DESCRIPTION	AIRCRAFT PARTS
2LA455010-00	STROBE LIGHT	A300-600, A310, A318, A319, A320, A321, A330, A330F, A340, AST
2LA455010-06	STROBE LIGHT	A300-600, A310, A318, A319, A320, A321, A330, A330F, A340, AST
2LA455010-21	STROBE LIGHT	A300-600, A310, A318, A319, A320, A321, A330, A330F, A340, AST
30059-1471	BACKPLATE DAMPENER	
30059-1480	PLATE DAMPENER	
30076-2460	BACKPLATE DAMPENER	
30079-2460	BLACKPLATE DAMPENER	
30080-1080	PM STATOR	
30080-1090	STATOR EXCITER	
30081-001	DC GENERATOR	
30081-010	DC GENERATOR	
30-0837-1	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727
30-0837-11	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B727, B737, B707
30-0837-13	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, C-130, B707, B727,CRJ
30-0837-15	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, C-130, B707, B727,CRJ
30-0837-17	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-19	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-21	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B727, B737, B707
30-0837-23	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-25	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-29	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-3	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-31	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727
30-0837-33	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-35	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-39	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-41	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-47	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-5	LIGHT ASSY	B737, B707, B727
30-0837-7	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,CRJ
30-0837-9	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B707, B727,DASH8
30-0881-1	STROBE LIGHT	A320
300-90496-0501	CIRCUIT CARD ASSEMBLY	
30-0906	STROBE LIGHT	
30-0906-1	STROBE LIGHT	
30-0906-10	STROBE LIGHT	
30-0906-101	STROBE LIGHT	
30-0906-103	STROBE LIGHT	
30-0906-104	STROBE LIGHT	B737, B727,MD80
30-0906-105	WING POS LIGHT	B737, B727,MD80
30-0906-106	STROBE LIGHT	
30-0906-107	STROBE LIGHT	
30-0906-109	STROBE LIGHT	
30-0906-110	STROBE LIGHT	
30-0906-111	STROBE LIGHT	
30-0906-113	STROBE LIGHT	
30-0906-115	STROBE LIGHT	
30-0906-116	STROBE LIGHT	
30-0906-117	STROBE LIGHT	
30-0906-118	STROBE LIGHT	
30-0906-119	STROBE LIGHT	
30-0906-121	STROBE LIGHT	



P/N	DESCRIPTION	AIRCRAFT PARTS
30-0906-122	STROBE LIGHT	
30-0906-123	STROBE LIGHT	
30-0906-124	STROBE LIGHT	
30-0906-125	STROBE LIGHT	
30-0906-126	STROBE LIGHT	
30-0906-128	STROBE LIGHT	
30-0906-129	STROBE LIGHT	
30-0906-13	STROBE LIGHT	
30-0906-15	STROBE LIGHT	
30-0906-17	STROBE LIGHT	
30-0906-19	STROBE LIGHT	
30-0906-21	STROBE LIGHT	
30-0906-22	STROBE LIGHT	
30-0906-23	STROBE LIGHT	
30-0906-24	STROBE LIGHT	
30-0906-25	STROBE LIGHT	
30-0906-26	STROBE LIGHT	
30-0906-3	STROBE LIGHT	
30-0906-4	STROBE LIGHT	
30-0906-5	STROBE LIGHT	
30-0906-6	STROBE LIGHT	
30-0906-7	STROBE LIGHT	
30-0906-9	STROBE LIGHT	
30-0906-SERIE	STROBE LIGHT	
30-0906-SERIES	HIGH- INTENSITY STROBE LIGHT	
30-0909-1	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737
30-0909-101	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737, B747,MD80
30-0909-103	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737,B727
30-0909-107	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737
30-0909-201	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737,B767
30-0909-203	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737
30-0909-207	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	B737
300SG SERIES	STARTER GENERATOR	
300SG1064	ARMATURE	
300SG1156	FIELD	
300SGL	STARTER GENERATOR	
300SGL SERIES	STARTER GENERATOR	
300SGL127Q	STARTER GENERATOR	DASH 8
300SGL153Q	STARTER GENERATOR	
30-1033	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-1	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-11	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-13	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-15	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-17	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-19	LIGHT-ANTI-COLLISION	C-212, CN-235, C-295,EMB
30-1033-21	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-23	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-25	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-27	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-29	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-3	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	EMB
30-1033-31	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-33	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-35	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	





P/N	DESCRIPTION	AIRCRAFT PARTS
30-1033-37	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-39	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-41	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-43	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-45	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-49	LIGHT	CN-235, C-295, EMB
30-1033-5	LIGHT ANTI COLLISION	CRJ700
30-1033-51	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-53	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-55	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-57	LIGHT-ANTI-COLLISION	CN-235, C-295, EMB
30-1033-59	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-61	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-63	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-65	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-67	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-7	AIRCRAFT NAVIGATIONAL LIGHT ANTI-COLLISION	
30-1033-SERIES	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	
30-1401-1	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30-1401-11	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30-1401-13	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30-1401-15	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30-1401-3	LIGHT ASSY	B737, B727, B767
30-1401-9	AIRCRAFT NAVIGATIONAL, STROBE LIGHT	B737, B727, B757
30-1738-3	WING POSITION LIGHT	C-295
30-1738-4	LIGHT-RIGHT POSITION(IR)	CN-235
30210	ACCUMULATOR HYDRAULIC	B737
30220	ACCUMULATOR HYDRAULIC	B747, B747-400, B737, B757
3022053-000	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	A330, A340, A340-500/600
3022053-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	A330, A340, A340-500/600
3024372	AUTOTRANSFORMER	
30-2505-3	UPPER FUSELAGE ANTI- COLLISION LIGHT	B737-800/900
30-2506-3	LOWER AIRCRAFT ANTICOLLISION FUSELAGE STROBE LIGHT	B737-800/900
30-2581-3	TAIL LOGO LIGHT	
30-2610-1	STROBE LIGHT	Dash8, CRJ
30-2683-1	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700
30-2683-10	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700
30-2683-11	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700
30-2683-12	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700
30-2683-13	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700
30-2683-14	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700
30-2683-2	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700
30-2683-5	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700
30-2683-6	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700



P/N	DESCRIPTION	AIRCRAFT PARTS
30-2683-9	WING POSITION NAVIGATIONAL LIGHT	B-727-200, EMB-190, B-737-800, B-737-700
30-2722-01	STROBE LIGHT ASSY	
3029683-001	HYDRAULIC MOTORPUMP ASSEMBLY	A319, A320, A321, A330, A340
3029981-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASS	DC-9, MD-80, MD-90
3031863-001	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	B747, B757, B767, A320, A320-100
3031863-001	HYDRAULIC PUMP	A320 NEO, A321 NEO
3031863-002	HYDRAULIC PUMP	A320 NEO, A321 NEO
30527-320	CONTROL UNIT	A300, A300-600, A310
3057992	AUTOTRANSFORMER	
3058959	STATOR	
3059-1471	BACKPLATE DAMPENER	
3076518	STATOR ASSY BRAKE	
3076548	STATOR	
31008-1066	ROTOR	
31073-052	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-053	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-054	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-055	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-057	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-058	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-060	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-063	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-064	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-065	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-067	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-068	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-080	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-090	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-100	AILERON SERVOCONTROL	A318, A319, A320, A321
31073-110	AILERON SERVOCONTROL	A318, A319, A320, A321
31077-100	INBOARD SPOILER ACTUATOR	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
31077-111	INBOARD SPOILER ACTUATOR	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
31077-200	INBOARD SPOILER ACTUATOR	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
31077-211	INBOARD SPOILER ACTUATOR	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
3111317	AUTOTRANSFORMER ASSY	
31164 SERIES	AC GENERATOR	
31164-1350	ROTOR EXCITER	
31164-1420	STATOR PM	
31164-5532	ROTOR	
31216-001	5 KVA GENERATOR AC	
3121624	AUTOTRANSFORMER	
3121631	AUTOTRANSFORMER	
31220-004	AC GENERATOR	UNK, C-130
31220-1020	STATOR	
312BS101-1	ISFD DEDICATED BATTERY CHARGER (DBC)	B737, B757, B767
31340-1032	STATOR MAIN	



P/N	DESCRIPTION	AIRCRAFT PARTS
31342-001	ALTERNATOR	CN-235
31342-003	GENERATOR-AC26KVA	CN-235
31342-004	GENERATOR-AC	CN-235, C-295
31342-006	AC GENERATOR	CN-235, C-295
31342-007	AC GENERATOR	C-295
31342-352	ROTOR ASSEMBLY	CN-235, C-295
314195	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASS	DC-9, MD-80, MD-90
3142-003	AC GENERATOR (26KVA	
3-1486	WHEEL ASSEMBLY	
315344	FIELD ASSY	
315A1701-111	LH THRUST REVERSER ASSY	
315A1701-12	THRUST REVERSER ASSY, RH	
315A1701-40	Thrust reverser	
315A1701-48	THRUST REVERSER	
315A1701-6	THRUST REVERSER	
315A1701-64	THRUST REVERS	
315A1701-77	THRUST REVERSER	B737
315A1701-78	THRUST REVERSER	
315A1701-78A	THRUST REVERSER	
315A1701-79	THRUST REVERSER	B737
315A1701-81	THRUST REVERSER	
315A1701-84	THRUST REVERSER	
315A1701-9	LH THRUST REVERSER ASSY	
315A1801-14	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-15	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-18	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-19	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-22	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-23	THRUST REVERSER HYDRAU	B737
315A1801-26	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B737
315A1801-27	THRUST REVERSER HYDRAU	B737
315A2800-1	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBLY	B-737
315A2800-2	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBLY	B-737
315A2801-1	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B-737
315A2801-4	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B-737
315A2801-5	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	B-737
31-7611-1	NAVIGATIONAL LIGHT SUBASSEMBLY	B-777-200
31-7611-2	NAVIGATIONAL LIGHT SUBASSEMBLY	B-777-200
3180131-1	ACCUMMULATOR	DC-10
3180131-2	ACCUMMULATOR	DC-10
3180131-3	ACCUMMULATOR	DC-10
3181-196-901	VACUUM AND PRESURE	
3181-233-901	VACUUM AND PRESURE	
32032-1900	HUB DAMPENER	
321-400-703-0	DOOR OPENING HYDRAULIC ACTUATOR	A320
321-400-704-0	DOOR OPENING HYDRAULIC ACTUATOR	A320
321-400-705-0	DOOR OPENING HYDRAULIC ACTUATOR	A320, A320-100
322200-10M00	NOSE WHEEL STEERING HANDWHEEL	A340
322200-1M00	NOSE WHEEL STEERING HANDWHEEL	A330
322200-2M00	NOSE WHEEL STEERING HANDWHEEL	A330
322200-9M00	NOSE WHEEL STEERING HANDWHEEL	A340
3250-70	BALLAST UNIT	A319, A320, A321, A320-100
3250-80	BALLAST UNIT	A319, A320, A321, A330, A340
3250-81	BALLAST	A320, A330, A340, A319
3282970-2	STOP MECHANISM	A-319, A-320, A-321, A-330, A-340,



P/N	DESCRIPTION	AIRCRAFT PARTS
3282970-3	STOP MECHANISM	A-319, A-320,A-321, A-330, A-340,
3282970-4	STOP MECHANISM	A-319, A-320,A-321, A-330, A-340,
3282970-5	STOP MECHANISM	CFM56-5A, 5B, 5C
3290003-44	EQUIPO FLIR THERMOGRAPHY	
3302196-13	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3302196-15	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3302196-19	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3303591-1	STRUT ASSEMBLY NOSE LANDING GEAR	C130
33-065-1	NORMAL ANTISKID VALVE MODULE (AVM)	B747,B757,B767
33-065-2	NORMAL ANTISKID VALVE MODULE (AVM)	B747,B757,B767
33-067-1	ALTERNATE ANTISKID VALVE MODULE (AVM)	B747,B757,B767
33-067-2	ALTERNATE ANTISKID VALVE MODULE (AVM)	B747,B757,B767
3314203-3	STRUT ASSY NOSE LANDING GEAR	C-130
3316498-1	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3316498-7	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3316500-15	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
332587	SHAFT DRIVE	
332A67-5840-01	AIR CONDITIONING CONTROL PANEL	
33793-3	RECEIVER, TRANSMITTER	
33823-2	CONTROL, RADAR SET	
33824-1	INDICATOR, AZIMUTH	
33862	MODULAR TX / RX	
33A64-1612-010	CONTROL BOX	
3402292-1	PANEL CONTROL	
340-7005-503	LINK TRUST R/H FWD	
340-7005-504	LINK TRUST L/H FWD	
340-7006-503	FWD MOUNT/CLEVIS ASSY LH	
340-7006-506	FWD MOUNT/CLEVIS ASSY RH	
340-7006-507	THRST MNT LNK L/H	
340-7006-510	THRST MOUNT LNK R/H	
341983	NOSE LANDING GEAR UPLOCK ASSEMBLY	
34265	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-1	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-10	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-11	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-12	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-13	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-14	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-15	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-16	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-17	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-2	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-3	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767



P/N	DESCRIPTION	AIRCRAFT PARTS
34265-4	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-5	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-6	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-7	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-8	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34265-9	COCKPIT LIGHT	B-707, B-727, B-737, B-747, B-757, B-767
34-61-11	-	
34755-5	CONTROL RADAR SET	
350448-5	STARTER	
350571-6	STARTER	
350880-6	VARIABLE DISPLACEMENT HYDRAULIC PUMP	B757, B767, DC-10, MD-11, A300-600, A310, B737, A320
350880-7	HYD PUMP	B757, B767, A300-600, A310, DC10, A320
35-825196-698	GEAR ASSY NOSE	
358800-1	NOSE LANDING GEAR UPLOCK ASSEMBLY	
358800-5	NOSE LANDING GEAR UPLOCK ASSEMBLY	
358800-9	NOSE LANDING GEAR UPLOCK ASSEMBLY	
35H	EXTINTOR	
3603100-1	FUEL CONTROL ASSEMBLY	
3603100-2	FUEL CONTROL ASSEMBLY	
3603100-9	FUEL CONTROL ASSEMBLY	
36051812-17	ELECTRICAL ENGINE STARTER	B-737-100/-200/-300/-400/-500
3605812-1	ELECTRICAL ENGINE STARTER	B737
3605812-10-1	ELECTRICAL ENGINE STARTER	B727, B737
3605812-11	ELECTRICAL ENGINE STARTER	B727
3605812-12	ELECTRICAL ENGINE STARTER	B727, C-130
3605812-13-1	ELECTRICAL ENGINE STARTER	B727, B737
3605812-14-1	ELECTRICAL ENGINE STARTER	B727, C-130, B737
3605812-16	ELECTRICAL ENGINE STARTER	B727, B737, C-130
3605812-17	ELECTRICAL ENGINE STARTER	B727, C-130, B737
3605812-18	ELECTRICAL ENGINE STARTER	B727, C-130
3605812-19	ELECTRICAL ENGINE STARTER	B727, B737
3605812-21	ELECTRICAL ENGINE STARTER	
3605812-2-1	ELECTRICAL ENGINE STARTER	B737
3605812-22	ELECTRICAL ENGINE STARTER	B-737-100/-200/-300/-400/-500
3605812-22-1	STARTER MOTOR ASSY	B-737-100/-200/-300/-400/-500, B727, MD80
3605812-3	ELECTRICAL ENGINE STARTER	
3605812-4	ELECTRICAL ENGINE STARTER	
3605812-9	ELECTRICAL ENGINE STARTER	
360900	SWITCH	
3609150-8	FUEL CONTROL ASSEMBLY	
3614278-1130	WEATHER CONTROL PANEL	
3617750-1	FCU APU	B727, B737, DC-8, DC-9, MD-80, MD80
3617750-2	TURBINE TYPE FUEL CONTROL UNIT	B737, B727, MD80
3617750-3	TURBINE TYPE FUEL CONTROL UNIT	B727, B737, DC-8, DC-9, MD-80
3617750-4	TURBINE TYPE FUEL CONTROL UNIT	B727, B737, DC-8, DC-9, MD-80
368-105	INTERRUPTOR, PULSADO	
36E135-2C	STARTER	



P/N	DESCRIPTION	AIRCRAFT PARTS
36E84	STARTER	
3704-1-000/1	HIGH SPEED OVEN	
370438-1	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
37100-1001	CLG DRESSED SHOCK STRUT	A340
371380	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
371688	FUEL CONTROL UNIT	
371688 SERIES	FUEL CONTROL UNIT	
371688-10	FUEL CONTROL UNIT	
37-231	ANTISKID SER. VAL.	B737
375322-10	ELECTRICAL ENGINE STARTER	
375322-7	ELECTRICAL ENGINE STARTER	
375322-8	ELECTRICAL ENGINE STARTER	
375322-9	ELECTRICAL ENGINE STARTER	C-130, B737
380258-1	PNEUMATIC AND SHAFT POWER GAS TURBINE ENGINE	
3804-1-000/1	HIGH SPEED OVEN	
380-97-1	380-97-1	A330
3810056-101	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-103	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-104	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-105	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-106	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-107	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-108	MODULE CONTROL VALVE THRUST REVERSER	B737
3810056-109	MODULE CONTROL VALVE THRUST REVERSER	B737
381116-1-7	ENGINE, GAS, TURBINE	C-130
381116-1-8	AUXILIARY POWER UNIT	C-130
381785	ROTOR	
381800-1001	LEADING EDGE SLAT ACTUATOR ASSEMBLY	B737
381800-1003	LEADING EDGE SLAT ACTUATOR ASSEMBLY	B737
381800-1005	LEADING EDGE SLAT ACTUATOR ASSEMBLY	B737
38210-394	VARIOMETRE	
383534-2-1	STARTER	C-130
383534-2-2	STARTER	C-130
3862160-9	APU COOLING FAN	B747, B757, B767, A300, A310
388058-1	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
388058-19	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
388058-9	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
3882350	FUEL CONTROL UNIT	
3882350 SERIES	FUEL CONTROL UNIT	
3882825-1	FUEL CONTROL ASSEMBLY	A320, B-737-500, B-737-300, B-737-400, MD-80
3882825-2	FUEL CONTROL ASSEMBLY	A320, B-737-500, B-737-300, B-737-400, MD-80
3882825-3	FUEL CONTROL ASSEMBLY	A320, B-737-500, B-737-300, B-737-400, MD-80
3882825-4	FUEL CONTROL ASSEMBLY	A320, B-737-500, B-737-300, B-737-400, MD-80
3882825-5	FUEL CONTROL ASSEMBLY	A320, B-737-500, B-737-300, B-737-400, MD-80
3882825-6	FUEL CONTROL ASSEMBLY	A320, B-737-500, B-737-300, B-737-400, MD-80
3882825-8	FUEL CONTROL ASSEMBLY	A320, B-737-500, B-737-300, B-737-400, MD-80
3882825-9	FUEL CONTROL ASSEMBLY	A320, B-737-500, B-737-300, B-737-400, MD-80



P/N	DESCRIPTION	AIRCRAFT PARTS
3883220-3	ACTUATOR IGV	A320, A320-100,B737
3883240-3	FUEL CONTROL ASSEMBLY	A340, A330
3883240-5	FUEL CONTROL ASSEMBLY	A340, A330
3883240-6	FUEL CONTROL ASSEMBLY	A340, A330
3883240-7	FUEL CONTROL ASSEMBLY	A340, A330
3888217-2	STARTER	A330, A340, B767,A310
3888217-3	APU STARTER	A330, A340, B767,A310
3888217-4	STARTER	A330, A340, B767,A310,MD80
3888217-X	STARTER	
3890010-102	PRESSURE RELIEF VALVE	B737
3890010-103	PRESSURE RELIEF VALVE	B737,B777
38H	EXTINTOR	
39-043A	PRESSURE CONTROL VALVE	B737
3910-0101-0000	HOUSING MOTOR	
39-249	DUAL PRESSURE CONTROL VALVE	DC-9
39-249-1	DUAL PRESSURE CONTROL VALVE	DC-9,B727
39-249-2	DUAL PRESSURE CONTROL VALVE	MD-80,DC9
3930-0100-0000	HOUSING ASSY	
393007-07869	INDICATOR ASSEMBLY CAPACITOR FUEL GAGE SYSTEM	P3 ORION, P3 CONVERSION
393007-07870	INDICATOR ASSEMBLY CAPACITOR FUEL GAGE SYSTEM	P3 ORION, P3 CONVERSION
393065-01858	INDICATOR	P3 ORION, P3 CONVERSION
39-353	HYD. VALVE	B737
394324	FLOW DIVIDER AND DRAIN	
394324 SERIES	FLOW DIVIDER AND DRAIN	
394390	FLOW DIVIDER AND DRAIN	
394390 SERIES	FLOW DIVIDER AND DRAIN	
394408	FLOW DIVIDER AND DRAIN	
394408 SERIES	FLOW DIVIDER AND DRAIN	
39-483	DUAL PRESSURE CTRL VALVE	B737
396362	ELECTRIC MOTOR ASSEMBLY	
396800	BLEED VALVE FUEL GEAR MOTOR	
396800-10	MOTOR GEAR HYDRAULIC	A318, A319, A320, A321
396800-11	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-12	MOTOR GEAR HYD	A318, A319, A320, A321,B717, MD90
396800-5	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-6	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-7	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-8	MOTOR GEAR HYDRAULIC	A318, A319, A320, A321
396800-9	BLEED VALVE FUEL GEAR MOTOR	A318, A319, A320, A321
396800-SERIES	BLEED VALVE FUEL GEAR MOTOR	
39900-303	VALVE	
399300-2	FUEL BOOSTER PUMP, SINGLE FUEL VOLUTE HOUSING & DOUBLE PUMP VOLUTE HOUSING	
399500-1	FUEL BOOSTER PUMP, SINGLE FUEL VOLUTE HOUSING & DOUBLE PUMP VOLUTE HOUSING	
3D3554-02	ISOLATION VALVE,DE-ICING	C-295
3LO-453	SWITCH-INERTIA 4G	ATR
3M304-6-10-0	RECEPTACLE	
3P99-136	STATOR	
4000695-6221	RECEIVER, RADIO NAVIG	
400SG SERIES	STARTER-GENERATOR	
400SG1008-1	END BELL	
400SG1028	HEAD MOUNTING, DE	
400SG1064	ARMATURE	
400SG1064-XL	ARMATURE	



P/N	DESCRIPTION	AIRCRAFT PARTS
400SG1156-11	STATOR ASSY	
400SG1156-32	FIELD	
400SG1156-35	FIELD	
400SG1156-36	FIELD	
400SG1301	END BELL	
400SG138Q	STARTER GENERATOR	Learjet
400SG159Q	STARTER GENERATOR	Learjet
400SG2064	ARMATURE ASSY	
40109-1	AIRCRAFT BATTERY	CN-235, C-295, P3 CONVERSION
40143	PUMP & MOTOR PACKAGE ASSEMBLY	C-212
40180	ELECTRIC HYD PUMP	
4019501	HYDRAULIC PUMP	ATR-72,Saab340
40-195-01	AC ELECTRIC HYDRAULIC PUMP	ATR-42
40205-1	LANDING LIGHT	
40205-1-4559	LANDING LIGHT	
40205-2	LANDING LIGHT	
40205-2-4559	LANDING LIGHT	
40205-3	LANDING LIGHT	
40205-3-4559	LANDING LIGHT	
40205-3-Q4559	LANDING LIGHT	
40205-3-Q4559X	LANDING LIGHT	
40205-4	LANDING LIGHT	
40205-4-4559	LANDING LIGHT	
40205-5	LANDING LIGHT	
40205-5-4559	LANDING LIGHT	
40205-6	LANDING LIGHT	
40205-6-Q4559	LANDING LIGHT	
40205-7-4559	LANDING LIGHT	
40205-7-Q4559	LANDING LIGHT	
402306-3	NLG STEERING CYLINDER ASSY	C-130
402306-5	NLG STEERING CYLINDER ASSY	
402306-7	NLG STEERING CYLINDER ASSY	
4037102	TAKE-OFF AND TAXI LIGHT	
4037132	TAKE-OFF AND TAXI LIGHT	
4049A	PUMP	C-212
40-533	HYTROL WHEEL SPEED TRANSDUCER	B737
40-621	WHEEL SPEED TRANSDUCER	C130
4065713	WING ICING INSPECTION LIGHT	
4065729	WING ICING INSPECTION LIGHT	
407009-1	INIDICATOR AZIMUTH	
4071	NICKEL-CADMIUN AIRCRAFT BATTERY	
4071-1	NICKEL-CADMIUN AIRCRAFT BATTERY	
4071-2	NICKEL-CADMIUN AIRCRAFT BATTERY	
41000740-103	THRUST REVERSER VALVE ASSEMBLY	
41000740-104	THRUST REVERSER VALVE ASSEMBLY	A300, A320, A330
4100519	STATOR ASSEMBLY	
4101054	LAVATORY / GALLEY VENT FAN	B737,B757
4101099F	FAN	A310, A320
4105DA	LANDING GEAR VALVE	B737
4122-009004	MOTOR PUMP	CN-235
4129RA	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA1	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA10	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA2	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA3	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737





P/N	DESCRIPTION	AIRCRAFT PARTS
4129RA4	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737, B757, B767
4129RA5	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA6	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA7	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737
4129RA8	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737, B747, B767
4129RA9	NOSE WHEEL STEERING METERING VALVE ASSEMBLY	B737, B757, B767, B777
4133801030	WHEEL PRESSURE TRANSDUCER	A318
414469	ELECTRIC MOTOR ASSEMBLY	
415509	HYDRAULIC PUMP	
4173763	LANDING LIGHT	A320
4191695	RETRACTABLE LANDING LIGHT	A300, A310, A320, A321
41C220-53	VALVE	P3 ORION, P3 CONVERSION
41EN49-6	SQUAT SWITCH	
42011	VARIABLE DELIVERY HYDRAULIC PUMP	FOKKER 50
4203503	HYD MOTOR	A320
42053	AUXILIARY HYDRAULIC ELECTRIC AC PUMP	ATR-42
4205400	VARIABLE DELIVERY HYDRAULIC PUMP	A300, 757-200, 747-100, 757-200, 757-300, 757-400, A320
4205401	VARIABLE DELIVERY HYDRAULIC PUMP	A300, 757-200, 747-100, 757-200, 757-300, 757-400, A320
4205601	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC PUMP	A319, A320, A321, A330, A340
4205602	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC PUMP	A319, A320, A321, A330, A340
4205603	ELECTRIC MOTOR DRIVEN VARIABLE DELIVERY HYDRAULIC PUMP	A319, A320, A321, A330, A340
4207902	HYDRAULIC PUMP	A330
4207904	HYDRAULIC PUMP	A330
4209939	AUTOTRANSFORMER	
4209946	AUTOTRANSFORMER, ASSY	
4213966	LOGO LIGHT	ATR-42, ATR-72
4213973	LIGHT TAXI	ATR-42, ATR-72, ATR
4213989	LIGHT LANDING	ATR-42, ATR-72
42-265	CONTROL BOX ASSEMBLY	B737
4233488	TAKE OFF LIGHT	A318, A319, A320, A321
4236534	RUNWAY TURN OFF LIGHT	A320
4236564	TAXI LIGHT	A319, A321, A310, A320
424244	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
4254964	AUTOTRANSFORMER, ASSY	
426368-1	SCREEN	
426368-3	RECEIVER, TRANSMITTER	
42-651-01	ANTI-SKID/AUTOBRAKE CTRL UNIT	B737
4273511	TAKE-OFF AND TAXI LIGHT	
4273527	TAKE-OFF AND TAXI LIGHT	
4289452	WING SCAN LIGHT	A330, A340
4289468	WING SCAN LIGHT	A330, A340
4292209	LANDING LIGHT	A340
4292491	LOGO LIGHT	A330, A340, A320
4292915	LIGHT LANDING	ATR-42, ATR-72
4295078	ENGINE SCAN LIGHT	A330, A340
4295085	ENGINE SCAN LIGHT	A330, A340
4295092	ENGINE SCAN LIGHT	A330, A340
4295107	ENGINE SCAN LIGHT	A330, A340
4295114	ENGINE SCAN LIGHT	A330, A340
4295121	ENGINE SCAN LIGHT	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
4295747	LIGHT TAXI	ATR-42, ATR-72
4298117	TAKE-OFF AND TAXI LIGHT	A330, A340
4299172	AUTOTRANSFORMER	A330, A340
430084-1	CAJA	
430110	ENGINE DEDICATED ALTERNATOR	A330, A340, A320
430116	ENGINE DEDICATED ALTERNATOR	A330, A340
430153	ENGINE DEDICATED ALTERNATOR	A320, A320-100
430201	ENGINE DEDICATED ALTERNATOR	A320, A320-100
430201-1	UNISON STATOR	A330, A340, A320
430202	ENGINE DEDICATED ALTERNATOR	A330, A340
430202-1	STATORA ALTERNATOR	A330, A340
430219	ALTERNATOR STATOR	A330, A340
4305890050	TRANSMITTER	A330
4315542	RETRACTABLE LANDING LIGHT	A319, A320
4319586	LIGHT LANDING	ATR-42, ATR-72
4325159	AUTOTRANSFORMER, EQUIPPED	A330, A340
4325173	AUTOTRANSFORMER	A330, A340
4328733	LOGO LIGHT	A330, A340, A320
4331772	RETRACTABLE LANDING LIGHT	A321, A320
4333302	LOGO LIGHT	B757
4333318	LOGO LIGHT	B757
4333325	LOGO LIGHT	B757
4333332	LOGO LIGHT	B757
435161-1	AMPLIFIER, ELECTRONIC	
4358532	LOGO LIGHT	A340, A330, A320
438023-2	INDICATOR TORQUEMET	
44090-3941-03	ANEMOMETRE	
443147-2	INDICATOR TORQUEMET	
45-0057-1	RETRACTABLE LANDING LIGHT ASSEMBLY	DC-9, MD-80, MD-90,DC10
45-0057-3	RETRACTABLE LANDING LIGHT ASSEMBLY	MD-80, MD-90, DC-9
45-0083-1	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757
45-0083-2	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757
45-0083-3	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757,B767
45-0083-5	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757,B767
45-0083-7	RETRACTABLE AIRCRAFT LANDING LIGHT	B737, B757,B727
45-0212-1	AIRCRAFT RETRACTABLE LANDING LIGHT	C-212, CN-235
450239402	AFT PINTLE SPHERICAL BEARING	A320
450239408	AFT PINTLE SPHERICAL BEARING	A320
45-0350-4	RETRACTABLE LANDING LIGHT	A330, A340
45-0351-1	RETRACTABLE LANDING LIGHT	B737,CRJ
45-0351-2	RETRACTABLE LANDING LIGHT	B737,B757
45-0351-3	RETRACTABLE LANDING LIGHT	B737,CRJ
45-0351-4	RET LANDING LIGHT	B737,A300, B767
45-0351-5	RETRACTABLE LANDING LIGHT	CRJ100
45-0351-6	RETRACTABLE LANDING LIGHT	EMB
452T1201-16	STOP/LOCK	B757, B767
453449	MAIN LANDING GEAR DOOR ACTUATO	B737
453665	HYD MOTOR PUMP	CN-235, CN-295
453665 / MPEV3-011-8UK2B	PUMP-HYDR MOTOR DRIVEN	CN-235, CN-295
453665 / MPEV3-011-8UK2B-MOD 4	PUMP-HYDR MOTOR DRIVEN	CN-235, CN-295
453665 / MPEV3-011-8UK2B-MOD4	PUMP-HYDR MOTOR DRIVEN	CN-235, CN-295
4538	HYDRAULIC PRIORITY RELIEF CARTRIDGE VALV	B737, B707



P/N	DESCRIPTION	AIRCRAFT PARTS
45-521212-605242CW	ACTUATOR FLAP 2VALVE 6	
4564-5A6-1	TRANSMITTER POSITION	
461940-2	VALVE SAFETY RELIEF	CN-235
462760	VALVE CHECK	
4704-1-000/1	HIGH SPEED OVEN	A330, A340
47369	STATOR & ROTOR ASSEMBLIES	B757
47369-1	STATOR	B757
4750	BALLAST	
476W2220-2G	ATTENDANT HANDSET CRADLE ASSEMBLY	A330, A340
476W2220-2H	ATTENDANT HANDSET CRADLE ASSEMBLY	A330, A340
476W2220-2K	ATTENDANT HANDSET CRADLE ASSEMBLY	A330, A340
476W2220-2L	ATTENDANT HANDSET CRADLE ASSEMBLY	A330, A340
4804-1-000/1	HIGH SPEED OVEN	A330, A340
4812 SERIES	MOTOR PUMP FILTER UNIT ASSY	A330, A340
48285-SERIES	AIRCRAFT DIRECT CURRENT MOTORS	A330, A340
48315-3	MOTOR FIELD	A330, A340
48348	STARTER MOTOR	A330, A340
48363-1-1	ENGINE STARTER MOTOR	B727
48363-1-3	ENGINE STARTER MOTOR	B727, C-130
48364-1-SERIES	ENGINE STARTER MOTOR	A330, A340
48378	ENGINE STARTER MOTOR	
48378-SERIES	ENGINE STARTER MOTOR	A330, A340
48-6	ELECTRIC MOTOR	A330, A340
490A-TS-DF-14-28	FUENTE DE POTENCIA	
4950029	STARTER MOTOR	T-62T-47C1, T62T-46C1, 46C2, 46C2A, 46C3, 46C3A, 46C7, 46C7A, 46C14, 46C16
4950136	MOTOR-STARTER	A320, A330, A340
4950703	MOTOR-STARTER	A320
4951799	STARTER MOTOR	T-62T-47C1, T62T-46C1, 46C2, 46C2A, 46C3, 46C3A, 46C7, 46C7A, 46C14, 46C16
4951957	APU STARTER	B707, B717, B723, B737
4952164	MOTOR-STARTER	A318, A319, A320, A321, A330, A340
49740	RAMP CONTROL MANIFOLD VALVE	C-130
4U4059	AFT ARGO DOOR LOCK CILINDER	C-130
50-0024	LIGHT	
50-0024-1	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-11	LIGHT	CN-235, C-295
50-0024-13	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-15	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-17	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-19	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-21	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-23	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-25	LIGHT TAXI	C-295
50-0024-3	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-5	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-7	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
50-0024-9	AIRCRAFT LANDING & TAXING LIGHT	A330, A340
500040-03	BATTERY	C-295
50-0176-1	LIGHT: TAKE-OFF	A319, A321, A320-100, A320
5003174	FUEL BOOST PUMP	A330, A340
5003588	MAIN WHEEL ASSEMBLY	A330, A340
5004236	BRAKE ASSEMBLY	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
5004236-2	BRAKE ASSEMBLY	A330, A340
5004236-3	BRAKE ASSEMBLY	A330, A340
5006473	BRAKE ASSY	
5006484	BRAKE ASSEMBLY	C-212
5006484-1	BRAKE ASSEMBLY	C-212
5006484-2	BRAKE ASSEMBLY	C-212
5006484-3	BRAKE ASSY	C-212
5006586	MAIN WHEEL ASSEMBLY	A330, A340
5006586-1	HUB ASSY	C-212
5006586-2	MAIN WHEEL ASSEMBLY	C-212
500702-5211	AXIVANE FAN	DC-9, MD-80
5009904-5	BREAK UNIT	
50-1026016-01	NLG RETRACTION ACTUATOR ASSY	A340-600
50-1026017-01	NLG RETRACT ACTUATOR ASSY	A340-600
50-1026034-00	NLG RETRACTION ACTUATOR ASSY	A340-600
501-1075-07	EMERGENCY POWER SUP	A330, A340
501-1-13775-004	STARTER MOTOR	A330, A340
501-1-13775-006	STARTER MOTOR	A330, A340
501-1-13775-06A	STARTER MOTOR	A330, A340
501-1-14561	STARTER MOTOR	A330, A340
501-1-14561-004	MOTOR-STARTER	A320
501-1-14972-001	END BELL	A330, A340
501-1228-03	FUENTE ALIMT EMERGENCIA	CRJ100
501-1228-04	BATTERY	CN-235, C-295, B707, B727, B737, MD80
5011637	SLEEVE-AXLEMLG	
5011637-1	SLEEVE-AXLEMLG	
5011637-1R	SLEEVE-AXLEMLG	
50-1205222-00	AFT PINTLE PIN LH	A340-500
50-1206222-00	AFT PINTLE PIN RH	A340/500
50130-1	SNUBBER	B737-600/700/700C/800/900/900ER
50150	THREE WAY, 2 POSITION SOLENOID OPERATED HYD VALVE	C-130
50150-20	VALVE, LINEAR, DIREC	C-130
50150-28	THREE WAY, 2 POSITION SOLENOID OPERATED HYD VALVE	C-130
50150-3	THREE WAY, 2 POSITION SOLENOID OPERATED HYD VALVE	C-130
50-2105020-00	LOWER TORQUE LINK	A330
50-2105021-00	UPPER TORQUE LINK	A330
50-2105025-00	BRAKE ROD	A330
50-2105026-00	RETRACTION LINK (LH)	A330
50-2105027-00	RETRACTION BRACKET (LH)	A330
50-2106026-00	RETRACTION LINK (RH)	A330
50-2106027-00	RETRACTION BRACKET (RH)	A330
50-2107001-00	MAIN FITTING LH	A330
50-2107002-00	SHORTENING LINK (LOWER)	A330
50-2107003-00	SHORTENING LINK (UPPER)	A330
50-2108001-00	MAIN FITTING (RH)	A330
50-2109001-01	SLIDING PISTON	A330
50-2109002-00	UPPER PISTON	A330
50-2109008-00	RECOIL NUT	A330
50-2113001-00	RETRACTION ACTUATOR CYLINDER	A330
50-2113002-00	RETRACTION ACTUATOR PISTON ROD	A330
50-2113003-00	RETRACTION ACTUATOR PISTON HEA	A330
50-2113004-00	RETRACTION ACTUATOR GLAND	A330



P/N	DESCRIPTION	AIRCRAFT PARTS
50-2117002-00	BOGIE BEAM	A330
50-2121001-00	UPPER SIDE STAY	A330
50-2121004-00	LOWER CARDAN PIN	A330
50-2123001-00	UPPER LOCK LINK	A330
50-2123002-00	LOWER LOCK LINK	A330
50304ARG	WATER BOILER	
5030999-5511	LH MAIN LANDING GEAR	
5030999-5512	RH MAIN LANDING GEAR	
5030999-5519	LH MAIN LANDING GEAR	
5030999-5520	RH MAIN LANDING GEAR	
503455	ARMATURE	
50-4505002-00	SLIDING TUBE	A320
50-4505030-01	MAIN FITTING (LH)	A320
50-4506001-01	MAIN FITTING (RH)	A320
50-4506030-01	MAIN FITTING (RH)	A320
5059	VALVES, HYDRAULIC SHUTTLE	B737
5059-2	VALVES, HYDRAULIC SHUTTLE	B737
5059-4	VALVES, HYDRAULIC SHUTTLE	B737
5060-1	VALVES, HYDRAULIC SHUTTLE	B737
5060-2	VALVES, HYDRAULIC SHUTTLE	B737
5060-3	SHUTTLE VALVE	B737
5060-5	HYDRAULIC SHUTTLE VALVE	B737
5060-6	PNEUDRAULICS INC	B737
5060809	HOUSING ASSEMBLY	
506115	FIELD COIL INDUIT	
506569-1	STATOR ASSEMBLY	CFM56-5A/B/C; CFM56-7B, A320
5101484-9	CIRCUIT CARD ASSY	S330, S340
5115	BALLAST	
51154-02	PUMP MOTOR PACKAGE	A319, A320, A321
51154-03	PUMP MOTOR PACKAGE	A319, A320, A321
51154-04	PUMP MOTOR PACKAGE	A319, A320, A321
51154-05	PUMP MOTOR PACKAGE	A319, A320, A321
51164	VARIABLE DELIVERY HYDRAULIC PUMP ASSEMBLY	ERJ 170/190
51164-01	VARIABLE DELIVERY HYDRAULIC PUMP ASSEMBLY	ERJ 170/190
51164-02	VARIABLE DELIVERY HYDRAULIC PUMP ASSEMBLY	ERJ 170/190
51164-03	VARIABLE DELIVERY HYDRAULIC PUMP ASSEMBLY	ERJ 170/190
51164-04	VARIABLE DELIVERY HYDRAULIC PUMP ASSEMBLY	ERJ 170/190
51164-05	VARIABLE DELIVERY HYDRAULIC PUMP ASSEMBLY	ERJ 170/190
51164-06	VARIABLE DELIVERY HYDRAULIC PUMP ASSEMBLY	ERJ 170/190
51166	PUMP MOTOR PACKAGE	ERJ 170/190
51166-01	PUMP MOTOR PACKAGE	ERJ 170/190
51166-02	PUMP MOTOR PACKAGE	ERJ 170/190
51166-03	PUMP MOTOR PACKAGE	ERJ 170/190
51166-04	PUMP MOTOR PACKAGE	ERJ 170/190
51166-1	PUMP MOTOR PACKAGE	A330, A340
51166-2	PUMP MOTOR PACKAGE	A330, A340
51166-3	PUMP MOTOR PACKAGE	A330, A340
5120D114-1	FIELD	A330, A340
51224-127	FIREWIRE ELEMENT ASSY, MEDIUM TEM	S330, S340
5136-215-91-10	INDICATOR TEMPERATURE	A330, A340
5136-217-91-10	BATTERY TEMP IND.	A330, A340
5141-1	AUDIO CONTROL PANEL	
5141-1-25	AUDIO PANEL CONTROL	A330, A340
5145-1	AUDIO PANEL CONTROL	
5145-1-24A	AUDIO PANEL CONTROL	



P/N	DESCRIPTION	AIRCRAFT PARTS
5145-1-40	AUDIO PANEL CONTROL	
5145-1-40A	AUDIO PANEL CONTROL	
5145-1-42	AUDIO CONTROL PANEL	A330, A340
5145-1-43	AUDIO PANEL CONTROL	
5145-1-43A	AUDIO PANEL CONTROL	
5145-1-44	AUDIO PANEL CONTROL	
5145-1-44A	AUDIO PANEL CONTROL	
5145-1-46	AUDIO PANEL CONTROL	
5145-1-46A	AUDIO PANEL CONTROL	
5145-1-47	AUDIO PANEL CONTROL	
5145-1-47A	AUDIO PANEL CONTROL	
5145-1-48	AUDIO PANEL CONTROL	
5145-1-48A	AUDIO PANEL CONTROL	
5145-1-60	PANEL - AUDIO S	B737
5145-1-60A	AUDIO PANEL CONTROL	
5145-1-61	AUDIO CONTROL PANEL	B737
5145-1-61A	AUDIO PANEL CONTROL	
5145-1-62A	AUDIO PANEL CONTROL	
5145-1-62B	AUDIO PANEL CONTROL	
5145-1-63	AUDIO PANEL CONTROL	
5145-1-63A	AUDIO PANEL CONTROL	
5145-1-64	AUDIO CONTROL PANEL	B737
5145-1-65	AUDIO PANEL CONTROL	
5145-1-65A	AUDIO PANEL CONTROL	
5145-1-66	PANEL-AUDIO SELECTOR	A330, A340
5145-1-69	AUDIO CONTROL PANEL	A330, A340
5145-1-70	AUDIO PANEL CONTROL	
5145-1-70A	AUDIO PANEL CONTROL	
5145-1-71	AUDIO PANEL CONTROL	
5145-1-71A	AUDIO PANEL CONTROL	
5145-1-77	AUDIO CONTROL PANEL	A330, A340
5145-1-77 MOD A	AUDIO CONTROL PANEL	A330, A340
5145-1-77 MOD B	AUDIO CONTROL PANEL	A330, A340
5145-1-SERIES	AUDIO PANEL CONTROL	B737
51509-002	DC STATIC VOLTAGE REGULATOR AND PROTECTION PANEL	C-212
51509-002R	DC STATIC VOLTAGE REGULATOR	
515090-4	ALTERNATING CURRENT GEARED MOTOR	B747
515090-5	ALTERNATING CURRENT GEARED MOTOR	B747
515090-6	ALTERNATING CURRENT GEARED MOTOR	B747
515986-3	ARMATURE ASSEMBLY MOTOR	A330, A340
515986-4	ARMATURE ASSEMBLY MOTOR	A330, A340
515986-5	ARMATURE	A330, A340
515Z2002-1	AXLE MLG	B787
516023-1	ALTERNATING CURRENT MOTOR	B727, B737, B747
516023-2	ALTERNATING CURRENT MOTOR	B737, B727, B747
516492-3	STATOR	A330, A340
516548-	CASING / STATOR ASSY	
516562-1	ALTERNATING CURRENT MOTOR	B747
517CUF12-1	SELECTOR, MODE, AUTOP	
518150	HYDRAULIC MOTORPUMP ASSEMBLY	A319, A320, A321, A330, A340
518157	HYDRAULIC MOTORPUMP ASSY	A330, A340
518196-3	FIELD	B737
518954-1	DIRECT CURRENT MOTOR	A330, A340
519022-3	ALTERNATING CURRENT GEARED MOTOR	B747



P/N	DESCRIPTION	AIRCRAFT PARTS
519022-4	ALTERNATING CURRENT GEARED MOTOR	B747
519022-5	ALTERNATING CURRENT GEARED MOTOR	B747
519022-6	ALTERNATING CURRENT GEARED MOTOR	B747
519022-7	ALTERNATING CURRENT GEARED MOTOR	B747
519022-8	ALTERNATING CURRENT GEARED MOTOR	B747
519806	DIRECT CURRENT MOTOR	
519806-SERIES	DIRECT CURRENT MOTOR	A330, A340
519852-2	ENGINE STARTER MOTOR	A300, MD-11, DC-10,B767
519852-3	ENGINE STARTER MOTOR	A300, MD-11, DC-10,A310
519852-4	ENGINE STARTER MOTOR	A300, MD-11, DC-10,A310
519852-SERIES	STARTER MOTOR	
519858-1	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-2	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-3	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-4	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-5	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-6	ENGINE STARTER MOTOR	B757, B767, A310, A300
519858-7	STARTER MOTOR	B757, B767, A310, A300,B727
519858-8	ENGINE STARTER MOTOR	B757, B767, A310, A300,B727
519892-1-2	ENGINE STARTER MOTOR	A330, A340
519892-2-3	ENGINE STARTER MOTOR	A330, A340
519892-3	ENGINE STARTER MOTOR	A330, A340
519892-3-1	ENGINE STARTER MOTOR	A330, A340
519892-3-3	ENGINE STARTER MOTOR	BAe146/BAe146-300
519892-4	ENGINE STARTER MOTOR	A330, A340
519892-4-1	ENGINE STARTER MOTOR	CL-600/CL-601
519892-5	ENGINE STARTER MOTOR	A330, A340
519892-5-1	ENGINE STARTER MOTOR	DHC-5
519892-6	ENGINE STARTER MOTOR	A330, A340
519892-6-1	ENGINE STARTER MOTOR	G-II/G-III
519892-6-2	ENGINE STARTER MOTOR	LAGPU-30
519892-6-3	ENGINE STARTER MOTOR	A330, A340
521603	INDICATOR OIL TEMP	
522-0688-003	ANTENNA	
522-1660-031	TRANSCEIVER, HF	B707, B727, B747
522-2213-00	CONTROL	
522-2377-003	IND HEADING	
522-24447-251	CONTROL BOX	
522-2996-00	MARKER BEACON	
522-4088-203	VHF TRAN	B737, DC-8,B727, A320
522719	INDICATOR POTABLE WATE	
528-20	WING TIP NAVIGATION LIGHT	A319-A320-A321
528-30	LIGHT-NAVIGATION, FORWARD SINGLE	A320
5283D100-1	STARTER APU	
5283D100-11	STARTER APU	
5283D100-13	STARTER APU	
5283D100-15	STARTER APU	
5283D100-17	STARTER APU	
5283D100-19	STARTER APU	
5283D100-21	STARTER MOTOR	B737,B777,B757,B727, B767
5283D100-23	STARTER MOTOR	B737,B777,B757
5283D100-25	STARTER MOTOR	
5283D100-27	STARTER MOTOR	A330, A340
5283D100-3	STARTER APU	
5283D100-5	STARTER APU	



P/N	DESCRIPTION	AIRCRAFT PARTS
5283D100-9	STARTER ELECTRIC	
5283D100-SERIES	MOTOR STARTER	
528-70	LIGHT-NAVIGATION, FORWARD DUAL (RH)	A318,A319,A320,A321
528-80	LIGHT-NAVIGATION, FORWARD DUAL (LH)	A318,A319,A320,A321
53080-06	MOTOR DRIVEN HYDRAULIC PUMP	B787
53150-1	VALVE LINEAR DIRECTI	C-130
53150-2	PRESSURE VALVE	A330, A340
53718-04	GENERATOR, ALTERNATING CURRENT	F15
53721-3	STRUT ASSY-NLG DOOR	B767
54-456	SLEEVE-AXLEMLG	
54-456-1	SLEEVE-AXLEMLG	
54-456-2	SLEEVE-AXLEMLG	
54-472	SLEEVE, MLG AXLE	A330
54-477	AXLE SLEEVE	A340
54-480	NLG AXLES SLEEVES	A330
54-592	AXLE SLEEVE	A340-500
54-592-1	AXLE SLEEVE CLDG	A340
54-593-1	AXLE SLEEVE	A340-600
549460 SERIES	CYLINDRAL HYD PRESS ACCUM	A330, A340
55-1000-200D9	TRANSMITTER,PRESSUR	CN-235
551050 SERIES	CYLINDRAL HYD PRESS ACCUM	A330, A340
551200 SERIES	CYLINDRAL HYD PRESS ACCUM	A330, A340
55-1205231-01	AFT PINTLE PIN NUT	A340-500
55-2105029-001	BOGIE BEAM PIVOT PIN	A330-300
55-2105042-00	FORWARD PINTLE PIN	A330
55-2105054-00	TORQUE LINK APEX PIN	A330
55-2105055-00	UPPER TORQUE LINK PIN	A330
55-2105056-00	LOWER TORQUE LINK PIN	A330
55-2105058-00	FORWARD PINTLE PIN LOCK BOLT	A330
55-2105059-00	PIN W2	A330
55-2105060-00	PIN W1	A330
55-2105061-00	PIN W	A330
55-2105072-00	TORQUE LINK APEX PIN NUT	A330
55-2105091-00	BRAKE ROD PIN	A330
55-2107007-00	PIN SM9	A330
55-2107008-00	PIN SM8	A330
55-2107009-00	PIN SM7	A330
55-2117003-00	WHEEL AXLE	A330
55-2119008-00	PIVOT LINK BRACKET	A330
55-2121002-00	LOWER SIDE STAY	A330
55-2121003-00	UPPER CARDAN PIN	A330
55-2121005-00	SIDE STAY UPPER PIN	A330
55-2121007-00	SIDE STAY LOWER PIN	A330
55-2121009-00	LOWER CARDAN NUT	A330
55-2123003-00	CARDAN LINK	A330
552430 SERIES	CYLINDRAL HYD PRESS ACCUM	A330, A340
5543001-8	SHIMMY DAMPER	
55-4505021-00	UPPER DIAPHRAGM TUBE	A320
55-4533005-00	UPPER DIAPHRAGM TUBE	A320
5617-352-91-11	INDICATOR ASSEMBLY	A330, A340
5617-352-91-12	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340
5617-353-99-10	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340
5617-355-91-11	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340
5617-358-91-10	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340
5617-359-80-10	DUAL ENGINE OIL PRESSURE TEMP IND	A330, A340





P/N	DESCRIPTION	AIRCRAFT PARTS
5618-1	MANO-CONTACT	A330, A340
569653	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
569911	STATOR AND COOLING JACKET	B757
570347	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	DHC-8
5704-1-000/1	HIGH SPEED OVEN	A330, A340
57186	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-01	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-02	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-03	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-04	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-05	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-06	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-07	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-10	PUMP MOTOR PACKAGE	B707, B727, B737, B747, B757, B767
57186-11	MOTOR PUMP	
57377	SERVOED ALTITUDE INDICATOR	
5804-1-000/1	HIGH SPEED OVEN	A330, A340
58057-82	GYRO COMPAS	
5821-01-3924589	RECEIVER TRANSMITTER	
5-87199-3001	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX ASSEMBLY	B707
5-87199-3002	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX ASSEMBLY	B707
5-87199-3003	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX ASSEMBLY	B707
5-87199-3004	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX ASSEMBLY	A330, A340
5-87199-3005	OUTBOARD AILERON LOCKOUT MECHANISM GEARBOX ASSEMBLY	B707
5-87448-3001	FLAP DRIVE POWER UNIT ASSEMBLY	B707
5-87448-3002	FLAP DRIVE POWER UNIT ASSEMBLY	A330, A340
5-87448-3006	FLAP DRIVE POWER UNIT ASSEMBLY	A330, A340
5-87448-3007	FLAP DRIVE POWER UNIT ASSEMBLY	B707
5906732	AC GENERATOR	A319, A321, A320
5909006	AC GENERATOR	A319, A321, A320
5910047	AC GENERATOR	A319, A321, B717, A320
5910139	APU GENERATOR	A330, A340
5910447-5059	NLG	B737
5910447-5161/3920208-515	NLG ASSY/DRAG BRACE	
5910447-5561/3920208-515	NLG ASSY/DRAG BRACE	
59111	FLAP POSITION INDICATOR	
5912833	APU GENERATOR	A330, A340
5913667	AC GENERATOR	A330, A340
5913667-1	GENERATOR-APU	A320
5913667-2	GENERATOR-APU	A320
5913667-3	GENERATOR-APU	A320
5913667-4	GENERATOR-APU	A320
59141	FLAP POSITION INDICATOR	
5936970-413008	FLAP CTRL VLV	
6002869	ANTI SKID MANIFOLD	
60-1321-1	POWER-SUPPLY-BTRY-EMER-LT	B727, B737, B747, EMB170, EMB190
60-1321-1LB	EMERGENCY EXIT LIGHT POWER SUPPLY	B747, B707, B727, B737
60-1321-5	EMERGENCY EXIT LIGHT POWER SUPPLY	B727, B747



P/N	DESCRIPTION	AIRCRAFT PARTS
60-1321-5LB	EMERGENCY EXIT LIGHT POWER SUPPLY	B727, B747
60-1321-7	EMERGENCY EXIT LIGHT POWER SUPPLY	B727, B747
60-1321-7LB	EMERGENCY EXIT LIGHT POWER SUPPLY	B727, B747
60-2650-1	POWER SUPPLY	P3 ORION, P3 CONVERSION
60-3274-5	POWER-SUPPLY	
60-3757-5	STROBE LIGHT	Q400
60-3895-1	POWER-SUPPLY-BTRY-EMER-LT	C-212, CN-235, C-295
604260	FIELD	A330, A340
60-4983-3	POWER SUPPLY ANTI-COLLISION SYSTEM	B737, B767,B777,B747
60-4983-5	STROBE POWER SUPPLY	B737
605146-4	STATOR	
605290	MOTOR DRIVEN VANEAXIAL FAN	
605290-SERIES	MOTOR DRIVEN VANEAXIAL FAN	A330, A340
605457-2	MOTOR DRIVEN CENTRIFUGAL FAN	DC-10, B747, B767, MD-11
605457-3	MOTOR DRIVEN CENTRIFUGAL FAN	B767, DC-10, MD-11, MD-80, B747
605457-7	FAN	B767, MD-80, B747,B737, B767, B777
605457-8	MOTOR DRIVEN CENTRIFUGAL FAN	B767, DC-10, MD-11, B747,B757
605675-1	MOTOR DRIVEN VANEAXIAL FAN	B727, B747, DC-8, B737,B757
605675-2	MOTOR DRIVEN VANEAXIAL FAN	B727, B747, DC-8
6058003-X	STARTER GENERATOR	Learjet
606622-1	CABIN AIR RECIRCULATION FAN	B747/300, B767/200, B767/300, B767/400,B737
606622-2	CABIN AIR RECIRCULATION FAN	B747/300, B767/200, B767/300, B767/400,DC9
606622-3	CABIN AIR RECIRCULATION FAN	B747/300, B767/200, B767/300, B767/400,DC9
606622-4	CABIN AIR RECIRCULATION FAN	B747/300, B767/200, B767/300, B767/400,DC10
606635-2	STATOR ASSY - MOTOR	A330, A340
606707-1	FWD CARGO COMP VENT FAN	B747-400, B767, B777-200, B777-300, MD80
606772-1	CABIN AIR RECIRCULATION FAN	B757, MD-11
606772-2	CABIN AIR RECIRCULATION FAN	B757, MD-11
606772-3	CABIN AIR RECIRCULATION FAN	B757, MD-11,B737
606772-4	CABIN AIR RECIRCULATION FAN	B757, MD-11
606772-5	CABIN AIR RECIRCULATION FAN	
606772-6	CABIN AIR RECIRCULATION FAN	B757, MD-11
606772-7	CABIN AIR RECIRCULATION FAN	B757, MD-11
606802-2	WASTE SYSTEM VACUUM BLOWER	B777-200,B757,B737,B767
607518-2	CONTROL TEMPERATURE	B737,B777,B757
607518-2 SERIES 2	TEMPERATURE CONTROL	B737
607518-2 SERIES 3	TEMPERATURE CONTROL	B737
607518-2 SERIES 4	TEMPERATURE CONTROL	B737
607618	MOTORPUMP ASSEMBLY	A330, A340
607618-1	BOMBA HIDRAULICA	P3 ORION, P3 CONVERSION
60863-25	ACCUMULATOR ASSEMBLY	B737
60863-25-1	ACCUMULATOR ASSEMBLY	B737
60863-50	ACCUMULATOR ASSEMBLY	B737
60863-50-1	ACCUMULATOR ASSEMBLY	B737
60946-3	ACCUMULATOR ASSEMBLY	B737
60946-4	ACCUMULATOR ASSEMBLY	B737
60946-5	ACCUMULATOR ASSEMBLY	B737
60B00263-1	AUTOBRAKE CONTROL MODULE	B727, B737, B747, B757
60B00263-2	AUTOBRAKE CONTROL MODULE	B727, B737, B747, B757
60B00263-3	AUTOBRAKE CONTROL MODULE	B727, B737, B747, B757



P/N	DESCRIPTION	AIRCRAFT PARTS
60B00263-4	AUTOBRAKE CONTROL MODULE	B727, B737, B747, B757
60B40125-208	SEAT ELECTRONICS BOX	S330, S340
610120-103	CONTROL ASSY LIGHT	P3
6111	MANIFOLD PRESSURE GAGE	A330, A340
611N0000009Y	CONTROL, INTERCOMMUNICATOR	CN-235, C-295
611N615A000	UNIDAD VALIDACIÓN	CN-235, C-295
61-2276-1	HOUSING ASSEMBLY	A330, A340
61-36-2	BALLAST	A330, A340
6146-1-6MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	
6146-1-7MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	
61474-108-1	TACHOMETER IND	A330, A340
61474-108-2	TACHOMETER IND	A330, A340
61533-102-1	TEMPERATURE IND	A330, A340
61533-103-1	INDICATOR TEMPERATURE	A330, A340
61533-104-1	TEMPERATURE IND	A330, A340
61533-106-1	INDICATOR TEMPERATURE	A330, A340
61533-107-1	TEMPERATURE IND	A330, A340
61533-109-1	TEMPERATURE IND	A330, A340
61533-111-1	TEMPERATURE IND	A330, A340
61533-121-1	TEMPERATURE IND	A330, A340
615600-1003	ELECTRIC MOTORPUMP	CRJ700 & ERJ
617-069-17	CONTROL ASSY PARKING	
6174-1	VALVE, HYDRAULIC FLOW REGULATOR, CARTRIDGE	B-727, B-737
6174-2	VALVE, HYDRAULIC FLOW REGULATOR, CARTRIDGE	B-727, B-737
61800	DEBOOST VALVE ASSEMBLIES	B737
62176 SERIES	LIQUID COOLED MOTOR	A330, A340
621T100	ACTUATOR ELECTRO-ME	
622-0555-003	INDICATOR SUBASSY	
622199	VAR. DISPLACEMENT HYDRAULIC MOTOR PUMP	B757, B767, B747
622-2360-001	CONTROL	A330, A340
622-2551-002	CONTROL EQUIP RADAR	CN-235
622-2938-001	RADIO ALTITUDE INDICATOR	A330, A340
622-4176-001	INDICATOR, HORIZONTAL	S330, S340
622-5222-120	ADF RECEIVER	B737
622-5486-001	SELECTOR	
622-6523-005	CONTROL NAVIGATION	
62270	HOLDER LINEAR ACTUATOR	
623272	VARIABLE DISPLACEMENT HYDRAULIC PUMP	DC-10, B747, B757, B767, A320
623303	VAR. DISPLACEMENT HYDRAULIC MOTOR PUMP	B757, B767, B747
623337	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
623339	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	707, 720, 727, 737
623977	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	A330, A340, A320
624372	ELECTRIC MOTOR ASSEMBLY	A330, A340
62461 SERIES	LIQUID COOLED MOTOR	A330, A340
6252	FUSE, HYDRAULIC QUANTITY MEASU	B737
6257	HYDRAULIC FUSE, VOLUMETRIC	B737
625868-1	SELECTOR CABIN ZONE TEMP	B757, B737
625868-1 SERIES	CABIN ZONE TEMPERATURE SELECTOR	A330, A340
6271	HYDRAULIC FUSE, VOLUMETRIC	B737
6271-1	HYDRAULIC FUSE, VOLUMETRIC	B737
6272-1	HYDRAULIC FUSE, VOLUMETRIC	B-737, B-747
6273-1	HYDRAULIC FUSE, VOLUMETRIC	B-737, B-747
62735	LIQUID COOLED MOTOR	B737
6273-5	HYDRAULIC FUSE, VOLUMETRIC	B-737, B-747
6274-1	HYDRAULIC FUSE, VOLUMETRIC	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
6373-1	VALVE, FLOW REGULATOR, HYDRAUL	B737
6373-2	VALVE FLOW REGULATOR HYDRAULIC	B737
64110-010-1	ALTIMETRO BAROMETRICO	
64141-361-1	BAROMETRIC ALTIM. STANDBY	CN-235, C-295
64191-203-1	DIAL MANOMETER	A330, A340
64191-204-1	PRESSURE GAUGE	
64191-214-1	PRESSURE GAUGE	
64191-217-1	PRESSURE GAUGE	
64191-225-1	PRESSURE GAUGE	
6430497-1	EXCITER ROTOR	A330, A340
6430580-1	STATOR RESOLVER	A330, A340
6430580-2	ROTOR RESOLVER	
6430580-3	STATOR RESOLVER	A330, A340
6430595-1	MAGNET-PERMANENT, GENERATOR	A330, A340
6430603-1	END BELL	S330, S340
6430603-2	END BELL	A330, A340
6430612-1	EXCITER STATOR	A330, A340
6430621-1	MAIN ROTOR ASSY	
6430621-2	MAIN ROTOR ASSY	
6430621-3	MAIN ROTOR ASSY	
6430624-1	ROTOR	B737
6430624-2	ROTOR	B737
6430624-3	ROTOR AC GENERATOR	A330, A340
6430624-4	AC GENERATOR ROTOR	A330, A340
6430657-1	RESISTOR BOBBIN	A330, A340
6430800-3	STATOR	
6430800-4	STATOR AND HOUSING ASSY	A330, A340
6431000-3	ROTOR	A330, A340
6431000-4	ROTOR	A330, A340
6431000-5	ROTOR	A330, A340
6431000-6	ROTOR	
6431000-7	ROTOR ASSY	A330, A340
6431001-2	STATOR AND HOUSING ASSY	A330, A340
6431006-1	EXCITER ROTOR	A330, A340
6431006-2	EXCITER ROTOR	A330, A340
645172-1	VACUUM BLOWER	B737, B747, B757, B767, B777
645172-2	VACUUM BLOWER	B737, B777
645405-1	CABIN AIR RECIRCULATION FAN	B737, B747
645405-2	CABIN AIR RECIRCULATION FAN	BBJ, B-737-500, B-737-900, B-737-300, B-737-600, B-737-400, B-737-800, B-737-700
645405-X	CABIN AIR RECIRCULATION FAN	B737, B747
645423-2	ROTOR & SHAFT ASSY	A330, A340
645423-3	ROTOR & SHAFT ASSY	A330, A340
645458-2	IMPELLER-FAN	
645705-1	CABIN AIR RECIRCULATION FAN	B757, MD-11
645705-2	CABIN AIR RECIRCULATION FAN	B757, MD-11
645705-3	CABIN AIR RECIRCULATION FAN LH	MD-11, B757, B747
645705-4	CABIN AIR RECIRCULATION FAN	B757, MD-11
648 50 00	SELF CONTAINED ANTICOLLISION LIGHT	A330, A340
64809-416-1	PRESSURE INDICATOR	A330, A340
64809-418-1	PRESSURE INDICATOR	A330, A340
64809-428-1	INDICPRESSION CARB	
64809-606-1	INDIC PRESSION HUI	A330, A340
6485000	ANTICOLLISION LIGHT	



P/N	DESCRIPTION	AIRCRAFT PARTS
64975-003-1	ELECTRIC TACHOMETER	A330, A340
65-0294	INDICATOR LIGHT	
65-0294-1	INDICATOR LIGHT ASSEMBLY	B737
65-0294-11	INDICATOR LIGHT ASSEMBLY	B737
65-0294-13	INDICATOR LIGHT ASSEMBLY	B737,EMB170
65-0294-15	INDICATOR LIGHT ASSEMBLY	B737,CRJ700
65-0294-17	INDICATOR LIGHT ASSEMBLY	B737,CRJ
65-0294-19	INDICATOR LIGHT ASSEMBLY	B737,ATR
65-0294-21	INDICATOR LIGHT ASSEMBLY	B737
65-0294-23	INDICATOR LIGHT ASSEMBLY	B737,ATR72
65-0294-25	INDICATOR LIGHT ASSEMBLY	B737,ATR72
65-0294-3	INDICATOR LIGHT ASSEMBLY	B737,B757
65-0294-5	INDICATOR LIGHT ASSEMBLY	B737,B757
65-0294-7	INDICATOR LIGHT ASSEMBLY	B737,B757
65-0294-9	INDICATOR LIGHT ASSEMBLY	B737,CRJ
65-17819-1	LG LOCK ACTUATOR ASSY	B737
65-17819-10	LG LOCK ACTUATOR ASSY	B737
65-17819-11	LG LOCK ACTUATOR ASSY	B737
65-17819-12	LG LOCK ACTUATOR ASSY	B737
65-17819-14	N.G. LOCK ACTUATOR ASSY	B737
65-17819-15	N.G. LOCK ACTUATOR ASSY	B737
65-17819-4	LG LOCK ACTUATOR ASSY	B737
65-17819-6	LG LOCK ACTUATOR ASSY	B737
65-17819-7	LG LOCK ACTUATOR ASSY	B737
65-17819-8	LG LOCK ACTUATOR ASSY	B737
65-17832-2	LANDING GEAR HYDRAULIC TRANSFE	B737
65-17832-3	LANDING GEAR HYDRAULIC TRANSFE	B737
65-17882-12	LG LOCK ACTUATOR ASSY	B737
65-17882-13	LG LOCK ACTUATOR ASSY	B737
65-17882-14	LG LOCK ACTUATOR ASSY	B737
65-17882-17	LG LOCK ACTUATOR ASSY	B737
65-17882-18	LG LOCK ACTUATOR ASSY	B737
65-17882-21	LG LOCK ACTUATOR ASSY	B737
65-17882-22	LG LOCK ACTUATOR ASSY	B737
65-17882-24	LG LOCK ACTUATOR ASSY	B737
65-17882-3	LG LOCK ACTUATOR ASSY	B737
65-17882-5	LG LOCK ACTUATOR ASSY	B737
65-17882-7	LG LOCK ACTUATOR ASSY	B737
6519009-71-1	STEP ASSY	
65-20846-1	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20846-2	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20846-3	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20846-4	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20846-8	INBOARD AND FILLET FLAP DRIVE POWER UNIT ASSEMBLY	B707
65-20848-1	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	A330, A340
65-20848-2	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	A330, A340
65-20848-3	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	A330, A340
65-20848-4	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	B707
65-20848-5	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	B707
65-20848-6	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	B707



P/N	DESCRIPTION	AIRCRAFT PARTS
65-20848-7	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	A330, A340
65-20848-8	INBOARD FLAP DRIVE ELL GEARBOX ASSEMBLY	B707
65-20852-1	INBOARD FLAP DRIVE TEE GEARBOX ASSEMBLY	A330, A340
65-20852-2	INBOARD FLAP DRIVE TEE GEARBOX ASSEMBLY	B707
65-20852-3	INBOARD FLAP DRIVE TEE GEARBOX ASSEMBLY	B707
65-3693	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-10	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-11	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-16	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-19	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-20	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-22	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-3	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-4	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-5	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-6	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-7	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-8	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-3693-9	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-44504-1	MAIN GEAR DAMPER ASSEMBLY	B737
65-44504-2	MAIN GEAR DAMPER ASSEMBLY	B737
65-44504-3	MAIN GEAR DAMPER ASSEMBLY	B737
65-44504-5	MAIN GEAR DAMPER ASSEMBLY	B737
65-44561-10	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-11	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-12	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-13	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-14	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-15	ACTUATOR AY	B737
65-44561-5	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-6	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-7	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-8	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44561-9	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-44610-3	NOSE GEAR HYDRAULIC ACTUATOR	B737
65-44610-4	ACTUATOR ASSY	B737
65-44625-10	LG LOCK ACTUATOR ASSY	B737
65-44625-11	NOSE GEAR HYDRAULIC ACTUATOR	B737
65-44625-14	LG LOCK ACTUATOR ASSY	B737
65-44625-18	NOSE GEAR LOCK ACTUATOR ASSEMBLY	B737-300, B737-400, B737-500
65-44625-4	LG LOCK ACTUATOR ASSY	B737
65-44625-5	NOSE GEAR HYDRAULIC ACTUATOR	B737
65-44625-6	LG LOCK ACTUATOR ASSY	B737
65-44625-8	NOSE GEAR HYDRAULIC ACTUATOR	B737
65-44625-9	NOSE GEAR HYDRAULIC ACTUATOR	B737
65-44660-4	GRAVEL DEFLECTOR ACTUATOR	B737
65-44660-5	GRAVEL DEFLECTOR ACTUATOR	B737
65-44690-10	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44690-11	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44690-15	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44690-16	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44690-4	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44690-8	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44691-3	LANDING GEAR MODULAR PACKAGE ASSEMBLY	B737, B747, B757
65-44691-4	LANDING GEAR MODULAR PACKAGE ASSEMBLY	B737, B747, B757



P/N	DESCRIPTION	AIRCRAFT PARTS
65-44691-5	LANDING GEAR MODULAR PACKAGE ASSEMBLY	B737, B747, B757
65-44691-6	LANDING GEAR MODULAR PACKAGE ASSEMBLY	B737, B747, B757
65-44710-2	NOSE WHEEL STEERING CYLINDER A	B737
65-44710-3	NOSE WHEEL STEERING CYLINDER A	B737
65-44710-4	STEERING ACTUATOR	B737
65-44710-5	NOSE WHEEL STEERING CYLINDER A	B737
65-44710-6	NOSE WHEEL STEERING CYLINDER A	B737
65-44710-7	CYLINDER ASSEMBLY	B737
65-44710-8	CYLINDER ASSEMBLY	B737
65-44710-9	CYLINDER ASSEMBLY	B737
65-44725-101	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-102	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-103	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-104	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-105	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-45	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-47	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-48	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-50	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-52	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-54	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-55	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-57	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-58	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-59	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-60	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-61	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-62	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-63	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-64	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-65	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-76	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-77	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-79	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-85	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-86	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-87	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-88	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-89	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-90	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-91	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-92	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-93	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-94	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-95	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-96	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-97	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-98	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44725-99	LEADING EDGE SLAT HYDRAULIC ACTUIATOR ASSEMBLY	B737
65-44761-10	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-12	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-15	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-44761-16	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-18	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-19	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-21	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44761-22	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	B-737
65-44771-2	MAIN GEAR DAMPER ASSEMBLY	B737
65-44771-3	MAIN GEAR DAMPER ASSEMBLY	B737
65-44771-4	MAIN GEAR DAMPER ASSEMBLY	B737
65-44810-3	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44810-4	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44810-5	MAIN GEAR LOCK ACTUATOR	B737
65-44810-6	MAIN GEAR LOCK ACTUATOR	B737
65-44825-10	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-11	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-12	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-13	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-14	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-15	MAIN GEAR LOCK ACTUATOR	B737
65-44825-16	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-17	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-18	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-7	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-8	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44825-9	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
65-44897-2	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44897-3	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44897-4	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44897-5	LANDING GEAR HYDRAULIC TRANSFE	B737
65-44898-2	MAIN GEAR DAMPER ASSEMBLY	B737
65-44898-3	MAIN GEAR DAMPER ASSEMBLY	B737
65-44898-5	MAIN GEAR DAMPER ASSEMBLY	B737
65-44898-7	MAIN GEAR DAMPER ASSEMBLY	B737
65-44898-8	DAMPER ASSY	B737
65-44910-11	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-12	ACTUATOR	B737
65-44910-13	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-27	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-28	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-29	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-30	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-31	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-32	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-6	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-7	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-8	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44910-9	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-11	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-12	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-15	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-16	MAIN GEAR ACTUATOR ASSEMBLY	B737





P/N	DESCRIPTION	AIRCRAFT PARTS
65-44925-21	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-22	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-27	MLG RETRACT ACTUATOR ASSY	B737
65-44925-28	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-29	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-30	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-31	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-32	MLG RETRACT ACTUATOR ASSY	B737
65-44925-33	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-34	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-35	MLG RETRACT ACTUATOR ASSY	B737
65-44925-36	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-41	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-42	MLG RETRACT ACTUATOR ASSY	B737
65-44925-7	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-8	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44925-9	MAIN GEAR ACTUATOR ASSEMBLY	B737
65-44960-23	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44960-24	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44960-25	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44960-27	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44960-28	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	B737
65-44975-3	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B737
65-44975-5	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B737
65-46100-54	SHOCK STRUT ASSY.	B737
65-46100-75	SHOCK STRUT ASSY	B737
65-46100-76	SHOCK STRUT ASSY	B737
65-46100-77	SHOCK STRUT ASSY	B737
65-46100-78	SHOCK STRUT ASSEMBLY	B737
65-46100-79	SHOCK STRUT ASSEMBLY	B737
65-46102-21	MLG TORSION LINK ASSEMBLY LOWE	B737-100
65-46102-23	LOWER TORSION LINK	B737-100
65-46103-13	UPR DRAG STRUT ASSY	B737-200
65-46106-3	MLG UNIVERSAL ASSY LOWER SIDE	B737-100
65-46106-7	MLG UNIVERSAL ASSY LOWER SIDE	B737-100
65-46106-9	MLG UNIVERSAL ASSY LOWER SIDE	B737-400
65-46107-1	MLG UNIVERSAL ASSY REACTION LI	B737-100
65-46107-3	MLG UNIVERSAL ASSY REACTION LI	B737-400
65-46108-1	ACTUATOR BEAM ASSEMBLY	B737
65-46108-12	ACTUATOR BEAM ASSEMBLY	B737
65-46108-14	MLG ACTUATOR BEAM ASSEMBLY	B737
65-46108-15	ACTUATOR BEAM ASSEMBLY	B737
65-46108-17	BEAM, ACTUATOR ASSY	B737
65-46108-19	ACTUATOR BEAM ASSEMBLY	B737
65-46108-21	MLG ACTUATOR BEAM ASSEMBLY	B737
65-46108-23	MLG ACTUATOR BEAM ASSEMBLY	B737
65-46108-3	ACTUATOR BEAM ASSEMBLY	B737
65-46108-6	MLG ACTUATOR BEAM ASSEMBLY	B737
65-46109-10	MLG ACTUATOR BEAM ARM ASSEMBLY	B737-200
65-46109-14	MLG ACTUATOR BEAM ARM ASSEMBLY	B737-200
65-46109-14L	MLG ACTUATOR BEAM ARM ASSEMBLY	B737-200
65-46109-18	MLG ACTUATOR BEAM ARM ASSEMBLY	B737-200
65-46112-13	SUPPORT LINK ASSEMBLY	B737
65-46112-16	SUPPORT LINK ASSEMBLY	B737
65-46112-19	SUPPORT LINK ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-46112-22	SUPPORT LINK ASSEMBLY	B737
65-46112-26	MLG SUPPORT LINK ASSEMBLY	B737
65-46112-30	SUPPORT LINK ASSEMBLY	B737
65-46112-31	MLG SUPPORT LINK ASSEMBLY	B737
65-46112-9	SUPPORT LINK ASSEMBLY	B737
65-46113-21	MLG TRUNNION PIN ASSEMBLY	B737-100
65-46113-25	MLG TRUNNION PIN ASSEMBLY	B737-100
65-46116-47	MLG INNER CYLINDER ASSY GROUP	B737-100
65-46116-50	MLG INNER CYLINDER ASSY GROUP	B737-100
65-46116-59	INNER CYL ASSY	B737-400
65-46116-61	MLG INNER CYLINDER ASSY GROUP	B737-100
65-46133-5	MLG SIDE STRUT ASSEMBLY UPPER	B737-100
65-46133-7	MLG SIDE STRUT ASSEMBLY UPPER	B737-400
65-46135-13	MLG REACTION LINK ASSEMBLY	B737-100
65-46135-18	MLG RACTION LINK ASSEMBLY	B737-400
65-46135-24	MLG REACTION LINK ASSEMBLY	B737-400
65-46138-16	MLG LINK ASSY UPPER DOWNLOCK	B737-100
65-46138-20	MLG LINK ASSY UPPER DOWNLOCK	B737-100
65-46139-12	MLG LINK ASSY LOWER DOWNLOCK	B737-400
65-46139-9	MLG LINK ASSY LOWER DOWNLOCK	B737-100
65-46140-6	MLG TEE BOLT ASSY DRAG STRUT	B737-100
65-46140-9	MLG TEE BOLT ASSY DRAG STRUT	B737-200
65-46141-10	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-11	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-12	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-15	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-16	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-17	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-18	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-19	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-20	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-21	UPLOCK ASSY	B737
65-46141-22	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-23	UPLOCK ASSY.	B737
65-46141-24	UPLOCK ASSY	B737
65-46141-25	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-26	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-5	MLG UPLOCK ASSEMBLY	B737
65-46141-6	MLG UPLOCK ASSEMBLY	B737
65-46141-7	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-8	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46141-9	MAIN GEAR UPLOCK ASSEMBLY	B737
65-46146-1	SHAFT	B737
65-46146-2	MLG SHAFT UPLOCK SUPPORT	B737
65-46146-3	MLG SHAFT UPLOCK SUPPORT	B737
65-46146-4	MLG SHAFT UPLOCK SUPPORT	B737
65-46160-11	SUPPORT TUBE	B737-400
65-46160-7	MLG SUPPORT TUBE ORIFICE	B737-100
65-46160-8	MLG SUPPORT TUBE ORIFICE	B737-100
65-46200-16	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-17	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-19	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-21	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-22	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-25	NOSE GEAR SHOCK STRUT ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-46200-26	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-27	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-28	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-29	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-30	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-32	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-33	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-34	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-35	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-36	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-37	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-38	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-39	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-40	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-41	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-42	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-43	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-46	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-47	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-48	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-49	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-50	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-51	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-52	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-53	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-55	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-56	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-60	STRUT ASSEMBLY SHOCK	B737
65-46200-61	STRUT ASSEMBLY SHOCK	B737
65-46200-62	STRUT ASSEMBLY SHOCK	B737
65-46200-63	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-64	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-65	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-66	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-67	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-69	STRUT ASSEMBLY SHOCK	B737
65-46200-74	STRUT ASSEMBLY SHOCK	B737
65-46200-76	STRUT ASSEMBLY SHOCK	B737
65-46200-77	STRUT ASSEMBLY SHOCK	B737
65-46200-78	NOSE GEAR SHOCK STRUT ASSEMBLY	B737
65-46200-80	STRUT ASSEMBLY SHOCK	B737
65-46200-81	STRUT ASSEMBLY SHOCK	B737
65-46200-82	STRUT ASSEMBLY SHOCK	B737
65-46200-83	STRUT ASSEMBLY SHOCK	B737
65-46203-26	COLLAR ASSY., NLG STEERING	B737-100
65-46204-4	NOSE GEAR MINOR COMPONENTS	B737
65-46205-1	NOSE GEAR MINOR COMPONENTS	B737
65-46205-7	NOSE GEAR MINOR COMPONENTS	B737
65-46205-9	NOSE GEAR MINOR COMPONENTS	B737
65-46210-27	NLG STEERING PLATE UPPER (DRIL	B737-100
65-46210-33	NLG STEERING PLATE UPPER (DRIL	B737-300
65-46210-34	NLG STEERING PLATE LOWER (DRIL	B737-300
65-46211-8	NLG OUTER CYLINDER	B737-100
65-46215-21	NLG INNER CYLINDER ASSEMBLY	B737-300
65-46215-22	NLG INNER CYLINDER ASSEMBLY	B737-300



P/N	DESCRIPTION	AIRCRAFT PARTS
65-46219-1	NLG METERING PIN	B737-100
65-46221-4	NLG GLAND NUT ASSEMBLY	B737-300
65-46226-11	NLG TUBE ORIFICE SUPPORT UPPER	B737-300
65-46226-9	NLG TUBE ORIFICE SUPPORT UPPER	B737-300
65-46230-1	BRACE ASSEMBLY LOWER DRAG	B737
65-46230-11	BRACE ASSEMBLY LOWER DRAG	B737
65-46230-13	BRACE ASSEMBLY LOWER DRAG	B737
65-46230-15	BRACE ASSEMBLY LOWER DRAG	B737
65-46230-17	BRACE ASSEMBLY LOWER DRAG	B737
65-46230-19	BRACE ASSEMBLY LOWER DRAG	B737
65-46230-5	BRACE ASSEMBLY LOWER DRAG	B737
65-46230-7	BRACE ASSEMBLY LOWER DRAG	B737
65-46232-1	NOSE GEAR MINOR COMPONENTS	B737
65-46232-3	NOSE GEAR MINOR COMPONENTS	B737
65-46232-5	NOSE GEAR MINOR COMPONENTS	B737
65-46232-6	NOSE GEAR MINOR COMPONENTS	B737
65-46245-1	LOCK LINK INSTALLATION	B737
65-46245-10	LOCK LINK INSTALLATION	B737
65-46245-11	LOCK LINK INSTALLATION	B737
65-46245-12	LOCK LINK INSTALLATION	B737
65-46245-13	LOCK LINK INSTALLATION	B737
65-46245-14	LOCK LINK INSTALLATION	B737
65-46245-3	LOCK LINK INSTALLATION	B737
65-46245-4	LOCK LINK INSTALLATION	B737
65-46245-5	LOCK LINK ASSEMBLY	B737
65-46245-6	LOCK LINK INSTALLATION	B737
65-46245-7	LOCK LINK INSTALLATION	B737
65-46245-8	LOCK LINK INSTALLATION	B737
65-46245-9	LOCK LINK INSTALLATION	B737
65-46255-10	NLG STEERING PLATE LOWER	B737-100
65-46288-11	NLG TORSION LINK ASSEMBLY	B737-300
65-46288-13	NLG TORSION LINK ASSEMBLY	B737-300
65-46288-15	TORSION LINK ASSEMBLY	B737-300
65-46428-1	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-11	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-14	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-15	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-16	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-17	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-18	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-19	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-2	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-20	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-21	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-22	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-23	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-24	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-25	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-26	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-27	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-3	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-30	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-31	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-32	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-33	OUTBOARD FLAP TRACK ASSEMBLY	



P/N	DESCRIPTION	AIRCRAFT PARTS
65-46428-34	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-35	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-36	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-4	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-5	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-6	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-7	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-8	OUTBOARD FLAP TRACK ASSEMBLY	
65-46428-9	OUTBOARD FLAP TRACK ASSEMBLY	
65-46481-1	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-200, B737-300, B737-400, B737-500
65-46481-101	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-102	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-103	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-104	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-105	FLAP CARRIAGE ASSY	B737, B737-300, B737-400, B737-500
65-46481-106	FLAP CARRIAGE ASSY	B737, B737-300, B737-400, B737-500
65-46481-107	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-108	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-109	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-11	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-110	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-111	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-112	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-113	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-114	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-115	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-116	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-117	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-118	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-119	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-12	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-120	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-121	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-122	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-123	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-124	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-13	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-133	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-134	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-135	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-136	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-300, B737-400, B737-500
65-46481-137	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-200
65-46481-138	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-200
65-46481-139	OUTBOARD FLAP CARRIAGE ASSEMBLY	A330, A340
65-46481-14	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-143	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-144	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-145	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-146	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-147	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-148	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-149	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-15	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-150	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-46481-16	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-17	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-18	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-19	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-20	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-21	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-22	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-23	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-24	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-25	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-26	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-27	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-28	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-31	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-32	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-33	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-34	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-37	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-38	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-39	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-40	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-41	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-42	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-45	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-46	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-47	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-48	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-49	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-50	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-51	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-52	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-53	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-54	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-55	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-56	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-57	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-58	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-59	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-60	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-61	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-62	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-63	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-64	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-65	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-66	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-67	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737, B737-200, B737-300, B737-400, B737-500
65-46481-68	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-69	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-70	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-72	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-73	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-74	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-75	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-76	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-46481-8	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-81	SPINDLE	B737
65-46481-82	SPINDLE	B737
65-46481-83	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-84	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-85	SPINDLE	B737
65-46481-86	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-87	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-88	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-89	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-90	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-91	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-92	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-93	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-94	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-95	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-46481-96	SPINDLE	B737
65-46481-97	FLAP CARRIAGE ASSY	B737, B737-300, B737-400, B737-500
65-46481-98	FLAP CARRIAGE ASSY	B737, B737-300, B737-400, B737-500
65-4829	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-1	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-3	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-4	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-5	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-4829-9	NOSE GEAR DRAG BRACE ASSEMBLY	A330, A340
65-49580-11	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-12	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-13	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-14	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-15	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-16	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-17	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-18	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-19	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-20	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-49580-21	FLIGHT SPOILER POWER CONTROL UNIT ASSEMBLY	B737
65-52807-76	FLAP&SLAT INDICATION MODULE	B737
65-60579-3	MLG DRAG STRUT ASSEMBLY LOWER	B737-200
65-60579-5	LWR DRAG STRUT ASSY	B737-200
65-61740-12	MLG OUTER CYLINDER ASSEMBLY	B737-400
65-61740-5	OUTER CYLINDER	B737-200
65-63378-18	MLG TRUNNION LINK ASSEMBLY	B737-400
65-63378-21	MLG TRUNNION LINK ASSEMBLY	B737-400
65-63378-7	MLG TRUNNION LINK ASSEMBLY	B737-200
65-63378-9	MLG TRUNNION LINK ASSEMBLY	B737-200
65-63397-10	MLG SIDE STRUT ASSEMBLY LOWER	B737-400
65-63397-9	MLG SIDE STRUT ASSEMBLY LOWER	B737-100
65-63663-3	MLG BELLCRANK ASSEMBLY	B737-100
65-63663-4	BELL CRANK	B737
65-63663-5	MLG BELLCRANK ASSEMBLY	B737-400
65-63663-7	MLG BELLCRANK ASSEMBLY	B737-400
65-63663-9	MLG BELLCRANK ASSEMBLY	B737-100
65-67158-1	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67158-2	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67158-3	OUTBOARD FLAP TRACK ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65-67158-4	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67158-5	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67158-6	OUTBOARD FLAP TRACK ASSEMBLY	B737
65-67963-3	MLG TORSION LINK ASSEMBLY UPPE	B737-100
65-73761-103	MLG SIDE STRUT ASSEMBLY	B737
65-73761-105	MLG SIDE STRUT ASSEMBLY	B737
65-73761-106	MLG SIDE STRUT ASSEMBLY	B737
65-73761-109	MAIN LANDING GEAR	B737
65-73761-11	MAIN LANDING GEAR	B737
65-73761-110	MAIN LANDING GEAR	B737
65-73761-111	MLG SIDE STRUT ASSEMBLY	B737
65-73761-112	MLG SIDE STRUT ASSEMBLY	B737
65-73761-113	MLG SIDE STRUT ASSY	B737
65-73761-114	MLG SIDE STRUT RH	B737
65-73761-115	MAIN LANDING GEAR	B737
65-73761-116	MAIN LANDING GEAR	B737
65-73761-12	MAIN LANDING GEAR	B737
65-73761-121	L/H MAIN LANDING GEAR	B737
65-73761-122	R/H MAIN LANDING GEAR ASSY	B737
65-73761-123	MLG SIDE STRUT ASSY.	B737
65-73761-124	MLG SIDE STRUT ASSEMBLY	B737
65-73761-125	MLG ASSEMBLY	B737
65-73761-126	MLG SIDE STRUT ASSY	B737
65-73761-127	LH LDG BARE CONF.	B737
65-73761-128	RH MAIN LG ASSY	B737
65-73761-13	MAIN LANDING GEAR	B737
65-73761-14	MAIN LANDING GEAR	B737
65-73761-15	MAIN LANDING GEAR	B737
65-73761-16	MAIN LANDING GEAR	B737
65-73761-21	NLG	B737
65-73761-22	MLG SIDE STRUT ASSEMBLY	B737
65-73761-23	MLG SIDE STRUT ASSEMBLY	B737
65-73761-24	MLG SIDE STRUT ASSEMBLY	B737
65-73761-25	MLG SIDE STRUT ASSEMBLY	B737
65-73761-26	MLG SIDE STRUT ASSEMBLY	B737
65-73761-31	MAIN LANDING GEAR	B737
65-73761-32	MAIN LANDING GEAR	B737
65-73761-33	MAIN LANDING GEAR	B737
65-73761-34	MAIN LANDING GEAR	B737
65-73761-35	MAIN LANDING GEAR	B737
65-73761-36	MAIN LANDING GEAR	B737
65-73761-37	MAIN LANDING GEAR	B737
65-73761-38	MAIN LANDING GEAR	B737
65-73761-39	MAIN LANDING GEAR	B737
65-73761-40	MAIN LANDING GEAR	B737
65-73761-41	MAIN LANDING GEAR	B737
65-73761-42	MAIN LANDING GEAR	B737
65-73761-43	MLG SIDE STRUT ASSEMBLY	B737
65-73761-44	MLG SIDE STRUT ASSEMBLY	B737
65-73761-45	MLG SIDE STRUT ASSEMBLY	B737
65-73761-46	MLG SIDE STRUT ASSEMBLY	B737
65-73761-47	MLG SIDE STRUT ASSEMBLY	B737
65-73761-48	MLG SIDE STRUT ASSEMBLY	B737
65-73761-49	MLG SIDE STRUT ASSEMBLY	B737
65-73761-50	MLG SIDE STRUT ASSEMBLY	B737





P/N	DESCRIPTION	AIRCRAFT PARTS
65-73761-55	MLG SIDE STRUT ASSEMBLY	B737
65-73761-56	MLG SIDE STRUT ASSEMBLY	B737
65-73761-65	MAIN LANDING GEAR	B737
65-73761-66	MAIN LANDING GEAR	B737
65-73761-77	MLG SIDE STRUT ASSEMBLY	B737
65-73761-78	MLG SIDE STRUT ASSEMBLY	B737
65-73761-81	MAIN LANDING GEAR	B737
65-73761-82	MAIN LANDING GEAR	B737
65-73761-85	MLG SIDE STRUT ASSEMBLY	B737
65-73761-86	MLG SIDE STRUT ASSEMBLY	B737
65-73761-87	MAIN LANDING GEAR	B737
65-73761-88	MAIN LANDING GEAR	B737
65-73761-93	MLG SIDE STRUT ASSEMBLY	B737
65-73761-94	MLG SIDE STRUT ASSEMBLY	B737
65-73761-95	MLG SIDE STRUT ASSEMBLY	B737
65-73761-96	MLG SIDE STRUT ASSEMBLY	B737
65-73761-97	MAIN LANDING GEAR	B737
65-73761-98	MAIN LANDING GEAR	B737
65-73762-18	NOSE GEAR ASSEMBLY	B737
65-73762-21	NOSE LANDING GEAR	B737
65-73762-25	GEAR ASSY., NLG	B737
65-73762-26	GEAR ASSY., NLG	B737
65-73762-27	GEAR ASSY., NLG	B737
65-73762-28	GEAR ASSY., NLG	B737
65-73762-4	GEAR ASSY., NOSE LANDING	B737
65-73762-5	NOSE GEAR ASSEMBLY	B737
65-73762-7	NOSE GEAR ASSEMBLY	B737
65-73762-9	NOSE GEAR ASSEMBLY	B737
6577 SERIES	VANEAXIAL FAN ASSEMBLY	A330, A340
65-79949-1	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-10	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-2	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-3	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-4	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-5	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-6	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-7	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-8	OUTBOARD FLAP CARRIAGE ASSEMBLY	B737
65-79949-9	OUTBOARD FLAP CARRIAGE ASSEMBLY	A330, A340
65-80051-1	UPPER DRAG BRACE	B737
65-80051-10	UPPER DRAG BRACE	B737
65-80051-11	UPPER DRAG BRACE	B737
65-80051-13	UPPER DRAG BRACE	B737
65-80051-14	UPPER DRAG BRACE	B737
65-80051-18	UPPER DRAG BRACE	B737
65-80051-20	UPPER DRAG BRACE	B737
65-80051-3	UPPER DRAG BRACE	B737
65-80051-5	UPPER DRAG BRACE	B737
65-80051-6	UPPER DRAG BRACE	B737
65-80051-7	UPPER DRAG BRACE	B737
65-80051-8	UPPER DRAG BRACE	B737
65806-002-1	CLOCK	B757,A319
65-84161-1	MLG NUT AFT TRUNNION	B737
65-84161-4	MLG NUT AFT TRUNNION	B737
65-84163-1	NOSE GEAR MINOR COMPONENTS	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65C25676-2	NLG OUTER CYLINDER	B737-300
65C25707-1	NLG STEM ORIFICE SUPPORT TUBE	B737-300
65C25707-2	NLG STEM ORIFICE SUPPORT TUBE	B737-300
65C26816-2	BRAKE ACCUMULATOR ISOLATION VA	B737
65C26816-3	BRAKE ACCUMULATOR ISOLATION VA	B737
65C26816-4	BRAKE ACCUMULATOR ISOLATION VA	B737
65C26816-5	BRAKE ACCUMULATOR ISOLATION V	B737
65C26816-6	BRAKE ACCUMULATOR ISOLATION VA	B737
65C26816-7	BRAKE ACCUMULATOR ISOLATION VA	B737
65C26816-8	BRAKE ACCUMULATOR ISOLATION VA	B737
65C26816-9	BRAKE ACCUMULATOR ISOLATION VA	B737
65C26833-2	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B747, B737
65C26833-3	DEPRESSURIZATION VALVE	B747, B737
65C26864-3	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBL	B737
65C-26864-3	OUTBOARD GROUND SPOILER ACTUATOR ASSEMBLY	A330, A340
65C26885-5	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B747, B737
65C26885-6	STEERING DEPRESSURIZATION VALVE ASSEMBLY	B747, B737
65C27360-1	NOSE GEAR MINOR COMPONENTS	B737
65C27360-11	NOSE GEAR MINOR COMPONENTS	B737
65C27360-12	NOSE GEAR MINOR COMPONENTS	B737
65C27360-5	NOSE GEAR MINOR COMPONENTS	B737
65C27360-7	NOSE GEAR MINOR COMPONENTS	B737
65C27360-9	NOSE GEAR MINOR COMPONENTS	B737
65C27501-1	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B747, B737
65C27501-2	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B747, B737
65C27501-3	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B747, B737
65C27503-1	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27503-2	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27503-3	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27506-1	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27506-2	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27506-3	TE FLAP DRIVE NO.2 AND 6 TRANSMISSION A	B737
65C27508-1	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B737
65C27508-2	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B737
65C27508-3	TE FLAP DRIVE, NO. 1 AND 8 TRANSMISSION ASSEMBLY	B737
65C27531-1	DOOR BRACKET	B737
65C27531-3	DOOR BRACKET	B737
65C31099-1	NLG LOCK ACTUATOR	B747, B737-300, B737-400, B737-500
65C31099-2	NOSE GEAR LOCK ACTUATOR ASSEMBLY	B737-300, B737-400, B737-501
65C31332-1	BEARING	B737
65C31332-2	BEARING	B737
65C31332-3	BEARING	B737
65C31332-4	BEARING	B737
65C31332-5	BEARING	B737
65C31332-6	MLG BEARING ASSY FWD TRUNNION	B737
65C31786-1	DOOR BRACKET	B737
65C31786-4	DOOR BRACKET	B737
65C32649-1	MLG BEARING ASSY FWD TRUNNION	B737
65C32649-2	MLG BEARING ASSY FWD TRUNNION	B737
65C32649-3	MLG BEARING ASSY FWD TRUNNION	B737
65C32950-1	MLG METERING PIN	B737-400
65C32950-2	MLG METERING PIN	B737-400
65C32956-1	MAIN GEAR ACTUATOR ASSY	B737
65C32956-3	ACTUATOR, MLG RETRACT	B737
65C32956-4	ACTUATOR, MLG RETRACT	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
65C32956-6	MAIN GEAR ACTUATOR ASSY	B737
65C32964-3	TRUNNION PIN ASSY	B737-400
65C32964-9	MLG TRUNNION PIN ASSEMBLY	B737-400
65C33032-6	MLG ACTUATOR BEAM ARM ASSEMBLY	B737-400
65C33033-3	MLG BOLT ASSY ACTUATOR BEAM IN	B737-400
65C33706-1	MLG BOLT ASSY REACTION LINK	B737-400
65C33706-3	MLG BOLT ASSY REACTION LINK	B737-400
65C33723-1	MLG BOLT REACTION LINK UPLOCK	B737
65C33723-2	MLG BOLT REACTION LINK UPLOCK	B737
65C33723-3	ELG BOLT REACTION LINK UPLOC	B737
65C34812-2	OUTBOARD FLAP TRACK ASSEMBLY	
65C34812-3	OUTBOARD FLAP TRACK ASSEMBLY	
65C34812-4	OUTBOARD FLAP TRACK ASSEMBLY	
65C34812-5	OUTBOARD FLAP TRACK ASSEMBLY	
65C34812-6	OUTBOARD FLAP TRACK ASSEMBLY	
65C34812-7	OUTBOARD FLAP TRACK ASSEMBLY	
65C34812-8	OUTBOARD FLAP TRACK ASSEMBLY	
65C35387-4	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C35615-2	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C35616-5	OUTBOARD FLAP TRACK ASSEMBLY	B737
65C36459-1	ACTUATOR ATTACH BOLT	B737
65C36459-2	MLG BOLT ACTUATOR ROD END	B737
65C37053-9	RUDDER PCU	B737
65C37817-1	NLG BOLT STEERING COLLAR	B737-100
65C38058-10	L/E ACTUADOR	B747, B737
65C38059-13	ACTUATOR ASSY	B747, B737
65C38059-14	LEADING EDGE SLAT HYD ACT ASSEM	B727,B737
65C38059-15	ACTUATOR ASSY	B747, B737
66005	VARIABLE DELIVERY HYDRAULIC PUMP	A330, A340
66005-01	VARIABLE DELIVERY HYDRAULIC PUMP	A330, A340
66007	VARIABLE DELIVERY HYDRAULIC PUMP	A330, A340
66007-01	VARIABLE DELIVERY HYDRAULIC PUMP	A330, A340
66068-05	VARIABLE DELIVERY HYDRAULIC PUMP	B757,B767
66068-06	VARIABLE DELIVERY HYDRAULIC PUMP	B757,B767,B727
66068-07	VARIABLE DELIVERY HYDRAULIC PUMP	B747,B757,B767,B777
66068-08	VARIABLE DELIVERY HYDRAULIC PUMP	B747,B757,B767,B777
6607A1-73	SWITCH, PRESSURE	
6608201-X	STARTER GENERATOR	Learjet
6608268-X	STARTER GENERATOR	Learjet
6608458-XXX	STARTER GENERATOR	Learjet
6608512-XXX	STARTER GENERATOR	Learjet
66087	VARIABLE DELIVERY HYDRAULIC PUMP	B737-300/400/500, B737-800/900,B727
66132-03	VARIABLE DELIVERY HYDRAULIC PUMP	B-767, B-777
66132-04	VARIABLE DELIVERY HYDRAULIC PUMP	B-767, B-777
66133-02	PUMP MOTOR PACKAGE	B-767, B-777
66133-03	PUMP MOTOR PACKAGE	B-767, B-777
66133-04	PUMP MOTOR PACKAGE	B-767, B-777
66172-01	PUMP HYDRAULIC	
66173-03	HYDRAULIC PUMP	Dash8
66198-01		
66198-01	VARIABLE DELIVERY HYDRAULIC PUMP	A330
66198-02	AP19V-21-02 ENGINE DRIVEN	
66198-02	VARIABLE DELIVERY HYDRAULIC PUMP	A340
66198-03	PUMP HYDRAULIC	



P/N	DESCRIPTION	AIRCRAFT PARTS
66198-03	VARIABLE DELIVERY HYDRAULIC PUMP	A340
662136-1	VALVE	
662136-1/81755	VALVE	
66432 SERIES	LIQUID COOLED MOTOR	A330, A340
66760-1	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
66760-2	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
66760-3	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
66760-4	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
66760-5	FLAP AND SLAT HYDRAULIC DEPRESSURIZATION MODULE	B757
67054	SERVOED MACH AIRSPEED IND	
670750-107	ACTUATOR ELECTRO -ME	
670764-103	GENERATOR TACHOMETE	
67085	SERVOED MACH AIRSPEED IND	
67115	SERVOED MACH AIRSPEED IND	
6805307L	VIBRATOR, IGNITION CO	
69-14106-1	LANDING GEAR HYDRAULIC TRANSFE	B737
69-14106-2	LANDING GEAR HYDRAULIC TRANSFE	B737
69-14106-3	LANDING GEAR HYDRAULIC TRANSFE	B737
69-14106-4	LANDING GEAR HYDRAULIC TRANSFE	B737
69-14106-5	LANDING GEAR HYDRAULIC TRANSFE	B737
69-14106-6	LANDING GEAR HYDRAULIC TRANSFE	B737
69-14106-7	LANDING GEAR HYDRAULIC TRANSFE	B737
693335	HYDRAULIC MOTORPUMP ASSEMBLY	A319, A320, A321, A330, A340
693337	HYDRAULIC MOTORPUMP ASSY	A320, A340
69-35385-1	AFT LOCK MECHANISM SHAFT	B737
69-35385-2	AFT LOCK MECHANISM SHAFT	B737
69-35391-1	NOSE GEAR MINOR COMPONENTS	B737
69-35391-2	DRAG BRACE,PIN	B737
69-35394-1	NOSE GEAR MINOR COMPONENTS	B737
69-35394-2	NOSE GEAR MINOR COMPONENTS	B737
69-35394-3	NOSE GEAR MINOR COMPONENTS	B737
69-35394-4	NLG PIN DRAG BRACE UPPER	B737
69-35396-1	NOSE GEAR MINOR COMPONENTS	B737
69-35396-2	NOSE GEAR MINOR COMPONENTS	B737
69-35396-3	NOSE GEAR MINOR COMPONENTS	B737
69-35396-4	LWR DRAG BRACE BOLT	B737
69-35396-5	NOSE GEAR MINOR COMPONENTS	B737
69-35500-3	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
69-35500-4	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
69-35500-5	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
69-35500-6	MAIN GEAR LOCK ACTUATOR ASSEMB	B737
69-36622-3	NLG ORIFICE PLATE UPPER	B737-100
69-37307-112	ENGINE APU FIRE MODULE	B737
69-37876-1	OUTBOATD STABILIZING TUBE ASSE	B737
69-38709-1	NOSE GEAR MINOR COMPONENTS	B737
69-38709-3	NOSE GEAR MINOR COMPONENTS	B737
69-38709-5	NOSE GEAR MINOR COMPONENTS	B737
69-38710-1	NOSE GEAR MINOR COMPONENTS	B737
69-38710-2	NOSE GEAR MINOR COMPONENTS	B737
69-38991-1	SIDE STRUT BOLT ASSEMBLY	B737
69-38993-1	MLG BOLT REACTION LINK UPLOCK	B737
69-38993-2	MLG BOLT REACTION LINK UPLOCK	B737
69-38993-3	MLG BOLT REACTION LINK UPLOCK	B737
69-38999-2	MLG SHAFT SPRING SUPPORT	B737-100
69-38999-4	MLG SHAFT SPRING SUPPORT	B737-100



P/N	DESCRIPTION	AIRCRAFT PARTS
69-39464-1	MLG BOLT ACTUATOR BEAM OUTBD	B737
69-39464-2	MLG BOLT ACTUATOR BEAM OUTBD	B737
69-39464-3	MLG BOLT ACTUATOR BEAM OUTBD	B737
69-39464-4	MLG BOLT ACTUATOR BEAM OUTBD	B737
69-39464-5	MLG BOLT ACTUATOR BEAM OUTBD	B737
69-39473-3	MLG BOLT ASSY LOWER DRAG STRUT	B737-100
69-39473-5	MLG BOLT ASSY LOWER DRAG STRUT	B737-100
69-39473-6	MLG BOLT ASSY LOWER DRAG STRUT	B737-100
69-41625-1	SHAFT,ACTUATOR UPLOCK	B737
69-41629-1	MLG BOLT DOWNLOCK LINK PIVOT	B737-100
69-41633-6	MLG NUT TRUNNION PIN	B737-400
69-42196-4	FORWARD TRUNION BEARING BOLT	B737
69-42196-5	FORWARD TRUNNION BEARING BOLT	B737
69-42199-1	ACTUATOR BEAM BOLT	B737
69-42199-2	ACTUATOR BEAM BOLT	B737
69-42199-3	ACTUATOR BEAM BOLT	B737
695001-9A	STRUT ASSEMBLY MAIN LANDING GEAR SHOCK C-130	C-130 HERCULES
695040	NLG STEERING CYLINDER ASSY	A330, A340
69-51833-3	MLG BOLT TEE FITTING ATTACHMEN	B737-200
69-51833-4	MLG BOLT TEE FITTING ATTACHMEN	B737-200
69-51838-1	BELLCRANK COLLAR	B737
69-51838-2	BELLCRANK COLLAR	B737
69-51838-3	COLLAR	B737
69-53800-1	BUNGIE SPRING ASSEMBLY	B737
69-53800-4	BUNGIE SPRING ASSEMBLY	B737
69-53869-1	UPLOCK RELEASE ROD ASSEMBLY	B737
69-53869-3	UPLOCK RELEASE ROD ASSEMBLY	B737
69-53869-5	UPLOCK RELEASE ROD ASSEMBLY	B737
695457-3	NLG STEERING CYLINDER ASSY	A330, A340
69-54600-1	LANDING GEAR HYDRAULIC TRANSFE	B737
69-54600-2	LANDING GEAR HYDRAULIC TRANSFE	B737
69-54975-1	OUTBOARD STABILIZING STUD ASSEM	B737
695568-1	NLG STEERING CYLINDER ASSY	A330, A340
695568-3	CYLINDER AND PISTON	C-130
695568-5	NLG STEERING CYLINDER ASSY	A330, A340
69-58854-2	FORWARD TRUNNION BEARING BOLD	B737
69-58854-3	FORWARD TRUNNION BEARING BOLT	B737
69-58854-4	FORWARD TRUNNION BEARING BOLT	B737
69-58854-5	FORWARD TRUNNION BEARING BOLT	B737
69-58871-1	FORWARD TRUNNION BEARING ASSEM	B737
69-58873-1	FORWARD TRUNNION BEARING ASSEM	B737
69-61383-4	NLG BOLT STEERING COLLAR	B737-100
69-61946-1	OUTBOARD STABILIZING TUBE ASSE	B737
69-62779-1	MLG BOLT ASSY UPPER DOWNLOCK	B737-100
69-62779-3	MLG BOLT ASSY UPPER DOWNLOCK	B737-100
69-67545-1	BUNGIE SPRING ASSEMBLY	B737
69-68115-1	NOSE GEAR MINOR COMPONENTS	B737
69-68148-1	MLG BOLT ASSY REACTION LINK	B737-100
69-68149-1	MLG BOLT ASSY UPPER SIDE STRUT	B737-100
69-68150-1	MLG BOLT ASSY SIDE STRUT	B737-100
69-68151-1	MLG BOLT ASSY LOWER SIDE STRUT	B737
69-68151-3	MLG BOLT ASSY LOWER SIDE STRUT	B737
69-72023-2	MLG TORSION LINK PIN LOWER	B737-100
69-72023-4	MLG TORSION LINK PIN	B737-100
69-73176-1	MLG FUSE BOLT FWD TRUNNION BEA	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
69-73176-2	MLG FUSE BOLT FWD TRUNNION BEA	B737
69-73677-1	NOSE GEAR MINOR COMPONENTS	B737
69-73677-3	NOSE GEAR MINOR COMPONENTS	B737
69-73677-5	NOSE GEAR MINOR COMPONENTS	B737
69-73677-9	NOSE GEAR MINOR COMPONENTS	B737
69-77044-1	TUBE	B737
69-77045-1	OUTBOARD STABILIZING STUD ASSE	B737
69-77063-2	MLG FUSE BOLT FWD TRUNNION BEA	B737
69-77145-3	MLG FUSE BOLT ASSY UPPER DRAG	B737-400
69-77145-5	MLG FUSE BOLT ASSY UPPER DRAG	B737-400
69-77496-10	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-11	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-12	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-13	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-14	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-17	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-18	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-19	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-20	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-21	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-22	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-23	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-26	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-27	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-28	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-29	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-30	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-5	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-6	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-7	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-8	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77496-9	MAIN GEAR ACTUATOR ASSEMBLY	B737
69-77522-1	MLG BOLT ASSY UPPER SIDE STRUT	B737-400
69-77523-1	MLG BOLT ASSY SIDE STRUT	B737-400
69-77524-1	MLG BOLT ASSY LOWER SIDE STRUT	B737
69-77524-3	MLG BOLT ASSY LOWER SIDE STRUT	B737
69-78313-2	MLG NUT TRUNNION PIN	B737-100
6F2392-5	FILTERED RESTRICTOR VALVE	B737
6F2392-6	FILTERED RESTRICTOR VALVE	B737
70.AA6.511	FAN ASSEMBLY	A330, A340
70.AA6.521	FAN ASSEMBLY	A330, A340
7002353-902	AZ 649 AIR DATA SENSOR	A330, A340
7002353-911	AZ 649 AIR DATA SENSOR	C-212, CN-235
7002353-912	AZ 649 AIR DATA SENSOR	A330, A340
7002353-913	AZ 649 AIR DATA SENSOR	A330, A340
7002493-906	INDICATOR, ATTITUDE	C-212
70-0366-1	BALLAST	B737,B757
70-0366-11	BALLAST	B767
70-0366-3	FLUORESCENT LAMP BALLAST ASSY	A330, A340
70-0366-5	FLUORESCENT LAMP BALLAST ASSY	B737
70-0366-7	BALLAST UNIT	B737,B757
70-0366-9	FLUORESCENT LAMP BALLAST ASSY	A330, A340
700842	CONSTANT SPEED DRIVE	B727, B747
700842A	CONSTANT SPEED DRIVE	B747
7008FS-972-P3	GT RING	



P/N	DESCRIPTION	AIRCRAFT PARTS
701284	STROBE LIGHT	
701285	POWER SUPPLY	
702200-1	FUEL BOOSTER PUMP, SINGLE FUEL VOLUTE HOUSING & DOUBLE PUMP VOLUTE HOUSING	A330, A340
702300-1	FUEL BOOSTER PUMP, SINGLE FUEL VOLUTE HOUSING & DOUBLE PUMP VOLUTE HOUSING	A330, A340
70277-10	ROTARY HYDRAULIC SNUBBER	B747
70277-16	ROTARY HYDRAULIC SNUBBER	B747
70277-17	ROTARY HYDRAULIC SNUBBER	B747
70277-18	ROTARY HYDRAULIC SNUBBER	B747
70277-20	ROTARY HYDRAULIC SNUBBER	B747
70277-21	ROTARY HYDRAULIC SNUBBER	B747
70277-24	ROTARY HYDRAULIC SNUBBER	B747
70277-25	ROTARY HYDRAULIC SNUBBER	B747
70277-26	ROTARY HYDRAULIC SNUBBER	B747
70277-27	ROTARY HYDRAULIC SNUBBER	B747
70277-30	ROTARY HYDRAULIC SNUBBER	B747
70277-34	ROTARY HYDRAULIC SNUBBER	B747
70277-35	ROTARY HYDRAULIC SNUBBER	B747
70277-36	ROTARY HYDRAULIC SNUBBER	B747
70277-37	ROTARY HYDRAULIC SNUBBER	B747
70277-38	ROTARY HYDRAULIC SNUBBER	B747
70277-39	ROTARY HYDRAULIC SNUBBER	B747
70277-50	ROTARY HYDRAULIC SNUBBER	B747
70277-51	ROTARY HYDRAULIC SNUBBER	B747
70277-52	ROTARY HYDRAULIC SNUBBER	B747
70277-53	ROTARY HYDRAULIC SNUBBER	B747
70277-8	ROTARY HYDRAULIC SNUBBER	B747
70277-9	ROTARY HYDRAULIC SNUBBER	B747
70290-7D544	FAUCET ASSEMBLY	
70304	SHUTTLE VALVE	
7040	IND-CLIMB	
705117K	CONSTANT SPEED DRIVE	B747,B727
705-15V9	IND STAND HORIZON	
70577-10	ROTARY HYDRAULIC SNUBBER	B747
70577-16	ROTARY HYDRAULIC SNUBBER	B747
70577-17	ROTARY HYDRAULIC SNUBBER	B747
70577-18	ROTARY HYDRAULIC SNUBBER	B747
70577-20	ROTARY HYDRAULIC SNUBBER	B747
70577-21	ROTARY HYDRAULIC SNUBBER	B747
70577-24	ROTARY HYDRAULIC SNUBBER	B747
70577-25	ROTARY HYDRAULIC SNUBBER	B747
70577-26	ROTARY HYDRAULIC SNUBBER	B747
70577-27	ROTARY HYDRAULIC SNUBBER	B747
70577-30	ROTARY HYDRAULIC SNUBBER	B747
70577-34	ROTARY HYDRAULIC SNUBBER	B747
70577-35	ROTARY HYDRAULIC SNUBBER	B747
70577-36	ROTARY HYDRAULIC SNUBBER	B747
70577-37	ROTARY HYDRAULIC SNUBBER	B747
70577-38	ROTARY HYDRAULIC SNUBBER	B747
70577-39	ROTARY HYDRAULIC SNUBBER	B747
70577-40	ROTARY HYDRAULIC SNUBBER	B747
70577-41	ROTARY HYDRAULIC SNUBBER	B747
70577-42	ROTARY SNUBBER	B747,B757,B777
70577-43	ROTARY SNUBBER	B747, B757



P/N	DESCRIPTION	AIRCRAFT PARTS
70577-44	ROTARY HYDRAULIC SNUBBER	B747,B757,MD80
70577-45	ROTARY SNUBBER LH DOOR	B747, B757,A320
70577-50	ROTARY HYDRAULIC SNUBBER	B747
70577-51	ROTARY HYDRAULIC SNUBBER	B747
70577-52	ROTARY HYDRAULIC SNUBBER	B747
70577-53	ROTARY HYDRAULIC SNUBBER	B747
70577-8	ROTARY HYDRAULIC SNUBBER	B747
70577-9	ROTARY HYDRAULIC SNUBBER	B747
706400-2	BLEED VALVE FUEL GEAR MOTOR	B737
706400-3	BLEED VALVE FUEL GEAR MOTOR	B737,A300, B767
706400-4	BLEED VALVE FUEL GEAR MOTOR	B737,B727
706786-2	DUAL CHANNEL FUEL GAGE AMPLIFIER	A330, A340
706786-3	DUAL CHANNEL FUEL GAGE AMPLIFIER	A330, A340
707304D	CONSTANT SPEED AC GENERATOR	DC-10,B727
707304E	CSD	A300, DC-10,B727
70895-1	BOX ASSY	
70900-3	ELECTRONIC CONTROL BOX	
710TS06Y11	NOSE WHEEL STEERING CONTROLLER	A318
710TS06Y12	NOSE WHEEL STEERING CONTROLLER	A330
71178-1	HYDRAULIC FUSE UNIT AND MANIFO	A330
71179-1	PITCH TRIMMER	A330
71179-2	HYRAULIC FUSE UNIT AND MANIFOL	A330
71182-2	HYDRAULIC FUSE UNIT AND MANIFO	A330
711TS06Y	NOSE WHEEL STEERING CONTROLLER	A318
712TS06Y	NOSE WHEEL STEERING CONTROLLER	A330
712TS06Y01	NOSE WHEEL STEERING CONTROLLER	A330
71404	DUAL BRAKE METERING VALVE	B757
71404-1	DUAL BRAKE METERING VALVE	B747, B747-400, B737,B777,B757
71404-2	DUAL BRAKE METERING VALVE	A330, A340
7151133E	DRIVE CONSTANT SPEED	
715776	ELECTRIC MOTOR ASSEMBLY	A330, A340
715TS06Y11	HAND STEERING TX	A318
715TS06Y12	NOSE WHEEL STEERING CONTROLLER	A330
716961	PUMP ASSEMBLY - VARIABLE DISPLACEMENT	
716TS06Y	CONTROL, NOSE WHEEL STEERING	A318
717042	TUBE	
717324	CHARGE FILTER CAP ASSEMBLY	A330, A340
717TS06Y	NOSE WHEEL STEERING CONTROLLER	A330
717TS06Y01	NOSE WHEEL STEERING CONTROLLER	A330
718644A	STATOR	A330, A340
720845	GENERATOR ASSEMBLY	CRJ100,200
720845 SERIES	GENERATOR ASSEMBLY	CRJ100,200
720845E	GENERATOR ASSEMBLY	CRJ100,200,B777,B767
720845-SERIES	GENERATOR ASSEMBLY	CRJ100,200
72095-1	MODULE CONTROL ASSEMBLY	A330, A340
72095-3	MODULE CONTROL ASSEMBLY	A320, A330, A340
72095-5	MODULE CONTROL ASSEMBLY	A320, A330, A340
72095-7	MODULE CONTROL ASSEMBLY	A320, A330, A340
72095-9	MODULE CONTROL ASSEMBLY	A320, A330, A340
721429	STATOR HOUSING ASSEMBLY	A330, A340
721429A	STATOR HOUSING ASSEMBLY	A330, A340
721429B	STATOR HOUSING ASSEMBLY	A330, A340
721429C	STATOR HOUSING ASSEMBLY	A330, A340
721429D	STATOR HOUSING ASSEMBLY	A330, A340
721429E	STATOR HOUSING ASSEMBLY	A330, A340





P/N	DESCRIPTION	AIRCRAFT PARTS
721432	ROTOR ASSEMBLY	A330, A340
721432A	ROTOR ASSEMBLY	A330, A340
721432B	ROTOR ASSEMBLY	A330, A340
721432C	ROTOR ASSEMBLY	A330, A340
721432D	ROTOR	A330, A340
721432E	ROTOR ASSEMBLY	
721435	SHAFT AND ROTOR ASSEMBLY	A330, A340
721437	EXCITER ROTOR ASSEMBLY	A330, A340
721643	PMG AND SUPPORT ASSEMBLY	A330, A340
72266-3	FUEL BOOSTER CANISTER PUMP	A330, A340
72305039-1	WINGTIP ANTICOLLISION LIGHT ASSEMBLY AND STEPDOWN CONVERTER POWER SUPPLY CABLE ASSEMBLY	B-737
72305039-2	WINGTIP ANTICOLLISION LIGHT ASSEMBLY AND STEPDOWN CONVERTER POWER SUPPLY CABLE ASSEMBLY	B-737
72305039-3	WINGTIP ANTICOLLISION LIGHT ASSEMBLY AND STEPDOWN CONVERTER POWER SUPPLY CABLE ASSEMBLY	B-737
72305039-4	WINGTIP ANTICOLLISION LIGHT ASSEMBLY AND STEPDOWN CONVERTER POWER SUPPLY CABLE ASSEMBLY	B-737
72390-2	FUEL BOOSTER CANISTER PUMP	A330, A340
725923	RACE - ROLLER BEARING	
725933	GEAR SHAFT	
725953	SHAFT	
72605371-1	WINGTIP ANTICOLLISION LIGHT ASSEMBLY AND STEPDOWN CONVERTER POWER SUPPLY CABLE ASSEMBLY	B-737
72605371-2	WINGTIP ANTICOLLISION LIGHT ASSEMBLY AND STEPDOWN CONVERTER POWER SUPPLY CABLE ASSEMBLY	B-737
72605371-3	WINGTIP ANTICOLLISION LIGHT ASSEMBLY AND STEPDOWN CONVERTER POWER SUPPLY CABLE ASSEMBLY	B-737
72605371-4	WINGTIP ANTICOLLISION LIGHT ASSEMBLY AND STEPDOWN CONVERTER POWER SUPPLY CABLE ASSEMBLY	B-737
7-26-4	INDICATOR, HOMIG	
726473	EXCITER STATOR	B757
726506	ROTOR ASSEMBLY EXCITER	B757
726506Y1	EXCITER ROTOR	
726828	PMG STATOR	B757
727429E	IDG	A330, A340
727792	IDG	B757
727792C	IDG	B757
727792D	IDG	B757
727792E	IDG	B757
727792F	IDG	B757
727792G	IDG	B757, B767
727792H	IDG	B757
727792J	IDG	B757, A300
727792K	IDG	B757, A300
727792L	IDG	B757
727792M	IDG	B757



P/N	DESCRIPTION	AIRCRAFT PARTS
727792N	IDG	B757
727810A	AUXILIARY GENERATOR	B757
727810B	AUXILIARY GENERATOR	B757, B767
727810C	AUXILIARY GENERATOR	B757, B767, A320, A340
728403	APU GENERATOR ADAPTER	A330, A340
728403A	APU GENERATOR ADAPTER	A330, A340
728403B	APU GENERATOR ADAPTER	A330, A340
728403C	APU GENERATOR ADAPTER	A330, A340
728749	RACE - OUTER ROLLER	
728843	ROTOR BALANCE ASSEMBLY	B757
728843 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
728843D	ROTOR	B757, B767, B747, A300
728843E	ROTOR	B757, B767, B747, A300
728843F	ROTOR	B757, B767, B747, A300
728843G	ROTOR	B757, B767, B747, A300
728843GY5	ROTOR BALANCE ASSEMBLY	B757, B767, B747, A300
728843H	ROTOR	B757, B767, B747, A300, A310
728843-SERIES	ROTOR BALANCE ASSEMBLY	
728905	STATOR	B757
728915B	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN GENERATOR	B737, B757
728915C	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN GENERATOR	B737, B757
728915D	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN GENERATOR	B737, B757
728915E	WOUND ASSEMBLY - SHAFT AND ROTOR MAIN GENERATOR	B737, B757
728915-SERIES	WOUND ASSEMBLY	
729208	ELECTRICAL HARNESS	B757
729208A	ELECTRICAL HARNESS	B757
729208B	ELECTRICAL HARNESS	B757
729346	STATOR HOUSING ASSEMBLY	B757, B767
729346A	STATOR HOUSING ASSEMBLY	B757, B767
729346B	STATOR HOUSING ASSEMBLY	B757, B767
729346C	STATOR HOUSING ASSEMBLY	B757, B767
729346D	STATOR HOUSING ASSEMBLY	B757, B767
729346E	STATOR HOUSING ASSEMBLY	B757, B767
729346F	STATOR HOUSING ASSEMBLY	B757, B767
729355	ROTOR BALANCE ASSEMBLY	B757
729355 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
729355B	ROTOR BALANCE ASSEMBLY	
729355C	ROTOR BALANCE ASSEMBLY	
729355D	ROTOR BALANCE ASSEMBLY	
729355E	ROTOR BALANCE ASSEMBLY	
729355F	ROTOR	B757, B767, B747, A300, A310
729355G	ROTOR	B757, B767, B747, A300, A310
729355-SERIES	ROTOR BALANCE ASSEMBLY	
729722	AUXILIARY GENERATOR	A300, A310
729722A	AUXILIARY GENERATOR	A300, A310
729722B	AUXILIARY GENERATOR	A300, A310, B757
729722C	AUXILIARY GENERATOR	A300, A310, B757
729825	INTEGRATED DRIVE GENERATOR	B757, B767
729825A	INTEGRATED DRIVE GENERATOR	B757, B767
729825B	INTEGRATED DRIVE GENERATOR	B757, B767
729825C	INTEGRATED DRIVE GENERATOR	B757, B767



P/N	DESCRIPTION	AIRCRAFT PARTS
729825D	INTEGRATED DRIVE GENERATOR	B757, B767
729825E	INTEGRATED DRIVE GENERATOR	B757, B767
729825F	INTEGRATED DRIVE GENERATOR	B757, B767
729825G	INTEGRATED DRIVE GENERATOR	B757, B767
729825H	INTEGRATED DRIVE GENERATOR	B757, B767
729825J	INTEGRATED DRIVE GENERATOR	B757, B767, B747
729825K	INTEGRATED DRIVE GENERATOR	B757, B767
729825L	INTEGRATED DRIVE GENERATOR	B757, B767, B737
729825M	INTEGRATED DRIVE GENERATOR	B757, B767
730732	HOUSING - WOBBLER	
7-3141-3	MAIN LANDING GEAR DOOR AC	B737
731488D	PORT PLATE ASSEMBLY	
731489C	PORT PLATE ASSEMBLY	
731681	EXCITER ROTOR ASSEMBLY	A330, A340
731753	CONSTANT SPEED DRIVE	B727, B747
731966	VAR. DISPLACEMENT HYDRAULIC MOTOR PUMP	B747-400, B757, B767, B747, B777
732036	MOTOR HOUSING AND STATOR SUBASSEMBLY	A330, A340
732591	AIR COOLING FAN	A330, A340
732591 SERIES	AIR COOLING FAN	A330, A340
732591C	AIR COOLING FAN	B767, B747
732591E	FAN	B747, B767, B757
732591F	FAN	B747, B767, B757
732591G	AIR COOLING FAN	B747, B767, B757
732591-SERIES	AIR COOLING FAN	A330, A340
733492	WOBBLER CONTROL ARM	
733742 SERIES	STATOR HOUSING	A330, A340
734556A	DRIVE CONSTANT SPEED HYDRAULIC	
735243	RACE - ROLLER BEARING	
736692 SERIES	STATOR HOUSING	A330, A340
737060	IDG	
737852A	INTEGRATED DRIVE GENERATOR	Fokker 50, Gulfstream V
738131	STATOR ASSEMBLY - PMG	DC-10
738156B	AC GENERATOR	A330, A340
738158A	AC GENERATOR	A330, A340
738229A	STATOR ASSEMBLY - AC GENERATOR	A330, A340
738290	STATOR HOUSING ASSEMBLY	
738290-SERIES	STATOR HOUSING ASSEMBLY	A330, A340
738292	DUAL FUEL GAGE AMPLIFIER	A330, A340
738299	ROTOR	A330, A340
738299 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
738299A	ROTOR BALANCE ASSEMBLY	A330, A340
738299B	ROTOR	B717
738299-SERIES	ROTOR BALANCE ASSEMBLY	
738301	SHAFT AND ROTOR ASSEMBLY	A330, A340
738316A	STATOR HOUSING ASSEMBLY	A330, A340
738690	INPUT HOUSING ASSEMBLY	A330, A340
738690 SERIES	INPUT HOUSING ASSEMBLY	A330, A340
738690-SERIES	INPUT HOUSING ASSEMBLY	
738955	EXCITER STATOR, ASSEMBLY	A330, A340
739515	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767, A320, A340
739515A	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767, B757
739515B	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
739515C	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
739515D	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
740119	INTEGRATED DRIVE GENERATOR	A330, A340, A320



P/N	DESCRIPTION	AIRCRAFT PARTS
740119 SERIES	INTEGRATED DRIVE GENERATOR	A330, A340
740119A	INTEGRATED DRIVE GENERATOR	A320
740119B	INTEGRATED DRIVE GENERATOR	A320
740119C	INTEGRATED DRIVE GENERATOR	A320
740119D	INTEGRATED DRIVE GENERATOR	A320, A319, A300
740119E	INTEGRATED DRIVE GENERATOR	A320, A319
740119F	INTEGRATED DRIVE GENERATOR	A320, A319
740119G	INTEGRATED DRIVE GENERATOR	A320, A319
740119H	INTEGRATED DRIVE GENERATOR	A319, A320, A321
740510	INTEGRATED DRIVE GENERATOR	
740510F	IDG	
740510G	IDG	
741434	ELECTRICAL HARNESS	A330, A340
741434A	ELECTRICAL HARNESS	A330, A340
741434B	ELECTRICAL HARNESS	A330, A340
741439	STATOR HOUSING ASSEMBLY	A330, A340
741756	STATOR HOUSING ASSEMBLY	A330, A340
741756 SERIES	STATOR HOUSING ASSEMBLY	A330, A340
741756A	STATOR HOUSING ASSEMBLY	A330, A340
741788	ASSEMBLY-EXCITER STATOR	A330, A340
741901	IDG	
742051	ROTOR	A330, A340
742051 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
742051A	ROTOR BALANCE ASSEMBLY	A330, A340
742051B	ROTOR BALANCE ASSEMBLY	A330, A340
742051SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
744041	INTEGRATED DRIVE GENERATOR	B757/B767/CRJ100
744041A	INTEGRATED DRIVE GENERATOR	B757/B767/CRJ100
744041B	INTEGRATED DRIVE GENERATOR	B757/B767/CRJ100
745329	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329A	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329B	INTEGRATED DRIVE GENERATOR	B747-300/B747-400/B767
745329C	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329D	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329E	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
745329F	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
746277 SERIES	STATOR HOUSING	A330, A340
747194	IDG	A330, A340
747194A	IDG	B747, B767
747194B	IDG	B747, B767
747194C	IDG	B747, B767
747194D	IDG	B747, B767
747194E	IDG	B747, B767
747194F	IDG	A330, A340
747532	HOUSING - WOBBLER - VARIABLE	
747533	PLATE - BEARING	
747536	PLATE - BEARING	
747542	HOUSING - WOBBLER - VARIABLE	
747-5750-1-0	AC MOTOR WITH BRAKE ASSEMBLY	A330, A340
747739	COVER	
747740	STATOR HOUSING	
747740 SERIES	STATOR HOUSING	A330, A340
747740A	STATOR HOUSING	
747740B	STATOR HOUSING	
747740C	STATOR HOUSING	



P/N	DESCRIPTION	AIRCRAFT PARTS
747740D	STATOR HOUSING	
747740E	STATOR HOUSING	
747740F	STATOR HOUSING	
747740G	STATOR HOUSING	
747768	ROTOR BALANCE ASSEMBLY	B757
747768 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
747768C	ROTOR	B757, B767, B747, A300,A310
747768D	ROTOR	B757, B767, B747, A300,A310
747768-SERIES	ROTOR BALANCE ASSEMBLY	
748169	EXCITER STATOR	
749198-2	HYDRAULIC RESERVOIR	A319
749436	DEAERATOR	
750860	INTEGRATED DRIVE GENERATOR	MD-11
750875	INTEGRATED DRIVE GENERATOR	MD-11
751341	EXCITER STATOR	A330, A340
751344	ROTOR ASSEMBLY, EXCITER	A330, A340
751344A	ROTOR ASSEMBLY, EXCITER	A330, A340
752063	ROTOR BALANCE ASSEMBLY	A330, A340
752063A	ROTOR BALANCE ASSEMBLY	A330, A340
752157	INTEGRATED DRIVE GENERATOR	A340
752157 SERIES	INTEGRATED DRIVE GENERATOR	A340
752157B	INTEGRATED DRIVE GENERATOR	A340
752157C	INTEGRATED DRIVE GENERATOR	A340
752157D	IDG	A340, A330
752168	INTEGRATED DRIVE GENERATOR	A330
752168A	INTEGRATED DRIVE GENERATOR	A330
752168B	INTEGRATED DRIVE GENERATOR	A330,B737
752685 SERIES	STATOR HOUSING ASSEMBLY	A330, A340
753088	HOUSING ASSY	
753129A	EXCITER ROTOR	B757
753129AY1	EXCITER ROTOR	
753129B	EXCITER ROTOR	B757
753129-SERIES	ROTOR ASSEMBLY EXCITER	
753367	ROTOR BALANCE ASSEMBLY	A330, A340
753367A	ROTOR BALANCE ASSEMBLY	A340
753383	STATOR ASSEMBLY-GENERATOR	A330, A340
753386	STATOR ASSEMBLY, PMG	A330, A340
753490A	STATOR AND PMG HOUSING ASSEMBLY	A340
753490B	STATOR AND PMG HOUSING ASSEMBLY	A340
753490C	STATOR AND PMG HOUSING ASSEMBLY	A340
754257	RESISTOR	
754661-10	SWITCH THERMOSTATIC	CN-235
755017	INTEGRATED DRIVE GENERATOR	A330
755017A	INTEGRATED DRIVE GENERATOR	A330
755017B	INTEGRATED DRIVE GENERATOR	A330
755057	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057A	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057B	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057C	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057D	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755057E	ELECTRICAL HARNESS ASSEMBLY	A330, A340
755359	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
755359A	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
755359B	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
755359C	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767



P/N	DESCRIPTION	AIRCRAFT PARTS
755359D	INTEGRATED DRIVE GENERATOR	B747-300, B747-400, B767
755469	IDG	CRJ100/200, Bombardier Challenger
755469B	IDG	CRJ100/200, Bombardier Challenger
755469C	IDG	CRJ100/200, Bombardier Challenger
755469D	IDG	CRJ100/200, Bombardier Challenger
755469E	IDG	CRJ100/200, Bombardier Challenger
755961	ROTOR BALANCE ASSEMBLY	
755961 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
755961D	ROTOR BALANCE ASSEMBLY	
755961E	ROTOR BALANCE ASSEMBLY	A330, A340
755961F	ROTOR BALANCE ASSEMBLY	
755961G	ROTOR BALANCE ASSEMBLY	
755961H	ROTOR BALANCE ASSEMBLY	A330, A340
755961J	ROTOR BALANCE ASSEMBLY	
755961K	ROTOR BALANCE ASSEMBLY	
755961L	ROTOR BALANCE ASSEMBLY	A330, A340
756066B	EXCITER ROTOR	A330, A340
756420	PMG STATOR	
756583	IDG	B777
756589	APU GENERATOR	B777
756589A	APU GENERATOR	B777 ,A320, A340
756642	WOUND ASSEMBLY	B757
756690	ROTOR ASSEMBLY EXCITER	B757
756692	ROTOR BALANCE ASSEMBLY	B757, B767, B747, A300
756829 SERIES	STATOR HOUSING	A330, A340
756910 SERIES	STATOR HOUSING ASSEMBLY	A330, A340
756911	EXCITER AND PMG HOUSING ASSEMBLY	A330
756911A	EXCITER AND PMG HOUSING ASSEMBLY	A330
756911B	EXCITER AND PMG HOUSING ASSEMBLY	A330
756911C	EXCITER AND PMG HOUSING ASSEMBLY	A330
756911D	EXCITER AND PMG HOUSING ASSEMBLY	A330
757030	ROTOR BALANCE ASSEMBLY	
757030 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
757030F	ROTOR BALANCE ASSEMBLY	
757030G	ROTOR BALANCE ASSEMBLY	
757030H	ROTOR BALANCE ASSEMBLY	
757050	EXCITER STATOR	
757066A	VSCF GEN	B777
757066B	VSCF GEN	B777
757066C	VSCF GEN	B777
757066D	VSCF GEN	B777
757066E	VSCF GEN	B777
757066F	VSCF GEN	B777
757066G	VSCF GEN	B777
757066H	VSCF GEN	B777
757068 SERIES	STATOR HOUSING ASSEMBLY	A330, A340
757068G	STATOR HOUSING ASSEMBLY	A330, A340
757100D	BALANCED ROTOR ASSEMBLY	
757100G	BALANCED ROTOR ASSEMBLY	
757100H	BALANCED ROTOR ASSEMBLY	
757100L	BALANCED ROTOR ASSEMBLY	
757483	WOBBLER - VARIABLE	
757484	WOBBLER - VARIABLE	
757485	WOBBLER - FIXED	
757652B	EXCITER ROTOR	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
757811	ELECTRICAL HARNESS	B757
758861B	EXCITER ROTOR ASSEMBLY	
758922	INTEGRATED DRIVE GENERATOR	A330, A340
758922A	INTEGRATED DRIVE GENERATOR	A330, A340
758926	AC GENERATOR	A330, A340
759467 SERIES	STATOR HOUSING	A330, A340
759768	INTEGRATED DRIVE GENERATOR	A300/A310
7609-37M52	TRANSMITTER	
7613-551-91-13	TERMOMETER	A330, A340
7613-551-91-14	T4 INDICATOR	A330, A340
761574	INTEGRATED DRIVE GENERATOR	B737
761574A	INTEGRATED DRIVE GENERATOR	B737
761574B	INTEGRATED DRIVE GENERATOR	B737,B747
762067A	STATOR HOUSING ASSEMBLY	B737
762067B	STATOR HOUSING ASSEMBLY	B737
762067C	STATOR HOUSING ASSEMBLY	B737
762067D	STATOR HOUSING ASSEMBLY	B737
762067E	STATOR HOUSING ASSEMBLY	B737
762067F	STATOR HOUSING ASSEMBLY	B737
762067G	STATOR HOUSING ASSEMBLY	B737
762109	STATOR ASSEMBLY - MAIN GENERATOR	A330, A340
762109A	STATOR ASSEMBLY - MAIN GENERATOR	A330, A340
762359	ROTOR BALANCE ASSEMBLY	
762359 SERIES	ROTOR	
762359A	ROTOR BALANCE ASSEMBLY	B737
762359AY3	ROTOR	
762359B	ROTOR BALANCE ASSEMBLY	B737
762359C	ROTOR BALANCE ASSEMBLY	B737
762359D	ROTOR BALANCE ASSEMBLY	B737
762359E	ROTOR BALANCE ASSEMBLY	B737
762359F	ROTOR BALANCE ASSEMBLY	B737
762359Y3	ROTOR	
762367	GENERATOR MAIN FIELD WOUND ASSEMBLY	A330, A340
762367A	GENERATOR MAIN FIELD WOUND ASSEMBLY	A330, A340
762367B	GENERATOR MAIN FIELD WOUND ASSEMBLY	A330, A340
762517A	STATOR	A330, A340
762620	VSCF	B777
762620A	VSCF	B777
762620B	VSCF	B777
762620C	VSCF	B777
762620D	VSCF	B777
762620E	VSCF	B777
762620F	VSCF	B777
762888B	INTEGRATED DRIVE GENERATOR	B717
763036A	BLOCK	B737-600/-700/-800/-900
763226-01	DIODE PACK	
763226-12	SEMICONDUCTOR	A330, A340
763226-13	DIODE PACK	
763226-14	DIODE PACK	
763457	INTEGRATED DRIVE GENERATOR	MD-11
763775	ELECTRICAL HARNESS	B767,B757
763775A	ELECTRICAL HARNESS	B767,B757
764294	STATOR ASSEMBLY-PMG	B737
764294A	PMG STATOR	
764635	CYLINDER BLOCK	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
764685-2	SWITCH AIRSPEED	
764821-2	NACELLE PRECOLLER	CN-235, C-295
764821-3	NACELLE PRECOLLER	A330, A340
764855	CYLINDER BLOCK	
764861-2	PRECOOLER	
764930 SERIES	STATOR HOUSING ASSEMBLY	A330, A340
764939	IDG	B777
764939A	IDG	B777
764939B	IDG	B777
766078-8	INSERT	
766088	INTEGRATED DRIVE GENERATOR	CRJ700
766088A	INTEGRATED DRIVE GENERATOR	CRJ700
766088B	INTEGRATED DRIVE GENERATOR	CRJ700
766088C	INTEGRATED DRIVE GENERATOR	CRJ700
766091	Cylinder Block and Piston	A330, A340
766219	INTEGRATED DRIVE GENERATOR	A320
766277A	IDG	CRJ
766277B	IDG	CRJ, CRJ700
766282B	APU GENERATOR	CRJ700
766288	GENERATOR ASSEMBLY	CRJ700, ERJ 170/190
766461	STATOR HOUSING	
766461 SERIES	STATOR HOUSING	A330, A340
766461A	STATOR HOUSING	
766461B	STATOR HOUSING	
766461C	STATOR HOUSING	
767091A	7.5 HP 6-POLE AC MOTOR	CRJ700, ERJ
767110 SERIES	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110A	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110B	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110C	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110D	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110E	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110F	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110G	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110H	ROTOR BALANCE ASSEMBLY	B777, B767-400
767110J	ROTOR BALANCE ASSEMBLY	
767114B	WOUND GENERATOR MAIN FIELD	
767114C	WOUND GENERATOR, MAIN FIELD	
767114D	WOUND GENERATOR, MAIN FIELD	
767146A	INTEGRATED DRIVE GENERATOR	B777, MD11
767173	STATOR HOUSING	
767173 SERIES	STATOR HOUSING	A330, A340
767173A	STATOR HOUSING	
767173B	STATOR HOUSING	
767173C	STATOR HOUSING	
767188	ROTOR BALANCE ASSEMBLY	A330, A340
767188 SERIES	ROTOR BALANCE ASSEMBLY	A330, A340
767188A	ROTOR BALANCE ASSEMBLY	A330, A340
767188B	ROTOR BALANCE ASSEMBLY	
767188C	ROTOR BALANCE ASSEMBLY	
767910	STATOR ASSEMBLY, GENERATOR	A330, A340
767912E	ROTOR BALANCE ASSEMBLY	
767912G	ROTOR BALANCE ASSEMBLY	
767916	STATOR HOUSING	B737
768342	ROTOR BALANCE ASSEMBLY	A330, A340





P/N	DESCRIPTION	AIRCRAFT PARTS
769068	IDG	B777
769068A	INTEGRATED DRIVE GENERATOR	B767/B777
769437D	ROTOR BALANCE ASSEMBLY	A330, A340
769437E	ROTOR BALANCE ASSEMBLY	A330, A340
769438	SHAFT ASSY	
769883	EXCITER STATOR	A330, A340
770401	EXCITER ROTOR	A330, A340
770402	PMG STATOR	
770404	STATOR ASSEMBLY, EXCITER	B737,B777
7704-1-000/1	HIGH SPEED OVEN	A330, A340
770604	ROTOR BALANCE ASSEMBLY	B777
770604A	ROTOR BALANCE ASSEMBLY	B777, A330
772181	INTEGRATED DRIVE GENERATOR	A318, A320, A340
772181A	INTEGRATED DRIVE GENERATOR	A318, A320, A340
772183	STATOR HOUSING ASSEMBLY	
772292	INTEGRATED DRIVE GENERATOR	A320
772294	STATOR HOUSING ASSEMBLY	A330, A340
772294A	STATOR HOUSING ASSEMBLY	A330, A340
772295	EXCITER STATOR HOUSING ASSEMBLY	
772295A	EXCITER STATOR HOUSING ASSEMBLY	
772-5370-003	INDICATOR	S330, S340
777-1492-001	RECEIVER	B747, B777
778-2996-004	AMPLIFIER	
778695-2	VALVE-PRESSURE REGULATOR	CN-235
78035-01118	INDICATOR ELECTRICA	
7804-1-000/1	HIGH SPEED OVEN	A330, A340
78169-01	AUTO BRAKE MODULE	B727, B737, B747, B757
78169-02	AUTO BRAKE MODULE	B727, B737, B747, B757
78169-03	AUTO BRAKE MODULE	B727, B737, B747, B757
78169-04	AUTO BRAKE MODULE	B727, B737, B747, B757
78-16923	STATOR ASSEMBLY	
78-17515-1	STATOR	A330, A340
782630-2	AIR CYCLE MACHINE	CN-235
782630-3	AIR CYCLE MACHINE	CN-235
782630-4	AIR CYCLE MACHINE	CN-235
782630-5	AIR CYCLE MACHINE	CN-235, C-212, C-295
782640-1	EXCHANGER	CN-235
782640-2	EXCHANGER	CN-235
783670-1	CONDENSER AND MIXER	C-212, CN-235
783670-2	CONDENSER AND MIXER	A330, A340
783670-3	CONDENSER AND MIXER	A330, A340
783670-4	CONDENSER AND MIXER	A330, A340
785804-1	HIGH PRESSURE BLEED VALVE	A330, A340
785804-2	HIGH PRESSURE BLEED VALVE	A330, A340
785804-3	HIGH PRESSURE BLEED VALVE	A330, A340
785804-X	HIGH PRESSURE BLEED VALVE	
785922	INTEGRATED DRIVE GENERATOR	A330, A340
785922A	INTEGRATED DRIVE GENERATOR	A330, A340
7901067F	3/4 INCH SPV WITH PRESSURE RELIEF	C-212
7923227/F	VALVE-3/4 TWIN MOTORIZED	CN-235
7923227F	3/4 INCH MOTORISED SPHERICAL PLUG PRESSURE RELIEF VALVE	CN-235, C-295
7923245/M	VALVE-2" MOTORIZED	
7923245M	2 INCH MOT. SPHERIC. PLUG VALVE	CN-235, C-295
7923245-M	FUEL GRAVITY TRANSFER VALVE	



P/N	DESCRIPTION	AIRCRAFT PARTS
7923327F	VALVE 3/4" TWIN MOTORIZED	A330, A340
792PG/SB	SWITCH ASSEMBLY, DIF	
7930-327-403	INSTRUMENT SWITCH UNIT	A330, A340
795242	RACE - ROLLER BEARING	
7970-161-401	SWITCHING UNIT, AUDIO	
798021-02-03	PRESELECTOR	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
80000000-12	STAB TRIM LIM SW & POS XMTR	B757,B767
8000282Y00	TAXI LIGHT	A320
8000283Y00	TAKE OFF LIGHT	A318,A319,A320,A322
8000351Y00	AUTOTRANSFORMER, EQUIPPED	A330, A340
8001580	STATOR	A330, A340
8060-140	STARTER GENERATOR	A330, A340
8060-140-1	STARTER GENERATOR	A330, A340
8060-141	STARTER GENERATOR	A330, A340
8060-141-1	STARTER GENERATOR	A330, A340
8060-3	STARTER GENERATOR	A330, A340
8060-300	STARTER GENERATOR	A330, A340
8060-300-1	STARTER GENERATOR	A330, A340
8060-3-1	STARTER GENERATOR	A330, A340
8060-320	STARTER GENERATOR	A330, A340
8060-320-1	STARTER GENERATOR	A330, A340
8060-3-300	STARTER GENERATOR	
8060-3-300-1	STARTER GENERATOR	
8060-3-320	STARTER GENERATOR	
8060-3-320-1	STARTER GENERATOR	
8060-XXX	STARTER GENERATOR	
81000-15001	LOGO LIGHT ASSEMBLY	A330, A340
81000-15002	LOGO LIGHT ASSEMBLY	A330, A340
81000-15003	LOGO LIGHT ASSEMBLY	A330, A340
81000-15004	LOGO LIGHT ASSEMBLY	A330, A340
81000-15005	LOGO LIGHT ASSEMBLY	A330, A340
81000-15006	LOGO LIGHT ASSEMBLY	A330, A340
81000-17501	LIGHT ASSY	B737, B747
81000-17502	MAP LIGHT	B737
81000-37601	LOGO LIGHT ASSY	B737,CRJ
81000-37602	LOGO LIGHT ASSY	B737,CRJ
81000-37801	EXTERIOR EMERGENCY LIGHTS	B-737
81000-37802	EXTERIOR EMERGENCY LIGHTS	B-737
81000-37901	EXTERIOR EMERGENCY LIGHTS	B-737
81000-38201	EXTERIOR EMERGENCY LIGHTS	B-737
81000-38202	EXTERIOR EMERGENCY LIGHTS	B-737
81000-38203	EXTERIOR EMERGENCY LIGHTS	B-737
81000-38204	EXTERIOR EMERGENCY LIGHTS	B-737
81000-38301	EXTERIOR EMERGENCY LIGHTS	B-737
81000-41601	EXTERIOR EMERGENCY LIGHTS	B-737
81000-41602	EXTERIOR EMERGENCY LIGHTS	B-737
81204433	5 SHAFT	
81204471	STATOR ASSEMBLY, MAIN EXCITER	A330, A340
81204654	ROTOR ASSEMBLY MAIN EXCITER	
81205155	PE HOUSING AND STATOR ASSEMBLY	A330, A340
81205162	ROTOR AND SHAFT ASSEMBLY, MACHINED	A320
81205162 RM	MAIN ROTOR	
81205162/S1	ROTOR AND SHAFT ASSEMBLY, MACHINED	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
81205162/S1RM	ROTOR AND SHAFT ASSEMBLY	
81205162RM	ROTOR AND SHAFT ASSEMBLY	
81205691	STATOR ASSEMBLY, WOUND, ME	A330, A340
81205820	HOUSING AND STATOR ASSEMBLY	
81205821	STATOR ASSEMBLY, WOUND MAIN	A320
81205961	ROTOR ASSEMBLY, FINISHED	A320
81207093	STATOR AND HOUSING ASSEMBLY, PE	A330, A340
81207174	MACHINED ROTOR & SHAFT ASSEMBLY	A330, A340
81207213	ROTOR ASSEMBLY, FINISHED ME	A330, A340
81207321	ROTOR ASSY	
81207327	EXCITER ROTOR	A320
81207367	ROTOR ASSEMBLY, FINISHED	A320
81207367/S/S2/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S3	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S3/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S3/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S3/S4/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S3/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S3/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S3/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S4	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S4/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S2/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S3	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S3/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S3/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S3/S4/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S3/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S3/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S3/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S4	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S4/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S1/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S2	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S3	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S3/S4	FINISHED ROTOR ASSEMBLY	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
81207367/S2/S3/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S3/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S3/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S3/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S3/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S3/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S4	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S4/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S2/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S3	FINISHED ROTOR ASSEMBLY	A320
81207367/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207367/S3/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S3/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S3/S4/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S3/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S3/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S3/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S4	FINISHED ROTOR ASSEMBLY	A320
81207367/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S4/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S4/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S5	FINISHED ROTOR ASSEMBLY	A320
81207367/S5/S6	FINISHED ROTOR ASSEMBLY	A320
81207367/S6	FINISHED ROTOR ASSEMBLY	A320
81207408	FINISHED ROTOR ASSEMBLY	
81207408/S8	FINISHED ROTOR ASSEMBLY	
81207408S2S3	ROTOR	
81207412	HOUSING AND STATOR ASSEMBLY	A330, A340
81207425	ROTOR ASSEMBLY, FINISHED	A320
81207425/S/S3/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S1	ROTOR ASSEMBLY, FINISHED	A330, A340
81207425/S1/S2	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S2/S3	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S2/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S2/S3/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S2/S3/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S2/S4	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S2/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S2/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S3	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S3/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S3/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S4	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S1/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S2	FINISHED ROTOR ASSEMBLY	A320
81207425/S2/S3	FINISHED ROTOR ASSEMBLY	A320
81207425/S2/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207425/S2/S3/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S2/S3/S5	FINISHED ROTOR ASSEMBLY	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
81207425/S2/S4	FINISHED ROTOR ASSEMBLY	A320
81207425/S2/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S2/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S3	FINISHED ROTOR ASSEMBLY	A320
81207425/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207425/S3/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S3/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S4	FINISHED ROTOR ASSEMBLY	A320
81207425/S4/S5	FINISHED ROTOR ASSEMBLY	A320
81207425/S5	FINISHED ROTOR ASSEMBLY	A320
81207425-S1	ROTOR ASSEMBLY FINISHED	
81207426	ROTOR AND SHAFT ASSEMBLY, MACHINED	A320
81207444	HOUSING AND STATOR ASSEMBLY	A330, A340
81207461	MACHINED ROTOR & SHAFT ASSEMBLY	A330, A340
81207474	ROTOR ASSEMBLY, FINISHED	
81207474/S8	FINISHED ROTOR ASSEMBLY	A330, A340
81207485	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207485/S1	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207485/S1/S2/S3	STATOR, MAIN, WOUND ASSEMBLY	
81207485-S1	STATOR ASSEMBLY MAIN WOUND	
81207491	MAIN FRAME, STATOR ASSEMBLY	A330, A340
81207504	NAMEPLATE	
81207540	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207540/S1	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207540-S1	STATOR ASSEMBLY MAIN WOUND	
81207552	ROTOR ASSEMBLY, FINISHED ME	A330, A340
81207562	ROTOR ASSEMBLY, FINISHED	A330, A340
81207562/S7	ROTOR ASSEMBLY, FINISHED	A330, A340
81207562/S8	ROTOR ASSEMBLY, FINISHED	A330, A340
81207563	ROTOR ASSEMBLY FINISHED	A330, A340
81207571	ROTOR ASSEMBLY, FINISHED	A330, A340
81207571/S7/S8	FINISHED ROTOR ASSEMBLY	A330, A340
81207571/S7S8	ROTOR	
81207571/S8	FINISHED ROTOR ASSEMBLY	A330, A340
81207587	MAIN WOUND STATOR ASSEMBLY	A330, A340
8120759/S1/S2	FINISHED ROTOR ASSEMBLY	A320
8120759/S1/S2/S3	FINISHED ROTOR ASSEMBLY	A320
8120759/S1/S3	FINISHED ROTOR ASSEMBLY	A320
8120759/S2	FINISHED ROTOR ASSEMBLY	A320
8120759/S2/S3	FINISHED ROTOR ASSEMBLY	A320
8120759/S3	FINISHED ROTOR ASSEMBLY	A320
8120759/SI	FINISHED ROTOR ASSEMBLY	A320
81207597	APU GEN ROTOR	A320,A319, A321
81207597/S1	FINISHED ROTOR ASSEMBLY	A320
81207597/S1/S2	FINISHED ROTOR ASSEMBLY	A320
81207597/S1/S2/S3	FINISHED ROTOR ASSEMBLY	A320
81207597/S1/S3	FINISHED ROTOR ASSEMBLY	A320
81207597/S2	FINISHED ROTOR ASSEMBLY	A320
81207597/S2/S3	FINISHED ROTOR ASSEMBLY	A320
81207597/S3	FINISHED ROTOR ASSEMBLY	A320
81207613	ROTOR AND SHAFT ASSEMBLY, MACHINED	A330, A340
81207659	EXCITER ROTOR	A330, A340
81207660	ROTOR ASSEMBLY, FINISHED	A330, A340
81207660/S1	FINISHED ROTOR ASSEMBLY	A320
81207660/S1/S2	FINISHED ROTOR ASSEMBLY	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
81207660/S1/S2/S3	FINISHED ROTOR ASSEMBLY	A320
81207660/S1/S2/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207660/S1/S2/S4	FINISHED ROTOR ASSEMBLY	A320
81207660/S1/S3	FINISHED ROTOR ASSEMBLY	A320
81207660/S1/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207660/S1/S4	FINISHED ROTOR ASSEMBLY	A320
81207660/S2	FINISHED ROTOR ASSEMBLY	A320
81207660/S2/S3	FINISHED ROTOR ASSEMBLY	A320
81207660/S2/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207660/S2/S4	FINISHED ROTOR ASSEMBLY	A320
81207660/S3	FINISHED ROTOR ASSEMBLY	A320
81207660/S3/S4	FINISHED ROTOR ASSEMBLY	A320
81207660/S4	FINISHED ROTOR ASSEMBLY	A320
81207673	AMENDMENT PLATE	
81207690	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207690/S1	STATOR ASSEMBLY, MAIN WOUND	A330, A340
81207690-S1	STATOR ASSEMBLY MAIN WOUND	
81207704	ROTOR ASSEMBLY, FINISHED	A330, A340
81207706	ROTOR ASSEMBLY, FINISHED	A330, A340
81207706/S8	ROTOR ASSEMBLY, FINISHED	A330, A340
81207707	ROTOR ASSEMBLY, FINISHED ME	A330, A340
81207736	FINISHED ROTOR ASSEMBLY	A330, A340
81207736/S1	FINISHED ROTOR ASSEMBLY	A320
81207736/S1/S2	FINISHED ROTOR ASSEMBLY	A320
81207736/S2	FINISHED ROTOR ASSEMBLY	A320
81207736/S2/S2	FINISHED ROTOR ASSEMBLY	A320
81207741	STATOR, MAIN, WOUND ASSEMBLY	
81207743	MAIN FRAME AND STATOR ASSEMBLY	
81207799	NAMEPLATE	
8127597/S1	APU GEN ROTOR	A320
8127597/S1/S2	APU GEN ROTOR	A320
8127597/S2	APU GEN ROTOR	A320
8160-530	STARTER GENERATOR	CN-235, C-295
81704611	ARMATURE ASSEMBLY	A330, A340
81704611/S1	ARMATURE ASSEMBLY	A330, A340
81704611-S1	ARMATURE	
81704875	YOKE, POLESHOE AND FIELD COILS ASSEMBLY	
81706312	ARMATURE ASSEMBLY	
8171-1	DIMMABLE ELECTRONIC FLUORESCENT LAMP BALLAST	B737,B777,B757
8171-1 MOD A	DIMMABLE ELECTRONIC FLUORESCENT LAMP BALLAST	A330, A340
8171-1A	DIMMABLE ELECTRONIC FLUORESCENT LAMP BALLAST	
8177-1	BALLAST UNIT	
8178-1	BALLAST	B737, B757, B767,B777, A320
8184-1	BALLAST UNIT	B737, B757, B767,B777,EMB
8184-1 MOD A	BALLAST UNIT	EMB170
8184-1 MODA	BALLAST UNIT	
8184-1A	ELECTRONIC BALLAST	
8184-1MODA	BALLAST	
8204-16-0000-01	STEAM OVEN ASSY	A330, A340
8204-16-0000-XX	STEAM OVEN ASSY	A330, A340
8204-66-0000-01	STEAM OVEN ASSY	A330, A340
8204-66-0000-XX	STEAM OVEN ASSY	A330, A340
820507-1	BRUSH BLOCK HOUSING ASSEMBLY	A330, A340
820906-3	AIR CYCLE MACHINE	A320
821386	CONDENSER/MIXER HEAT EXCHANGER	A330, A340



P/N	DESCRIPTION	AIRCRAFT PARTS
821386-1	HEAT EXCHANGER CONDENSER MIXER	C-295
821386-2	HEAT EXCHANGER CONDENSER MIXER	C-295
822-1114-001	RECEIVER, TRANSMITTER	
822-1383-101	EMETTEUR/RECEPTEUR	
82410605	ICE PROTECTION PANEL ASSEMBLY	A330, A340
82410605-023	ICE PROTECTION PANEL ASSEMBLY	A330, A340
82410615-003	ADVISORY SIGN/PASSENGER WARNING PANEL ASSEMBLY	
82410615-005	ADVISORY SIGN/PASSENGER WARNING PANEL ASSEMBLY	DASH8
82410615-007	ADVISORY SIGN/PASSENGER WARNING PANEL ASSEMBLY	A330, A340
82410615-951	ADVISORY SIGN/PASSENGER WARNING PANEL ASSEMBLY	
82410924-001	EXTERIOR LIGHTS,AND TAIL LOGO LIGHTS PANEL ASSEMBLY	DASH 8 SERIE 400
82410924-003	EXTERIOR LIGHTS,AND TAIL LOGO LIGHTS PANEL ASSEMBLY	DASH 8 SERIE 400
82410924-007	EXTERIOR LIGHTS,AND TAIL LOGO LIGHTS PANEL ASSEMBLY	DASH 8 SERIE 400
82410924-009	EXTERIOR LIGHTS,AND TAIL LOGO LIGHTS PANEL ASSEMBLY	DASH 8 SERIE 400,EMB900
824375-2-002	CONTROL PROP ELECTRONIC	CN-235, C-295
8260-120	STARTER GENERATOR	ATR-42, ATR-72
8260-121	STARTER GENERATOR	ATR-42, ATR-72,B737
8260-123	STARTER GENERATOR	ATR-42, ATR-72,B747
8260-150	STARTER GENERATOR	CN-235, C-295
8260-XXX	STARTER GENERATOR	
83000-0502	HEAT CONTROL UNIT	
83000-0503	HEAT CONTROL UNIT	
83000-0504	HEAT CONTROL UNIT	
83000-05601	HEAT CONTROL UNIT	B737,MD80
83000-05602	WINDOW HEAT CONTROL	B737,ATR
83000-05603	HEAT CONTROL UNIT	B737,B707
83000-05604	HEAT CONTROL UNIT	B737
83000-0564	HEAT CONTROL UNIT	
83115-05601	TRANSFORMER	
83427	COFFE/LAVATORY PUMP	Q400
8347	GEARBOX ASSEMBLY, AIR	
8348M1	GEARBOX, LANDING	C-130
835760-401	ALTERNATING CURRENT MOTOR	A330, A340
8-372-02	PROXIMITY SENSOR	A318
8-372-04	PROXIMITY SENSOR	A318
8402	STEAM OVEN	A319-A320-A330
841923	AC ROTOR ASSEMBLY	A330, A340
8423-001	ACCUMULATOR HYDRAULIC	A330, A340
8423-030	ACCUMULATOR HYDRAULIC	A330, A340
8423-030-1	ACCUMULATOR HYDRAULIC	A330, A340
8424-001	ACCUNULATOR HYDRAULIC	C-130
8425-030	ACCUMULATOR HYDRAULIC	A330, A340
8426-001	ACCUMULATOR HYDRAULIC	A330, A340
848354	VARIABLE DISPLACEMENT	A330, A340, A320
8-484-01	PROXIMITY SENSOR	A320/340
848847	HYDRAULIC PUMP	
849589	VARIABLE DISPLACEMENT HYDRAULIC PUMP	B737
85464-2	AC GENERATOR	A330, A340, A320
85465-1	ROTOR ASSEMBLY	B737, A320
85465-2	ROTOR ASSEMBLY	B737, A320
85465-3	ROTOR	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
8-614-01	SENSOR PROX. LEAD. EDGE	
861561	MOTOR HOUSING AND STATOR SUBASSEMBLY	A330, A340
8680-045-401	VACUUM AND PRESURE	
8680-045-403	VACUUM AND PRESURE R	
86815-1	AC GENERATOR	A330, A340, A320
869843	FLUID PRESSURE REGULATING VALVE	
869843 SERIES	FLUID PRESSURE REGULATING VALVE	
87006	STATOR	
87006-1	STATOR AC GEN	A330, A340, A320
87006-10	STATOR AC GEN	A330, A340
87006-11	STATOR AC GEN	A330, A340
87006-12	STATOR AC GEN	B737
87006-12 (9387M17P12)	STATOR AC GEN	
87006-2	STATOR AC GEN	A330, A340, A320
87006-3	STATOR AC GEN	A330, A340, A320
87006-4	STATOR AC GEN	A330, A340, A320
87006-5	STATOR AC GEN	A330, A340, A320
87006-9	STATOR AC GEN	A330, A340, A320
87006-SERIES	STATOR/HOUSING ASSEMBLY	
87006-X	STATOR ALTERNATOR	
8701000000	REP Y CALIBRACION EQ MEDIDA	
87014-1	STATOR	B737
87014-2	STATOR	B737
8704-1-000/1	HIGH SPEED OVEN	A330, A340
871829	ARMATURE ASSEMBLY	A330, A340
8804-1-000/1	HIGH SPEED OVEN	A330, A340
887111	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	A330, A340
887477	AC DRIVEN MOTORPUMP ASSEMBLY	B737, B727
887479	AC DRIVEN MOTORPUMP ASSEMBLY	B-737, B-747
887480	AC DRIVEN MOTORPUMP ASSEMBLY	B-727, B-737
887673	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	B757, A320
8-930	KDM 706 A DISTANCE MEASURING EQUIPMENT	A330, A340
8-930-03	BATTERY CHARGER	B747, B757, B767, B737
8-930-03 MOD A	BATTERY CHARGER	A330, A340
8-933-01	PROXIMITY SENSOR	A320
8940	PUMP, WATER	
895-20077	OXYGEN CYLINDER AND REGULATOR ASSEMBLY	
895380-1	TORQUE LIMITER ASSEMBLY	C-212-200, JET PROP 690, MU-2, METRO 23, DO-228, METRO III, JETSTREAM 31, MERLIN IIIC, C-212-300, MERLIN III B, JET PRO COMMANDER, MERLIN IVC, MU-2N/2P
895380-2	TORQUE LIMITER ASSEMBLY	C-212-200, JET PROP 690, MU-2, METRO 23, DO-228, METRO III, JETSTREAM 31, MERLIN IIIC, C-212-300, MERLIN III B, JET PRO COMMANDER, MERLIN IVC, MU-2N/2P
895380-3	TORQUE LIMITER ASSEMBLY	C-212-200, JET PROP 690, MU-2, METRO 23, DO-228, METRO III, JETSTREAM 31, MERLIN IIIC, C-212-300, MERLIN III B, JET PRO COMMANDER, MERLIN IVC, MU-2N/2P





P/N	DESCRIPTION	AIRCRAFT PARTS
895380-4	TORQUE LIMITER ASSEMBLY	C-212-200, JET PROP 690, MU-2, METRO 23, DO-228, METRO III, JETSTREAM 31, MERLIN III C, C-212-300, MERLIN III B, JET PRO COMMANDER, MERLIN IVC, MU-2N/2P
896380	TORQUE LIMITER ASSEMBLY	
896380 SERIES	TORQUE LIMITER ASSEMBLY	
897390	FUEL PUMP ASSEMBLY	
897390 SERIES	FUEL PUMP ASSEMBLY	
8DJ100WAD22	INDICATOR	
8DJ100WAD3	TITIND	
8DJ179	T INDICATOR	
8DJ185WAA1	EGT INDICATOR	DC-10
8DJ81CDW4	INDICATOR	B727, B737
8DJ81CFA4	INDICATOR	C-212, CN-235
8ES002769-03	POWER SUPPLY UNIT, BEACON LIGHTS (	A300, A318, A319, A320, A321, CRJ100
8ES005045-	POWER SUPPLY UNIT	A320-100, A330, A340, A320
8ES005045 SERIES	ENERGY BOX	A330, A340
8ES005045-00	POWER SUPPLY UNIT	A319, A320, A321, A330, A340
8ES005045-SERIES	POWER SUPPLY UNIT	A320-100, A330, A340, A320
8ES005236-13	POWER UNIT, SINGLE (REPL. F. -03)	A320
8ES005238-	POWER UNIT	A319, A320, A321, A320-100
8ES005238-13	POWER UNIT, TRIPLE (REPL. F. -03)	A319, A320, A321, A320-100
8ES005238-SERIES	POWER UNIT	A319, A320, A321, A320-100
8ES005304-	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES005304 SERIES	ENERGY BOX	A319, A321, A330, A340, A320
8ES005304-00	POWER SUPPLY UNIT, SINGLE FLASH	A319, A321, A330, A340, A320
8ES005304-SERIES	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES005309	ENERGY BOX	A330, A340
8ES005309 SERIES	ENERGY BOX	A330, A340
8ES005309-00	POWER SUPPLY UNIT	A319, A320, A321, A330, A340
8ES005421-09	CONTROLLER, POWER SUPPLY UNIT, STR	EMB
8ES403701-02	TRANSFORMER ASSEMBLY	A320, A321, A330, A340
8ES403703-02	TRANSFORMER ASSEMBLY	A320, A321, A330, A340
8ES405368-00	TRANSFORMER ASSEMBLY	A320, A321, A330, A340
8ES455012-	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES455012 SERIES	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES455012-00	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES455012-06	POWER SUPPLY UNIT	A318, A319, A320, A321, A330, A340, A380
8ES455012-SERIES	POWER SUPPLY UNIT	A319, A321, A330, A340, A320
8ES455438-07	POWER SUPPLY UNIT	A320, A320-100, A340, A330
8ES455440-06	POWER SUPPLY UNIT	B737
8F106-1	ARMATURE ASSEMBLY	A330, A340
8TJ146AAW3	OQSENSOR	
8TJ50GAS5	TRANSMITTER, RATE OF	B727, B737
90000581-1	WHEEL N ASSY	
9008D07-1	ALTERNATING CURRENT MOTOR	A300
90-10072-1	ENTRY DOOR SNUBBER ASSEMBLY	B737, B727, B707
90-10072-2	SNUBBER	B737, DC10
901020-1	STRUT ASSEMBLY, MLG SHOCK	P3 ORION
901917-101	SHOCK STRUT ASSEMBLY	P3 ORION
901918-105	SHOCK STRUT ASSEMBLY	P3 ORION
901918-5	SHOCK STRUT ASSEMBLY	P3 ORION
90421-2	CONNECTORS	



P/N	DESCRIPTION	AIRCRAFT PARTS
909269-3	CARTRIDGE	P3 ORION, P3 CONVERSION
912072-1	CARTRIDGE	A330, A340
915F251-1	EXCITER STATOR	
915F716-1	SEMICONDUCTOR DEVICE SET	A330, A340
915F716-2	SEMICONDUCTOR DEVICE SET	A330, A340
9201000-198	VALVE REGULATING	
9201000-206	GA CONTENTS TRANSMITTER	
9210M42P03	STATOR ASSY	A330, A340
933402	HYD MOTOR PUMP	CN-235, CN-295
933402 / MPEV3-011-8UK2B	PUMP-HYDR MOTOR DRIVEN	CN-235, CN-295
933402 / MPEV3-011-8UK2C	PUMP-DC ELEC MOTOR	CN-235, CN-295
93-343	PLATE PRESSURE BRAK	
937958-103	STRUT ASSEMBLY, MLG SHOCK	P3 ORION
9387M16P01	ROTOR ASSEMBLY	B737, A320
9387M16P02	ROTOR ASSEMBLY	B737, A320
9387M16P02 (85465-2)	ROTOR	
9387M16P03	FADEC GEN ROTOR	CFM56/CF6
9387M17P	STATOR	
9387M17P SERIES	STATOR/HOUSING ASSEMBLY	
9387M17P0 SERIES	STATOR	
9387M17P06	STATOR AND HOUSING ASSEMBLY	A330, A340, A320
9387M17P06 (87006-3)	FADEC STATOR	
9387M17P07	FADEC GEN STATOR	CFM56/CF6
9387M17P08	STATOR AND HOUSING ASSEMBLY	A330, A340, A320
9387M17P08 (87006-5)	FADEC STATOR	
9387M17P09	STATOR AND HOUSING ASSEMBLY	A330, A340
9387M17P09 (87006-9)	FADEC STATOR	
940D412-2	EXCITER ROTOR	A330, A340
943D367	SEMICONDUCTOR DEVICE SET	A330, A340
943D367-SERIES	SEMICONDUCTOR DEVICE SET	A330, A340
943D724-4	STATOR EXCITER	A330, A340
9-464-06	FUEL FLOW / FUEL USED INDICATOR	CN235
9-464-40 MOD B	INDICATOR, LIQUID QTY	
9-464-40 MOD D	INDICATOR, RATE OF FL	
946F177	SEMICONDUCTOR DEVICE SET	A330, A340
946F177-1	SEMICONDUCTOR	B737
946F177-SERIES	SEMICONDUCTOR DEVICE SET	A330, A340
946F931-2	GENERATOR STATOR	
946J498-2	AC GENERATOR	
946J598-1	AC GENERATOR	
947F226-3	EXCITER ARMATURE CAPACITOR AND DIODE ASSEMBLY	A330, A340
948F463-4	10 KVA GENERATOR	
948F723-1	STATOR GENERATOR	A330, A340
949F283	SEMICONDUCTOR DEVICE SET	A330, A340
9506111-501	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-502	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-503	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-504	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-505	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)



P/N	DESCRIPTION	AIRCRAFT PARTS
9506111-506	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-507	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-508	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-509	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-510	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-511	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-512	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-513	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-514	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-515	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-516	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-517	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-518	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-519	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-520	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-521	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-522	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-523	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-524	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-525	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-526	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-527	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-528	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-529	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-530	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-531	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
9506111-532	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
950F236-5	ARMATURE ASSEMBLY	A330, A340
9535416	PLATE BACKING BRAKE	
9542719	WHEEL DRIVEN UNIT	A330, A340
9542719-1	WHEEL DRIVEN UNIT	A330, A340
9542719-2	WHEEL DRIVEN UNIT	A330, A340
9542719-3	WHEEL DRIVEN UNIT	A330, A340
9542732-2	CONTROL VALVE ASSEMBLY	C-212
9543476	NOSE WHEEL ASSEMBLY	A330, A340
9550339	TRANSDUCER ASSEMBLY	B737
9550493-1	WHEEL LANDING GEAR	
9550604L	SKID CONTROL VALVE UNIT	B737
9560685	BRAKE MULTIPLE DISK	C-130
9560685-1	BRAKE MULTIPLE DISK	C-130
95-61260-0005	CONTROL -DSPLAY UNIT	C-295
95-61295-0001	FLIGHT CONTROL GROUP	C-295
95-94064-0001	DOUBLE SEAT	C-295
95-94064-0001B01	SEAT DOUBLE ASSY	C-295
95-94064-0001B05	DOUBLE SEAT	A330, A340
95-94064-0001E03	SEAT DOUBLE ASSY	C-295
95-94064-0002	SEAT DOUBLE ASSY	C-295
95-94064-0003	SEAT DOUBLE ASSY	
95-94064-0003B01	SEAT DOUBLE ASSY	C-295
95-94064-0003B05	SEAT DOUBLE ASSY	C-295
95-94064-0003E03	SEAT DOUBLE ASSY	C-295
9600-15-0000	CEILING LIGHT ASSEMBLY	B737
9600-26-0000	CEILING LIGHT ASSEMBLY	B737
9600-32-0000	CEILING LIGHT ASSEMBLY	B737
9600-40-0000	CEILING LIGHT ASSEMBLY	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
9600-44-0000	CEILING LIGHT ASSEMBLY	B737
9600-51-0000	CEILING LIGHT ASSEMBLY	B737
9600-55-0000	CEILING LIGHT ASSEMBLY	B737
9600-58-0000	CEILING LIGHT ASSEMBLY	B737
9601-15-0000	CEILING LIGHT ASSEMBLY	B737
9601-26-0000	CEILING LIGHT ASSEMBLY	B737
9601-32-0000	CEILING LIGHT ASSEMBLY	B737
9601-40-0000	CEILING LIGHT ASSEMBLY	B737
9601-44-0000	CEILING LIGHT ASSEMBLY	B737
9601-51-0000	CEILING LIGHT ASSEMBLY	
9601-55-0000	CEILING LIGHT ASSEMBLY	B737
9601-58-0000	CEILING LIGHT ASSEMBLY	B737
9602-15-0000	CEILING LIGHT ASSEMBLY	B-737
9602-26-0000	CEILING LIGHT ASSEMBLY	B-737
9602-28-0000	CEILING LIGHT ASSEMBLY	B-737
9602-32-0000	CEILING LIGHT ASSEMBLY	B-737
9602-38-0000	CEILING LIGHT ASSEMBLY	B-737
9602-40-0000	CEILING LIGHT ASSEMBLY	B-737
9602-44-0000	CEILING LIGHT ASSEMBLY	B-737
9602-51-0000	CEILING LIGHT ASSEMBLY	B-737
9602-55-0000	CEILING LIGHT ASSEMBLY	B-737
9602-58-0000	CEILING LIGHT ASSEMBLY	B-737
96109-31-105	CORE, EMS, PPU, FWD, SIDE	A400M
96109-31-107	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	A400M
96109-31-109	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	A400M
96109-32-105	CORE, EMS, PPU, FWD, TOP	A400M
96109-32-107	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	A400M
96109-32-109	BOLT ASSY, PPU, FWD, SIDE & TOP HOUSINGS	A400M
96109-33-101	AFT MOUNT - PYLON FASTENERS	A400M
96109-33-103	AFT MOUNT - PYLON FASTENERS	A400M
96109-33-105	AFT MOUNT - PYLON FASTENERS	A400M
965C380-2	STATOR MOTOR	B737
971533	DC ELECTRIC MOTORPUMP ASSEMBLY	A330, A340
971808	HIDRAULIC PUMP	EMB-135/-145, DHC-8
971844	VARIABLE DISPLACEMENT	A330, A340, A320
972424	HYDRAULIC PUMP ASSEMBLIES	B-777
972630	VARIABLE DISPLACEMENT	A330, A340, A320
972952	HYDRAULIC PUMP ASSEMBLIES	B-777
973545	MOTOR HOUSING STATOR SUBASSEMBLY	
974540	HYDRAULIC PUMP	A330
974800	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	A330, A340, A340-500/600
974947	VARIABLE DISPLACEMENT	A330, A340, A320
974976	VARIABLE DISPLACEMENT	A330, A340, A320
977J024-3	AC GENERATOR	A330, A340
977J024-4	AC GENERATOR	A330, A340
977J024-4S	AC GENERATOR	A330, A340
977J024-4T	AC GENERATOR	A330, A340
977J150-1	AC GENERATOR	A300, DC-10, MD-11
977J150-2	AC GENERATOR	A300, DC-10, MD-11
977J150-3	AC GENERATOR	A300, DC-10, MD-11
977J150-4	AC GENERATOR	MD-11, A300, MD-10, DC-10, B767
977J150-X	AC GENERATOR	
977J330-2	AC GENERATOR	A330, A340
977J330-3	AC GENERATOR	
9808-20	INDICATOR VOR	



P/N	DESCRIPTION	AIRCRAFT PARTS
9900-26-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-26-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
99003-3	GYRO DIRECTION	
9900-40-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-40-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-44-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-44-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-51-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-51-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-55-0000	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9900-55-0001	BULLNOSE CEILING LIGHT ASSEMBLY	A330, A340
9901-26-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9901-26-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9901-40-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9901-40-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9901-44-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9901-44-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9901-51-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9901-51-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9901-55-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9901-55-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-26-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-26-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-40-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-40-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-44-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-44-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-51-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-51-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-55-0000	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9902-55-0001	BULLNOSE CEILING LIGHT ASSEMBLY	B-737
9910059-3	AIR MIXER MOTOR	
9912147-26	FUEL QTY INDICATOR	
9912147-27	FAN INDICATOR	
9A1164	BRAKE ASSEMBLY	A330, A340
9B72-1	STATOR	
9F83-7	STATOR	
A15580-P1	CLOCK	S330, S340
A15586	FE CLOCK	DC-10
A24A9430-1	CONTROL BOX	
A25313002	VALVE-BRAKE SEL	A319
A25313002-1	SELECTOR VALVE	A319
A25313003	SELECTOR VALVE	A330
A25313003-1	SELECTOR VALVE	A330
A25315	PARKING BRAKE VALVE	A319
A25315020	HYD. PARKING BRAKE VALVE	A330
A25315020-1	PARKING BRAKE VALVE	A330
A25315020-2	PARKING BRAKE VALVE	A319
A25315-1	VALVE	A319
A25317-1	SAFETY VALVE	A330
A25434021	EMERGENCY BRAKE DUAL DISTRIBUT	A330
A25434021-001	EMERGENCY BRAKE DUAL DISTRIBUT	A330
A25434021-1	EMERGENCY BRAKE DUAL DISTRIBUT	A330
A25434021-2	EMERGENCY BRAKE VALVE	A330
A25460-2	AUTOMATIC SELECTOR	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
A25461-1	AUTOMATIC SELECTOR	A319
A25461-102	AUTOMATIC SELECTOR	A319
A25461-103	SELECTOR VALVE	A319
A25461-104	AUTOMATIC SELECTOR	A319
A25461-1-1	AUTOMATIC SELECTOR	A320
A33982	AXLE SLEEVE	A319
A3410-2	FAN COWL HOLD OPEN ROD	A319, A320,A321
A34440	AXEL SLEEVE	A319
A35104	AXLE SLEEVE	A321
A35104-1	SLEEVE-AXLEMLG	
A35399	AXLE SLEEVE	A319
A35534	AXLE SLEEVE	A318
A35778	SLEEVE-AXLEMLG	
A-440	HORIZONTE ARTI	
A489-5	ACTUATOR ELECTRO-MECH	C-130
A68982	SERVOVALVE, NOSE WHEEL STRG	A320
A68982-002	SERVOVALVE, NOSE WHEEL STEER	A319
A68982-004	SERVOVALVE, NOSE WHEEL STEER	A319
A853550-1	COMPRESSOR	A330, A340
A853550-31	COMPRESSOR	A330, A340
A853790-11	FAN MOTOR	A330, A340
AC62982	BRAKE CONTROL VALVE	S330, S340
AC900085	OXYGEN REGULATOR ASSEMBLY	A330, A340
ACG7301-5505	ACTUATOR ASSY-SIDE CARGO DOOR	DC-10
ACM18048	SEPARATOR PIPELINE	
ACM28766	VALVE REDUCING	
ACP2788AA02	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AB04	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AB05	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AD01	AUDIO CONTROL PANEL	A330, A340, A320
ACP2788AE01	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt A	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt B	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt C	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt D	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt E	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt F	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt G	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt H	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt J	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380



P/N	DESCRIPTION	AIRCRAFT PARTS
ACP2788AF01 Amdt K	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt L	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
ACP2788AF01 Amdt M	AUDIO CONTROL PANEL	A318, A319, A320, A321, A330, A340, A380
AD-2758	AIRCRAFT BATTERY	A330, A340
AE1502U01	UNIVERSAL BRAKE COOLING FAN	A318
AE1502U02	MOTOR ASSY BRAKE FAN	A318
AE1602A11-0120	FAN AXLE KIT, MOTOR	A330
AE1602A12-0110	CARRIER FAN AXLE	A330
AG10113AA02	LIGHT	
AG34-109	DRIVE SHAFT	
AG34-20	GENERATOR ROTOR ASSY	
AH52443	WHEEL	
AH9033	WHEEL, MLG	
AHA1292	BRAKE UNIT	CN-235
AHA1802	BRAKE UNIT	CN-235
AHA2424	BRAKE UNIT	C-295
AHM8337	SHUTTLE VALVE	C-295
AP9VM-2-06	MOTOR DRIVEN HYDRAULIC PUMP	B787
AR02404	ROTARY ACTUATOR	A330
AR-204A-SERIES	FUEL RATE INDICATOR	A330, A340
AR-207	FUEL RATE INDICATOR	A330, A340
AR-207-SERIES	FUEL RATE INDICATOR	A330, A340
AR4701-1	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AR4701-13	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	B767
AR4701-15	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AR4701-17	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AR4701-3	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AR4701-5	DOUBLE ROLLER ELECTRIC STRIKE ASSEMBLY	A330, A340
AR9262-3W11DXXX	FAUCET ASSEMBLY	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
AR9262-3W12DXXX	FAUCET ASSEMBLY	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
AR9262-3W13DXXX	FAUCET ASSEMBLY	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
AR9262-3W1DXXX	FAUCET ASSEMBLY	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
AR9262-3W31DXXX	FAUCET ASSEMBLY	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
AR9262-3WXDXXX	FAUCET ASSEMBLY	
AR9262-5W12DXXX	FAUCET ASSEMBLY	A300, A300-600, A310, A318, A319, A320, A321, A330, A340, A350, A380, AST
AT-1108/ARC	ANTENA VHF/UHF	
AV16B1350	VALVE	B737,DC10
AV16B1464C	VALVE	C-130
AV24B13225C	VALVE HIDRAULIC	
B1390	CYLINDER COMPRESSED	



P/N	DESCRIPTION	AIRCRAFT PARTS
B16138	TRANSDUCER	
B-26-138-00	COMMUTATOR	
B2700-14	BRAKE METERING VALVE ASSEMBLY	B737
B40812001-107	TERMINAL BOX	
B4154210003	ALTIMETER PRESSURE	
B43617-10-001	ALTITUDE INDICATOR	
B709-4	SENSOR SOBREVE	
B709-7	INDICADOR, TORQUEMET	
BA03600	AC GENERATOR	A330, A340
BA03600 SERIES	APU AC GENERATOR	
BA03603	A320 APU GENERATOR	A319, A320, A321
BA03603A	GENERATOR-APU	A319, A320, A321
BA03604	GENERATOR-APU	A320, A320-100,A330
BA04100 SERIES	APU AC GENERATOR	
BA04103	APU GENERATOR	A330, A340
BA04104	APU GENERATOR	A330, A340
BA04105	APU GENERATOR	A330, A340
BA16501-01	GENERATOR-APU	A320, A330, A340
BACB30LE6-36	BOLT	
BACB30LJ20CD43	MLG BOLT ASSY ACTUATOR BEAM IN	B737-100
BH138XAH	CONTACTOR C.ALTERNA 50A	CN-235
BH185R-307	INDICATOR TEMPERATU	
BPF-5/8	COVER	
BPS7-3	BATTERY POWER SUPPLY	B747, B757, B767, B737,B777
C16298AA	TEMPERATURE IND	A330, A340
C20105000	TACH GENERATOR	A318
C20105000-1	TACHOMETER	A318
C20105000-2	TACHOMETER	A318
C20105100	TACHOMETER	A330
C20259000	AXLE SLEEVE	A320
C20288000-2	LH BRAKE ACCUMULATOR	A330
C20327000-001	LVDT SERVO VALVE	A330/340
C20374000-1	VALVE-SERVO BRAKE	A319-320
C20374000-2	VALVE-SERVO BRAKE	A319
C23005	PITCH DAMPER	A318
C23005-2	PITCH DAMPER	A318
C23097-106	SHOCK ABSORBER	
C23110610	TELESCOPIC STRUT	A318
C23110610-2	TELESCOPIC STRUT	A318
C23110810	TELESCOPIC STRUT	A318
C24245005-2A	UPLOCK BOX-MAIN L.G. RH	
C24592020	MASTER CYLINDER	A330
C24592020-1	MASTER CYLINDER	A330
C24703001	PARKING BRAKE SELECTOR VALVE	A320
C24703001-3	PARKING BRAKE SELECTOR VALVE	A320
C24703001-4	PARKING BRAKE SELECTOR VALVE	A319
C24703003	PARKING BRAKE SELECTOR VALVE	A319
C24730000-2	UPLOCK ASSEMBLY	A319
C24730000-3	UPLOCK ASSY-DOOR	A320
C24730000-4	UPLOCK ASSEMBLY	A320
C24730000-5	UPLOCK ASSEMBLY	A320
C24730001-4	UPLOCK ASSEMBLY	A318
C24730001-6	NLG UPLOCK ASSY	A318
C24730100	NLG DOOR UPLOCK ASSY	A318
C24730100-3	UPLOCK ASSEMBLY	A318





P/N	DESCRIPTION	AIRCRAFT PARTS
C24736000	HYDRAULIC CONTROL UNIT	A320
C24736000-0-1	SERVO CONTROL	A320
C24736000-0-2	HYDRAULIC CONTROL UNIT	A320
C24736000-1	HYDRAULIC CONTROL UNIT	A320
C24736000-2	HYDRAULIC CONTROL UNIT	A320
C24736001	HYDRAULIC CONTROL UNIT	A320
C24736001-0-1	HYDRAULIC CONTROL UNIT	A320
C24736001-0-2	HYDRAULIC CONTROL UNIT	A319
C24736001-1	SERVO CONTROL	A319
C24736001-2	HYDRAULIC CONTROL UNIT	A319
C24736001-3	HYDRAULIC CONTROL UNIT	A319
C24736100-1	HYDRAULIC CONTROL UNIT	A318
C24747000	VALVE, SELECTOR	A320
C24747000-1	VALVE, SELECTOR	A320
C24757020	SAFETY VALVE	A340
C24777020-1	NORMAL BRAKE MANIFOLD ASSEMBLY	A330
C24777020-2	NORMAL BRAKE MANIFOLD ASSEMBLY	A330
C24777020-3	NORMAL BRAKE MANIFOLD ASSY	A320
C24777020-3A	NORMAL BRAKE MANIFOLD ASSY	A330
C24779020	BRAKE MANIFOLD ASSY	A340
C24837101	HOUSING/BRAKE MANIFOLD	A319
C24837101-1	MANIFOLD-NORMAL BRAKE ASSY	A319
C24837101-3	BRAKE MANIFOLD ASSY	A319
C24837101-4	MANIFOLD ASSY	A319
C24856000-11	ELECTRO-HYDRAULIC BLOCK	A330
C24856001-2	ELECTRO-HYDRAULIC BLOCK	A330
C24856001-3	ELECTRO-HYDRAULIC BLOCK	A330
C24856001-4	ELECTRO-HYDRAULIC BLOCK	A330
C24856001-5	ELECTRO-HYDRAULIC BLOCK	A330
C24856001-6	ELECTRO-HYDRAULIC BLOCK	A330
C24856001-7	ELECTRO-HYDRAULIC BLOCK	A330
C24856001-9	HYDRAULIC CONTROL UNIT	A330
C24998000	SWIVEL SELECTOR VALVE	A320
C2536310002	INDICATOR TEMPERATU	
C2-96000-8	ACTUATOR, WINDSHIELD WIPER	A330, A340
C2-96100-8	MOTOR , WIPER, WINDSHI	S330, S340
C4154210003	INDICATOR TEMPERATU	
C450-000217	ARMATURE ASSY	
C5120-1	STARTER MOTOR	A330, A340, FOKKER 50/100
C5120-2	STARTER MOTOR	A330, A340, FOKKER 50/100
C5120-3	STARTER MOTOR	A330, A340, FOKKER 50/100
C51LM0020	RESERVOIR FILLING VALVE	A318, A319, A320, A321
C661063-0107	AIRSPEED INDICATOR	
CA.24200.1	PNEUDRALIC ACCUMULATOR 0.75 LITER	A330, A340
CA.24200.3	PNEUMATIC ACCUMULATOR 0.75 LITER	A330, A340
CA.24600.1	1/4 INCH HYDRAULIC RELIEF VALVE	A330, A340
CA.24600.3	1/4 INCH HYDRAULIC RELIEF VALVE	A330, A340
CA.24800.3	PRESELECTOR CE DIRECCION	A330, A340
CA.38800.1	MANUAL HYDRAULIC STOPCOCK	A330, A340
CA24200.3	PNEUDRALIC ACCUMULATOR 0.75 LITER	A330, A340
CA242001	PNEUDRALIC ACCUMULATOR 075 LITER	
CA242003	PNEUDRALIC ACCUMULATOR 075 LITER	
CA246	VALVE-1/4" RELEASING	
CA246001	1/4 INCH HYDRAULIC RELIEF VALVE	
CA24600-1	VALVE-1/4" RELEASING	C-212



P/N	DESCRIPTION	AIRCRAFT PARTS
CA246003	1/4 INCH HYDRAULIC RELIEF VALVE	
CA246-1E	VALVE-1/4" RELEASING	
CA248003	PRESELECTOR CE DIRECCION	
CA24800-3	PRESELECTOR-STEERI	C-212
CA388001	MANUAL HYDRAULIC STOPCOCK	
CA38800-1	VALVE	C-212
CA-B0614-0003	ORDENADOR,DIGITAL	CN-235
CP1200-2	CONTROL PENDANT	CN-235, C-295
CP3938AA02	COMMUTATEUR PRINCIPAL	
CRA49044	LEG ASSY-NLG	A340
CRA49045	LEG ASSY-NLG	A340
CRA49219	LEG ASSY-NLG	A340
CRA49220	LEG ASSY-NLG	A340
CRA49221	LEG ASSY-NLG	A340
D102740	MOTOR TYPE 160-45-511	A330, A340
D105300-4	ARMATURE	A330, A340
D107318	CENTRIFUGAL FUEL BOOSTER PUMP	A330, A340
D107318-14	ARMATURE	A330, A340
D126111-501	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
D126111-503	PASSENGER SERVICE UNIT	DASH 8 SERIES (100-200-300-400)
D1834	AIR COOLED OIL COOLER	A330, A340
D1834 SERIES	AIR COOLED OIL COOLER	A330, A340
D1834-100	OIL COOLER	A330, A340
D1834-100A	OIL COOLER	C-212
D1834-SERIES	OIL COOLER	A330, A340
D23064000	LEG STRUCTURE	A318
D23064000-10	LEG STRUCTURE	A318
D23064000-11	LEG STRUCTURE	A318
D23064000-12	LEG STRUCTURE	A318
D23064000-13	LEG STRUCTURE	A318
D23064000-14	LEG STRUCTURE	A318
D23064000-15	LEG STRUCTURE	A318
D23064000-16	LEG STRUCTURE	A318
D23064000-17	LEG STRUCTURE	A318
D23064000-18	LEG STRUCTURE	A318
D23064000-19	LEG STRUCTURE	A318
D23064000-2	LEG STRUCTURE	A318
D23064000-20	LEG STRUCTURE	A318
D23064000-21	LEG STRUCTURE	A318
D23064000-3	LEG STRUCTURE	A318
D23064000-4	LEG STRUCTURE	A318
D23064000-5	LEG STRUCTURE	A318
D23064000-6	LEG STRUCTURE	A318
D23064000-7	LEG STRUCTURE	A318
D23064000-8	LEG STRUCTURE	A318
D23064000-9	LEG STRUCTURE	A318
D23064001	LEG STRUCTURE	A318
D23064001-1	LEG STRUCTURE	A318
D23064001-10	LEG STRUCTURE	A318
D23064001-11	LEG STRUCTURE	A318
D23064001-12	LEG STRUCTURE	A318
D23064001-13	LEG STRUCTURE	A318
D23064001-14	LEG STRUCTURE	A318
D23064001-15	LEG STRUCTURE	A318
D23064001-16	LEG STRUCTURE	A318



P/N	DESCRIPTION	AIRCRAFT PARTS
D23064001-2	LEG STRUCTURE	A318
D23064001-3	LEG STRUCTURE	A318
D23064001-5	LEG STRUCTURE	A318
D23064001-6	LEG STRUCTURE	A318
D23064001-7	LEG STRUCTURE	A318
D23064001-8	LEG STRUCTURE	A318
D23064001-9	LEG STRUCTURE	A318
D23064005	LEG STRUCTURE	A318
D23064005-1	LEG STRUCTURE	A318
D23064005-2	LEG STRUCTURE	A318
D23064005-3	LEG STRUCTURE	A318
D23064005-4	LEG STRUCTURE	A318
D23064005-5	LEG STRUCTURE	A318
D23064005-6	LEG STRUCTURE	A318
D23066000	LEG FITTINGS	A318
D23066000-1	LEG FITTINGS	A318
D23066000-2	LEG FITTINGS	A318
D23066000-3	D23066000-3	A318
D23066000-5	LEG FITTINGS	A318
D23067000	SHOCK ABSORBER	A318
D23067005	SHOCK ABSORBER	A318
D23071000	NLG ACTUATING CYLINDER ASSY	A320
D23071001	NLG ACTUATING CYLINDER ASSY	A319
D23073000-2	FORESTAY ASSY	A320
D23073000-3	FORESTAY ASSY	A318
D23073000-4	FORESTAY ASSY	A320
D23073000-5	FORESTAY ASSY	A320
D23073000-6	FORESTAY ASSY	A320
D23073000-7	FORESTAY ASSY	A320
D23073000-8	FORESTAY ASSY.	A318
D23074000	FORESTAY	A318
D23074000-1	FORESTAY	A318
D23074000-2	FORESTAY	A318
D23074000-3	FORESTAY	A318
D23074000-4	FORESTAY	A318
D23074000-5	FORESTAY	A318
D23074000-6	FORESTAY	A318
D23075000-1	LOCK LINK	A318
D23075000-2	LOCK LINK	A318
D23075000-3	LOCK LINK	A318
D23077000-1	LOCK SPRING	A318
D23079000-9	FORESTAY ASSY	A318
D23081000	SWIVEL BEARING	A318
D23081020	SWIVEL BEARING	A318
D23116000	ANTI-SHIMMY VALVE	A318
D23119000	ELECTRICAL BOX	A318
D23119010	ELECTRICAL BOX	A318
D23119500	ELECTRICAL BOX	A318
D23119500-1	ELECTRICAL BOX	A318
D23119510	BOX ELECTRICAL NLG	A318
D23119510-1	ELECTRICAL BOX	A318
D23119550	ELECTRICAL BOX	A330
D23119700	ELECTRICAL BOX	A318
D23119700-1	ELECTRICAL BOX	A318
D23119720	ELECTRICAL BOX	A318



P/N	DESCRIPTION	AIRCRAFT PARTS
D23119720-1	ELECTRICAL BOX	A318
D23119750	ELECTRICAL BOX	A318
D23119751	ELECTRICAL BOX, NLG	A318
D23119760	ELECTRICAL BOX	A318
D23119761	ELECTRICAL BOX	A318
D23119770	ELECTRICAL BOX	A318
D23119771	ELECTRICAL BOX	A318
D23120000	1M UPPER ELECTRICAL HARNESS	A318
D23120000-1	1M UPPER ELECTRICAL HARNESS	A318
D23120001	1M UPPER ELECTRICAL HARNESS	A318
D23121000	UPPER ELECTRICAL HARNESS 2M	A318
D23121000-1	UPPER ELECTRICAL HARNESS 2M	A318
D23121001	UPPER ELECTRICAL HARNESS 2M	A318
D23121001-1	UPPER ELECTRICAL HARNESS 2M	A318
D23121111	UPPER ELECTRICAL HARNESS	A318
D23121111-1	2M UPPER ELECTRICAL HARNESS	A318
D23150000	LOWER ELECTRICAL HARNESS	A318
D23150000-1	LOWER ELECTRICAL HARNESS	A318
D23150001	LOWER ELECTRICAL HARNESS	A318
D23154000	INTERMEDIATE ELECTRICAL HARNES	A318
D23154000-1	INTERMEDIATE ELECTRICAL HARNES	A318
D23154001	INTERMEDIATE ELECTRICAL HARNES	A318
D23175000	LEG (NLG)	A318
D23175000-1	LEG (NLG)	A318
D23175000-10	LEG (NLG)	A320
D23175000-11	LEG (NLG)	A318
D23175000-12	LEG (NLG)	A318
D23175000-13	LEG (NLG)	A318
D23175000-14	LEG (NLG)	A318
D23175000-15	LEG (NLG)	A318
D23175000-16	LEG (NLG)	A318
D23175000-17	LEG (NLG)	A318
D23175000-18	LEG (NLG)	A318
D23175000-19	LEG (NLG)	A318
D23175000-2	LEG (NLG)	A318
D23175000-20	LEG (NLG)	A318
D23175000-21	LEG (NLG)	A318
D23175000-22	LEG (NLG)	A318
D23175000-24	NOSE LANDING GEAR LEG	A318
D23175000-4	LEG (NLG)	A320
D23175000-5	LEG (NLG)	A320
D23175000-6	LEG (NLG)	A320
D23175000-7	LEG (NLG)	A320
D23175000-8	LEG (NLG)	A318
D23175000-9	LEG (NLG)	A318
D23175001	LEG (NLG)	A320
D23175001-1	LEG (NLG)	A320
D23175001-10	LEG (NLG)	A318
D23175001-11	LEG (NLG)	A318
D23175001-12	LEG (NLG)	A318
D23175001-16	LEG (NLG)	A318
D23175001-18	NOSE LANDING GEAR LEG	A318
D23175001-2	LEG (NLG)	A320
D23175001-3	LEG (NLG)	A320
D23175001-4	LEG (NLG)	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
D23175001-5	LEG (NLG)	A320
D23175001-7	LEG (NLG)	A320
D23175001-8	LEG (NLG)	A318
D23175001-9	LEG (NLG)	A318
D23175005	NOSE LANDING GEAR	A320
D23175005-1	NOSE LANDING GEAR	A320
D23175005-16	NLG ASSY	A320
D23175005-2	NOSE LANDING GEAR	A320
D23175005-3	NOSE LANDING GEAR	A320
D23175005-4	NOSE LANDING GEAR	A318
D23175005-5	NOSE LANDING GEAR	A318
D23175005-6	NOSE LANDING GEAR	A318
D23175005-7	GEAR, NOSE LANDING	A318
D23278000	TOWING FITTING	A320
D23278100	TOWING FITTING	A318
D23278200	TOWING FITTING	A319
D23281000	TOWING FITTING	A320
D23281100	TOWING FITTING	A320
D23285000	LEG ASSY-NLG	A340
D23285000-1	LEG ASSY-NLG	A340
D23285000-2	LEG ASSY-NLG	A340
D23285001	LEG ASSY-NLG	A340
D23285001-1	LEG ASSY-NLG	A340
D23285001-10	LEG ASSY-NLG	A340
D23285001-11	LEG ASSY-NLG	A340
D23285001-12	LEG ASSY-NLG	A340
D23285001-123	LEG ASSY-NLG	A340
D23285001-124	LEG ASSY-NLG	A340
D23285001-125	LEG ASSY-NLG	A340
D23285001-126	LEG ASSY-NLG	A340
D23285001-127	LEG ASSY-NLG	A340
D23285001-128	LEG ASSY-NLG	A340
D23285001-129	LEG ASSY-NLG	A340
D23285001-13	LEG ASSY-NLG	A340
D23285001-130	LEG ASSY-NLG	A340
D23285001-131	LEG ASSY-NLG	A340
D23285001-132	LEG ASSY-NLG	A340
D23285001-133	LEG ASSY-NLG	A340
D23285001-134	LEG ASSY-NLG	A340
D23285001-14	LEG ASSY-NLG	A340
D23285001-15	LEG ASSY-NLG	A340
D23285001-16	LEG ASSY-NLG	A340
D23285001-17	LEG ASSY-NLG	A340
D23285001-18	LEG ASSY-NLG	A340
D23285001-19	LEG ASSY-NLG	A340
D23285001-2	LEG ASSY-NLG	A340
D23285001-20	LEG ASSY-NLG	A340
D23285001-21	LEG ASSY-NLG	A340
D23285001-22	LEG ASSY-NLG	A340
D23285001-223	LEG ASSY-NLG	A340
D23285001-23	LEG ASSY-NLG	A340
D23285001-24	LEG ASSY-NLG	A340
D23285001-25	LEG ASSY-NLG	A340
D23285001-26	LEG ASSY-NLG	A340
D23285001-27	LEG ASSY-NLG	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
D23285001-28	LEG ASSY-NLG	A340
D23285001-29	LEG ASSY-NLG	A340
D23285001-3	LEG ASSY-NLG	A340
D23285001-30	LEG ASSY-NLG	A340
D23285001-31	LEG ASSY-NLG	A340
D23285001-32	LEG ASSY-NLG	A340
D23285001-323	LEG ASSY-NLG	A340
D23285001-33	LEG ASSY-NLG	A340
D23285001-34	LEG ASSY-NLG	A340
D23285001-4	LEG ASSY-NLG	A340
D23285001-5	LEG ASSY-NLG	A340
D23285001-6	LEG ASSY-NLG	A340
D23285001-7	LEG ASSY-NLG	A340
D23285001-8	LEG ASSY-NLG	A340
D23285001-9	LEG ASSY-NLG	A340
D23285050	LEG ASSY-NLG	A340
D23285050-1	LEG ASSY-NLG	A340
D23285051	LEG ASSY-NLG	A340
D23285051-1	LEG ASSY-NLG	A340
D23285051-10	LEG ASSY-NLG	A340
D23285051-11	LEG ASSY-NLG	A340
D23285051-12	LEG ASSY-NLG	A340
D23285051-13	LEG ASSY-NLG	A340
D23285051-14	LEG ASSY-NLG	A340
D23285051-15	LEG ASSY-NLG	A340
D23285051-16	LEG ASSY-NLG	A340
D23285051-17	LEG ASSY-NLG	A340
D23285051-2	LEG ASSY-NLG	A340
D23285051-3	LEG ASSY-NLG	A340
D23285051-4	LEG ASSY-NLG	A340
D23285051-5	LEG ASSY-NLG	A340
D23285051-6	LEG ASSY-NLG	A340
D23285051-7	LEG ASSY-NLG	A340
D23285051-8	LEG ASSY-NLG	A340
D23285051-9	LEG ASSY-NLG	A340
D23285101	LEG ASSY-NLG	A340
D23285101-1	LEG ASSY-NLG	A340
D23285101-10	LEG ASSY-NLG	A340
D23285101-104	LEG ASSY-NLG	A340
D23285101-11	NOSE LANDING GEAR LEG	A330
D23285101-117	LEG ASSY-NLG	A340
D23285101-118	LEG ASSY-NLG	A340
D23285101-119	LEG ASSY-NLG	A340
D23285101-12	LEG ASSY-NLG	A340
D23285101-120	LEG ASSY-NLG	A340
D23285101-121	LEG ASSY-NLG	A340
D23285101-122	LEG ASSY-NLG	A340
D23285101-123	LEG ASSY-NLG	A340
D23285101-124	LEG ASSY-NLG	A340
D23285101-125	LEG ASSY-NLG	A340
D23285101-126	LEG ASSY-NLG	A340
D23285101-127	LEG ASSY-NLG	A340
D23285101-128	LEG ASSY-NLG	A340
D23285101-13	LEG ASSY-NLG	A340
D23285101-14	LEG ASSY-NLG	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
D23285101-15	LEG ASSY-NLG	A340
D23285101-16	LEG ASSY-NLG	A340
D23285101-17	LEG ASSY-NLG	A340
D23285101-18	LEG ASSY-NLG	A340
D23285101-19	LEG ASSY-NLG	A340
D23285101-2	LEG ASSY-NLG	A340
D23285101-20	LEG ASSY-NLG	A340
D23285101-21	LEG ASSY-NLG	A340
D23285101-217	LEG ASSY-NLG	A340
D23285101-22	LEG ASSY-NLG	A340
D23285101-23	LEG ASSY-NLG	A340
D23285101-24	LEG ASSY-NLG	A340
D23285101-25	LEG ASSY-NLG	A340
D23285101-26	LEG ASSY-NLG	A340
D23285101-27	LEG ASSY-NLG	A340
D23285101-28	LEG ASSY-NLG	A340
D23285101-3	LEG ASSY-NLG	A340
D23285101-317	LEG ASSY-NLG	A340
D23285101-4	LEG ASSY-NLG	A340
D23285101-5	LEG ASSY-NLG	A340
D23285101-6	LEG ASSY-NLG	A340
D23285101-7	LEG ASSY-NLG	A340
D23285101-8	LEG ASSY-NLG	A340
D23285101-9	LEG ASSY-NLG	A340
D23285151	LEG ASSY-NLG	A340
D23285151-1	LEG ASSY-NLG	A340
D23285151-10	LEG ASSY-NLG	A340
D23285151-104	LEG ASSY-NLG	A340
D23285151-11	LEG ASSY-NLG	A340
D23285151-117	LEG ASSY-NLG	A340
D23285151-118	LEG ASSY-NLG	A340
D23285151-119	LEG ASSY-NLG	A340
D23285151-12	LEG ASSY-NLG	A340
D23285151-120	LEG ASSY-NLG	A340
D23285151-121	LEG ASSY-NLG	A340
D23285151-122	LEG ASSY-NLG	A340
D23285151-123	LEG ASSY-NLG	A340
D23285151-124	LEG ASSY-NLG	A340
D23285151-125	LEG ASSY-NLG	A340
D23285151-126	LEG ASSY-NLG	A340
D23285151-127	LEG ASSY-NLG	A340
D23285151-128	LEG ASSY-NLG	A340
D23285151-13	LEG ASSY-NLG	A340
D23285151-14	LEG ASSY-NLG	A340
D23285151-15	LEG ASSY-NLG	A340
D23285151-16	LEG ASSY-NLG	A340
D23285151-17	LEG ASSY-NLG	A340
D23285151-18	LEG ASSY-NLG	A340
D23285151-19	LEG ASSY-NLG	A340
D23285151-2	LEG ASSY-NLG	A340
D23285151-20	LEG ASSY-NLG	A340
D23285151-21	LEG ASSY-NLG	A340
D23285151-217	LEG ASSY-NLG	A340
D23285151-22	LEG ASSY-NLG	A340
D23285151-23	LEG ASSY-NLG	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
D23285151-24	LEG ASSY-NLG	A340
D23285151-25	LEG ASSY-NLG	A340
D23285151-26	LEG ASSY-NLG	A340
D23285151-27	LEG ASSY-NLG	A340
D23285151-28	LEG ASSY-NLG	A340
D23285151-3	LEG ASSY-NLG	A340
D23285151-317	LEG ASSY-NLG	A340
D23285151-4	LEG ASSY-NLG	A340
D23285151-5	LEG ASSY-NLG	A340
D23285151-6	LEG ASSY-NLG	A340
D23285151-7	LEG ASSY-NLG	A340
D23285151-8	LEG ASSY-NLG	A340
D23285151-9	LEG ASSY-NLG	A340
D23285200	NOSE LANDING GEAR LEG	A340
D23285350	LEG ASSY-NLG	A340
D23287000	STEERING ACTUATOR	A330
D23297000	LOCK LINK	A330
D23297000-1	LOCK LINK	A330
D23298000	LOCKSTAY ACTUATOR	A330
D23299000	DOWNLOCK SPRING	A330
D23352000-2	NLG RETRACTION ACTUATOR	A330
D23352000-3	RETRACTION ACTUATOR	A330
D23354000	NLG ELECTRICAL TOW BOX	A318
D23354000-1	ELECTRICAL BOX	A318
D23354000-2	ELECTRICAL BOX	A318
D23354010	ELECTRICAL BOX	A318
D23354010-1	ELECTRICAL BOX	A318
D23354010-2	ELECTRICAL BOX	A318
D23354100	ELECTRICAL BOX	A318
D23354100-1	ELECTRICAL BOX	A318
D23354100-2	ELECTRICAL BOX	A318
D23355000	AXLE PROTECTIVE SLEEVE	A318
D23355020	AXLE PROTECTIVE SLEEVE	A318
D23355500	AXLE PROTECTIVE SLEEVE	A318
D23441000	LEG ASSY-NLG	A340
D23441050	LEG ASSY-NLG	A340
D23443100	LEG FITTING	A330
D23443100-1	LEG FITTING	A330
D23443100-2	LEG FITTING	A330
D23443100-3	LEG FITTING	A330
D23443100-4	LEG FITTING	A330
D23443100-5	LEG FITTING	A330
D23443100-6	LEG FITTING	A330
D23443100-7	LEG FITTING	A330
D23443200	LEG FITTING	A330
D23444000	DRAG STAY UPPER ARM	A330
D23445000	TOWING FITTING ASSY	A330
D23449000	STEERING ACTUATOR	A330
D23450000	CHANGE - OVER VALVE	A330
D23544000	TOWING FITTING ASSY	A330
D23581000	LEG ASSY-NLG	A340
D23581050	LEG ASSY-NLG	A340
D23581100	NLG LEG, NOSE LANDING GEAR	A330
D23581100-1	GEAR LEG, NOSE LANDING	A330
D23581100-10	GEAR LEG, NOSE LANDING	A330





P/N	DESCRIPTION	AIRCRAFT PARTS
D23581100-108	NOSE LANDING GEAR LEG	A330
D23581100-109	LEG ASSY-NLG	A340
D23581100-11	NOSE LANDING GEAR LEG	A330
D23581100-110	LEG ASSY-NLG	A340
D23581100-111	LEG ASSY-NLG	A340
D23581100-112	LEG ASSY-NLG	A340
D23581100-113	LEG ASSY-NLG	A340
D23581100-114	LEG ASSY-NLG	A340
D23581100-115	LEG ASSY-NLG	A340
D23581100-116	LEG ASSY-NLG	A340
D23581100-117	LEG ASSY-NLG	A340
D23581100-118	LEG ASSY-NLG	A340
D23581100-119	LEG ASSY-NLG	A340
D23581100-12	NOSE LANDING GEAR LEG	A330
D23581100-120	NOSE LANDING GEAR LEG	A330
D23581100-13	NOSE LANDING GEAR LEG	A330
D23581100-14	NOSE LANDING GEAR LEG	A330
D23581100-15	NOSE LANDING GEAR LEG	A330
D23581100-16	NLG LEG, NOSE LANDING GEAR	A330
D23581100-17	NOSE LANDING GEAR LEG	A330
D23581100-18	NLG, NOSE LANDING GEAR	A330
D23581100-19	NOSE LANDING GEAR LEG	A330
D23581100-2	NOSE LANDING GEAR LEG	A330
D23581100-20	NOSE LANDING GEAR	A330
D23581100-3	NOSE LANDING GEAR LEG	A330
D23581100-3-5	LEG ASSY-NLG	A340
D23581100-4	NOSE LANDING GEAR LEG	A330
D23581100-5	NOSE LANDING GEAR LEG	A330
D23581100-6	NOSE LANDING GEAR LEG	A330
D23581100-7	NOSE LANDING GEAR LEG	A330
D23581100-8	NOSE LANDING GEAR LEG	A330
D23581100-9	NOSE LANDING GEAR LEG	A330
D23581150	LEG ASSY-NLG	A340
D23581150-1	NOSE LANDING GEAR LEG	A330
D23581150-10	NOSE LANDING GEAR LEG	A330
D23581150-108	NOSE LANDING GEAR LEG	A330
D23581150-109	LEG ASSY-NLG	A340
D23581150-11	NOSE LANDING GEAR LEG	A330
D23581150-110	LEG ASSY-NLG	A340
D23581150-111	LEG ASSY-NLG	A340
D23581150-112	LEG ASSY-NLG	A340
D23581150-113	LEG ASSY-NLG	A340
D23581150-114	LEG ASSY-NLG	A340
D23581150-115	LEG ASSY-NLG	A340
D23581150-116	LEG ASSY-NLG	A340
D23581150-117	LEG ASSY-NLG	A340
D23581150-118	LEG ASSY-NLG	A340
D23581150-119	LEG ASSY-NLG	A340
D23581150-12	LEG ASSY-NLG	A340
D23581150-120	LEG ASSY-NLG	A340
D23581150-13	LEG ASSY-NLG	A340
D23581150-14	LEG ASSY-NLG	A340
D23581150-15	LEG ASSY-NLG	A340
D23581150-16	LEG ASSY-NLG	A340
D23581150-17	LEG ASSY-NLG	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
D23581150-18	LEG ASSY-NLG	A340
D23581150-19	LEG ASSY-NLG	A340
D23581150-2	NOSE LANDING GEAR LEG	A330
D23581150-20	LEG ASSY-NLG	A340
D23581150-3	NOSE LANDING GEAR LEG	A330
D23581150-3-5	LEG ASSY-NLG	A340
D23581150-4	LEG ASSY-NLG	A340
D23581150-5	NOSE LANDING GEAR LEG	A330
D23581150-6	NOSE LANDING GEAR LEG	A330
D23581150-7	NOSE LANDING GEAR LEG	A330
D23581150-8	NOSE LANDING GEAR LEG	A330
D23581150-9	NOSE LANDING GEAR LEG	A330
D23581200	NOSE LANDING GEAR LEG	A330
D23581200-1	LEG ASSY-NLG	A340
D23581200-2	LEG ASSY-NLG	A340
D23581200-3	NOSE LANDING GEAR LEG	A330
D23581300	LEG ASSY-NLG	A340
D23581300-1	LEG ASSY-NLG	A340
D23581300-10	LEG ASSY-NLG	A340
D23581300-108	LEG ASSY-NLG	A340
D23581300-109	LEG ASSY-NLG	A340
D23581300-11	LEG ASSY-NLG	A340
D23581300-110	LEG ASSY-NLG	A340
D23581300-111	LEG ASSY-NLG	A340
D23581300-112	LEG ASSY-NLG	A340
D23581300-113	LEG ASSY-NLG	A340
D23581300-114	LEG ASSY-NLG	A340
D23581300-115	LEG ASSY-NLG	A340
D23581300-116	LEG ASSY-NLG	A340
D23581300-117	LEG ASSY-NLG	A340
D23581300-118	LEG ASSY-NLG	A340
D23581300-119	LEG ASSY-NLG	A340
D23581300-12	LEG ASSY-NLG	A340
D23581300-120	LEG ASSY-NLG	A340
D23581300-13	LEG ASSY-NLG	A340
D23581300-14	LEG ASSY-NLG	A340
D23581300-15	LEG ASSY-NLG	A340
D23581300-16	LEG ASSY-NLG	A340
D23581300-17	LEG ASSY-NLG	A340
D23581300-18	LEG ASSY-NLG	A340
D23581300-19	LEG ASSY-NLG	A340
D23581300-2	LEG ASSY-NLG	A340
D23581300-20	LEG ASSY-NLG	A340
D23581300-3	LEG ASSY-NLG	A340
D23581300-4	LEG ASSY-NLG	A340
D23581300-5	LEG ASSY-NLG	A340
D23581300-6	LEG ASSY-NLG	A340
D23581300-7	LEG ASSY-NLG	A340
D23581300-8	LEG ASSY-NLG	A340
D23581300-9	LEG ASSY-NLG	A340
D23581350	LEG ASSY-NLG	A340
D23581350-1	LEG ASSY-NLG	A340
D23581350-10	LEG ASSY-NLG	A340
D23581350-108	LEG ASSY-NLG	A340
D23581350-109	LEG ASSY-NLG	A340



P/N	DESCRIPTION	AIRCRAFT PARTS
D23581350-11	LEG ASSY-NLG	A340
D23581350-110	LEG ASSY-NLG	A340
D23581350-111	LEG ASSY-NLG	A340
D23581350-112	LEG ASSY-NLG	A340
D23581350-113	LEG ASSY-NLG	A340
D23581350-114	LEG ASSY-NLG	A340
D23581350-115	LEG ASSY-NLG	A340
D23581350-116	LEG ASSY-NLG	A340
D23581350-117	LEG ASSY-NLG	A340
D23581350-118	LEG ASSY-NLG	A340
D23581350-119	LEG ASSY-NLG	A340
D23581350-12	LEG ASSY-NLG	A340
D23581350-120	LEG ASSY-NLG	A340
D23581350-13	LEG ASSY-NLG	A340
D23581350-14	LEG ASSY-NLG	A340
D23581350-15	LEG ASSY-NLG	A340
D23581350-16	LEG ASSY-NLG	A340
D23581350-17	LEG ASSY-NLG	A340
D23581350-18	LEG ASSY-NLG	A340
D23581350-19	LEG ASSY-NLG	A340
D23581350-2	LEG ASSY-NLG	A340
D23581350-20	LEG ASSY-NLG	A340
D23581350-3	LEG ASSY-NLG	A340
D23581350-4	LEG ASSY-NLG	A340
D23581350-5	LEG ASSY-NLG	A340
D23581350-6	LEG ASSY-NLG	A340
D23581350-7	LEG ASSY-NLG	A340
D23581350-8	LEG ASSY-NLG	A340
D23581350-9	LEG ASSY-NLG	A340
D23581400	LEG ASSY-NLG	A330
D23581400-01	LEG ASSY-NLG	A330
D23582100-1	MAIN FITTING SHOCK ABSORBER	A330
D23582100-10	MAIN FITTING SHOCK ABSORBER	A330
D23582100-105	MAIN FITTING SHOCK ABSORBER	A330
D23582100-106	MAIN FITTING SHOCK ABSORBER	A330
D23582100-107	MAIN FITTING SHOCK ABSORBER	A330
D23582100-108	MAIN FITTING SHOCK ABSORBER	A330
D23582100-109	MAIN FITTING SHOCK ABSORBER	A330
D23582100-11	MAIN FITTING SHOCK ABSORBER	A330
D23582100-110	MAIN FITTING SHOCK ABSORBER	A330
D23582100-111	MAIN FITTING SHOCK ABSORBER	A330
D23582100-112	MAIN FITTING SHOCK ABSORBER	A330
D23582100-113	MAIN FITTING SHOCK ABSORBER	A330
D23582100-114	MAIN FITTING SHOCK ABSORBER	A330
D23582100-12	MAIN FITTING SHOCK ABSORBER	A330
D23582100-13	MAIN FITTING SHOCK ABSORBER	A330
D23582100-2	MAIN FITTING SHOCK ABSORBER	A330
D23582100-205	MAIN FITTING SHOCK ABSORBER	A330
D23582100-206	MAIN FITTING SHOCK ABSORBER	A330
D23582100-207	MAIN FITTING SHOCK ABSORBER	A330
D23582100-208	MAIN FITTING SHOCK ABSORBER	A330
D23582100-209	MAIN FITTING SHOCK ABSORBER	A330
D23582100-210	MAIN FITTING SHOCK ABSORBER	A330
D23582100-211	MAIN FITTING SHOCK ABSORBER	A330
D23582100-212	MAIN FITTING SHOCK ABSORBER	A330



P/N	DESCRIPTION	AIRCRAFT PARTS
D23582100-213	MAIN FITTING SHOCK ABSORBER	A330
D23582100-214	MAIN FITTING SHOCK ABSORBER	A330
D23582100-3	MAIN FITTING SHOCK ABSORBER	A330
D23582100-306	MAIN FITTING SHOCK ABSORBER	A330
D23582100-307	MAIN FITTING SHOCK ABSORBER	A330
D23582100-308	MAIN FITTING SHOCK ABSORBER	A330
D23582100-309	MAIN FITTING SHOCK ABSORBER	A330
D23582100-310	MAIN FITTING SHOCK ABSORBER	A330
D23582100-311	MAIN FITTING SHOCK ABSORBER	A330
D23582100-312	MAIN FITTING SHOCK ABSORBER	A330
D23582100-313	MAIN FITTING SHOCK ABSORBER	A330
D23582100-4	MAIN FITTING SHOCK ABSORBER	A330
D23582100-5	MAIN FITTING SHOCK ABSORBER	A330
D23582100-6	MAIN FITTING SHOCK ABSORBER	A330
D23582100-7	MAIN FITTING SHOCK ABSORBER	A330
D23582100-8	MAIN FITTING SHOCK ABSORBER	A330
D23582100-9	MAIN FITTING SHOCK ABSORBER	A330
D23582200	MAIN FITTING SHOCK ABSORBER	A330
D23582200-1	MAIN FITTING SHOCK ABSORBER	A330
D23582200-2	MAIN FITTING SHOCK ABSORBER	A330
D23582200-3	MAIN FITTING SHOCK ABSORBER	A330
D23582210	MAIN FITTING SHOCK ABSORBER	A330
D23582210-1	MAIN FITTING SHOCK ABSORBER	A330
D23582210-2	MAIN FITTING SHOCK ABSORBER	A330
D23582210-3	MAIN FITTING SHOCK ABSORBER	A330
D23582300	MAIN FITTING SHOCK ABSORBER	A330
D23582300-1	MAIN FITTING SHOCK ABSORBER	A330
D23582300-10	MAIN FITTING SHOCK ABSORBER	A330
D23582300-105	MAIN FITTING SHOCK ABSORBER	A330
D23582300-106	MAIN FITTING SHOCK ABSORBER	A330
D23582300-107	MAIN FITTING SHOCK ABSORBER	A330
D23582300-108	MAIN FITTING SHOCK ABSORBER	A330
D23582300-109	MAIN FITTING SHOCK ABSORBER	A330
D23582300-110	MAIN FITTING SHOCK ABSORBER	A330
D23582300-111	MAIN FITTING SHOCK ABSORBER	A330
D23582300-2	MAIN FITTING SHOCK ABSORBER	A330
D23582300-205	MAIN FITTING SHOCK ABSORBER	A330
D23582300-206	MAIN FITTING SHOCK ABSORBER	A330
D23582300-207	MAIN FITTING SHOCK ABSORBER	A330
D23582300-208	MAIN FITTING SHOCK ABSORBER	A330
D23582300-209	MAIN FITTING SHOCK ABSORBER	A330
D23582300-210	MAIN FITTING SHOCK ABSORBER	A330
D23582300-211	MAIN FITTING SHOCK ABSORBER	A330
D23582300-3	MAIN FITTING SHOCK ABSORBER	A330
D23582300-306	MAIN FITTING SHOCK ABSORBER	A330
D23582300-307	MAIN FITTING SHOCK ABSORBER	A330
D23582300-308	MAIN FITTING SHOCK ABSORBER	A330
D23582300-309	MAIN FITTING SHOCK ABSORBER	A330
D23582300-310	MAIN FITTING SHOCK ABSORBER	A330
D23582300-4	MAIN FITTING SHOCK ABSORBER	A330
D23582300-5	MAIN FITTING SHOCK ABSORBER	A330
D23582300-6	MAIN FITTING SHOCK ABSORBER	A330
D23582300-7	MAIN FITTING SHOCK ABSORBER	A330
D23582300-8	MAIN FITTING SHOCK ABSORBER	A330
D23582300-9	MAIN FITTING SHOCK ABSORBER	A330



P/N	DESCRIPTION	AIRCRAFT PARTS
D23585000	BOX & ELECTRICAL HARNESS TOWBA	A330
D23585000-100	BOX & ELECTRICAL HARNESS TOWBA	A330
D23589000	NLG LEG ASSEMBLY	A319
D23589000-1	LEG ASSY (NLG)	A319
D23589000-10	LEG ASSY (NLG)	A318
D23589000-2	LEG ASSY (NLG)	A319
D23589000-3	LEG ASSY (NLG)	A319
D23589000-4	LEG ASSY (NLG)	A319
D23589000-9	LEG ASSY (NLG)	A318
D23589020	NLG LEG ASSEMBLY	A319
D23589020-1	LEG ASSY (NLG)	A319
D23589020-2	LEG ASSY (NLG)	A319
D23589020-3	LEG ASSY (NLG)	A319
D23589020-4	LEG ASSY (NLG)	A319
D23589020-5	LEG ASSY (NLG)	A319
D23589020-6	LEG ASSY (NLG)	A319
D23589020-7	NLG	A320/321
D23589040	NLG LEG ASSEMBLY	A319
D23589510	NLG LEG ASSEMBLY	A319
D23589510-1	LEG ASSY (NLG)	A318
D23589510-6	LEG ASSY (NLG)	A318
D23589510-7	LEG ASSY (NLG)	A318
D23589520	NLG LEG ASSEMBLY	A319
D23589520-1	LEG ASSY (NLG)	A319
D23589520-11	NOSE LANDING GEAR ASSY	A320
D23589520-12	NOSE LANDING GEAR LEG	A320
D23589520-2	LEG ASSY (NLG)	A319
D23589520-3	LEG ASSY (NLG)	A319
D23589520-4	LEG ASSY (NLG)	A319
D23589520-5	LEG ASSY (NLG)	A319
D23589520-6	LEG ASSY (NLG)	A319
D23589520-7	LEG ASSY (NLG)	A319
D23589520-9	LEG ASSY (NLG)	A319
D23589540	NLG LEG ASSEMBLY	A319
D23590000-1	LEG STRUCTURE	A318
D23590000-10	LEG STRUCTURE	A320
D23590030-1	LEG STRUCTURE	A318
D23591520-5	BARREL STRUCTURE	A320
D23592020	NLG SHOCK	A320
D23592020-2	SHOCK ABSORBER	A320/321
D23596000	FORESTAY ASSEMBLY	A318
D23599000	NLG FORESTAY	A320
D23607000-1	LEG FITTINGS	A320
D23611000	NLG LOCKING SPRING	A320
D23612000	LOCK LINK	A320
D23613000	NLG ACTUATING CYL.	A318
D23627000	1M UPPER HARNESS	A320
D23628000-1	2M UPPER ELECTRICAL HARNESS	A320
D23630000	LOWER HARNESS	A319/320
D23757500-9	NLG LETG	A321
D24005000	ALTERNATE BRAKE MANIFOLD ASSEM	A318
D24029000-3	NORMAL BRAKE MANIFOLD ASSEMBLY	A340
D25050	GCU	CN-235
D25-050	G.C.U	A330, A340
D25-051	REGULATOR	C-295



P/N	DESCRIPTION	AIRCRAFT PARTS
D26AB1040	VALVE, CUT-OUT	A340
D26AB1041	VALVE, CUT-OUT	A340
D26AB1042	VALVE	A330
D26AB1060	VENT VALVE	A340
D26AB1061	FREE FALL VENT VALVE	A330
D26AB1083	LANDING GEAR CUT-OUT VALVE	A340
D26AB1084	CUT OUT VALVE	A340
D31AB4411	LDG SELECTOR VALVE AND MANIFOL	A340
D31AB4411-2	LDG SELECTOR VALVE AND MANIFOL	A340
D31AB4411-3	LDG SELECTOR VALVE AND MANIFOL	A340
D31AB4412	LDG SELECTOR VALVE AND MANIFOL	A330
D31AB4413	LDG SELECTOR VALVE AND MANIFOL	A330
D31AB4414	LDG SELECTOR VALVE AND MANIFOL	A330
D31AB4430	SAFETY VALVE	A340
D31AB4433	SAFETY VALVE	A330
D3215303000000	REAR PINTLE PIN	A320
D3215303200000	PIN - PINTLE REAR MLG	A320
D3215303200200	PIN - PINTLE REAR MLG	A319
D3215303200400	PIN - PINTLE REAR MLG	A319
D3215303200600	PIN - PINTLE REAR MLG	A318
D3215600400000	PIN - PINTLE REAR MLG	A321
D3215600400200	PIN - PINTLE REAR MLG	A320/321
D3215600400400	PIN - PINTLE REAR MLG	A321
D3215601000000	NUT ASSY - PINTLE PIN	A320/321
D3221011600000	ROD ASSY	A320
D3221011600100	ROD ASSY	A320
D3221011600400	ROD ASSY	A320
D455-07-001	ENGINE FIRE SHUT-OFF SWITCH	A330, A340
D455-08-001	ENGINE FIRE SHUT-OFF SWITCH	A330, A340
D5528000100551	ELEVATOR ASSY	A320
D59636-1	LOCK LINK UPPER LINK	A320
D59885	SLEEVE-AXLE PROTECTIVE	
D6000-5	HYDRAULIC ACTUATOR WINDSHIELD WIPER	A330, A340
D61366	AXLES NUT	A320
D61530-1	PIN	A320
D61686	RETRACTION ACTUATOR PIN	A330
D61845	LOCK LINK UPPER ARM	A330
D61846	LOCK LINK LOWER ARM	A330
D61870-1	LOCK LINK CENTER PIN	A330
D62581	SLEEVE-AXLE PROTECTIVE	
D62660	TORQUE LINK APEX PIN	A330
D63996	MAIN FITTING	A330
D64000	UPPER FLANGE	A330
D64001	LOWER TORQUE LINK	A330
D64002	UPPER TORQUE LINK	A330
D64003	MAIN FITTING HINGE PIN	A330
D64005	LOWER TORQUE LINK PIN	A330
D64006	UPPER TORQUE LINK PIN	A330
D64034	DRAG STAY UPPER PIN	A330
D64036	DRAG STAY CENTER PIN	A330
D64037	DRAG STAY LOWER ARM	A330
D64433	APEX PIN	A320
D65046	SLIDING TUBE	A330
D65051	CYLINDER	A330
D65233	BARREL	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
D65520	TUBE, BUSHED TURNING	A320
D65628-1	CROSS PIN	A320
D65644	END FITTING	A320
D65989	RING	A320
D66331	DRAG STAY LWR ARM MAIN FITTING	A330
D66679	SLIDING ROD	A320
D66680	WHEEL AXLE	A320/321
D67201	SLIDING TUBE	A330
D67237	RESTRICTOR VALVE	A330
D67241	RESTRICTOR	A330
D67247-1	LOWER TORQUE LINK PIN	A330
D67634	TURNING SLEEVE	A330
D67788	LOCK LINK UPR ARM MAIN FITTING	A330
D67802	FORESTAY LOWER LINK	A320
D68053-1	RESTRICTOR VALVE	A330
D68100-1	SUPPORT TUBE	A330
D68346	RESTRICTOR VALVE	A330
D68347	RESTRICTOR	A330
D717-01-001	EMERGENCY POWER SUPPLY	A330, A340
D717-02-001	EMERGENCY POWER SUPPLY	B737
D94412	FAN	A330, A340
DL404-38	TRIPLE RPM INDICATOR	
DL412	INDICADOR DE NI	
DM ELT14-1-1	TRANSMITTER EMERGENCY LOCATOR	A330, A340
DM ELT8.1	EMERGENCY LOCATOR TRANSMITTER SYSTEM DM ELT 8.1	CN-235
DMELT14-1-1	TRANSM-EMER LOCATOR	C-212, CN-235
DSI 421/106	DIRECT READING PRESSURE GAGE	A330, A340
DSI1421/106	INDICATOR	
DSI421/106	DIRECT READING PRESS	A330, A340
DSI-421/106	DIRECT READING PRESSURE GAGE	A330, A340
E21324000-1	BRAKE PEDAL TRANSMITTER	A318
E21330000-1	ABS MANIFOLD	A318
E21336000	SENSOR BOX	A319
E2588M42	ARMATURE	
E709-01-001	CEILING LIGHT	B737, B757
E709-01-100	CEILING LIGHT	B737, B757
E709-03-001	CEILING LIGHT	B737, B757
E709-04-001	CEILING LIGHT	B737, B757
EA1045-037-2	PUMP MOTOR HYD SYSTEM	C-130
EM48-6	ELECTRIC MOTOR	CN-235/CN-295
EM48-6-1	ELECTRIC MOTOR	CN-235/CN-295
EVCTA740C	FAN-RECIRCULATION	CN-235, C-295
EVT174-2	BRAKE COOLING FAN	A300, A310, A318, A319, A320
EVT174-2E	BRAKE COOLING FAN	A310, A318, A319, A320
EVT174-2E SERIES	BRAKE COOLING FAN	A300, A310, A318, A319, A320
EVT174-2E1	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E2	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E3	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E31	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E31AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E31AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E31AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E3AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E3AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E3AmdtC	BRAKE COOLING FAN	A300, A310, A320



P/N	DESCRIPTION	AIRCRAFT PARTS
EVT174-2E4	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E41	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E41AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E41AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E41AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E4AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E4AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E4AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E5	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E51	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E51AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E51AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E51AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E5AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E5AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E5AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E6	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E6AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E6AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E6AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E7	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E7AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E7AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E7AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8AmdtA	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8AmdtABC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8AmdtB	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E8AmdtC	BRAKE COOLING FAN	A300, A310, A320
EVT174-2E9	BRAKE COOLING FAN	A300, A310, A320
EVT174-500E	BRAKE FAN MOTOR	A320, A310
EVT174-M	BRAKE COOLING FAN	A330, A340
F1001940-00	LED LOADING AREA LIGHT	A330, A340, A320
F100940-00	LED LOADING AREA LIGHT	A330, A340
F11QB3121	TRANSFORMER - RECTIFIER	A300, A310, A300-600
F11QB3121-020	TRANSFORMER RECTIFIER	A330, A340
F11QY3121	TRANSFORMER - RECTIFIER	A300, A310, A300-600
F3215002520000	SLEEVE	A330
F3215003600200	PIN ASSY	A330/340
F3215005900100	PIN ASSEMBLY RH	A330
F3215006000800	MLG PINTLE PIN ASSEMBLY RH	A330
F3215006000900	MLG PINTLE PIN ASSEMBLY	A330
F3215006001000	MLG PINTLE PIN ASSEMBLY RH	A330
F3215006001100	MLG PINTLE PIN ASSEMBLY	A330
F3215500900000	MLG PINTLE PIN ASSEMBLY	A330
F3215500900100	MLG PINTLE PIN ASSEMBLY	A330
F3215500900400	MLG PINTLE PIN ASSEMBLY	A340
F3215500900500	MLG PINTLE PIN ASSEMBLY	A340
F3215500900800	MLG PINTLE PIN ASSEMBLY	A340
F3215500900900	MLG PINTLE PIN ASSEMBLY	A340
F3215500901000	MLG PINTLE PIN ASSEMBLY	A340
F3215500901100	MLG PINTLE PIN ASSEMBLY	A340
F32155011001	MLG PINTLE PIN ASSEMBLY	A330
F3215501200000	PLUG ASSY-GREASER	A330
F3215501400000	NUT-ASSY	A330





P/N	DESCRIPTION	AIRCRAFT PARTS
F32155014002	NUT-ASSY SPC	A330
F3215501400200	NUT-ASSY SPC	A330
F3215502000000	AFT PINTLE PIN - LH	A330
F3215502000100	AFT PIN ASSEMBLY RH	A330
F3215502100000	LH AFT PINTLE PIN	A330/340
F3215502100100	AFT PINTLE PIN (RH)	A330/340
F3215502300000	PLUG ASSY-GREASER	A330
F34PB6224	FAN	A300
F34PC6224	FAN	A310
F5311233920000	PINTLE PIN	A330/340
F5312058120000	PINTLE PIN	A330
F62B0050M1	VALVE SOLENOID	
FC103063N2	CONTROL SELECTOR S	
FE174-004	DOOR DAMPER	A319, A320, A321
G4-1505-1429	LIGHT ANTI-COLLISION	ATR-42, ATR-72
G4710A19	LOGO LIGHT	C-212, CN-235
G5944	CONTROL INTERCOM	
G7490-33	FLIGHT ID/ATC/TCAS Control Panel	A330, A340
G836-6-20	QUANTITY MEASURING FUSE ASSEMB	B737
G8400A37-24	LIGHT	ATR
G-8400A-37-24	AIRCRAFT NAVIGATIONAL ROTATING WARNING LIGHT	A330, A340
G-8895-1	LANDING LIGHT	A330, A340
G-8895-4559	LANDING LIGHT	A330, A340
GA63612	BARREL	A320
GA63797	ARM ASSEMBLY LOCK LINK UPPER	A330
GA63843-1	BODDY ASSY	A330
GA64713	FLANGE UPPER BUSHED	A330
GA64717	LINK LOWER BUSHED TORQUE	A330
GA65226	BARREL ASSEMBLY	A320
GA65227	LINK, TORQUE, NLG	A319
H10-56	HEADSET CABIN INTERCOMM	C-212, CN-235, C-295
H138JFM	GYRO HORIZON	
ID663B/U	INDICATOR, BEARING	
IFD9-464-40	INDICATOR, LIQUID QTY	
IPTE-27-1000-4000SG	TRANSMITER-	S330, S340
L2889	SOLENOID, ELECTRICAL	
LM320SA12	BRACKET SIDE	C-212, CN-235
LM320-SA12	BRACKET-SIDE	
LM-320-SA12	FRONT SIDE MOUNTING ASSEMBLY	A330, A340
LM320SA13	BRACKET-ENGINE FRONT TOP	CN-235
LM-320-SA13	FRONT TOP MOUNTING ASSEMBLY	A330, A340
LM320SA14	BRACKET-UPPER	CN-235
LM320SA18	MOUNTING-REAR	CN-235
LM-320-SA18	FRONT LEFT AND RIGHT SIDE MOUNT BRACKET ASSEMBLY	A330, A340
LM320SA19	MOUNTING-REAR	CN-235, C-295
LM-320-SA19	MOUNTING-REAR	A330, A340
LT-100	DC TO DC CONVERTER	A330, A340
LT103	POWER SUPPLY	
LT-103	DC TO DC CONVERTER	A330, A340
LT52A	CONVERTER	C-212, CN-235, C-295
LT-52A	DC TO DC CONVERTER	A330, A340
LT-53	DC TO DC CONVERTER	A330, A340
LT53A	CONVERTER	
LT-55	CONVERTER	



P/N	DESCRIPTION	AIRCRAFT PARTS
LT-70	DC TO DC CONVERTER	A330, A340
LT-73	DC TO DC CONVERTER	A330, A340
M732591	AIR COOLING FAN	A330, A340
M732591 SERIES	AIR COOLING FAN	A330, A340
M732591DF	FAN ASSEMBLY-AIR COOLING	B747, B767,DASH8
M762620C	VSCF	B777
M83383/04-10	CIRCUIT BREAKER	CN-235
M83383-04-10	CIRCUIT BREAKERS	CN-235
MF30-3913-30ZE5	MOTOR HYDRAULIC	C130
MGE23-400A	MOTOR-GENERATOR	C-130
MI585161	XMTR TRANSMITTER	A320
MK14LL	INDICATOR	A330, A340
MODEL 5318	ALTERNATING CURRENT GENERATOR	A330, A340
MPEV3-011-8UK2B	PUMP-HYDR.MOTOR DRIV	CN-235, C-295
MPEV3-011-8UK2C	PUMP-HYDR.MOTOR DRIV	CN-235, C-295
MPEV3-012-2B	HYDRAULIC PUMP	CRJ
MPEV3-032-2	PUMP HYD. MOTOR	C-130
MPEV3-032-2A	HYDRAULIC MOTORPUMP ASSEMBLY	C130
MS14218T4-12	REMACHE	
MS17401-1	ALTIMETER PRESSURE	
MS28008-1	INDICATOR, TEMPERATURE	
MS3452W14S-7S	CONECTOR RECEPTACULO	
NAS6610D43	CARDAN BRACKET BOLT	A320
NC6-P-1A	ROTOR	
NTX138-100	VHF FM TRANSCEIVER	
P11487	RELAY, ELECTROMAGNETIC	
P603744A	ROTOR	
PMP05VC040	MOTOR C7BBA. HID.	C-212
PMP3V-3-05	VARIABLE DELIVERY HYDRAULIC PUMP	B757,B767
PMP3V-3-06	VARIABLE DELIVERY HYDRAULIC PUMP	B757,B767
PMP3V-3-07	VARIABLE DELIVERY HYDRAULIC PUMP	B747,B757,B767,B777
PMP3V-3-08	VARIABLE DELIVERY HYDRAULIC PUMP	B747,B757,B767,B777
PTG9/16A	GEARBOX	
PTG9/16B	GEARBOX	
PV3-044-48	HYDRAULIC PUMP	CRJ,CRJ200
R1624-4	ROTARY ACTUATOR ASSEMBLY	A330, A340
R5294	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M2	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M2-1	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M2-2	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M4	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
R5294M4-2	ELECTROMECHANICAL LINEAR ACTUATOR	A330, A340
RB56423	BRUSH	
RBC6	U.P.S. SALA FUSION	
RCS60-1L	INDICATOR AIR SPEED	
RG12240-1	CENTRIFUGAL FUEL BOOST PUMP	A330, A340
RG12240D	CENTRIFUGAL FUEL BOOST PUMP	A330, A340
S231T260-1	INDICATOR PRESSURE OXYG	
S274A101-1	ACCUMULATOR HYDRAULIC ASSEMBLY (300 CU. IN.)	
S274T120-10	ANTISKID	B757, B767, B737
S27W813-11	FUSE ASSEMBLY, FLOW RATE	B-777
S282T003-3	BATTERY CHARGER	
S283A325-1	EXTERIOR EMERGENCY LIGHTS	B-737
S283A325-10	EXTERIOR EMERGENCY LIGHTS	B-737
S283A325-2	EXTERIOR EMERGENCY LIGHTS	B-737



P/N	DESCRIPTION	AIRCRAFT PARTS
S283A325-3	EXTERIOR EMERGENCY LIGHTS	B-737
S283A325-4	EXTERIOR EMERGENCY LIGHTS	B-737
S283A325-5	EXTERIOR EMERGENCY LIGHTS	B-737
S283A325-6	EXTERIOR EMERGENCY LIGHTS	B-737
S283A325-7	EXTERIOR EMERGENCY LIGHTS	B-737
S283A325-8	EXTERIOR EMERGENCY LIGHTS	B-737
S283A325-9	EXTERIOR EMERGENCY LIGHTS	B-737
S369-100	ACCUMULATORS	A330, A340
S369-50	ACCUMULATORS	A330, A340
S417A501-609	CEILING LIGHT ASSEMBLY	B737
S417A501-610	CEILING LIGHT ASSEMBLY	B737
S417A501-611	CEILING LIGHT ASSEMBLY	B737
S417A501-612	CEILING LIGHT ASSEMBLY	B737
S417A501-613	CEILING LIGHT ASSEMBLY	B737
S417A501-614	CEILING LIGHT ASSEMBLY	B737
S417A501-615	CEILING LIGHT ASSEMBLY	B737
S417A501-616	CEILING LIGHT ASSEMBLY	B737
S417T102-1	WASTE SYSTEM VACUUM BLOWER	B777-200
S4-3300930-01	MAIN LANDING GEAR DOOR ACTUATO	A330
S4-3300930-02	MLG DOOR ACTUATOR	A330
S4-3300950-02	NLG DOOR ACTUATOR	A330
S4-3300955	ACTUATOR	A330
S4-3401310-03	SAFETY VALVE	A319
S4-3401310-04	SAFETY VALVE	A319
S462-25	ACCUMULATORS	A330, A340
S462-50	ACCUMULATORS	A330, A340
S463-100	ACCUMULATORS	A330, A340
S463-50	ACCUMULATORS	A330, A340
S477-100	ACCUMULATORS	A330, A340
S477-200	ACCUMULATORS	A330, A340
S477-50	ACCUMULATORS	A330, A340
S512-25	ACCUMULATORS	A330, A340
S513-100	ACCUMULATORS	A330, A340
S-513-100-2	ACCUMULATOR, HYDRAULIC	C-130
S513-200	ACCUMULATORS	A330, A340
S513-50	ACCUMULATORS	A330, A340
S618-A	ACCUMULATORS	A330, A340
SA716961	PUMP, VAR. DISPLACEM ENT	
SAS261-019	FLUID PRESS REG VALVE	
SD1582	ROTOR BALANCE ASSEMBLY	B777, A330
SETL-OC420G	CABIN PRESSURIZATION INDICATOR	
SETL-OC420Y	CABIN PRESSURIZATION INDICATOR	
SL40933	WASHER-LOCK	A330
SLN40927	AFT PINTLE PIN NUT	A330
SLN41180	NUT AFT PINTLE PIN	A330/340
SLN41193	REAR PINTLE PIN NUT	A320
SPC38B	INVERTER STATIC	
SPL5568-3	ACTUATOR, MECHANICAL	S330, S340
SPL5568-5	ACTUATOR, MECHANICAL	
SPL5569-3	FLAP BOST SENSOR LH	P3 ORION, P3 CONVERSION
SRD-9B	INDICATOR, PRESSURE	S330, S340
SSD120-30A	ENCODER-DECODER, COM	S330, S340
ST104A	INDICATOR	C-130
ST-106AB	TRANSMITTER DUCT PRESSURE	B727, A300, B737, B747
ST107R	BRAKE PRESSURE TRANSMITTER	B737



P/N	DESCRIPTION	AIRCRAFT PARTS
ST-107R	HYDRAULIC PRESSURE TRANSMITTER	B737, B727,B767, B777
ST-109C	SYNCHRO TRANSMITTER DIAPHRAGM ACTUATED	
STM3758V08-4 / 7	REMACHE/PASADOR	
TG 255-001	TACHOMETER GENERATOR	P3 ORION
TG 255-002	TACHOMETER GENERATOR	P3 ORION
TG 255-003	TACHOMETER GENERATOR	P3 ORION
TG 255-004	TACHOMETER GENERATOR	P3 ORION
TG 255-005	TACHOMETER GENERATOR	P3 ORION
TG 255-006	TACHOMETER GENERATOR	P3 ORION
TG 255-007	TACHOMETER GENERATOR	P3 ORION
TG 255-008	TACHOMETER GENERATOR	P3 ORION
TYPE200-CV	AUTOTRANSFORMADOR VARIABLE	A330, A340
V1-4360-2	HYD VALVE FUSE	B767
V2-4360-2	HYD VALVE FUSE	B767
VA4110	EXTRACTION FAN	A330, A330F, A340, AST
VD3810	MIXED FLOW FAN	A300-600, A310, A318, A319, A320, A321, A330, A330F, A340
VD3820	MIXED FLOW FAN	A300, A300-600, A310, A318, A319, A320, A321, A330, A330F
VD3820-01	MIXED FLOW FAN	A300, A300-600, A310, A318, A319, A320, A321, A330, A330F
VD3820MOD1	MIXED FLOW FAN	A300, A300-600, A310, A318, A319, A320, A321, A330, A330F
VR3910	EXTRACTION FAN	A330, A340, A320
VT442-2	WATER QUANTITY INDICATOR	A318,A319, A320, A321, A330, A340
VT442-2 AMENDT. A	WATER QUANTITY INDICATOR	A318,A319, A320, A321, A330, A340
WHEEL RIMS	WHEEL RIMS, SHOCK ABSORBERS, MOTOR HOUSINGS & MOTORPUMPS PIECES	A330, A340
WL 102AMS1	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL 102AMS2	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL 102AMS3	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL 102AMS4	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL 102AMS5	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL 102AMS6	ALTIMETER AIRSPEED INDICATOR	A330, A340
WL102AMS1	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300
WL102AMS2	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300,CRJ
WL102AMS3	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300,DASH8
WL102AMS4	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300,CRJ
WL102AMS5	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300,DASH8
WL102AMS6	ALTIMETER AIRSPEED INDICATOR	B737-300/400/500/800/900, B747-300,CRJ
Z212H0000110	CONTROL UNIT	A330, A340, A320
Z212H0001110	CONTROL UNIT	A330, A340, A320
Z212H0002110	CONTROL UNIT	A330, A340, A320
Z212H0003110	CONTROL UNIT	A330, A340, A320
Z212H0004110	CONTROL UNIT	A330, A340
Z212H0005110	CONTROL UNIT	A330, A340
Z212H0007110	CONTROL UNIT	A330, A340, A320
Z212H0009110	CONTROL UNIT	A330, A340, A320
Z212H0010110	CONTROL UNIT	A330, A340, A320
Z220H0000110	CONTROL UNIT DRAINMAST	A320



P/N	DESCRIPTION	AIRCRAFT PARTS
Z220H0001110	CONTROL UNIT DRAINMAST	A320
Z220H0002110	CONTROL UNIT DRAINMAST	A-300-600, A310, A318, A319, A320, A321